



**Count on it.**

Form No. 3363-870 Rev A

# Parts Catalog

## 22in Recycler<sup>®</sup> Lawn Mower

Model No. 20334—Serial No. 310000001 and Up

# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# List of Abbreviations


**AR:** as required  
**ASM:** assembly  
**BBC:** blade brake clutch  
**CARR:** carriage  
**CCW:** counter clock wise  
**CW:** clockwise  
**DEG:** degrees  
**ECM:** electronic control module  
**EXT:** external  
**FH:** flat head  
**GA:** gauge  
**HD:** heavy-duty  
**HF:** hex flange  
**HH:** hex head  
**HHF:** hex head flange  
**HHFTF:** hex head flange thread forming  
**HJ:** hex jam  
**HLH:** hex lag head  
**HOC:** height-of-cut

**HSBH:** hex socket button head  
**HSFH:** hex socket flat head  
**HSH:** hex socket head  
**HWH:** hex washer head  
**HWHTF:** hex washer head thread forming  
**HYD:** hydraulic  
**LH:** left hand  
**NI:** nylon insert  
**NPTF:** national pipe thread fine  
**PFH:** phillips flat head  
**PPH:** phillips pan head  
**PPHTF:** phillips pan head thread forming  
**PRH:** phillips round head  
**PTH:** phillips truss head  
**PTO:** power-take-off  
**RH:** right hand  
**ROPS:** roll-over protection system  
**RRB:** rear roller brush

**SFH:** slotted fillister head  
**SHH:** slotted hex head  
**SHWH:** slotted hex washer head  
**SPH:** slotted pan head  
**SQH:** square head  
**SRH:** slotted round head  
**STD:** standard  
**TAP:** self tapping  
**TTH:** torx truss head

# Contents


- Housing and Rear Door Assembly ..... 4
- Front Axle Assembly ..... 5
- Transmission, Rear Wheel and Height-of-Cut Assembly ..... 6
- Engine and Blade Assembly ..... 7
- Handle Assembly ..... 8
- Electrical Assembly ..... 9
- Rear Bag Assembly ..... 10
- Attachments and Accessories ..... 11



## Housing and Rear Door Assembly


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 117-1084    | 1    | Housing ASM         |
| 1:2  | 94-8072     | 1    | Decal-Danger        |
| 1:3  | 115-4676    | 1    | Decal-Recycler      |
| 1:4  | 112-8867    | 1    | Decal-Port, Washout |
| 2    | 114-7957    | 1    | Chute-Recycle       |
| 3    | 114-7961    | 1    | Baffle-Rear         |
| 4    | 46-8091     | 9    | Screw-HWH           |
| 5    | 114-7963-01 | 1    | Baffle-Front        |
| 6    | 114-7960    | 1    | Deflector-Recycle   |
| 7    | 114-7959    | 1    | Latch-Recycle       |
| 8    | 117-1031    | 1    | Spring-Compression  |
| 9    | 114-7958    | 1    | Knob-Recycle        |
| 10   | 32104-120   | 2    | Screw-PPH           |
| 11   | 114-7992    | 1    | Rear Door ASM       |
| 11:2 | 114-7982    | 1    | Decal-Warning       |

| Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| 12   | 114-7924    | 1    | Spring-Torsion              |
| 14   | 112-6401    | 1    | Coupling-Hose, Washout Port |
| 15   | 112-6400    | 1    | Port-Washout                |
| 16   | 112-6438    | 1    | Washer-Seal, Washout Port   |
| 17   | 3254-5      | 1    | Washer-Tooth, Internal      |
| 18   | 3218-6      | 1    | Nut-Jam                     |
| 23   | 115-2859    | 1    | Spring-Torsion              |
| 24   | 112-6416    | 1    | Bracket-Cover               |
| 25   | 99-8445     | 2    | Screw-HWH                   |
| 26   | 99-5291     | 1    | Rod-Cover                   |
| 27   | 99-5293     | 1    | Spring-Torsion              |
| 28   | 115-8449    | 1    | Deflector-Side              |
| 29   | 115-8447    | 1    | Chute-Discharge, Side       |
| 31   | 117-5928    | 1    | Decal-Bag On Demand         |



## Front Axle Assembly


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 114-7987    | 1    | Bumper               |
| 2    | 105-6849    | 2    | Screw-Thread Forming |
| 3    | 115-1956-03 | 2    | Plate-HOC, Front     |
| 4    | 105-1818    | 2    | Bushing-Mount, HOC   |
| 5    | 105-1807    | 2    | Arm-Pivot, Front     |
| 6    | 105-1809    | 2    | Arm-Spring           |
| 7    | 40-1940     | 2    | Washer               |
| 8    | 614650      | 2    | Bolt-Shoulder        |
| 9    | 105-3048    | 2    | Washer-Flat          |
| 10   | 322-6       | 2    | Screw-HH             |
| 11   | 115-2894    | 2    | 8 Inch Wheel ASM     |
| 12   | 105-3042    | 2    | Knob-Lever, HOC      |
| 13   | 322-3       | 4    | Screw-HH             |
| 14   | 3296-29     | 6    | Nut-Lock, NI         |



## Transmission, Rear Wheel and Height-of-Cut Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 114-7955-03 | 1    | Plate-LH, Rear (HOC)  |
| 2    | 114-7956-03 | 1    | Plate-RH, Rear (HOC)  |
| 3    | 115-2893    | 1    | Shield-Trailing       |
| 4    | 3296-29     | 4    | Nut-Lock, NI          |
| 5    | 115-8406    | 2    | Anchor-Bag            |
| 6    | 105-9437    | 2    | Screw-PPH             |
| 7    | 322-3       | 4    | Screw-HH              |
| 8    | 108-9781    | 2    | Arm-Pivot, Rear       |
| 9    | 108-9780    | 2    | Arm-Spring            |
| 10   | 108-9779    | 2    | Retainer-Bushing, HOC |
| 11   | 110-1792    | 2    | Wheel Cover ASM       |
| 11:2 | 614426      | 1    | Washer-Stepped        |
| 12   | 614650      | 2    | Bolt-Shoulder         |

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 13   | 115-4695    | 2    | 8 Inch Wheel Gear ASM |
| 14   | 105-3042    | 2    | Knob-Lever, HOC       |
| 15   | 104-8699    | 2    | Bearing-Ball          |
| 16   | 108-9782    | 2    | Bushing-Sleeve        |
| 17   | 115-4652    | 1    | Transmission          |
| 18   | 114-7977-03 | 1    | Bracket-Transmission  |
| 19   | 108-7476    | 3    | Screw-Plastite        |
| 20   | 110-7191    | 2    | Washer-Thrust         |
| 21   | 32151-61    | 2    | Ring-Retaining        |
| 22   | 115-4668    | 2    | Gear-Pinion, 12T      |
| 23   | 115-4669    | 1    | Belt-V                |
| 24   | 117-1092    | 2    | Screw-PTH             |




## Engine and Blade Assembly

| Ref. | Part Number | Qty. | Description                      |
|------|-------------|------|----------------------------------|
| 1    |             | 1    | Engine-Briggs, 128T05-3123-B1 ●■ |
| 2    | 106-3999    | 1    | Spacer-Driver                    |
| 3    | 106-3987    | 1    | Blade Driver ASM                 |
| 4    | 108-9764-03 | 1    | Blade-22 Inch                    |
| 5    | 108-3766-03 | 1    | Support-Blade                    |
| 6    | 105-8579    | 1    | Bolt-Blade                       |
| 7    | 105-3030-03 | 1    | Guide-Belt                       |
| 8    | 95-1726     | 3    | Screw-Taptite                    |
| 9    | 104-7577-03 | 1    | Shield-Muffler                   |
| 10   | 32144-1     | 3    | Screw-Taptite                    |
| 11   | 2210-316    | 1    | Stop-Rope                        |
| 12   | 119-0302    | 1    | Decal-Shroud                     |
| 13   | 114-7937    | 1    | Cover-Belt                       |
| 14   | 46-8091     | 2    | Screw-HWH                        |

● Not serviced separately


■ Obtain parts from [www.briggsandstratton.com](http://www.briggsandstratton.com)



## Handle Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 119-3810-05 | 1    | Handle                |
| 2    | 99-1588     | 1    | Bar-Control, Traction |
| 3    | 104-8678    | 1    | Handle-Control        |
| 4    | 86-9671     | 1    | Guide-Rope            |
| 5    | 99-1589     | 1    | Lever-Traction        |
| 7    | 3256-1      | 1    | Washer-Flat           |
| 8    | 3296-73     | 2    | Nut-Lock, NI          |
| 11   | 104-8690    | 1    | Spring-Torsion        |
| 12   | 104-8679-03 | 1    | Bail-Brake            |


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 13   | 115-8435    | 1    | Cable-Traction       |
| 14   | 117-5976    | 2    | Knob-Handle, Locking |
| 15   | 3230-6      | 2    | Screw-CARR           |
| 16   | 106-6805    | 1    | Guide-Cable          |
| 17   | 117-1019    | 1    | Decal                |
| 18   | 99-5239     | 1    | Anchor-Cable         |
| 19   | 115-8437    | 1    | Cable-Brake          |
| 20   | 105-6841    | 1    | Guide-RH             |
| 21   | 105-6842    | 1    | Guide-LH             |



## Electrical Assembly

| Ref. | Part Number | Qty. | Description               |
|------|-------------|------|---------------------------|
| 1    | 114-7936    | 1    | Tray-Battery              |
| 2    | 106-8397    | 1    | Battery-12 Volt           |
| 4    | 112-8763    | 1    | Decal-Terminal, Battery   |
| 5    | 119-3811    | 1    | Decal-Battery Tray        |
| 6    | 108-9760    | 1    | Mount-Switch              |
| 7    | 700918      | 1    | Key                       |
| 8    | 114-2619    | 1    | Decal-Pos, Electric Start |
| 9    | 46-5780     | 1    | Starter Switch ASM        |
| 9:1  | 3254-5      | 1    | Washer-Tooth, Internal    |

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 9:2  | 218-461     | 1    | Nut-HH              |
| 10   | 321-50      | 1    | Screw-HH            |
| 11   | 115-4675    | 1    | Harness-Wire        |
| 11:1 | 99-6124     | 1    | Fuse-40 Amp         |
| 12   | 114-1588    | 1    | Charger-Battery     |
| 13   | 104-7953    | 1    | Decal-Harness       |
| 14   | 32144-97    | 1    | Screw-PPH, Plastite |
| 15   | 614249      | 1    | Strap-Tie           |



## Rear Bag Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 114-2679-03        | 1           | Frame-Bag          |
| 2           | 115-4673           | 1           | Grass Bag ASM      |

# Attachments and Accessories

## For 20334 22in Recycler Lawn Mower

| Product Name                       | Model/Part |
|------------------------------------|------------|
| Traction Assist Handle Kit.....    | 108-8120   |
| Loose Parts Kit .....              | 117-4134   |
| Replacement Bag .....              | 59310      |
| Replacement Frame and Bag Kit..... | 59312      |
| 22 Inch Blade Kit.....             | 59534      |



**Count on it.**