




MODEL NO. 07345-50001 &amp; UP


**PARTS  
CATALOG**
**POWER PLATFORM**


T-1791

**FRAME ASSEMBLY**

| Ref. No. | Part No. | Description                                 | No. Used |
|----------|----------|---------------------------------------------|----------|
| 1        | 3290-255 | Pin - Cotter Hair                           | 1        |
| 2        | 67-5360  | Decal - Danger                              | 1        |
| 3        | 92-2792  | Mounting Plate Assembly                     | 1        |
| 4        | 32148-9  | Insert - Threaded                           | 24       |
| 5        | 83-6620  | Decal - Instruction                         | 1        |
| 6        | 92-2785  | Platform Assembly<br>(Incl. Ref. #2, 4 & 5) | 1        |
| 7        | 92-9028  | Cover Assembly                              | 1        |

| Ref. No. | Part No.  | Description     | No. Used |
|----------|-----------|-----------------|----------|
| 8        | 92-9026   | Wire Harness    | 1        |
| 9        | 92-9033   | Clamp - J       | 1        |
| 10       | 32104-116 | Screw - Tapping | 1        |
| 11       | 3290-379  | Tie - Cable     | 1        |
| 12       | 92-9027   | Wire Harness    | 1        |
| 13       | 32128-20  | Nut - Lock      | 4        |
| 14       | 3234-17   | Screw           | 4        |




T-1792

SHIELD ASSEMBLY

| Ref. No. | Part No. | Description                                | No. Used |
|----------|----------|--------------------------------------------|----------|
| 1        | 80-8040  | Decal - Warning                            | 1        |
| 2        | 65-5100  | Handle - Hood                              | 1        |
| 3        | 3256-23  | Washer - Flat                              | 2        |
| 4        | 62-7400  | Decal - Toro                               | 1        |
| 5        | 93-9560  | Shield Assembly<br>(Incl. Ref. #1, 4 & 12) | 1        |
| 6        | 92-2799  | Trim                                       | 1        |

| Ref. No. | Part No. | Description       | No. Used |
|----------|----------|-------------------|----------|
| 7        | 74-0720  | Tube - Manual     | 1        |
| 8        | 322-3    | Screw - Hex Head  | 4        |
| 9        | 2412-133 | R-Clamp           | 2        |
| 10       | 3296-47  | Nut - Lock        | 2        |
| 11       | 46-8091  | Screw - Tapping   | 2        |
| 12       | 32148-6  | Insert - Threaded | 2        |




T-1793

## IDLER ARM ASSEMBLY

| Ref. No. | Part No. | Description    | No. Used |
|----------|----------|----------------|----------|
| 1        | 32146-2  | Nut – Hex Lock | 1        |
| 2        | 41353    | Pulley – Idler | 1        |
| 3        | 3256-24  | Washer         | 2        |
| 4        | 92-9025  | Spacer         | 1        |
| 5        | 92-9020  | Arm – Idler    | 1        |

| Ref. No. | Part No. | Description      | No. Used |
|----------|----------|------------------|----------|
| 6        | 323-9    | Screw – Hex Head | 1        |
| 7        | 256-116  | Bushing – Flange | 2        |
| 8        | 32151-47 | E-Ring           | 1        |
| 9        | 49-6920  | Spring           | 1        |




T-1794

PULLEY ASSEMBLY

| Ref. No. | Part No. | Description    | No. Used |
|----------|----------|----------------|----------|
| 1        | 3296-45  | Nut            | 1        |
| 2        | 92-2651  | Washer         | 1        |
| 3        | 92-2783  | Belt - V       | 1        |
| 4        | 92-9014  | Pulley         | 1        |
| 5        | 92-2650  | Spacer         | 4        |
| 6        | 251-82   | Bearing - Ball | 2        |
| 7        | 3-6168   | Key - Square   | 2        |
| 8        | 92-9032  | Shaft          | 1        |

| Ref. No. | Part No. | Description       | No. Used |
|----------|----------|-------------------|----------|
| 9        | 87-2750  | Spacer - Bearing  | 1        |
| 10       | 32151-83 | Ring - Snap       | 1        |
| 11       | 92-9016  | Pulley            | 1        |
| 12       | 32146-2  | Nut - Hex Lock    | 2        |
| 13       | 93-9554  | Support - Bearing | 1        |
| 14       | 323-12   | Screw - Hex Head  | 2        |
| 15       | 32148-7  | Insert - Threaded | 2        |

\*Not Illustrated



T-1795

## TOOLBOX (Optional)

| Ref.<br>No. | Part No. | Description | No.<br>Used |
|-------------|----------|-------------|-------------|
| 1           | 92-2775  | Latch       | 1           |
| 2           | 92-2773  | Toolbox     | 1           |

| Ref.<br>No. | Part No. | Description         | No.<br>Used |
|-------------|----------|---------------------|-------------|
| 3           | 92-2796  | Key                 | 1           |
| 4           | 323-4    | Screw - Cap Hex Hd. | 4           |

# TORO PART NUMBER INDEX

| Part No. | Description             | Pg. Ref.<br>No. No. Qty. | Part No.  | Description         | Pg. Ref.<br>No. No. Qty. |
|----------|-------------------------|--------------------------|-----------|---------------------|--------------------------|
| 41353    | Pulley – Idler          | 3 2 1                    | 92-9032   | Shaft               | 4 8 1                    |
| 3-6168   | Key – Square            | 4 7 2                    | 92-9033   | Clamp – J           | 1 9 1                    |
| 46-8091  | Screw – Tapping         | 2 11 2                   | 93-9554   | Support – Bearing   | 4 13 1                   |
| 49-6920  | Spring                  | 3 9 1                    | 93-9560   | Shield Assembly     | 2 5 1                    |
| 62-7400  | Decal – Toro            | 2 4 1                    | 2412-133  | R-Clamp             | 2 9 2                    |
| 65-5100  | Handle – Hood           | 2 2 1                    | 251-82    | Bearing – Ball      | 4 6 2                    |
| 67-5360  | Decal – Danger          | 1 2 1                    | 256-116   | Bushing – Flange    | 3 7 2                    |
| 74-0720  | Tube – Manual           | 2 7 1                    | 322-3     | Screw – Hex Head    | 2 8 4                    |
| 80-8040  | Decal – Warning         | 2 1 1                    | 323-4     | Screw – Cap Hex Hd. | 5 4 4                    |
| 83-6620  | Decal – Instruction     | 1 5 1                    | 323-9     | Screw – Hex Head    | 3 6 1                    |
| 87-2750  | Spacer – Bearing        | 4 9 1                    | 323-12    | Screw – Hex Head    | 4 14 2                   |
| 92-2650  | Spacer                  | 4 5 4                    | 3234-17   | Screw               | 1 14 4                   |
| 92-2651  | Washer                  | 4 2 1                    | 3256-23   | Washer – Flat       | 2 3 2                    |
| 92-2773  | Toolbox                 | 5 2 1                    | 3256-24   | Washer              | 3 3 2                    |
| 92-2775  | Latch                   | 5 1 1                    | 3290-255  | Pin – Cotter Hair   | 1 1 1                    |
| 92-2783  | Belt – V                | 4 3 1                    | 3290-379  | Tie – Cable         | 1 11 1                   |
| 92-2785  | Platform Assembly       | 1 6 1                    | 3296-45   | Nut                 | 4 1 1                    |
| 92-2792  | Mounting Plate Assembly | 1 3 1                    | 3296-47   | Nut – Lock          | 2 10 2                   |
| 92-2796  | Key                     | 5 3 1                    | 32104-116 | Screw – Tapping     | 1 10 1                   |
| 92-2799  | Trim                    | 2 6 1                    | 32128-20  | Nut – Lock          | 1 13 4                   |
| 92-9014  | Pulley                  | 4 4 1                    | 32146-2   | Nut – Hex Lock      | 3 1 1                    |
| 92-9016  | Pulley                  | 4 11 1                   | 32146-2   | Nut – Hex Lock      | 4 12 2                   |
| 92-9020  | Arm – Idler             | 3 5 1                    | 32148-6   | Insert – Threaded   | 2 12 2                   |
| 92-9025  | Spacer                  | 3 4 1                    | 32148-7   | Insert – Threaded   | 4 15 2                   |
| 92-9026  | Wire Harness            | 1 8 1                    | 32148-9   | Insert – Threaded   | 1 4 24                   |
| 92-9027  | Wire Harness            | 1 12 1                   | 32151-47  | E-Ring              | 3 8 1                    |
| 92-9028  | Cover Assembly          | 1 7 1                    | 32151-83  | Ring – Snap         | 4 10 1                   |

## COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

## MAINTENANCE RECORD

[illegible]

## MAINTENANCE RECORD

[illegible]

Compliance with Radio Interference Regulations Certified.  
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.