
FORM NO. 3317–866

LAWN-BOY

PART NO. 94–1614

PARTS CATALOG

BATTERY KIT



C–2356

BATTERY ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	703858	Screw	2
2	612690	Case–Battery	1
3	55–7520	Battery Pack	1
4	612510	Pad Battery	1
5	3256–49	Washer	2
6	704998	Nut	2

Copyright 1995 The Lawn–Boy Inc.
All Rights Reserved

TPS