




MODEL NO. 79105-6900001 & UP

PARTS CATALOG

44" RECYCLER® CUTTING UNIT




C-2297A

DECK ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	26-0671	Bolt - Blade	3
2	3290-465	Washer - Belleville	3
3	92-7952	Blade - Recycler	3
4	80-4342	Shaft - Spindle	3
5	80-4360	Shield - Bearing	3
6	80-4380	Spacer - Hardened	3
7	38-7820	Bearing - Ball	6
8	62-3661	Spacer - Bearing	3
9	88-4510	Spindle	3
10	93-3825	Deck Assembly	1
11	32144-41	Screw - Hex Washer Hd. Thread Forming	12
12	88-5360	Spacer - Pulley	3
13	88-5330	Pulley - Deck	3
14	3219-6	Nut - Hex	3

Ref. No.	Part No.	Description	No. Used
15	3296-39	Nut - Lock	2
16	56-7530	Bolt - Shoulder	2
17	93-3881	Pan - Front Deck Suspension	1
18	323-9	Screw - Hex Hd. Cap	2
19	80-6990	Washer - Hardened	4
20	93-9847	Spacer	2
21	3296-39	Nut - Hex Lock	2
22	61-9980	Screw - Adjusting	2
23	3256-22	Washer - Flat	2
24	3296-42	Nut - Lock	2
25	93-9849	Bracket - Deck R.H.	1
26	93-9848	Bracket - Deck L.H.	1
27	322-12	Screw - Hex Hd. Cap	2
28	3296-29	Nut - Lock	2




C-2297A

DECK ASSEMBLY

Ref. No.	Part No.	Description	No. Used
29	55-4300	Decal - Warning	2
30	68-3650	Decal - Danger Deflector	1
31	66-1340	Decal - Discharge	1
32	93-3776	Decal - Deck Recycler	1
33	93-3777	Decal - Belt	1
34	93-1122	Decal - Danger	1


Ref. No.	Part No.	Description	No. Used
35	93-7282	Decal - Wheel Adjustment	1
36	68-3660	Decal - Shield Danger	2
37	3290-307	Pin - Hair Cotter	4
38	80-6990	Washer - Hardened	2
39	93-3884	V-Belt	1
40	3256-24	Washer - Flat	2



C-2298A

BELT COVER & DEFLECTOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	29-5590	Bracket - Pivot	2	17	3230-1	Screw - Carriage	4
2	3296-5	Nut - Lock	2	18	84-5760	Plate - Kicker	4
3	40-6230	Spring - Torsion	2	19	3296-29	Nut - Lock	4
4	57-6980	Deflector Assembly	1	20	93-3866	Cover - Belt L.H.	1
5	3211-15	Screw - Hex Hd. Cap	2	21	32104-76	Screw - Self Tapping	9
6	283-2	Pin - Clevis	2	23	3290-456	Washer - Lock	4
7	3290-307	Pin - Cotter	2	24	93-3865	Cover - Belt R.H.	1
8	56-6591	Bolt - Wheel	2	25	93-3876	Insert - Belt Cover	1
9	701756	Wheel - Deck	2	26	3296-29	Nut - Lock	4
10	93-8010	Plate - Gage Wheel	2	27	3231-21	Bolt - Carriage	2
11	3296-59	Nut - Lock	2	28	3296-39	Nut - Lock	2
12	3230-23	Screw - Carriage	4	29	3256-5	Washer - Flat	2
13	93-7651	Baffle - R.H.	1	30	59-4310	Spacer	4
14	32149-1	Nut - Keps	8	31	43-8480	Decal - Danger	1
15	322-6	Screw - Hex Hd. Cap	4				
16	93-7652	Baffle - L.H.	1				



C-2299

IDLER & BRAKE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	323-12	Screw - Hex Hd. Cap	1
2	3256-24	Washer - Flat	3
3	88-5070	Guide - Idler Belt	1
4	88-5630	Pulley - Idler Flat	2
5	93-3860	Bracket - Idler	1
6	3296-39	Nut - Lock	2
7	88-5960	Guide - Trans. Belt L.H.	1
8	322-3	Screw - Hex Hd. Cap	9
9	3296-29	Nut - Lock	12
10	5-4460	Washer - Fender	3
11	3296-42	Nut - Lock	3
12	67-0710	Ball - Swivel	3
13	93-3841	Brake Assembly	3

Ref. No.	Part No.	Description	No. Used
14	93-9342	Spring - Torsion	1
15	93-3848	Bellcrank	1
16	93-3852	Rod - Brake Center	1
17	93-9341	Spacer - Pivot	2
18	3256-23	Washer - Flat	2
19	322-14	Screw - Hex Hd. Cap	2
20	323-10	Screw - Hex Hd. Cap	1
21	93-3845	Bellcrank	1
22	93-3853	Rod - Brake R.H.	1
23	93-3850	Spring - Deck Engage	1
24	93-3851	Rod - Brake L.H.	1
25	3220-2	Nut - Hex Jam	1

TORO PART NUMBER INDEX

3318-168

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
701756	Wheel – Deck	3	9	2	93-7282	Decal – Wheel Adjustment	2	35	1
5-4460	Washer – Fender	4	10	3	93-7651	Baffle – R.H.	3	13	1
26-0671	Bolt – Blade	1	1	3	93-7652	Baffle – L.H.	3	16	1
29-5590	Bracket – Pivot	3	1	2	93-8010	Plate – Gage Wheel	3	10	2
38-7820	Bearing – Ball	1	7	6	93-9341	Spacer – Pivot	4	17	2
40-6230	Spring – Torsion	3	3	2	93-9342	Spring – Torsion	4	14	1
43-8480	Decal – Danger	3	31	1	93-9847	Spacer	1	20	2
55-4300	Decal – Warning	2	29	2	93-9848	Bracket – Deck L.H.	1	26	1
56-6591	Bolt – Wheel	3	8	2	93-9849	Bracket – Deck R.H.	1	25	1
56-7530	Bolt – Shoulder	1	16	2	283-2	Pin – Clevis	3	6	2
57-6980	Deflector Assembly	3	4	1	322-3	Screw – Hex Hd. Cap	4	8	9
59-4310	Spacer	3	30	4	322-6	Screw – Hex Hd. Cap	3	15	4
61-9980	Screw – Adjusting	1	22	2	322-12	Screw – Hex Hd. Cap	1	27	2
62-3661	Spacer – Bearing	1	8	3	322-14	Screw – Hex Hd. Cap	4	19	2
66-1340	Decal – Discharge	2	31	1	323-9	Screw – Hex Hd. Cap	1	18	2
67-0710	Ball – Swivel	4	12	3	323-10	Screw – Hex Hd. Cap	4	20	1
68-3650	Decal – Danger Deflector	2	30	1	323-12	Screw – Hex Hd. Cap	4	1	1
68-3660	Decal – Shield Danger	2	36	2	3211-15	Screw – Hex Hd. Cap	3	5	2
80-4342	Shaft – Spindle	1	4	3	3219-6	Nut – Hex	1	14	3
80-4360	Shield – Bearing	1	5	3	3220-2	Nut – Hex Jam	4	25	1
80-4380	Spacer – Hardened	1	6	3	3230-1	Screw – Carriage	3	17	4
80-6990	Washer – Hardened	1	19	4	3230-23	Screw – Carriage	3	12	4
80-6990	Washer – Hardened	2	38	2	3231-21	Bolt – Carriage	3	27	2
84-5760	Plate – Kicker	3	18	4	3256-5	Washer – Flat	3	29	2
88-4510	Spindle	1	9	3	3256-22	Washer – Flat	1	23	2
88-5070	Guide – Idler Belt	4	3	1	3256-23	Washer – Flat	4	18	2
88-5330	Pulley – Deck	1	13	3	3256-24	Washer – Flat	4	2	3
88-5360	Spacer – Pulley	1	12	3	3256-24	Washer – Flat	2	40	2
88-5630	Pulley – Idler Flat	4	4	2	3290-307	Pin – Cotter	3	7	2
88-5960	Guide – Trans. Belt L.H.	4	7	1	3290-307	Pin – Hair Cotter	2	37	4
92-7952	Blade – Recycler	1	3	3	3290-456	Washer – Lock	3	23	4
93-1122	Decal – Danger	2	34	1	3290-465	Washer – Belleville	1	2	3
93-3776	Decal – Deck Recycler	2	32	1	3296-5	Nut – Lock	3	2	2
93-3777	Decal – Belt	2	33	1	3296-29	Nut – Lock	4	9	12
93-3825	Deck Assembly	1	10	1	3296-29	Nut – Lock	3	19	4
93-3841	Brake Assembly	4	13	3	3296-29	Nut – Lock	3	26	4
93-3845	Bellcrank	4	21	1	3296-29	Nut – Lock	1	28	2
93-3848	Bellcrank	4	15	1	3296-39	Nut – Hex Lock	1	21	2
93-3850	Spring – Deck Engage	4	23	1	3296-39	Nut – Lock	4	6	2
93-3851	Rod – Brake L.H.	4	24	1	3296-39	Nut – Lock	1	15	2
93-3852	Rod – Brake Center	4	16	1	3296-39	Nut – Lock	3	28	2
93-3853	Rod – Brake R.H.	4	22	1	3296-42	Nut – Lock	4	11	3
93-3860	Bracket – Idler	4	5	1	3296-42	Nut – Lock	1	24	2
93-3865	Cover – Belt R.H.	3	24	1	3296-59	Nut – Lock	3	11	2
93-3866	Cover – Belt L.H.	3	20	1	32104-76	Screw – Self Tapping	3	21	9
93-3876	Insert – Belt Cover	3	25	1	32144-41	Screw – Hex Washer Hd.	1	11	12
93-3881	Pan – Front Deck	1	17	1	32149-1	Nut – Keps	3	14	8
93-3884	V-Belt	2	39	1					

*Not Illustrated

