



**Count on it.**

# Parts Catalog

## **Greensmaster® 1000 Mower**

Model No. 04052—Serial No. 310002001 and Up

# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# List of Abbreviations

**AR:** as required

**ASM:** assembly

**BBC:** blade brake control

**BHTF:** button head thread forming

**CARR:** carriage

**CCW:** counter clockwise

**CW:** clockwise

**DEG:** degrees

**ECM:** electronic control module

**EXT:** external

**FH:** flat head

**GA:** gauge

**HD:** heavy-duty

**HF:** hex flange

**HH:** hex head

**HHF:** hex head flange

**HHFTF:** hex head flange thread forming

**HJ:** hex jam

**HLH:** hex lag head

**HOC:** height-of-cut

**HSBH:** hex socket button head

**HSFH:** hex socket flat head

**HSH:** hex socket head

**HWH:** hex washer head

**HWHTF:** hex washer head thread forming

**HYD:** hydraulic

**LH:** left hand

**NI:** nylon insert

**NPTF:** national pipe thread fine

**PFH:** phillips flat head

**PPH:** phillips pan head

**PPHTF:** phillips pan head thread forming

**PRH:** phillips round head

**PTH:** phillips truss head

**PTO:** power-take-off

**RH:** right hand

**ROPS:** roll-over protection system

**RRB:** rear roller brush

**SFH:** slotted fillister head

**SHH:** slotted hex head

**SHWH:** slotted hex washer head

**SPH:** slotted pan head

**SQH:** square head

**SRH:** slotted round head


**STD:** standard

**TAP:** self tapping

**TTH:** torx truss head

# Contents


|                                             |    |
|---------------------------------------------|----|
| Frame Assembly . . . . .                    | 4  |
| Engine Mount And Frame Assembly . . . . .   | 5  |
| Reel Drive Assembly . . . . .               | 6  |
| Reel Assembly . . . . .                     | 8  |
| Drum Drive Assembly . . . . .               | 9  |
| Drum and Basket Assembly . . . . .          | 11 |
| Differential Assembly No. 93-6055 . . . . . | 12 |
| Inner Countershaft Assembly . . . . .       | 13 |
| Outer Crankshaft Assembly . . . . .         | 14 |
| Engine Assembly . . . . .                   | 15 |
| Bellcrank Assembly . . . . .                | 16 |
| Handle Assembly . . . . .                   | 17 |
| Cylinder and Crankcase Assembly . . . . .   | 19 |
| Piston and Crankshaft Assembly . . . . .    | 20 |
| Valve and Camshaft Assembly . . . . .       | 21 |
| Lubrication Equipment Assembly . . . . .    | 22 |
| Cooling Equipment Assembly . . . . .        | 23 |
| Electric Equipment Assembly . . . . .       | 24 |
| Control Equipment Assembly . . . . .        | 25 |
| Carburetor Assembly . . . . .               | 26 |
| Air Filter and Muffler Assembly . . . . .   | 27 |
| Fuel Tank and Valve Assembly . . . . .      | 28 |
| Starter Assembly . . . . .                  | 29 |
| Label Set . . . . .                         | 30 |
| Attachments and Accessories . . . . .       | 31 |



## Frame Assembly

| Ref. | Part Number | Qty. | Description            | Ref.   | Part Number | Qty. | Description                 |
|------|-------------|------|------------------------|--------|-------------|------|-----------------------------|
| 1    | 65-7850-03  | 1    | Kickstand ASM          | 18     | 88-7110     | 1    | Rod-Support, Frame          |
| 2    | 3256-2      | 3    | Washer-Flat            | 19     | 52-2890     | 2    | Bushing-Nylon               |
| 3    | 32128-25    | 1    | Nut-HF                 | 20     | 93-6093     | 1    | RH Side Plate ASM           |
| 4    | 3296-29     | 2    | Nut-Lock, NI           | 20:1   |             | 1    | RH Sideplate/Bushing ASM    |
| 5    | 65-7910     | 2    | Spacer                 |        |             |      | ●                           |
| 6    | 33025-00    | 2    | Nut-Lock               | 20:1:2 | 63-9510     | 1    | Bushing                     |
| 7    | 99-3755     | 2    | Spring-Compression     | 20:2   | 93-9389     | 2    | Decal-Warning, Belt (Japan) |
| 8    | 99-2098     | 2    | Washer                 | 20:2   | 93-9356     | 2    | Decal-Warning, Belt         |
| 9    | 99-2096     | 2    | Screw-Adjuster, Bedbar | 21     | 3254-6      | 2    | Washer-Lock, Internal       |
| 10   | 32120-93    | 2    | Ring-Retaining         | 22     | 323-4       | 6    | Screw-HH                    |
| 11   | 106-5335    | 2    | Washer-Wave            | 23     | 3253-21     | 6    | Washer-Lock                 |
| 12   | 106-5344    | 4    | Bushing-Flange, Keyed  | 24     | 323-5       | 2    | Screw-HH                    |
| 13   | 112-9272-01 | 1    | Crossmember            | 25     | 65-7890     | 1    | Bracket                     |
| 14   | 106-5363    | 2    | Shaft-Adjuster         | 26     | 65-7880     | 1    | Spring-Extension            |
| 15   | 99-2097     | 2    | Detent                 | 27     | 322-10      | 1    | Screw-HH                    |
| 16   | 3253-4      | 2    | Washer-Lock            | 28     | 65-7900     | 1    | Retainer-Spring             |
| 17   | 322-26      | 2    | Screw-HH               | 29     | 322-5       | 2    | Screw-HH                    |


● Not serviced separately



## Engine Mount And Frame Assembly

| Ref.   | Part Number | Qty. | Description                 | Ref. | Part Number | Qty. | Description                          |
|--------|-------------|------|-----------------------------|------|-------------|------|--------------------------------------|
| 1      | 88-7670     | 1    | Mount-Engine                | 17   | 93-6051     | 2    | Screw-HOC                            |
| 2      | 3234-1      | 4    | Screw-HHF                   | 18   | 3242-4      | 2    | Screw-Set, SQH                       |
| 3      | 3253-21     | 4    | Washer-Lock                 | 19   | 3218-2      | 2    | Nut-Jam                              |
| 4      | 3256-24     | 2    | Washer-Flat                 | 20   | 32128-21    | 2    | Nut-HF                               |
| 7      | 65-7510     | 2    | Grommet-Handle              | 21   | 93-6090     | 2    | Arm-HOC                              |
| 8      | 93-6038     | 1    | Arm-Support, Handle (LH)    | 22   | 93-6048     | 1    | Bracket-HOC, RH                      |
| 9      | 93-6037     | 1    | Arm-Support, Handle (RH)    | 23   | 93-6049     | 1    | Bracket-HOC, LH                      |
| 10     | 93-6024     | 2    | Bushing-Support, Handle     | 24   | 65-8570     | 2    | Rod-Mounting                         |
| 11     | 3290-467    | 2    | Pin-Hair                    | 25   | 99-6241     | 1    | Wiehle Roller ASM (.20 Inch Spacing) |
| 12     | 93-6029     | 2    | Pin-Clevis, Ring            | 25:2 | 52-3180     | 2    | Bearing-Roller, Front                |
| 13     | 3296-29     | 2    | Nut-Lock, NI                | 25:3 | 302-5       | 2    | Fitting-Grease                       |
| 14     | 322-9       | 2    | Screw-HH                    | 26   | 3255-8      | 4    | Washer-Lock                          |
| 15     | 323-4       | 2    | Screw-HH                    | 27   | 322-2       | 4    | Screw-HH                             |
| 16     | 93-6094     | 1    | LH Side Plate ASM           | 28   | 3231-5      | 2    | Screw-CARR                           |
| 16:1   |             | 1    | LH Sideplate/Bushing ASM    | 29   | 92-8914     | 4    | Bolt-Face, Tapered                   |
| 16:1:2 | 63-9510     | 1    | Bushing                     | 30   | 93-6064     | 1    | Seal-Catcher, Grass                  |
| 16:2   | 93-9356     | 1    | Decal-Warning, Belt         | 33   | 93-6025-01  | 1    | Tube-Frame, Rear                     |
| 16:2   | 93-9389     | 1    | Decal-Warning, Belt (Japan) |      |             |      |                                      |


● Not serviced separately



## Reel Drive Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 92-8013     | 1    | Housing-Clutch        |
| 2    | 322-5       | 3    | Screw-HH              |
| 3    | 3296-29     | 2    | Nut-Lock, NI          |
| 4    | 251-318     | 1    | Bearing-Ball          |
| 5    | 302-5       | 1    | Fitting-Grease        |
| 6    | 253-118     | 1    | Seal-Oil              |
| 7    | 88-7720     | 1    | Spring-Wave           |
| 8    | 32151-75    | 1    | Ring-Retaining        |
| 9    | 93-6056     | 1    | Shaft-Power           |
| 10   | 88-7150     | 2    | Key                   |
| 11   | 65-6940     | 1    | Clutch-Slider, Jaw    |
| 12   | 88-7830     | 1    | Clutch And Pulley ASM |
| 12:3 | 251-336     | 2    | Bearing-Ball          |
| 12:5 | 32151-95    | 1    | Ring-Retaining        |
| 12:6 | 32151-89    | 1    | Ring-Retaining, Bowed |
| 13   | 3254-4      | 1    | Washer-Lock/Int       |
| 14   | 3219-5      | 1    | Nut-Hex               |
| 15   | 65-6970     | 1    | Seal-Felt             |
| 16   | 93-9014     | 1    | Pin-Clutch, Actuator  |
| 17   | 65-6290     | 1    | Spring-Detent, Clutch |
| 18   | 3296-42     | 1    | Nut-Lock, NI          |


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 20   | 95-5731     | 1    | Screw-Drive          |
| 21   | 88-7170     | 1    | Lever-Clutch         |
| 22   | 88-7860     | 1    | Spacer               |
| 23   | 3290-414    | 1    | Washer-Belleville    |
| 24   | 80-0700     | 1    | Screw-HH, Torx       |
| 25   | 65-8960     | 1    | Boot-Clutch          |
| 26   | 233-69      | 1    | Knob                 |
| 27   | 65-7190-01  | 1    | Cover-Arm            |
| 28   | 65-7131     | 1    | Seal-Cover, Strip    |
| 29   | 3289-23     | 2    | Capscrew             |
| 30   | 3296-39     | 2    | Nut-Lock, NI         |
| 31   | 65-8640     | 1    | Housing-Bearing      |
| 32   | 253-96      | 1    | Seal-Oil             |
| 33   | 65-8290     | 2    | Standoff-Cover       |
| 34   | 251-342     | 1    | Bearing-Ball         |
| 35   | 32151-92    | 1    | Ring-Retaining       |
| 36   | 253-163     | 1    | Seal                 |
| 37   | 3290-485    | 1    | Washer-Wave          |
| 38   | 65-6200     | 1    | Belt                 |
| 39   | 88-7840     | 1    | Pulley And Drive ASM |
| 39:4 | 32151-95    | 1    | Ring-Retaining       |



## Reel Drive Assembly (continued)

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 40   | 88-7850     | 1    | Idler Pulley ASM      |
| 40:1 | 88-7180     | 1    | Pulley-Idler          |
| 40:2 | 38-7820     | 1    | Bearing-Ball          |
| 40:3 | 88-7190     | 1    | Spacer                |
| 40:4 | 32120-42    | 1    | Ring-Retaining        |
| 40:5 | 88-7200     | 1    | Washer-Flat           |
| 40:6 | 3234-14     | 1    | Screw-HHF             |
| 41   | 3254-2      | 1    | Washer-Lock, Internal |
| 42   | 88-7700-01  | 1    | Cover-Drive, Reel     |
| 43   | 88-7770     | 2    | Strip-Seal, Front     |

| Ref. | Part Number | Qty. | Description                    |
|------|-------------|------|--------------------------------|
| 44   | 88-7790     | 1    | Strip-Seal, Upper              |
| 45   | 88-7800     | 1    | Strip-Seal, Lower              |
| 46   | 237-160     | 1    | Plug-Rubber                    |
| 47   | 92-4817     | 1    | Decal-Engagement, Reel (Japan) |
| 47   | 93-7346     | 1    | Decal-Engagement, Reel         |
| 48   | 321-20      | 4    | Screw-HH                       |
| 49   | 3254-8      | 4    | Washer-Lock                    |
| 50   | 302-11      | 1    | Fitting-Lube, 45 DEG           |
| 51   | 106-8737    | 4    | Nut-Retainer                   |




## Reel Assembly

| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 112-9471    | 1    | Grass Shield ASM      |
| 1:2  | 84-6560     | 1    | Decal-Warning (Japan) |
| 1:2  | 93-8064     | 1    | Decal-Danger, Ce      |
| 1:3  | 106-2619    | 1    | Strip-Seal            |
| 2    | 65-6450     | 1    | Bracket-LH            |
| 3    | 65-6460     | 1    | Bracket-RH            |
| 4    | 321-3       | 4    | Screw-HH              |
| 5    | 3256-22     | 6    | Washer-Flat           |
| 6    | 3296-42     | 4    | Nut-Lock, NI          |
| 7    | 36-7260     | 1    | Bar-Off, Cut          |

| Ref. | Part Number | Qty. | Description                      |
|------|-------------|------|----------------------------------|
| 8    | 104-2065    | 5    | Screw-HWH                        |
| 9    | 93-4263     | 1    | Bedknife-Tournament Cut (Greens) |
| 10   | 57-4910     | 13   | Screw-Special                    |
| 11   | 93-6097     | 1    | 11 Blade Reel ASM                |
| 12   | 112-9281-01 | 1    | Bedbar-Standard                  |
| 13   | 52-2900     | 4    | Washer-Plastic                   |
| 14   | 117-9493    | 2    | Bolt-Bedbar                      |
| 15   | 3296-28     | 2    | Nut-Lock, NI                     |
| 16   | 52-2860     | 4    | Washer                           |






## Drum Drive Assembly

| Ref. | Part Number | Qty. | Description                        |
|------|-------------|------|------------------------------------|
| 1    | 88-7530     | 2    | Spacer                             |
| 2    | 88-7540     | 2    | Washer-Backup                      |
| 3    | 105-5365    | 1    | Pulley-Drum, LH                    |
| 4    | 108-9414    | 1    | Housing-Support, Differential (LH) |
| 5    | 322-5       | 4    | Screw-HH                           |
| 6    | 3296-29     | 4    | Nut-Lock, NI                       |
| 7    | 253-160     | 4    | Seal-Grease                        |
| 8    | 251-338     | 2    | Bearing-Ball                       |
| 9    | 86-7130     | 2    | Spacer-Pulley                      |
| 10   | 302-5       | 2    | Fitting-Grease                     |
| 11   | 65-6210     | 2    | Belt                               |
| 12   | 65-6660     | 2    | Pulley                             |
| 13   | 3296-57     | 2    | Nut-Lock, NI                       |
| 14   | 94-9018     | 2    | Washer-Plastic                     |
| 15   | 253-161     | 2    | Seal-V-Ring                        |
| 16   | 65-6220-01  | 1    | Cover-End, Reel                    |
| 17   | 322-3       | 2    | Screw-HH                           |
| 18   | 3254-2      | 2    | Washer-Lock, Internal              |
| 19   | 65-6590     | 2    | Flangette-Bearing                  |
| 20   | 88-7880     | 2    | Bearing                            |


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 21   | 95-0923     | 2    | Flangette              |
| 22   | 92-7302     | 1    | Nut-Bearing, Lock      |
| 23   | 253-163     | 1    | Seal                   |
| 24   | 251-342     | 1    | Bearing-Ball           |
| 25   | 65-8640     | 1    | Housing-Bearing        |
| 26   | 65-8720     | 2    | Closure-Plate, Side    |
| 27   | 65-8730     | 4    | Clamp-Bearing          |
| 28   | 253-96      | 1    | Seal-Oil               |
| 29   | 3296-39     | 2    | Nut-Lock, NI           |
| 30   | 323-7       | 2    | Screw-HH               |
| 31   | 88-7680-01  | 1    | Cover-Belt Drum, LH    |
| 32   | 88-7810     | 2    | Seal-Strip, Drum Cover |
| 33   | 321-11      | 8    | Screw-HH               |
| 34   | 3254-8      | 8    | Washer-Lock            |
| 35   | 88-7850     | 2    | Idler Pulley ASM       |
| 35:1 | 88-7180     | 1    | Pulley-Idler           |
| 35:2 | 38-7820     | 1    | Bearing-Ball           |
| 35:3 | 88-7190     | 1    | Spacer                 |
| 35:4 | 32120-42    | 1    | Ring-Retaining         |
| 35:5 | 88-7200     | 1    | Washer-Flat            |
| 35:6 | 3234-14     | 1    | Screw-HHF              |



## Drum Drive Assembly (continued)

| Ref. | Part Number | Qty. | Description                        |
|------|-------------|------|------------------------------------|
| 36   | 105-5364    | 1    | Pulley-Drum, RH                    |
| 37   | 108-9416    | 1    | Housing-Support, Differential (RH) |
| 38   | 88-7690-01  | 1    | Cover-Drum, Belt (RH)              |
| 39   | 104-1843    | 2    | Fitting-Grease, 90 DEG             |
| 40   | 88-7580     | 1    | Shaft-Wheel, Transport (LH)        |


| Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| 41   | 88-7590     | 1    | Shaft-Wheel, Transport (RH) |
| 42   | 302-11      | 1    | Fitting-Lube, 45 DEG        |
| 43   | 302-34      | 2    | Fitting-Lube                |
| 44   | 3234-14     | 8    | Screw-HHF                   |
| 45   | 106-8737    | 8    | Nut-Retainer                |



## Drum and Basket Assembly


| Ref. | Part Number | Qty. | Description  |
|------|-------------|------|--------------|
| 1    | 93-9047     | 2    | Drum         |
| 2    | 94-5850     | 1    | Spindle-Drum |
| 3    | 253-159     | 2    | Seal         |
| 4    | 251-82      | 2    | Bearing-Ball |
| 5    | 65-6520     | 1    | Spacer       |
| 6    | 65-6530     | 1    | Spacer       |
| 7    | 3296-33     | 1    | Nut-Lock, NI |
| 8    | 94-5852     | 1    | Hub-Drum     |
| 9    | 3253-4      | 16   | Washer-Lock  |

| Ref. | Part Number | Qty. | Description                  |
|------|-------------|------|------------------------------|
| 10   | 322-9       | 8    | Screw-HH                     |
| 11   | 88-7520     | 1    | Shaft-Extension, Drum (LH)   |
| 12   | 88-7510     | 1    | Shaft-Extension, Drum (RH)   |
| 13   | 322-5       | 8    | Screw-HH                     |
| 14   | 93-6055     | 1    | Differential ASM             |
| 15   | 65-9120     | 1    | Pulley-Housing, Differential |
| 16   | 65-7230     | 1    | Basket-Grass                 |
| 17   | 104-8300    | 4    | Nut-Flange, NI               |
| 18   | 3257-30     | 2    | Key-Woodruff                 |



## Differential Assembly No. 93-6055


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 2    | 95-5741     | 1    | Carrier-Differential  |
| 2:1  | 95-5738     | 4    | Bearing-Needle        |
| 2:2  | 95-5737     | 2    | Seal-Oil              |
| 4    | 95-5745     | 4    | Washer                |
| 5    | 95-5736     | 1    | Axle (Long)           |
| 6    | 104-0503    | 1    | Gear Set-Differential |
| 7    | 95-5744     | 2    | Washer-Flat           |
| 9    | 95-5747     | 1    | Pin-Drive             |
| 10   | 95-5746     | 4    | Ring-Retaining        |
| 11   | 95-5735     | 1    | Axle (Short)          |
| 12   | 95-5740     | 1    | Carrier-Differential  |
| 12:1 | 95-5738     | 4    | Bearing-Needle        |
| 12:2 | 95-5737     | 2    | Seal-Oil              |
| 13   | 95-5739     | 4    | Screw                 |
| 14   | 95-5734     | 1    | Grease                |



## Inner Countershaft Assembly

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 1    | 2412-139    | 1    | Clamp-Hose        |
| 2    | 65-6800     | 1    | Boot-Differential |
| 3    | 2412-140    | 1    | Clamp-Hose        |
| 4    | 321-2       | 3    | Screw-HH          |
| 5    | 3253-3      | 5    | Washer-Lock       |
| 6    | 88-7250-03  | 1    | Cover-Box, Rear   |
| 7    | 88-7240-03  | 1    | Cover-Box, Front  |
| 8    | 65-6902     | 1    | Strip-Seal, Cover |
| 9    | 65-6903     | 1    | Strip-Seal, Cover |
| 10   | 65-6901     | 1    | Strip-Seal, Cover |
| 11   | 65-6720     | 1    | Plate-Screw       |
| 12   | 321-3       | 2    | Screw-HH          |
| 13   | 3256-22     | 2    | Washer-Flat       |
| 14   | 93-1448     | 1    | Bracket Cover ASM |


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 15   | 88-7230     | 1    | Housing-Shaft, Counter |
| 16   | 322-5       | 1    | Screw-HH               |
| 17   | 3254-2      | 1    | Washer-Lock, Internal  |
| 18   | 88-7870     | 1    | Idler Pulley ASM       |
| 18:2 | 38-7820     | 2    | Bearing-Ball           |
| 18:3 | 88-7380     | 1    | Spacer-Pulley          |
| 18:4 | 32120-42    | 1    | Ring-Retaining         |
| 18:5 | 88-7200     | 1    | Washer-Flat            |
| 18:6 | 3234-14     | 1    | Screw-HHF              |
| 19   | 86-7140     | 1    | Spacer                 |
| 20   | 65-6850     | 1    | Key-Square             |
| 21   | 65-8910     | 1    | Pulley-Countershaft    |
| 22   | 65-9080     | 1    | Belt                   |
| 23   | 88-7710     | 1    | Seal-V-Ring            |



## Outer Crankshaft Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 88-7970     | 2    | Clip                   |
| 2    | 3253-4      | 3    | Washer-Lock            |
| 3    | 32149-1     | 3    | Nut-Keps               |
| 4    | 65-6710     | 1    | Flangette-Bearing      |
| 5    | 108-7663    | 1    | Bearing-Race, Extended |
| 6    | 65-6700     | 1    | Flangette-Lube         |
| 6:1  | 302-55      | 1    | Fitting-Grease         |
| 7    | 11-9030     | 1    | Screw-Shoulder         |
| 8    | 3296-42     | 1    | Nut-Lock, NI           |
| 9    | 3272-6      | 2    | Pin-Cotter             |
| 10   | 3272-8      | 1    | Pin-Cotter             |
| 11   | 117-1433    | 1    | Lower Brake Lever ASM  |
| 12   | 3257-30     | 1    | Key-Woodruff           |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 13   | 3296-63     | 1    | Nut-Lock, NI          |
| 14   | 92-9212     | 1    | Pulley-Shaft, Input   |
| 15   | 65-8700     | 1    | Band-Brake            |
| 16   | 86-7130     | 1    | Spacer-Pulley         |
| 17   | 283-75      | 1    | Pin-Clevis            |
| 18   | 65-6760     | 1    | Housing-Bearing       |
| 19   | 302-64      | 1    | Fitting-Grease        |
| 20   | 253-160     | 2    | Seal-Grease           |
| 21   | 251-338     | 1    | Bearing-Ball          |
| 24   | 3234-1      | 4    | Screw-HHF             |
| 25   | 322-5       | 3    | Screw-HH              |
| 26   | 3254-6      | 2    | Washer-Lock, Internal |
| 27   | 117-1430    | 2    | Bolt-Mount, Brake     |



## Engine Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 1    | 115-1066    | 1    | Engine ASM             |
| 1:2  | 115-1615    | 1    | Decal-Surface, Hot     |
| 1:3  | 115-1613    | 1    | Decal-Danger           |
| 1:4  | 93-9886     | 1    | Decal-Fuel             |
| 1:5  | 104-2628    | 8    | Screw-HWH              |
| 1:6  | 104-9771    | 2    | Bracket-Guard, Muffler |
| 1:7  | 110-7359    | 1    | Muffler Shield ASM     |
| 1:8  | 110-7361-03 | 1    | Guard-Muffler          |
| 2    | 33114-016   | 2    | Screw-HH               |
| 3    | 32180-030   | 1    | Clip-Harness           |
| 4    | 33023-00    | 1    | Nut-Lock               |

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 5    | 117-1365-03 | 1    | Plate-Harness, Wire     |
| 6    | 3256-22     | 1    | Washer-Flat             |
| 7    | 33113-016   | 1    | Screw-HH                |
| 8    | 1-323430    | 1    | Module-Interlock        |
| 9    | 115-1610    | 1    | Harness-Wire            |
| 11   | 94-5780     | 4    | Screw-HWH               |
| 13   | 88-7960     | 1    | Bracket-Cable, Throttle |
| 14   | 94-9015     | 1    | Screw-HH                |
| 15   | 104-2065    | 1    | Screw-HWH               |
| 16   | 104-8300    | 4    | Nut-Flange, NI          |
| 17   | 3255-9      | 2    | Washer-Lock             |




## Bellcrank Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 94-9007     | 1    | Bellcrank Cover ASM |
| 1:2  | 84-7280     | 1    | Decal-Danger, Japan |
| 1:2  | 93-7273     | 1    | Decal-Danger        |
| 2    | 93-6074     | 1    | Stud                |
| 3    | 3256-70     | 1    | Washer-Flat         |
| 4    | 93-6073     | 1    | Washer-Nylon        |
| 5    | 110-1718    | 2    | Screw-HHF           |
| 6    | 3256-78     | 1    | Washer-Flat         |
| 7    | 112-9388    | 1    | Traction Lever ASM  |
| 7:2  | 65-8770     | 2    | Bushing-Bellcrank   |
| 7:3  | 302-5       | 1    | Fitting-Grease      |
| 8    | 3272-5      | 1    | Pin-Cotter          |
| 9    | 93-6011     | 1    | Spring-Torsion      |
| 10   | 104-7201    | 3    | Nut-HF              |
| 12   | 112-9398    | 1    | Clutch Bracket ASM  |
| 12:2 | 65-8770     | 2    | Bushing-Bellcrank   |
| 12:3 | 302-5       | 1    | Fitting-Grease      |
| 13   | 93-6099     | 1    | Washer              |

| Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| 14   | 93-6012     | 1    | Spring-Torque, Clutch Lever |
| 15   | 93-6013-03  | 1    | Shield-Belt                 |
| 16   | 65-8260     | 1    | Spacer-Shaft, Engine        |
| 17   | 3253-4      | 6    | Washer-Lock                 |
| 18   | 33114-016   | 5    | Screw-HH                    |
| 20   | 112-9392    | 1    | Lever-Clutch                |
| 21   | 112-9390    | 1    | Guide-Belt                  |
| 22   | 93-9024     | 1    | Cable Link ASM              |
| 23   | 112-9385    | 1    | Idler Pulley ASM            |
| 23:1 | 98-7297     | 1    | Pulley-Idler                |
| 23:2 | 38-7820     | 2    | Bearing-Ball                |
| 23:3 | 32120-42    | 1    | Ring-Retaining              |
| 24   | 3256-4      | 1    | Washer-Flat                 |
| 25   | 3296-45     | 1    | Nut-Lock, NI                |
| 26   | 92-9216     | 1    | Pulley-Drive, Input         |
| 27   | 92-9218     | 1    | Belt-V, Matched Set         |
| 28   | 65-8270     | 1    | Washer                      |
| 29   | 33114-025   | 1    | Screw-HH                    |






## Handle Assembly


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 1    | 115-1098    | 1    | Throttle Lever ASM    |
| 2    | 115-1751-03 | 1    | Traction Bracket ASM  |
| 3    | 100-1270    | 1    | Switch-Proximity      |
| 4    | 112-9420    | 1    | Switch-Engine         |
| 5    | 104-2628    | 4    | Screw-HWH             |
| 6    | 94-5870     | 1    | Cable Clutch ASM      |
| 7    | 94-5871     | 1    | Cable Brake ASM       |
| 8    | 115-1677    | 1    | Brake Lever ASM       |
| 9    | 115-1068-03 | 1    | Brake Bracket ASM     |
| 10   | 104-8300    | 2    | Nut-Flange, NI        |
| 11   | 112-9321    | 1    | Lever-Traction        |
| 12   | 112-9317    | 2    | Bushing-Flanged       |
| 13   | 110-2415    | 2    | Clamp-Handle          |
| 14   | 112-9318    | 4    | Screw-HHF W/Lock      |
| 15   | 104-9774    | 1    | Knob-Red              |
| 16   | 115-1124    | 1    | Console ASM           |
| 16:2 | 115-1720    | 1    | Decal-Lever, Traction |
| 16:3 | 104-2618    | 1    | Decal-Lever, Brake    |
| 16:4 | 115-1614    | 1    | Decal-Warning         |
| 16:5 | 93-6085     | 1    | Decal-Throttle        |
| 17   | 99-7420     | 1    | Plug-Hole             |

| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 18   | 115-1130    | 1    | Decal-Console      |
| 19   | 323-34      | 2    | Screw-HH           |
| 20   | 3253-21     | 2    | Washer-Lock        |
| 21   | 3256-24     | 2    | Washer-Flat        |
| 22   | 110-7364    | 2    | Pin-Handle, Pivot  |
| 23   | 3296-28     | 2    | Nut-Lock, NI       |
| 24   | 104-9760    | 1    | Knob-Black         |
| 25   | 112-9478    | 1    | Handle             |
| 26   | 3296-56     | 1    | Nut-Lock, NI       |
| 27   | 3256-22     | 1    | Washer-Flat        |
| 28   | 66-2921     | 2    | Washer-Friction    |
| 29   | 115-1713    | 1    | Cable-Throttle     |
| 30   | 94-5780     | 2    | Screw-HWH          |
| 31   | 3290-378    | 4    | Tie-Cable          |
| 32   | 321-8       | 1    | Screw-HH           |
| 33   | 115-1727    | 2    | Screw-HHF          |
| 34   | 1-804254    | 2    | Nut                |
| 35   | 104-7201    | 1    | Nut-HF             |
| 36   | 3-5787      | 1    | Spring-Compression |
| 37   | 11-9030     | 1    | Screw-Shoulder     |




## Handle Assembly (continued)

| Ref. | Part Number | Qty. | Description  |
|------|-------------|------|--------------|
| 38   | 3296-42     | 1    | Nut-Lock, NI |
| 39   | 119-1347    | 1    | Meter-Hour   |




## Cylinder and Crankcase Assembly

| Ref.   | Part Number | Qty. | Description             |
|--------|-------------|------|-------------------------|
| 130    | 108-2522    | 4    | Bolt-Flanged (6X30)     |
| 130A   | 115-1759    | 4    | Bolt-Flanged (8X45)     |
| 187    | 115-1760    | 4    | Bolt-Upset, Wsp (6X16)  |
| 551    | 93-8516     | 2    | Pin-Dowel (6X12)        |
| 601    | 93-8517     | 3    | Bearing-Ball            |
| 11004  | 93-8504     | 1    | Gasket-Head             |
| 11008B | 115-1757    | 1    | Head-Cylinder           |
| 11022  | 93-8508     | 1    | Case-Rocker             |
| 11060  | 93-8525     | 1    | Gasket-Cover, Crankcase |
| 11060A | 93-8509     | 2    | Gasket-Case, Rocker     |
| 14069  | 93-8510     | 1    | Breather                |
| 49015  | 93-8520     | 1    | Cover-Crankcase         |
| 49120  | 93-8515     | 1    | Crankcase               |
| 92043  | 93-8512     | 2    | Pin                     |
| 92049  | 93-8511     | 2    | Seal-Oil                |
| 92150  | 93-8524     | 1    | Stud                    |




## Piston and Crankshaft Assembly

| Ref.  | Part Number | Qty. | Description             |
|-------|-------------|------|-------------------------|
| 13001 | 93-8502     | 1    | Piston                  |
| 13002 | 93-8501     | 1    | Pin-Piston              |
| 13008 | 93-8503     | 1    | Set-Ring, Piston        |
| 13025 | 94-6837     | 1    | Piston Ring Set (.05Mm) |
| 13029 | 94-6836     | 1    | Piston (0.5 O S)        |
| 13251 | 93-8528     | 1    | Connecting Rod ASM      |
| 49119 | 93-8518     | 1    | Crankshaft ASM          |
| 59056 | 94-9043     | 1    | Gear-Helical            |
| 92036 | 93-8500     | 2    | Ring-Retaining          |
| 92038 | 93-8698     | 1    | Key                     |
| 92153 | 115-1805    | 2    | Bolt (6X30)             |




## Valve and Camshaft Assembly

| Ref.   | Part Number | Qty. | Description            |
|--------|-------------|------|------------------------|
| 511    | 108-9442    | 1    | Key                    |
| 12004  | 93-8532     | 1    | Valve-Intake           |
| 12005  | 93-8529     | 1    | Valve-Exhaust          |
| 12009  | 93-8531     | 2    | Retainer-Spring, Valve |
| 12016  | 93-8535     | 2    | Arm-Rocker             |
| 12032  | 93-8539     | 2    | Tappet                 |
| 13070A | 115-1758    | 1    | Guide                  |
| 13116  | 93-8538     | 2    | Rod-Push               |
| 21118  | 93-8543     | 1    | Decompressor           |
| 49078  | 115-1763    | 2    | Spring-Valve, Engine   |
| 49118  | 93-8544     | 1    | Camshaft ASM           |
| 92015  | 93-8533     | 2    | Nut                    |
| 92015A | 93-8534     | 2    | Nut                    |
| 92043  | 93-8542     | 1    | Pin                    |
| 92043A | 93-8540     | 2    | Pin                    |
| 92049  | 115-1762    | 1    | Seal-Oil               |
| 92144  | 93-8541     | 1    | Spring                 |
| 92150  | 93-8536     | 2    | Bolt                   |




## Lubrication Equipment Assembly

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>             |
|-------------|--------------------|-------------|--------------------------------|
| 11009       | 93-8514            | 2           | Gasket-Plug, Drain (14.2X19X2) |
| 16115       | 93-8523            | 2           | Cap-Filler, Oil                |
| 92055       | 94-9041            | 2           | O-Ring (20Mm)                  |
| 92066A      | 115-1761           | 2           | Plug (14X12)                   |



## Cooling Equipment Assembly


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>  |
|-------------|--------------------|-------------|---------------------|
| 130         | 115-1765           | 7           | Bolt-Flanged (6X8)  |
| 130A        | 115-1764           | 1           | Bolt-Flanged (6X14) |
| 49089       | 93-8563            | 1           | Shroud-Engine       |
| 49089A      | 93-8565            | 1           | Shroud-Engine       |
| 59041       | 93-8572            | 1           | Fan                 |
| 59066       | 115-1804           | 1           | Housing-Fan         |
| 92027       | 93-8564            | 1           | Collar (6.8X10X6)   |
| 92153       | 115-1766           | 3           | Bolt                |



## Electric Equipment Assembly

| Ref.   | Part Number | Qty. | Description                    |
|--------|-------------|------|--------------------------------|
| 130    | 100-2610    | 6    | Bolt-Flanged (6X25)            |
| 314    | 93-8568     | 1    | Nut-Hex, Fine (14Mm)           |
| 21047  | 99-4267     | 1    | Coil-Lighting                  |
| 21130  | KW10087     | 1    | Cap-Sparkplug                  |
| 21171  | 94-9031     | 1    | Ignition Coil ASM              |
| 21194  | 99-6237     | 1    | Flywheel ASM                   |
| 26031  | 115-1767    | 1    | Harness                        |
| 92009  | 95-9716     | 2    | Screw                          |
| 92022  | 93-8569     | 1    | Washer                         |
| 92037  | 115-1771    | 1    | Clamp                          |
| 92038  | 93-8571     | 1    | Key                            |
| 92059  | 115-1768    | 1    | Tube (5X6X75)                  |
| 92070  | 108-2557    | 1    | Sparkplug (Bpr5Es) (Ngk) Solid |
| 92071A | 115-1772    | 1    | Grommet                        |
| 92170  | 93-8583     | 1    | Clamp                          |






## Control Equipment Assembly


| Ref.  | Part Number | Qty. | Description         |
|-------|-------------|------|---------------------|
| 130   | 115-1809    | 2    | Bolt-Flanged (6X12) |
| 214   | 115-1778    | 1    | Screw-Pan (4X14)    |
| 311   | 100-2668    | 1    | Nut-Hex (4Mm)       |
| 554   | 93-8607     | 1    | Pin-Snap (1.2X21.2) |
| 13168 | 93-8598     | 1    | Lever               |
| 13183 | 93-8592     | 1    | Plate               |
| 39003 | 93-8609     | 1    | Arm-Pivot           |
| 39129 | 94-9030     | 1    | Spring-Governor     |
| 39182 | 115-1754    | 1    | Control Panel ASM   |
| 42036 | 108-2567    | 1    | Sleeve              |
| 49046 | 115-1811    | 1    | Rod-Governor        |
| 49103 | 93-8603     | 1    | Arm-Governor        |
| 49110 | 115-1812    | 1    | Governor ASM        |
| 59226 | 115-1773    | 1    | Panel-Control       |

| Ref.   | Part Number | Qty. | Description           |
|--------|-------------|------|-----------------------|
| 92002  | 93-8606     | 1    | Bolt (6X28)           |
| 92015  | 93-8631     | 1    | Nut                   |
| 92015A | 93-8595     | 1    | Nut                   |
| 92015B | 93-8597     | 1    | Nut                   |
| 92022  | 94-6842     | 1    | Washer (6.2X20X0.5)   |
| 92022A | 93-8590     | 1    | Washer                |
| 92026  | 115-1776    | 1    | Spacer                |
| 92081  | 115-1775    | 1    | Spring                |
| 92144  | 93-8588     | 1    | Spring                |
| 92145  | 115-1810    | 1    | Spring                |
| 92150  | 115-1813    | 1    | Bolt                  |
| 92151  | 115-1774    | 1    | Bolt (4X22)           |
| 92200  | 93-8608     | 1    | Washer (6.5X11.5X2.0) |




## Carburetor Assembly

| Ref.   | Part Number | Qty. | Description        |
|--------|-------------|------|--------------------|
| 172    | 93-8632     | 2    | Bolt-Stud (6X18)   |
| 172A   | 115-1814    | 1    | Bolt-Stud (6X73)   |
| 11009  | 93-8624     | 1    | Gasket             |
| 11060  | 93-8613     | 3    | Gasket             |
| 15003  | 94-9032     | 1    | Carburetor ASM     |
| 16060  | 93-8633     | 1    | Pipe-Intake        |
| 16073  | 94-9048     | 1    | Insulator          |
| 16183  | 94-6844     | 1    | Float ASM          |
| 16184  | 93-8625     | 1    | Float Chamber ASM  |
| 16185  | 94-9033     | 1    | Throttle Valve ASM |
| 16186  | 93-8617     | 1    | Choke Valve ASM    |
| 23013  | 93-8626     | 1    | Screw ASM          |
| 23013A | 93-8619     | 1    | Screw ASM          |
| 39076  | 94-9034     | 1    | Limiter            |
| 49121  | 94-9035     | 1    | Nozzle-Main        |
| 92009  | 94-6845     | 1    | Screw              |
| 92015  | 93-8631     | 2    | Nut                |
| 92037  | 94-6846     | 1    | Clamp              |
| 92037A | 93-8629     | 1    | Clamp              |
| 92063  | 94-9036     | 1    | Jet-Main (No.65)   |
| 92064  | 94-9037     | 1    | Jet-Pilot (No.40)  |
| 92150  | 93-8627     | 1    | Bolt               |
| 92190  | 93-8630     | 1    | Tube               |



## Air Filter and Muffler Assembly


| Ref.   | Part Number | Qty. | Description         |
|--------|-------------|------|---------------------|
| 172    | 115-1819    | 2    | Bolt-Stud (6X16)    |
| 311    | 93-8656     | 2    | Nut-Hex (6Mm)       |
| 411    | 115-1816    | 2    | Washer-Plain (5Mm)  |
| 461    | 93-8655     | 2    | Washer-Spring (6Mm) |
| 11010  | 93-8634     | 1    | Air Filter ASM      |
| 11011  | 93-8635     | 1    | Case Filter ASM     |
| 11012  | 93-8638     | 1    | Cap-Filter, Air     |
| 11013  | 93-8636     | 1    | Element-Filter, Air |
| 11013A | 93-8637     | 1    | Element-Filter, Air |
| 11060  | 93-8654     | 1    | Gasket-Muffler      |
| 11060A | 93-8657     | 1    | Gasket-Filter, Air  |
| 13183  | 93-8642     | 1    | Plate-Filter, Air   |
| 18049  | 93-8652     | 1    | Pipe-Exhaust        |
| 32033  | 93-8658     | 1    | Pipe                |
| 49070  | 115-1817    | 1    | Muffler             |
| 92015  | 93-8631     | 3    | Nut                 |
| 92027  | 93-8651     | 1    | Collar              |
| 92153  | 93-8640     | 2    | Bolt                |
| 92190  | 93-8659     | 1    | Tube                |
| 92200  | 93-8650     | 2    | Washer (.5X18X2.0)  |



## Fuel Tank and Valve Assembly


| Ref.   | Part Number | Qty. | Description            |
|--------|-------------|------|------------------------|
| 130    | 115-1864    | 2    | Bolt-Flanged (5X8)     |
| 130A   | 115-1867    | 4    | Bolt-Flanged (8X18)    |
| 187    | 115-1760    | 4    | Bolt-Upset, Wsp (6X16) |
| 410    | 93-8668     | 1    | Washer-Plain (10Mm)    |
| 11009  | 93-8673     | 1    | Gasket                 |
| 11009A | 93-8662     | 1    | Gasket                 |
| 11047  | 93-8681     | 1    | Bracket                |
| 23062  | 104-2383    | 1    | Bracket-Tank           |
| 49019  | 94-6849     | 1    | Filter-Tapper, Fuel    |
| 49019A | 94-6826     | 1    | Filter-Fuel            |
| 51001  | 119-4132    | 1    | Fuel Tank ASM          |
| 51023  | 93-8669     | 1    | Fuel Tapper ASM        |
| 51036  | 93-8674     | 1    | Cup-Tapper, Fuel       |

| Ref.   | Part Number | Qty. | Description         |
|--------|-------------|------|---------------------|
| 51048  | 93-8660     | 1    | Fuel Cap ASM        |
| 92009  | 93-8670     | 1    | Screw               |
| 92009A | 93-8661     | 2    | Screw               |
| 92015  | 93-8675     | 1    | Nut                 |
| 92015A | 94-9042     | 1    | Nut                 |
| 92037  | 115-1861    | 2    | Clamp-Clip, Hose    |
| 92055  | 93-8671     | 1    | O-Ring              |
| 92081  | 93-8663     | 1    | Spring              |
| 92170  | 115-1865    | 2    | Clamp               |
| 92171  | 115-1862    | 1    | Clamp               |
| 92192  | 115-1863    | 1    | Tube (6.2X13.2X200) |
| 92192A | 115-1866    | 1    | Tube (4X11X160)     |



## Starter Assembly

| Ref.   | Part Number | Qty. | Description          |
|--------|-------------|------|----------------------|
| 130    | 115-1765    | 3    | Bolt-Flanged (6X8)   |
| 11012  | 94-9044     | 1    | Cap-Grip             |
| 13070  | 93-8562     | 1    | Guide-Pawl           |
| 13165  | 93-8554     | 2    | Pawl-Starter, Recoil |
| 32099  | 94-9046     | 1    | Case-Starter, Recoil |
| 46075  | 94-9045     | 1    | Grip-Starter, Recoil |
| 49080  | 93-8567     | 1    | Pulley-Recoil        |
| 49088  | 93-8552     | 1    | Recoil Starter ASM   |
| 59101  | 93-8556     | 1    | Reel-Starter, Recoil |
| 59106  | 93-8560     | 1    | Rope (4X1500)        |
| 92009  | 93-8553     | 1    | Screw                |
| 92033  | 93-8561     | 1    | Ring-Retaining       |
| 92144  | 93-8555     | 2    | Spring-Return        |
| 92144A | 93-8557     | 1    | Spring               |



## Label Set

| Ref.   | Part Number | Qty. | Description        |
|--------|-------------|------|--------------------|
| 56030  | 94-9027     | 1    | Label-Recoil       |
| 56030A | 93-8687     | 1    | Decal-Choke        |
| 56031  | 93-8689     | 1    | Decal-Instructions |
| 56031A | 93-8690     | 1    | Decal-Maintenance  |
| 56038  | 94-9028     | 1    | Label-Kawasaki     |
| 56070  | 93-8692     | 1    | Decal-Warning      |

# Attachments and Accessories

## For 04052 Greensmaster 1000 Mower

| Product Name                               | Model/Part  |
|--------------------------------------------|-------------|
| Light Kit.....                             | 04061       |
| Dethatcher Kit.....                        | 04109       |
| Dethatcher Kit.....                        | 04111       |
| Out Front Brush Kit.....                   | 04119       |
| Wheel Kit .....                            | 04123       |
| Groomer Reel Kit.....                      | 04131       |
| Full Roller ASM (21 inch) .....            | 104-2642    |
| Hour Meter Kit.....                        | 105-5350    |
| Roller Rebuild Kit.....                    | 107-1588    |
| Bedbar-Aggressive .....                    | 112-9279-03 |
| Operator Presence Kit .....                | 112-9282    |
| Smooth Scraper Kit.....                    | 112-9285    |
| Scraper Brush Kit.....                     | 112-9286    |
| Comb Scraper Kit .....                     | 112-9287    |
| Wide Wiehle Scraper Kit.....               | 112-9288    |
| Narrow Wiehle Scraper Kit.....             | 112-9289    |
| Bedknife-Edgemax, Microcut.....            | 115-1880    |
| Bedknife-Edgemax, Tournament Cut.....      | 115-1881    |
| 16-Tooth Traction Pulley Kit .....         | 115-1886    |
| Spark Arrestor Kit .....                   | 117-1441    |
| 14 Blade Reel ASM .....                    | 117-1449    |
| MVP Filter and Spark Plug Kit.....         | 30065       |
| Swaged Roller ASM.....                     | 52-3590     |
| Auxiliary Roller Kit.....                  | 65-8560     |
| .25 inch Clip Kit.....                     | 65-9000     |
| Wiehle Roller ASM (Cast Iron).....         | 71-1550     |
| Wiehle Roller ASM (.43 inch Spacing) ..... | 88-6790     |
| Bedknife-Microcut.....                     | 93-4262     |
| Bedknife-Low Cut .....                     | 93-4264     |
| 8 Blade Reel ASM .....                     | 93-6087     |
| Wiehle Roller ASM (2.5 inch Dia).....      | 93-9045     |
| Height-of-Cut Bar ASM .....                | 94-9010     |
| Jet-Main, No. 62 (High Altitude) .....     | 98-8735     |
| Jet-Main, No. 60 (High Altitude) .....     | 98-8736     |



**Count on it.**