

LAWN-BOY®

21" SILVER SERIES WALK-BEHIND MOWER

MODEL NO.10202-6900001 & UP
MODEL NO.10302-6900001 & UP
MODEL NO.10310-6900001 & UP

PARTS CATALOG

PRODUCT CHANGES

In an effort to make improvements available to LAWN-BOY owners as quickly as possible, minor changes are incorporated into LAWN-BOY products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your Parts Catalog, see your LAWN-BOY Distributor or his Authorized LAWN-BOY Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Product has two identification numbers; a model number and a serial number. The two numbers are stamped on a plate mounted on the deck. In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized Service Dealer, supply the following information:

1. Model and serial number.
2. Part number, description, and the quantity of part(s) desired.


NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
4 Cycle Engine, Fuel Tank And		Handle Assembly	6
Blade Assembly	1	Rear Catcher Assembly	
Deck And Wheel Assembly		(Model No.10310 Only)	7
(Model No. 10202 Only)	2	Engine Assembly, TVS115-57904D	8-10
Deck And Wheel Assembly		Carburetor No. 632078A	11
(Model No.10302 & 10310 Only)	3	Rewind Starter No. 590702	12
Rear Axle Assembly		Recoil Starter Assembly 590739 (Optional)	13
(Model No.10302 & 10310 Only)	4	Numeric Parts Index	14-15
Gear Case Assembly		Maintenance Record	16-18
(Model No. 10302 & 10310 Only)	5		

Accessories

Description	Model / Parts No.	Description	Model / Parts No.
Side Catcher Assembly	89814	Rear Catcher Assembly	
Leaf Shredder Attachment	89860	(Model No. 10310 Standard)	
Replacement Bags		(Model No. 10202 & 10302 Optional)	89800
Leaf Bag	89804	Mow & Feed Fertilizer Spreader	52070
Leaf Bag Kit w/Chute	89811		




C-2136

4 CYCLE ENGINE, FUEL TANK & BLADE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	16-2139	Guard – Muffler (Incl. Ref.#2)	1
2	65-2690	Decal – Warning	1
3	3274-52	Screw	2
4		Engine – 4 Cycle	1
5	92-8644	Decal – Shroud (Model No. 10202 Only)	1
*	92-8643	Decal – Shroud (Model No. 10302 & 10310 Only)	1
6	92-1701	Stop – Rope	1
7	613227	Screw – Set (Model No. 10302 & 10310 Only)	1
8	92-1024	Guide – Belt (Model No. 10302 & 10310 Only)	1

9	92-1624	Screw – Engine Mount	3
10	92-9575	Pulley – Engine (Model No. 10302 & 10310 Only)	1
11	677525	Plate & Collar Ass'y	1
12	612543	Blade – 21"	1
13	92-1630	Fan – Mulching	1
14	603164	Nut – Blade	1
15	92-4855	Shroud – Engine	1
16	92-4854	Cover – Recoil	1
17	93-4196	Shield – Grass	1
18	92-4852	Screw	4
20	92-4851	Decal – Oil (Model No. 10302 & 10310 Only)	1
21	94-8083	Decal – Primer	1

*Not Illustrated




C-2137

DECK & WHEEL ASSEMBLY (Model No. 10202 Only)

Ref. No.	Part No.	Description	No. Used
1	604604	Grommet – Plastic	2
2	614677	Screw – Thread Forming	2
3	92-1097	Decal – Danger	1
4	92-8630	Plate – Cover, Mulch	1
*	607560	Plate – Cover	1
5	614682	Knob	1
6	39-5770	Decal – Danger	1
7	92-7742	Handle Bracket Ass'y – RH	1
8	16-4359	Housing & Baffle Ass'y (Incl. Ref. #1-3, 6, & 9)	1
9	93-7250	Decal – Warning	1
*	93-7253	Decal – Warning (French)	1
10	92-7743	Handle Bracket Ass'y – LH	1
11	92-2915	Decal – H. O. C. L.H.	2
*	92-2914	Decal – H. O. C. R.H.	2
14	92-1005	Spring Arm Assembly	2

Ref. No.	Part No.	Description	No. Used
15	614672	Bolt – Shoulder	4
16	684777	Wheel Ass'y – 8"	2
17	614650	Bolt – Wheel	2
18	322-3	Screw	4
19	92-8647	Shield – Trailing	1
20	3296-39	Nut	4
21	92-1008	Knob – H. O. C. Lever	4
22	614687	Arm – Spring, Front	2
23	92-1099	Bolt – Wheel	2
24	684776	Wheel Ass'y – 6"	2
25	40-1940	Washer – Wheel Bolt	4
26	614637	Bracket – H. O. C.	4
27	92-4890	Washer	4
28	92-7731	Plate – Baffle	2
29	92-4881	Plate – H. O. C. Front	2
30	613765	Nut – Cage	1

*Not Illustrated




C-2138

DECK & WHEEL ASSEMBLY (Model No. 10302 & 10310 Only)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	92-1097	Decal - Danger	1	17	92-7724	Handle Bracket Ass'y - L.H.	1
2	604604	Grommet - Plastic	2	20	322-3	Screw - Hex. Hd.	6
3	92-2915	Decal - H. O. C. L.H.	2	21	92-8647	Shield - Trailing	1
*	92-2914	Decal - H. O. C. R.H.	2	22	3296-29	Nut	6
4	614677	Screw - Thread Forming	2	23	92-1008	Knob - H. O. C.	2
5	39-5770	Decal - Danger	1	24	614687	Arm - Spring	2
6	92-8630	Plate - Cover, Mulch	1	25	614672	Bolt - Shoulder	2
*	607560	Plate - Cover	1	26	684776	Wheel Assembly - 6"	2
7	614682	Knob	1	27	92-1099	Bolt - Wheel	2
8	92-7723	Handle Bracket Ass'y - RH	1	28	40-1940	Washer	2
9	614671	Cover - Drive	1	29	614637	Bracket - H. O. C.	2
10	92-9665	Screw	1	30	92-4890	Washer	2
11	49-2040	Screw - Thread Forming	2	31	92-4881	Plate H. O. C.	2
12	92-7728	Guide - Transmission	1	32	92-7731	Plate - Baffle	1
13	93-7250	Decal - Warning	1	33	613765	Nut - Cage	1
*	93-7253	Decal - Warning (French)	1	34	16-4369	Housing & Baffle Ass'y (Incl. Ref. # 1-5, & 13)	1
15	605120	Grommet - Shroud Mtg.	1				
16	92-7735	Gear Case Ass'y	1				

*Not Illustrated




REAR AXLE ASSEMBLY (Model No. 10302 & 10310 Only)

Ref. No.	Part No.	Description	No. Used
2	614447	Spacer – Axle Shaft	2
3	92-1004	Spring Arm Ass'y	2
4	70-9760	Bushing	2
5	92-7746	Pivot Arm Ass'y – Rear (Incl. Ref.#4, 6, & 8)	2
6	614442	Fitting – Grease	2
7	47-2900	Bushing	2
8	65-4730	Washer – Thrust Pivot Arm	2
9	65-4740	Washer – Thrust, Keyed	4
10	65-2720	Ring – Klip. Special	4
11	65-4710	Ring – Friction	2
12	65-4760	Washer – Clutch, Plastic	2

Ref. No.	Part No.	Description	No. Used
13	66-6050	Key – Rocking, LH	1
*	66-6040	Key – Rocking, RH	1
14	65-4750	Gear – Pinion	2
15	65-4720	Spring – Compression	2
16	94-1609	Cover Wheel	2
17	92-1057	Bolt – Wheel	2
18	92-1042	Wheel Ass'y – 8"	2
19	614426	Washer – Stepped	2
21	610358	Nut	2
22	32144-85	Screw	2
23	93-7381	V-Belt	1
24	92-1008	Knob	2

*Not Illustrated




C-1292

GEAR CASE ASSEMBLY **(Model No. 10302 & 10310 Only)**

Ref. No.	Part No.	Description	No. Used
1	32144-4	Screw - Taptite	4
2	614668	Cover - Gear Case	1
3	55-3760	Pinion - 15 Tooth	1
4	614696	Shaft - Intermediate	1
5	36-4791	Washer	2
6	60-8750	Bushing	2
7	93-0239	Shaft - Output	1
8	3285-19	Pin - Groove	2
9	60-8850	Bushing - Output	2

Ref. No.	Part No.	Description	No. Used
10	92-7727	Gearcase	1
11	62-6660	Spacer	1
12	614669	Pulley - Half	2
13	3256-24	Washer	1
14	3296-5	Nut	1
15	38-7820	Bearing - Ball	1
16	60-8890	Gear - Bevel Pinion	1
17	36-4780	Washer - Thrust	2
18	614596	Gear 34 Tooth	1

*Not Illustrated




C-2139

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93-4185	Handle - Upper	1
2	93-7383	Guide - Rope	1
3	92-4853	Handle - Starter	1
4	92-5424	Clip - Rope Insert	1
5	92-5412	Stop - Pivot	2
6	93-4184	Bail - Brake	1
7	92-1001	Bail -Control (Model No. 10302 & 10310 Only)	1
8	92-7726	Cable - Traction	1
9	614697	Screw - Handle	2
10	614243	Knob - Handle	2
11	614643	Handle - Lower	1

Ref. No.	Part No.	Description	No. Used
12	93-7380	Anchor - Cable, (Lower) (Model No. 10302 & 10310 Only)	1
13	614249	Tie Strap	A/R
14	92-7729	Anchor - Cable, (Upper) (Model No. 10302 & 10310 Only)	1
15	92-7730	Screw	1
16	614695	Nut	2
17	92-1044	Cable - Brake	1
18	92-1045	Cable - Throttle	1
19	321-49	Screw	1
20	93-3653	Handle-Guard	1




REAR CATCHER ASSEMBLY (Model No. 10310 Only)

Ref. No.	Part No.	Description	No. Used
1	684729	Chute & Support Assembly (Incl. Ref.# 2,3 & 9)	1
2	614589	Nut - Cap	1
3	614591	Chute Support	1
4	684727	Adaptor Assembly	1
5	614700	Tie Strap	1

Ref. No.	Part No.	Description	No. Used
6	*	Bag Assembly	1
7	613462	Hanger Clamp	2
8	613455	Wide Hanger	1
	613463	Narrow Hanger	1
9	92-2919	Decal - Danger	1

*Includes Ref.#5 and instruction sheet for installing bag to adapter assembly. Order via model #89801.

ENGINE TVS115-57905D




ENGINE TVS115—57905D

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	36478A	Cylinder (Incl. 2,7,20 & 125)	1	103	651007	Screw, Torx T—15	2
2	26727	Dowel Pin	2	110	34961	Ground Wire	1
6	33734	Breather Element	1	119	36477	Cylinder Head Gasket	1
7	36557	Breather Body Ass'y. (Incl. 6 & 12A)	1	120	36476	Cylinder Head	1
12A	36558	Breather Cover & Tube (Incl. 12B)	1	125	36471	Exhaust Valve (Std.) (Incl. 151)	1
12B	34695	Breather Tube Elbow	1	125	36472	Exhaust Valve (1/32" OS) (Incl. 151)	1
14	28277	Washer	1	126	29314B	Intake Valve (Std.) (Incl. 151)	1
15	30589	Governor Rod	1	126	29315C	Intake Valve (1/32" OS) (Incl. 151)	1
16	32651	Governor Lever	1	127	650691	Washer	2
17	31335	Governor Lever Clamp	1	129	650818	Screw	2
18	650548	Screw, 8—32 x 5/16"	1	130	6021A	Screw	6
19	35998	Extension Spring	1	135	35395	Resistor Spark Plug (RJ19LM)	1
20	32600	Oil Seal	1	150	35991	Valve Spring	2
30	36517	Crankshaft	1	151	31673	Valve Spring Cap	2
40	36073	Piston, Pin & Ring Set (Std.)	1	169	27234A	Valve Cover Gasket	1
40	36074	Piston, Pin & Ring Set (.010" OS)	1	172	32755	Valve Cover	1
40	36075	Piston, Pin & Ring Set (.020" OS)	1	174	30200	Screw	2
41	36070	Piston & Pin Ass'y. (Std.) (Incl. 43)	1	178	29752	Nut & Lock Washer	2
41	36071	Piston & Pin Ass'y. (.010" OS) (Incl. 43)	1	182	6201	Screw	2
41	36072	Piston & Pin Ass'y. (.020" OS) (Incl. 43)	1	184	26756	Carburetor To Intake Pipe Gasket	1
42	36076	Ring Set (Std.)	1	185	36544	Intake Pipe	1
42	36077	Ring Set (.010" OS)	1	186	36255	Governor Link	1
42	36078	Ring Set (.020" OS)	1	189	650839	Screw	2
43	20381	Piston Pin Retaining Ring	2	191	36559	S.E. Brake Bracket (Incl. 195)	1
45	30963B	Connecting Rod (Incl. 46)	1	195	610973	Terminal	1
46	32610A	Connecting Rod Bolt	2	200	35999	Control Bracket	1
48	27241	Valve Lifter	2	207	36200	Throttle Link	1
50	35992	Camshaft (MCR)	1	209	30200	Screw	2
52	29914	Oil Pump Ass'y.	1	223	650451	Screw	2
69	35261	Mounting Flange Gasket	1	224	34690A	Intake Pipe Gasket	1
70	34311D	Mounting Flange (Incl. 72 thru 83)	1	238	650932	Screw	2
72	36083	Oil Drain Plug	1	239	34338	Air Cleaner Gasket	1
75	27897	Oil Seal	1	241	35797	Air Cleaner Collar	1
80	30574A	Governor Shaft	1	245	35066	Air Cleaner Filter	1
81	30590A	Washer	1	250	35986	Air Cleaner Cover	1
82	30591	Governor Gear Ass'y. (Incl. 81)	1	260	35826	Blower Housing	1
83	30588A	Governor Spool	1	261	30200	Screw	2
86	650488	Screw	6	262	650831	Screw	2
89	611004	Flywheel Key	1	275	36473	Muffler (Incl. 277)	1
90	611112	Flywheel	1	277	650988	Screw	2
92	650815	Belleville Washer	1	285	35000A	Starter Cup	1
93	650816	Flywheel Nut	1	287	650926	Screw	2
100	34443A	Solid State Ignition	1	290	34357	Fuel Line	1
101	610118	Spark Plug Cover	1	292	26460	Fuel Line Clamp	2
				300	35586	Fuel Tank (Incl. 292 & 301)	1
				301	35355	Fuel Cap	1
				305	35819A	Oil Fill Tube	1
				306	34265	"O"—Ring	1

ENGINE TVS115–57905D

Ref. No.	Part No.	Description	No. Used
307	35499	"O"–Ring	1
309	651014	Screw, 10–32 x 7/16"	1
310	36259	Dipstick	1
313	34080	Spacer	1
370A	36261	Lubrication Decal	1
380	632078A	Carburetor (Incl. 184)	1
390	590702	Rewind Starter	1
		(NOTE: This engine could have been built with 590739 starter. Refer to the design of the rope pulley strength ribs for part identification. Individual starter parts do not interchange. Refer to service bulletin 116.)	


Ref. No.	Part No.	Description	No. Used
400	36481	Gasket Set (Incl. Items Marked PK in Notes) Incl. part #'s: 26756 (1), 27234A (1), 33735 (1), 34265 (1), 34338 (1), 34690A (1), 35261 (1), 36477 (1)	1
416	36085	Spark Arrestor Kit (Incl. 417) (Optional)	1
417	650760	Screw (Optional)	1
420	730225	SAE 30 4–Cycle Engine Oil (Quart)	1



CARBURETOR No. 632078A


Ref. No.	Part No.	Description	No. Used
1	631615	Shaft And Lever Assembly	1
3	631616	Shutter – Throttle	1
4	650506	Screw	1
5	631767	Spring – Return	1
6	631183	Seal – Dust	1
7	631184	Washer – Flat	1
9	632047	Primer – Bulb & Retainer	1
11	631027	Plug	1
12	631021	Needle Seat & Clip Assy (Incl. Ref. #13)	1

Ref. No.	Part No.	Description	No. Used
13	631022	Clip	1
14	632019	Float – Carburetor	1
15	631024	Shaft – Float	1
16	631700	Bowl – Float	1
21	631334	Gasket – Bowl	1
22	632071	Nut – Bowl	1
25	631028	Gasket – Bowl	1
26	631775	Fitting – Inlet	1



RECOIL STARTER ASSEMBLY 590702

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
0	590702	Recoil Starter	1	8	590700	Pulley & Rewind Spring Ass'y.	1
1	590599A	Spring Pin (Incl. 4)	1	11	590703	Starter Housing Ass'y (40 degree grommet)	1
2	590600	Washer	1	12	590535	Starter Rope (98" X 9/64" dia.)	1
3	590696	Retainer	1	13	590701	Starter Handle	1
4	590601	Washer	2				
5	590697	Brake Spring	1				
6	590698	Starter Dog	2				
7	590699	Dog Spring	2				



RECOIL STARTER ASSEMBLY 590739 (Optional)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
0	590739	Rewind Starter	1	11	590638	Starter Housing Ass'y (40 degree grommet)	1
3	590740	Retainer	1	12	590535	Starter Rope (Length 98" x 9/64" dia.)	1
6	590616	Starter Dog	2	13	590701	Starter Handle	1
7	590617	Dog Spring	2	14	590741	Locking Tab	1
8	590618A	Pulley & Rewind Spring Ass'y	1				

LAWN—BOY PART NUMBER INDEX

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
*	Bag Assembly	7 6 1	62—6660	Spacer	5 11 1
603164	Nut — Blade	1 14 1	65—2690	Decal — Warning	1 2 1
604604	Grommet — Plastic	2 1 2	65—2720	Ring — Klip. Special	4 10 4
604604	Grommet — Plastic	3 2 2	65—4710	Ring — Friction	4 11 2
605120	Grommet — Shroud Mtg.	3 15 1	65—4720	Spring — Compression	4 15 2
607560	Plate — Cover	2 * 1	65—4730	Washer — Thrust Pivot Arm	4 8 2
607560	Plate — Cover	3 * 1	65—4740	Washer — Thrust, Keyed	4 9 4
610358	Nut	4 21 2	65—4750	Gear — Pinion	4 14 2
612543	Blade — 21	1 12 1	65—4760	Washer — Clutch, Plastic	4 12 2
613227	Screw — Set	1 7 1	66—6040	Key — Rocking, RH	4 * 1
613455	Wide Hanger	7 8 1	66—6050	Key — Rocking, LH	4 13 1
613462	Hanger Clamp	7 7 2	70—9760	Bushing	4 4 2
613463	Narrow Hanger	7 1	92—1001	Bail —Control	6 7 1
613765	Nut — Cage	2 30 1	92—1004	Spring Arm Ass'y	4 3 2
613765	Nut — Cage	3 33 1	92—1005	Spring Arm Assembly	2 14 2
614243	Knob — Handle	6 10 2	92—1008	Knob	4 24 2
614249	Tie Strap	6 13 A/R	92—1008	Knob — H. O. C.	3 23 2
614426	Washer — Stepped	4 19 2	92—1008	Knob — H. O. C. Lever	2 21 4
614442	Fitting — Grease	4 6 2	92—1024	Guide — Belt	1 8 1
614447	Spacer — Axle Shaft	4 2 2	92—1042	Wheel Ass'y — 8	4 18 2
614589	Nut — Cap	7 2 1	92—1044	Cable — Brake	6 17 1
614591	Chute Support	7 3 1	92—1045	Cable — Throttle	6 18 1
614596	Gear 34 Tooth	5 18 1	92—1057	Bolt — Wheel	4 17 2
614637	Bracket — H. O. C.	2 26 4	92—1097	Decal — Danger	3 1 1
614637	Bracket — H. O. C.	3 29 2	92—1097	Decal — Danger	2 3 1
614643	Handle — Lower	6 11 1	92—1099	Bolt — Wheel	2 23 2
614650	Bolt — Wheel	2 17 2	92—1099	Bolt — Wheel	3 27 2
614668	Cover — Gear Case	5 2 1	92—1624	Screw — Engine Mount	1 9 3
614669	Pulley — Half	5 12 2	92—1630	Fan — Mulching	1 13 1
614671	Cover — Drive	3 9 1	92—1701	Stop — Rope	1 6 1
614672	Bolt — Shoulder	2 15 4	92—2914	Decal — H. O. C. R.H.	2 * 2
614672	Bolt — Shoulder	3 25 2	92—2914	Decal — H. O. C. R.H.	3 * 2
614677	Screw — Thread Forming	2 2 2	92—2915	Decal — H. O. C. L.H.	3 3 2
614677	Screw — Thread Forming	3 4 2	92—2915	Decal — H. O. C. L.H.	2 11 2
614682	Knob	2 5 1	92—2919	Decal — Danger	7 9 1
614682	Knob	3 7 1	92—4851	Decal — Oil	1 20 1
614687	Arm — Spring	3 24 2	92—4852	Screw	1 18 4
614687	Arm — Spring, Front	2 22 2	92—4853	Handle — Starter	6 3 1
614695	Nut	6 16 2	92—4854	Cover — Recoil	1 16 1
614696	Shaft — Intermediate	5 4 1	92—4855	Shroud — Engine	1 15 1
614697	Screw — Handle	6 9 2	92—4881	Plate — H. O. C. Front	2 29 2
614700	Tie Strap	7 5 1	92—4881	Plate H. O. C.	3 31 2
677525	Plate & Collar Ass'y	1 11 1	92—4890	Washer	2 27 4
684727	Adaptor Assembly	7 4 1	92—4890	Washer	3 30 2
684729	Chute & Support Assembly	7 1 1	92—5412	Stop — Pivot	6 5 2
684776	Wheel Ass'y — 6	2 24 2	92—5424	Clip — Rope Insert	6 4 1
684776	Wheel Assembly — 6	3 26 2	92—7723	Handle Bracket Ass'y — RH	3 8 1
684777	Wheel Ass'y — 8	2 16 2	92—7724	Handle Bracket Ass'y — L.H.	3 17 1
16—2139	Guard — Muffler	1 1 1	92—7726	Cable — Traction	6 8 1
16—4359	Housing & Baffle Ass'y	2 8 1	92—7727	Gearcase	5 10 1
16—4369	Housing & Baffle Ass'y	3 34 1	92—7728	Guide — Transmission	3 12 1
36—4780	Washer — Thrust	5 17 2	92—7729	Anchor — Cable, (Upper)	6 14 1
36—4791	Washer	5 5 2	92—7730	Screw	6 15 1
38—7820	Bearing — Ball	5 15 1	92—7731	Plate — Baffle	2 28 2
39—5770	Decal — Danger	3 5 1	92—7731	Plate — Baffle	3 32 1
39—5770	Decal — Danger	2 6 1	92—7735	Gear Case Ass'y	3 16 1
40—1940	Washer	3 28 2	92—7742	Handle Bracket Ass'y — RH	2 7 1
40—1940	Washer — Wheel Bolt	2 25 4	92—7743	Handle Bracket Ass'y — LH	2 10 1
47—2900	Bushing	4 7 2	92—7746	Pivot Arm Ass'y — Rear	4 5 2
49—2040	Screw — Thread Forming	3 11 2	92—8630	Plate — Cover, Mulch	2 4 1
55—3760	Pinion — 15 Tooth	5 3 1	92—8630	Plate — Cover, Mulch	3 6 1
60—8750	Bushing	5 6 2	92—8643	Decal — Shroud	1 * 1
60—8850	Bushing — Output	5 9 2	92—8644	Decal — Shroud	1 5 1
60—8890	Gear — Bevel Pinion	5 16 1	92—8647	Shield — Trailing	2 19 1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
92-8647	Shield - Trailing	3 21 1	93-7383	Guide - Rope	6 2 1
92-9575	Pulley - Engine	1 10 1	94-1609	Cover Wheel	4 16 2
92-9665	Screw	3 10 1	94-8083	Decal - Primer	1 21 1
93-0239	Shaft - Output	5 7 1	321-49	Screw	6 19 1
93-3653	Handle-Guard	6 20 1	322-3	Screw	2 18 4
93-4184	Bail - Brake	6 6 1	322-3	Screw - Hex. Hd.	3 20 6
93-4185	Handle - Upper	6 1 1	3256-24	Washer	5 13 1
93-4196	Shield - Grass	1 17 1	3274-52	Screw	1 3 2
93-7250	Decal - Warning	2 9 1	3285-19	Pin - Groove	5 8 2
93-7250	Decal - Warning	3 13 1	3296-5	Nut	5 14 1
93-7253	Decal - Warning (French)	2 * 1	3296-29	Nut	3 22 6
93-7253	Decal - Warning (French)	3 * 1	3296-39	Nut	2 20 4
93-7380	Anchor - Cable, (Lower)	6 12 1	32144-4	Screw - Taptite	5 1 4
93-7381	V-Belt	4 23 1	32144-85	Screw	4 22 2

MAINTENANCE RECORD

[illegible]

[illegible]

MAINTENANCE RECORD

[illegible]