



Count on it.

Form No. 3365-738 Rev A

Parts Catalog

42in Two-Stage Snowthrower

Model No. OEM-190-032—Serial No. 1 and Up

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquid Propane

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head


Contents

Housing, Auger and Gearbox Assembly..... 4

Handle, Belt and Drive Assembly 6

Pulley Assembly 8


Housing, Auger and Gearbox Assembly



Housing, Auger and Gearbox Assembly (continued)


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	112-1135	1	Auger Gearbox ASM	33	112-3659	1	Plug-Grease
2	112-0959	1	Impeller ASM	34	112-3660	1	Seal-Grease
3	112-0957	1	Housing ASM	35	112-0813	1	Washer-Thrust
4	112-0965	1	Bracket-Housing, Brace	36	112-3661	1	Washer-Flat
5	112-0961	1	LH Spiral Auger ASM	37	112-3662	1	Washer-Thrust
6	112-0962	1	RH Spiral Auger ASM	38	119-3957	1	Bearing-Thrust
7	119-3956	1	Screw	39	112-3664	1	Bearing-Flange
8	112-1072	1	Bolt-CARR	40	112-3665	1	Bearing-Flange
9	112-0598	1	Bolt-CARR	41	112-3667	1	Seal-Grease
10	112-6070	1	Screw-TAP	42	112-0956	1	Crank Chute ASM
11	112-0990	1	Pin-Cotter	43	112-0966	1	Bracket-Chute
12	112-1006	1	Sleeve	44	112-0968	1	Reinforcement-Chute
13	112-1020	1	Pin-Shear	45	112-0598	1	Bolt-CARR
14	112-1130	1	Pin-Roll	46	112-1073	1	Bolt-CARR
15	112-1159	1	Washer-Flat	47	112-0971	1	Bolt-CARR
16	112-0435	1	Washer-Bell	48	112-0479	1	Bolt-CARR
17	112-1179	1	Bearing-Flange	49	112-1085	1	Screw-HH
18	112-1022	1	Bearing-Flange	50	112-6179	1	Screw-Hex
19	112-1061	1	Bracket-Plate, Skid	51	112-0636	1	Nut-Lock, Flange
20	112-1063	1	Shoe-Slide	52	112-0650	1	Nut-Lock, Flange
21	112-0980	1	Spacer	53	119-3958	1	Pin-Spirol
22	112-1066	1	Housing-Bearing, Hex	54	112-1002	1	Keeper-Flange, Chute
23	112-3650	1	Housing-Reducer, RH	55	112-1007	1	Chute-Lower
24	112-3651	1	Housing-Reducer, LH	56	112-0999	1	Chute-Upper
25	112-3652	1	Plate-Brace, Housing	57	112-1009	1	Adapter-Chute, Discharge
26	112-0587	1	Screw-TAP	58	112-1008	1	Guide-Cable
27	112-3653	1	Axle-Spiral	59	112-0929	1	Bushing
28	112-3654	1	Key-Hi Pro	60	119-3959	1	Joint Block ASM
29	112-3655	1	Pin-Spirol, Spring	61	112-1064	1	Bracket-Cable
30	112-3656	1	Gear-Worm, 20T	62	112-1067	1	Bracket-Crank, Chute
31	112-3657	1	Shaft-Worm	63	112-0511	1	Nut-Lock, Flange
32	112-3658	1	Collar-Thrust	64	112-1000	1	Spacer

Handle, Belt and Drive Assembly



Handle, Belt and Drive Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	119-3955	1	Knob	57	112-0406	1	Spring-Compression
2	112-1065	1	Handle-Tilt, Chute	58	112-0407	1	Washer-Flat
3	112-1008	1	Guide-Cable	59	112-1168	1	Washer-Flat
4	112-0650	1	Nut-Lock, Flange	60	112-1024	1	Cable-Lift, W/Trigger
5	112-0944	1	Bracket-Tilt, Chute	61	112-1032	1	Rod-Index, Lift
6	112-1073	1	Bolt-CARR	62	112-1040	1	Tube-Handle, Lift
7	112-1169	1	Washer-Saddle	63	112-0937	1	Housing-Bearing
8	112-0929	1	Bushing	64	112-0967	1	Cover-Belt
9	112-0556	1	Screw-HWH	65	112-0492	1	Screw-HH
10	119-3964	1	Bolt-Eye	66	112-1096	1	Screw-HSH
11	112-0485	1	Washer-Spring	67	112-0668	1	Nut-Lock, Flange
12	112-1039	1	Tube-Support, Chute	68	112-1122	1	Key-Square
13	119-3965	1	Pin-Cotter	69	112-1123	1	Key-Hi Pro
14	119-3959	1	Joint Block ASM	70	112-1134	1	Drive-Angle, Right
15	112-1031	1	Rod-Crank, Chute	71	112-1137	1	Coupler-Flexible
16	112-1025	1	Cable-Chute	72	112-1180	1	Bearing-Ball (W/Out Collar)
17	112-1026	1	Cable-Chute	73	112-1033	1	Rod-Keeper, Belt
18	112-1131	1	Pin-Roll	74	112-0437	1	Nut-Hex
19	112-0993	1	Knob-Crank, Chute	75	112-0946	1	7 Inch Pulley Spindle ASM
20	112-1141	1	Nut-Push	76	119-3968	1	Bracket-Mounting, Pulley
21	112-1028	1	Rod	77	119-3963	1	Nut
22	119-3962	1	Pin-Keeper, Belt	78	112-0513	1	Screw-HH
23	112-0945	1	Rod ASM	79	112-0972	1	Pin
24	112-1052	1	Plate-RH Mounting	80	112-0395	1	Screw-HWH
25	112-1051	1	Plate-LH Mounting	81	112-1097	1	Pin-Clevis
26	112-0950	1	Lift Bracket ASM	82	112-1101	1	Keeper-Belt
27	112-0594	1	Screw-HH	83	112-0636	1	Nut-Lock, Flange
28	112-0975	1	Screw-HH	84	112-1115	1	Nut-Hex, Center Lock
29	112-1090	1	Screw-HH	85	112-0912	1	Pin-Hair
30	119-3954	1	Pin-Release, Quick	86	112-0989	1	Pin-Clip, Internal
31	112-0982	1	Nut-Hex Castle	87	112-1145	1	Reflector
32	112-0909	1	Nut-Lock	88	112-1014	1	Spring-Extension
33	112-1117	1	Nut-Hex, Lock	89	112-0324	1	Spring-Extension
34	112-0412	1	Pin-Cotter	90	112-1156	1	Washer-Flat
35	119-3960	1	Pin-Cotter, Bow Tie	91	112-1018	1	Washer-Isomount
36	112-1132	1	Ring-Snap	92	112-1174	1	Bolt-Shoulder
37	112-1062	1	Plate-Skid	93	112-0508	1	Spacer-Shoulder
38	112-1163	1	Washer-Flat	94	112-1037	1	Tube-Support, LH
39	112-1167	1	Washer-Flat	95	112-1038	1	Tube-Support, RH
40	112-1170	1	Washer-Bell	96	119-3961	1	Belt-V
41	112-1053	1	Bracket-Mounting	97	112-1196	1	Belt- V Type
42	112-1019	1	Bolt-Shoulder	98	112-0303	1	Pulley-Idler, 3.50 Inch
43	119-3966	1	Bearing-Flange	99	112-1057	1	Bracket-Idler
44	112-1042	1	Pulley-Drive	100	112-0565	1	Bolt-Shoulder
45	112-1030	1	Rod	101	112-0557	1	Screw-HH
46	112-1048	1	Link	102	112-3678	1	Spring-Extension
47	112-1049	1	Link	103	112-0544	1	Washer-Flat
48	112-1050	1	Link	104	112-0522	1	Nut-Hex
49	112-0376	1	Pin-Bracket, Lift	105	119-3958	1	Pin-Spirol
50	112-1068	1	Bracket-Lift	106	112-0978	1	Bolt-Hex
51	119-3967	1	Screw-Washer, Hex Index	107	112-0421	1	Screw-HH
52	112-1093	1	Screw-Pan HD	108	112-0365	1	Pulley
53	112-1095	1	Bolt-HH	109	112-3679	1	Idler Pivot ASM
54	112-1130	1	Pin-Roll	110	112-3676	1	Spacer
55	112-0995	1	Grip				
56	112-0527	1	Tie-Cable				



Pulley Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	112-0330	1	Nut-Lock, Flange
2	112-0377	1	Bearing-Ball
3	112-3680	1	Spacer
4	112-3684	1	Shaft-Spindle
5	112-3682	1	Pulley-Deck, 7 Inch
6	112-3683	1	Pulley-3.75 Inch

Notes:

Notes:

Notes:



Count on it.