

LAWN-BOY®

21" SILVER SERIES WALK—BEHIND MOWER

MODEL NO. 10314—6900001—7900001 & UP

PARTS CATALOG

PRODUCT CHANGES

In an effort to make improvements available to LAWN-BOY owners as quickly as possible, minor changes are incorporated into LAWN-BOY products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your Parts Catalog, see your LAWN-BOY Distributor or his Authorized LAWN-BOY Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Product two identification numbers; a model number and a serial number. The two numbers are stamped on a plate mounted on the deck. In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized Service Dealer, supply the following information:

1. Model and serial number.
2. Part number, description, and the quantity of part(s) desired.


NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
Mulch Plate & Wheel Assembly	1	Engine Assembly	7-10
Cover Assembly	2	Recoil Starter Assembly	11
Rear Axle Assembly	3	Carburetor Assembly	12
Gear Case Assembly	4	Handle Assembly	13
Engine Assembly	5	Rear Catcher Assembly	14
Blade Assembly	6	Numeric Parts Index	15-16

Accessories


Description	Model / Parts No.	Description	Model / Parts No.
Side Bagging Kit	Model No. 89814	Leaf Bag Kit w/Chute	Model No. 89811
Leaf Bag	Model No. 89804	Mower & Feed Fertilizer	
Leaf Shredder Kit	Model No. 89860	Spreader	Model No. 52070



C-2501

MULCH PLATE & WHEEL ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
5	614672	Bolt — Shoulder Height Adj.	2	16	92—4881	Plate — Height Adj.	2
8	40—1940	Washer	2	17	92—7731	Plate — Baffle	2
10	92—1008	Knob — Height Adjust	4	18	613765	Nut — Cage	1
11	614687	Arm — Spring	2	19	94—1610	Grommet — Plastic	2
12	92—1099	Bolt — Shoulder	2	20	614677	Screw — Sems Thr'd Form.	2
13	684776	Wheel & Tire Ass'y 6"	2	21	92—8630	Plate — Mulch	1
14	614637	Bracket — Wheel Height Adj.	2	22	614682	Knob — Cover Plate	1
15	92—4890	Washer	2				




C-2146A

COVER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92-9665	Screw - Phillips Hd.	1
2	49-2040	Screw - Hex Hd.	2
4	92-7728	Guide - Transmission	1
5	605120	Grommet	1
6	92-7735	Gear Case Assembly	1
7	92-7724	Bracket - Handle L.H.	1
8	92-2915	Decal - H.O.C.	2
9	322-3	Screw - Hex Hd. Cap	6
10	92-8647	Shield - Trailing	1

Ref. No.	Part No.	Description	No. Used
11	3296-29	Nut - Lock	6
12	93-7250	Decal - Warning	1
13	16-4369	Housing	1
14	92-1097	Decal - Discharge	1
15	92-2914	Decal - H.O.C.	2
16	39-5770	Decal - Danger	1
17	607560	Plate - Cover	1
18	92-7723	Bracket - Handle R.H.	1
19	614671	Cover - Drive	1




REAR AXLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
2	614447	Spacer – Axle Shaft	2
3	92-1004	Spring Arm Ass'y	2
4	70-9760	Bushing	2
5	92-7746	Pivot Arm Ass'y – Rear (Incl. Ref.#4, & 7)	2
7	47-2900	Bushing	2
8	65-4730	Washer – Thrust Pivot Arm	2
9	65-4740	Washer – Thrust, Keyed	4
10	65-2720	Ring – Klip. Special	4
11	65-4710	Ring – Friction	2
12	65-4760	Washer – Clutch, Plastic	2

Ref. No.	Part No.	Description	No. Used
13	66-6050	Key – Rocking, LH	1
*	66-6040	Key – Rocking, RH	1
14	65-4750	Gear – Pinion	2
15	65-4720	Spring – Compression	2
16	94-1609	Cover Wheel	2
17	92-1057	Bolt – Wheel	2
18	92-1042	Wheel Ass'y – 8"	2
19	614426	Washer – Stepped	2
21	610358	Nut	2
22	32144-85	Screw	2
23	93-7381	V-Belt	1

*Not Illustrated




C-1292

GEAR CASE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	32144-4	Screw - Taptite	4
2	614668	Cover - Gear Case	1
3	55-3760	Pinion - 15 Tooth	1
4	614696	Shaft - Intermediate	1
5	36-4791	Washer	2
6	60-8750	Bushing	2
7	93-0239	Shaft - Output	1
8	3285-19	Pin - Groove	2
9	60-8850	Bushing - Output	2
10	92-7727	Gearcase	1

Ref. No.	Part No.	Description	No. Used
11	62-6660	Spacer	1
12	614669	Pulley - Half	2
13	3256-24	Washer	1
14	3296-5	Nut	1
15	38-7820	Bearing - Ball	1
16	60-8890	Gear - Bevel Pinion	1
17	36-4780	Washer - Thrust	2
18	614596	Gear 34 Tooth	1
*	92-7735	Gear Case Complete	1


*Not Illustrated



C—2502A

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	93—4302	Screw — Sems	3	8	93—1230	Cover	1
2	93—0294	Decal — Recoil	1	9	66—7460	Bulb — Primer	1
3	92—1701	Stop — Rope	1	10	44—2750	Body — Primer	1
4	92—6380	Tank & Shroud	1	12	612782	Line — Gas	1
5	93—3660	Gas Cap Assembly (Incl. Ref. #6—8, & 16)	1	13	95—1726	Screw — Engine	3
6	609150	Baffle — Foam	1	14	93—4196	Shield — Grass	1
7	613311	Gasket	1	15	92—8615	Applique — Shroud	1
				16	93—3175	Baffle — Gas Cap	1




C-2001

BLADE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92-6542	Pulley - Engine	1
2	677525	Plate & Collar	1
3	612543	Blade -21"	1

Ref. No.	Part No.	Description	No. Used
4	92-1630	Fan - Mulching	1
5	603164	Nut - Blade	1
6	613227	Screw - Set	1




C-2128A

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	614699	Screw	3
2	130743	Nut	1
3	614640	Hub – Starter	1
4	684743	Flywheel	1
5	93–1216	Base – Shroud	1

Ref. No.	Part No.	Description	No. Used
6	607199	Key	1
7	614702	Screw	4
8	93–4304	Shroud Assembly	1
9	316959	Washer – Lock	1




C-2379

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
2	609482	Screw	2
3	610383	Retainer – Filter	1
4	93-1231	Cover – Air Cleaner	1
5	609493	Element – Filter Air	1
6	93-4320	Shield – Fuel	1

Ref. No.	Part No.	Description	No. Used
7	44-3174	Hose – Primer	1
8	93-4331	Carburetor Assembly (Incl. Ref. #9)	1
9	92-4948	Gasket – Carburetor	2
10	93-1221	Shield – Carburetor	1




C-1296

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
1	94-5737	Short Block (Incl. Ref. #2, Ref. #9 pg. 8)	1
2	93-1233	Gasket - Exhaust	1
3		CD Ignition	1
*	681678	Cover & Terminal	1
4	614009	Plug - Spark	1
5	684049	CD Ignition (Incl. Ref. #3)	1
6	613208	Screw - Hex. Washer Hd.	2
7	93-4306	Spring - Compression	1
8	93-4312	Brake Plate Assembly	1
9	92-9698	Screw - Shoulder	1
10	614702	Screw	1

Ref. No.	Part No.	Description	No. Used
11	3290-459	Rivet - Plastic	2
12	92-2925	Strap - Insulation	1
13	60-9010	Strap - Ground	1
14	92-1156	Wire - Brake Switch Lead	1
15	53-4690	Stop - Ground Strap	1
16	12-5450	Screw - Thread Forming	1
17	14-6009	Mounting Plate	1
18	614654	Plate - Muffler	1
19	607601	Screw	4
20	93-4343	Baffle	1
21	609471	Screw	3
22	614674	Cover - Muffler	1

*Not Illustrated




C-2500

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
1	681737	Set – Ring	1
2	252-76	Bearing – Thrust	1
3	92-4923	Piston & Ring Set	1
*	92-4925	Piston & Connecting Rod (Incl. Ref. #1-8, 12, & 13)	1
4	606608	Pin – Wrist	1
5	303712	Ring – Retaining	2
6	92-4921	Connecting Rod Assembly (Incl. Ref. #6-8, 12, & 13)	1
7	92-4927	Bearing	1
8	677982	Liner – Split (Set of 2)	1
9	94-5713	Crankshaft	1
10	681830	Bearing – Upper Main	1

Ref. No.	Part No.	Description	No. Used
11	611396	Seal – Oil	2
12	683911	Bearing – Needle	1
13	611393	Screw – Hex. Hd.	2
14	614636	Screw – Torx. Washer Hd.	4
16	602588	Reed – Carburetor	1
17	602587	Reed – Backup Plate	1
18	612872	Screw	2
19	681831	Bearing – Needle	1
20	609629	Dowel	1
21	609123	Plug – Core	4
22	252-80	Washer – Thrust	1
*	610372	Sealer	1

*Not Illustrated




C-1309

RECOIL STARTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93-4304	Housing Assembly	1
2	92-4928	Rope - Starter	1
3	92-4929	Pulley Assembly	1
4	92-4930	Spring - Dog	2
5	92-4931	Dog	2

Ref. No.	Part No.	Description	No. Used
6	92-9692	Retainer	1
7	92-4933	Screw	1
8	92-4934	Spring	1
9	92-4935	Spring Keeper Assembly	1




C-2130A

CARBURETOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	92-6376	Air Vane & Shaft	1	12	603145	Spring	1
2	610165	Retainer - Speed Control	1	13	602850	Gasket	1
3	93-1225	Lever - Speed Adjust	1	14	92-6371	Nozzle	1
4	610834	Collar - Air Vane	1	15	611071	Filter - Fuel	1
5	92-4944	Spring - Governor	1	16	678113	Float & Arm Assembly	1
6	92-6373	Disc - Throttle	1	17	92-6389	Pin	1
7	92-4949	Bracket - Throttle Control	1	18	92-9691	Float Chamber	1
8	613269	Screw	2	19	608850	Screw	4
9	93-4324	Carburetor Body	1	20	612383	Washer	1
10	92-9697	Kit - Float Valve, Body & Seat (Incl. Ref. #12)	1	21	92-6370	Main Jet	1
				*	92-6385	Jet - High Altitude	1
				*	93-4331	Carburetor Assembly	1


*Not Illustrated



C-2148B

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	93-4184	Bail - Flywheel Brake	1	12	92-7738	Cable - Flywheel Brake	1
2	92-1001	Bail - SP Control	1	13	92-7729	Anchor - Cable SP Upper	1
3	92-5412	Stop - Pivot	2	14	92-7726	Cable - Traction	1
4	95-1713	Handle - Upper	1	15	3296-73	Nut - Lock	2
5	321-49	Screw - Hex Hd. Cap	1	16	93-7383	Guide - Rope	1
6	92-7734	Cable - Throttle	1	17	321-50	Screw - Hex Hd. Cap	1
8	614697	Screw - Handle	2	18	612825	Handle - Starter	1
9	614643	Handle - Lower	1	19	612824	Clip - Rope Insert	1
10	93-7380	Anchor - Cable SP Lower)	1	21	93-3653	Guard - Handle	1
11	614243	Knob	2				



REAR CATCHER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	684729	Chute & Support Assembly (Incl. Ref.# 2,3 & 9)	1
2	614589	Nut – Cap	1
3	614591	Chute Support	1
4	684727	Adaptor Assembly	1

Ref. No.	Part No.	Description	No. Used
5	614700	Tie Strap	1
*6	89801	Bag Assembly	1
7	613462	Hanger Clamp	2
8	613455	Wide Hanger	1
9	92-2919	Decal – Danger	1

*Includes Ref.#5 and instruction sheet for installing bag to adapter assembly. Order via model #89801.

LAWN—BOY PART NUMBER INDEX

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
89801	Bag Assembly	14 *6 1	614699	Screw	7 1 3
130743	Nut	7 2 1	614700	Tie Strap	14 5 1
303712	Ring — Retaining	10 5 2	614702	Screw	7 7 4
316959	Washer — Lock	7 9 1	614702	Screw	9 10 1
602587	Reed — Backup Plate	10 17 1	677525	Plate & Collar	6 2 1
602588	Reed — Carburetor	10 16 1	677982	Liner — Split (Set of 2)	10 8 1
602850	Gasket	12 13 1	678113	Float & Arm Assembly	12 16 1
603145	Spring	12 12 1	681678	Cover & Terminal	9 * 1
603164	Nut — Blade	6 5 1	681737	Set — Ring	10 1 1
605120	Grommet	2 5 1	681830	Bearing — Upper Main	10 10 1
606608	Pin — Wrist	10 4 1	681831	Bearing — Needle	10 19 1
607199	Key	7 6 1	683911	Bearing — Needle	10 12 1
607560	Plate — Cover	2 17 1	684049	CD Ignition	9 5 1
607601	Screw	9 19 4	684727	Adaptor Assembly	14 4 1
608850	Screw	12 19 4	684729	Chute & Support Assembly	14 1 1
609123	Plug — Core	10 21 4	684743	Flywheel	7 4 1
609150	Baffle — Foam	5 6 1	684776	Wheel & Tire Ass'y 6	1 13 2
609471	Screw	9 21 3	12—5450	Screw — Thread Forming	9 16 1
609482	Screw	8 2 2	14—6009	Mounting Plate	9 17 1
609493	Element — Filter Air	8 5 1	16—4369	Housing	2 13 1
609629	Dowel	10 20 1	36—4780	Washer — Thrust	4 17 2
610165	Retainer — Speed Control	12 2 1	36—4791	Washer	4 5 2
610358	Nut	3 21 2	38—7820	Bearing — Ball	4 15 1
610372	Sealer	10 * 1	39—5770	Decal — Danger	2 16 1
610383	Retainer — Filter	8 3 1	40—1940	Washer	1 8 2
610834	Collar — Air Vane	12 4 1	44—2750	Body — Primer	5 10 1
611071	Filter — Fuel	12 15 1	44—3174	Hose — Primer	8 7 1
611393	Screw — Hex. Hd.	10 13 2	47—2900	Bushing	3 7 2
611396	Seal — Oil	10 11 2	49—2040	Screw — Hex Hd.	2 2 2
612383	Washer	12 20 1	53—4690	Stop — Ground Strap	9 15 1
612543	Blade —21	6 3 1	55—3760	Pinion — 15 Tooth	4 3 1
612782	Line — Gas	5 12 1	60—8750	Bushing	4 6 2
612824	Clip — Rope Insert	13 19 1	60—8850	Bushing — Output	4 9 2
612825	Handle — Starter	13 18 1	60—8890	Gear — Bevel Pinion	4 16 1
612872	Screw	10 18 2	60—9010	Strap — Ground	9 13 1
613208	Screw — Hex. Washer Hd.	9 6 2	62—6660	Spacer	4 11 1
613227	Screw — Set	6 6 1	65—2720	Ring — Klip. Special	3 10 4
613269	Screw	12 8 2	65—4710	Ring — Friction	3 11 2
613311	Gasket	5 7 1	65—4720	Spring — Compression	3 15 2
613455	Wide Hanger	14 8 1	65—4730	Washer — Thrust Pivot Arm	3 8 2
613462	Hanger Clamp	14 7 2	65—4740	Washer — Thrust, Keyed	3 9 4
613765	Nut — Cage	1 18 1	65—4750	Gear — Pinion	3 14 2
614009	Plug — Spark	9 4 1	65—4760	Washer — Clutch, Plastic	3 12 2
614243	Knob	13 11 2	66—6040	Key — Rocking, RH	3 * 1
614426	Washer — Stepped	3 19 2	66—6050	Key — Rocking, LH	3 13 1
614447	Spacer — Axle Shaft	3 2 2	66—7460	Bulb — Primer	5 9 1
614589	Nut — Cap	14 2 1	70—9760	Bushing	3 4 2
614591	Chute Support	14 3 1	92—1001	Bail — SP Control	13 2 1
614596	Gear 34 Tooth	4 18 1	92—1004	Spring Arm Ass'y	3 3 2
614636	Screw — Torx. Washer Hd.	10 14 4	92—1008	Knob — Height Adjust	1 10 4
614637	Bracket — Wheel Height Adj.	1 14 2	92—1042	Wheel Ass'y — 8	3 18 2
614640	Hub — Starter	7 3 1	92—1057	Bolt — Wheel	3 17 2
614643	Handle — Lower	13 9 1	92—1097	Decal — Discharge	2 14 1
614654	Plate — Muffler	9 18 1	92—1099	Bolt — Shoulder	1 12 2
614668	Cover — Gear Case	4 2 1	92—1156	Wire — Brake Switch Lead	9 14 1
614669	Pulley — Half	4 12 2	92—1630	Fan — Mulching	6 4 1
614671	Cover — Drive	2 19 1	92—1701	Stop — Rope	5 3 1
614672	Bolt — Shoulder Height Adj.	1 5 2	92—2914	Decal — H.O.C.	2 15 2
614674	Cover — Muffler	9 22 1	92—2915	Decal — H.O.C.	2 8 2
614677	Screw — Sems Thr'd Form.	1 20 2	92—2919	Decal — Danger	14 9 1
614682	Knob — Cover Plate	1 22 1	92—2925	Strap — Insulation	9 12 1
614687	Arm — Spring	1 11 2	92—4881	Plate — Height Adj.	1 16 2
614696	Shaft — Intermediate	4 4 1	92—4890	Washer	1 15 2
614697	Screw — Handle	13 8 2	92—4921	Connecting Rod Assembly	10 6 1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
92-4923	Piston & Ring Set	10 3 1	93-1216	Base - Shroud	7 5 1
92-4925	Piston & Connecting Rod	10 * 1	93-1221	Shield - Carburetor	8 10 1
92-4927	Bearing	10 7 1	93-1225	Lever - Speed Adjust	12 3 1
92-4928	Rope - Starter	11 2 1	93-1230	Cover	5 8 1
92-4929	Pulley Assembly	11 3 1	93-1231	Cover - Air Cleaner	8 4 1
92-4930	Spring - Dog	11 4 2	93-1233	Gasket - Exhaust	9 2 1
92-4931	Dog	11 5 2	93-3175	Baffle - Gas Cap	5 16 1
92-4933	Screw	11 7 1	93-3653	Guard - Handle	13 21 1
92-4934	Spring	11 8 1	93-3660	Gas Cap Assembly	5 5 1
92-4935	Spring Keeper Assembly	11 9 1	93-4184	Bail - Flywheel Brake	13 1 1
92-4944	Spring - Governor	12 5 1	93-4196	Shield - Grass	5 14 1
92-4948	Gasket - Carburetor	8 9 2	93-4302	Screw - Sems	5 1 3
92-4949	Bracket - Throttle Control	12 7 1	93-4304	Housing Assembly	11 1 1
92-5412	Stop - Pivot	13 3 2	93-4304	Shroud Assembly	7 8 1
92-6370	Main Jet	12 21 1	93-4306	Spring - Compression	9 7 1
92-6371	Nozzle	12 14 1	93-4312	Brake Plate Assembly	9 8 1
92-6373	Disc - Throttle	12 6 1	93-4320	Shield - Fuel	8 6 1
92-6376	Air Vane & Shaft	12 1 1	93-4324	Carburetor Body	12 9 1
92-6380	Tank & Shroud	5 4 1	93-4331	Carburetor Assembly	8 8 1
92-6385	Jet - High Altitude	12 * 1	93-4331	Carburetor Assembly	12 * 1
92-6389	Pin	12 17 1	93-4343	Baffle	9 20 1
92-6542	Pulley - Engine	6 1 1	93-7250	Decal - Warning	2 12 1
92-7723	Bracket - Handle R.H.	2 18 1	93-7380	Anchor - Cable SP Lower)	13 10 1
92-7724	Bracket - Handle L.H.	2 7 1	93-7381	V-Belt	3 23 1
92-7726	Cable - Traction	13 14 1	93-7383	Guide - Rope	13 16 1
92-7727	Gearcase	4 10 1	94-1609	Cover Wheel	3 16 2
92-7728	Guide - Transmission	2 4 1	94-1610	Grommet - Plastic	1 19 2
92-7729	Anchor - Cable SP Upper	13 13 1	94-5713	Crankshaft	10 9 1
92-7731	Plate - Baffle	1 17 2	94-5737	Short Block	9 1 1
92-7734	Cable - Throttle	13 6 1	95-1713	Handle - Upper	13 4 1
92-7735	Gear Case Assembly	2 6 1	95-1726	Screw - Engine	5 13 3
92-7735	Gear Case Complete	4 * 1	252-76	Bearing - Thrust	10 2 1
92-7738	Cable - Flywheel Brake	13 12 1	252-80	Washer - Thrust	10 22 1
92-7746	Pivot Arm Ass'y - Rear	3 5 2	321-49	Screw - Hex Hd. Cap	13 5 1
92-8615	Applique - Shroud	5 15 1	321-50	Screw - Hex Hd. Cap	13 17 1
92-8630	Plate - Mulch	1 21 1	322-3	Screw - Hex Hd. Cap	2 9 6
92-8647	Shield - Trailing	2 10 1	3256-24	Washer	4 13 1
92-9665	Screw - Phillips Hd.	2 1 1	3285-19	Pin - Groove	4 8 2
92-9691	Float Chamber	12 18 1	3290-459	Rivet - Plastic	9 11 2
92-9692	Retainer	11 6 1	3296-5	Nut	4 14 1
92-9697	Kit - Float Valve, Body	12 10 1	3296-29	Nut - Lock	2 11 6
92-9698	Screw - Shoulder	9 9 1	3296-73	Nut - Lock	13 15 2
93-0239	Shaft - Output	4 7 1	32144-4	Screw - Taptite	4 1 4
93-0294	Decal - Recoil	5 2 1	32144-85	Screw	3 22 2

[illegible]

MAINTENANCE RECORD

[illegible]