
42” SNOW BLADE KIT

MODEL NO. 79150–6900001 & UP | **PARTS CATALOG**




BLADE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92–6045	Frame	1
2	3296–39	Nut – Lock	6
3	3296–15	Nut – Lock	1
4	92–6043	Quadrant	1
5	92–6037	Blade	1
6	3218–3	Nut – Jam	2
7	88–1000	Decal – Danger	1

Ref. No.	Part No.	Description	No. Used
8	92–6034	Plate	1
9	3231–1	Bolt – Carriage	5
10	3216–2	Screw – Hex Hd. Cap	1
11	4564	Rod – Lower Pivot	1
12	92–6035	Spacer	2
13	3272–11	Pin – Cotter	2
14	323–15	Screw – Hex Hd. Cap	1

©The TORO Company –1996
All Rights Reserved




C−1623

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	6542	Grip	1
2	92−6039	Handle	1
3	933512	Pin − Hairpin	2
4	3272−12	Pin − Cotter	5
5	3256−28	Washer − Flat	4
6	92−6046	Brace − Mounting	1
7	3296−23	Nut − Lock	2
8	102572	Spring	1
9	108749	Rod − Bellcrank	1
10	3272−10	Pin − Cotter	5
11	92−6041	Bellcrank	1
12	88−1010	Pad − Rubber	1

Ref. No.	Part No.	Description	No. Used
13	92−6044	Shaft	1
14	108747	Rod − Latch	1
15	3218−3	Nut − Jam	2
16	100653	Eyebolt	2
17	4629	Spring	2
18	92−6038	Latch	1
19	3256−26	Washer − Flat	5
20	92−6035	Spacer	2
21	108753	Rod	1
22	3256−24	Washer − Flat	1
23	92−6042	Pivot − Handle	1
24	325−6	Screw − Hex Hd. Cap	2




−1624

MOUNTING BRACKET ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3296−29	Nut − Lock	23
2	322−3	Screw − Hex Hd. Cap	21
3	88−0960	Tube − Support	1
4	88−0970	Rod − Support	1

Ref. No.	Part No.	Description	No. Used
5	88−0930	Bracket − L.H.	1
6	92−6001	Brace − Center	2
7	88−0920	Bracket R.H.	1
8	88−0940	Brace	2



LIFT ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	105316	Cap	1
2	6542	Grip	1
3	88−0980	Rod − Lift	1
4	102213	Trunnion	1
5	92−6036	Spacer	1
6	3296−23	Nut − Lock	1
7	3296−29	Nut − Lock	4
8	88−0950	Bracket − Support	1

Ref. No.	Part No.	Description	No. Used
9	3230−2	Bolt − Carriage	2
10	92−6040	Handle − Lift	1
11	3256−26	Washer − Flat	1
12	933512	Cotter − Hairpin	1
13	88−1080	Fastener − Footpad	2
14	3256−2	Washer − Flat	2
15	322−3	Screw − Hex Hd. Cap	2

TORO PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.
4564	Rod − Lower Pivot	1	11	1
4629	Spring	2	17	2
6542	Grip	2	1	1
6542	Grip	4	2	1
100653	Eyebolt	2	16	2
102213	Trunnion	4	4	1
102572	Spring	2	8	1
105316	Cap	4	1	1
108747	Rod − Latch	2	14	1
108749	Rod − Bellcrank	2	9	1
108753	Rod	2	21	1
933512	Cotter − Hairpin	4	12	1
933512	Pin − Hairpin	2	3	2
92−6046	Brace − Mounting	2	6	1
88−0920	Bracket R.H.	3	7	1
88−0930	Bracket − L.H.	3	5	1
88−0940	Brace	3	8	2
88−0950	Bracket − Support	4	8	1
88−0960	Tube − Support	3	3	1
88−0970	Rod − Support	3	4	1
88−0980	Rod − Lift	4	3	1
88−1000	Decal − Danger	1	7	1
88−1010	Pad − Rubber	2	12	1
88−1080	Fastener − Footpad	4	13	2
92−6001	Brace − Center	3	6	2
92−6034	Plate	1	8	1
92−6035	Spacer	1	12	2
92−6035	Spacer	2	20	2
92−6036	Spacer	4	5	1
92−6037	Blade	1	5	1
92−6038	Latch	2	18	1
92−6039	Handle	2	2	1
92−6040	Handle − Lift	4	10	1
92−6041	Bellcrank	2	11	1
92−6042	Pivot − Handle	2	23	1
92−6043	Quadrant	1	4	1
92−6044	Shaft	2	13	1
92−6045	Frame	1	1	1
322−3	Screw − Hex Hd. Cap	3	2	21
322−3	Screw − Hex Hd. Cap	4	15	2
323−15	Screw − Hex Hd. Cap	1	14	1
325−6	Screw − Hex Hd. Cap	2	24	2
3216−2	Screw − Hex Hd. Cap	1	10	1
3218−3	Nut − Jam	1	6	2
3218−3	Nut − Jam	2	15	2
3230−2	Bolt − Carriage	4	9	2
3231−1	Bolt − Carriage	1	9	5
3256−2	Washer − Flat	4	14	2
3256−24	Washer − Flat	2	22	1
3256−26	Washer − Flat	4	11	1
3256−26	Washer − Flat	2	19	5
3256−28	Washer − Flat	2	5	4
3272−10	Pin − Cotter	2	10	5
3272−11	Pin − Cotter	1	13	2
3272−12	Pin − Cotter	2	4	5
3296−15	Nut − Lock	1	3	1
3296−23	Nut − Lock	4	6	1
3296−23	Nut − Lock	2	7	2
3296−29	Nut − Lock	3	1	23
3296−29	Nut − Lock	4	7	4
3296−39	Nut − Lock	1	2	6

*Not Illustrated

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

Date								

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.

Litho in U.S.A.

MAINTENANCE RECORD

Date								

3318–509

MAINTENANCE RECORD

Date								