




MODEL NO. 20441-6900001 & UP MODEL NO. 20443-6900001 & UP MODEL NO. 20453-6900001 & UP	<b>PARTS CATALOG</b>
<b>21" RECYCLER<sup>®</sup></b> Rear Bagging Mower	




C-2288

## HOUSING ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	16-9269	Cover - Recycling (Incl. Ref. #4) (Model No. 20441 & 20443)	1
2	93-0242	Grommet (Model No. 20441 & 20443)	4
3	32144-4	Screw - Tapping (Model No. 20441 & 20443)	4
4	85-7060	Decal - Danger (Model No. 20441 & 20443)	1
5	93-0236	Bracket - Handle R.H.	1
6	93-0262	Decal - Warning	1
7	93-0248	Decal - Warning	1
8	92-2915	Decal - HOC L.H.	1
9	92-2914	Decal - HOC R.H.	1
10	93-0235	Bracket - Handle L.H.	1


Ref. No.	Part No.	Description	No. Used
11	92-1005	Spring Arm Assembly	2
12	92-9592	Wheel Assembly	2
13	614650	Bolt - Shoulder	4
14	92-8647	Shield - Trailing	1
15	40-1940	Washer	4
16	92-1008	Knob - Height Adjust	4
17	614687	Spring Arm Assembly	2
18	614672	Bolt - Shoulder	4
19	92-9591	Wheel Assembly	2
20	614637	Bracket - Wheel Height Adj.	4
21	92-4890	Washer	4
22	3296-39	Nut - Lock	4
23	93-0231	Screw - Plastite	2
24	93-0222	Baffle - Front	1
25	93-0216	Kicker - Front	1



## HOUSING ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
26	92-4881	Plate – Height Adjust	2
27	16-9259	Deck Assembly (Incl. Ref. #6 & 7 pg. 1) (Incl. Ref. #14 pg. 3)	1


Ref. No.	Part No.	Description	No. Used
28	3296-2	Nut – Lock (Model No. 20441 & 20443)	1
29	32105-27	Screw – Hex Washer Hd. (Model No. 20441 & 20443)	1



C-2289

## ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	92-6396	Shroud - Engine (Model No. 20441 Only)	1	7	32104-118	Screw - Phillips Hd. (Model No. 20441 Only)	2
2	93-4302	Screw - Sems (Model No. 20441 Only)	3	8	68-3632	Line - Fuel (Model No. 20441 Only)	1
3	93-0246	Decal - Engine (Model No. 20441 Only)	1	9		Engine (Model No. 20441 Only)	1
4	93-1200	Cover - Strap (Model No. 20441 Only)	1	12	52-7320	Retainer - Blade (Model No. 20441 Only)	1
5	92-1701	Rope - Stop (Model No. 20441 Only)	1	13	93-0245	Decal - Deck	1
6	55-3578	Gas Cap Assembly (Model No. 20441 Only)	1	14	39-5770	Decal - Danger	1
				15	66-5370	Spring - Compression (Model No. 20441 Only)	1




C-2244A

## SHROUD & BLOCK ASSEMBLY (Model No. 20441 Only)

Ref. No.	Part No.	Description	No. Used
1	614699	Screw	3
2	93-1231	Cover - Air Filter	1
3	609493	Element - Air Filter	1
4	93-4320	Plug	1
5	44-3172	Hose - Primer	1
6	93-1227	Shield - Carburetor	1
7	92-4948	Gasket - Carburetor	2
9	609482	Screw	2
10	93-4331	Carburetor Assembly	1
12	94-5731	Short Block Assembly	1
13	607199	Key	1


Ref. No.	Part No.	Description	No. Used
14	614702	Screw	4
15	93-1216	Base - Shroud	1
16	684743	Flywheel Assembly	1
17	614640	Hub - Starter	1
18	316959	Washer - Lock	1
19	130743	Nut	1
20	93-1248	Shroud	1
21	44-2750	Body - Primer	1
22	66-7460	Bulb - Primer	1
23	93-4304	Rope	1



C-1899

## BRAKE & MUFFLER ASSEMBLY (Model No. 20441 Only)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	3290-459	Rivet	2	12	93-1233	Gasket - Exhaust	1
2	60-9010	Strap - Ground	1	13	614009	Plug - Spark	1
3	92-2925	Strap - Insulation	1	14	684049	Ignition Assembly (Incl. Ref. #20)	1
4	12-5450	Screw - Thread Forming	1	15	84-7820	Plate - Brake Mount	1
5	53-4690	Stop - Ground Strap	1	16	613208	Screw - Hex Washer Hd.	2
6	92-1156	Wire - Brake Switch Lead	1	17	614702	Screw	1
7	614654	Plate - Muffler	1	18	93-4312	Plate - Brake Assembly	1
8	607601	Screw	4	19	92-9698	Screw - Shoulder	1
9	614681	Baffle	1	20	681678	Lead & Cover Assembly	1
10	609471	Screw	3	21	93-4306	Spring - Compression	1
11	93-1108	Cover - Muffler	1				




C-2292A

## BLOCK ASSEMBLY (Model No. 20441 Only)

Ref. No.	Part No.	Description	No. Used
1	681737	Set – Rings, Piston	1
3	92-4923	Piston & Ring Set	1
*	92-4925	Piston & Connecting Rod (Incl. Ref. #1, 3-7 & 13)	1
4	606608	Pin – Wrist	1
5	303712	Ring – Retaining	2
6	92-4921	Connecting Rod Assembly (Incl. Ref. #8, 12 & 13)	1
7	92-4927	Bearing	1
8	677982	Liner – Split (Set of 2)	1
9	94-5733	Crankshaft	1

Ref. No.	Part No.	Description	No. Used
10	681830	Bearing – Upper Main	1
11	611396	Seal – Oil	2
12	683911	Bearing – Needle	1
13	611393	Screw – Hex. Hd.	2
14	614636	Screw – Hex. Washer Hd.	3
16	602588	Reed – Carburetor	1
17	602587	Reed – Backup Plate	1
18	612872	Screw	2
19	681831	Bearing – Needle	1
20	609629	Dowel	1
21	609123	Plug – Core	4

\*Not Illustrated




C-2130B

## CARBURETOR ASSEMBLY (Model No. 20441 Only)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	92-6376	Air Vane & Shaft	1	13	602850	Gasket	1
2	610165	Retainer - Speed Control	1	14	92-6371	Nozzle	1
3	93-1225	Lever - Speed Adjust	1	15	611071	Filter - Fuel	1
4	610834	Collar - Air Vane	1	16	678113	Float & Arm Assembly	1
5	92-4944	Spring - Governor	1	17	92-6389	Pin	1
6	92-6373	Disc - Throttle	1	18	92-9691	Float Chamber	1
7	92-4949	Bracket - Throttle Control	1	19	608850	Screw	4
8	613269	Screw	2	20	612383	Washer	1
9	93-4324	Carburetor Body	1	21	92-6370	Main Jet	1
10	92-9697	Kit - Float Valve, Body & Seat (Incl. Ref. #12)	1	22	93-4320	Shield - Fuel	1
12	603145	Spring	1	*	92-6385	Jet - High Altitude	1
				*	93-4331	Carburetor Assembly	1

\*Not Illustrated




C-2290

## ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	32144-111	Screw - Phillips Pan Hd.	2
2	93-8470	Screw - Clamp (P/W Eng.) (Model No. 20443 & 20453)	1
3	2210-249	Clamp - Casing (P/W Eng.) (Model No. 20443 & 20453)	1
4		Engine - Quantum 4HP (Model No. 20441 & 20453)	1
5	93-0243	Shroud - Qt Wedge (Model No. 20443 & 20453)	1
6	2210-316	Stop - Rope (P/W Eng.) (Model No. 20443 & 20453)	1
7	93-0247	Decal - Engine (Model No. 20443 & 20453)	1
8	32144-121	Screw (Model No. 20443 & 20453)	2
9	92-2289	Plate - Logo	1
10	82-8550	Shield - Muffler Model No. 20443 & 20453)	1

Ref. No.	Part No.	Description	No. Used
11	32144-73	Screw - Hex Washer Hd. Thread Forming (Model No. 20443 & 20453)	3
12	322-3	Screw - Hex Hd. Cap	4
13	3296-29	Nut - Lock	4
14	93-0217	Kicker - Rear	1
15	93-0223	Baffle - Rear	1
16	62-7540	Retainer - Blade (Model No. 20443 & 20453)	1
17	93-0241	Blade - Steel Deck	1
18	93-0219	Accelerator	1
19	3253-22	Washer - Lock	1
20	26-0670	Bolt - Blade	1
21	93-0218	Kicker - Side	1
22	92-1624	Screw - Engine	3




C-2291

## HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3296-73	Nut - Lock	2
2	93-7383	Guide - Rope	1
3	321-51	Screw - Hex Hd. Cap	1
4	612825	Handle - Starter (Model No. 20441 Only)	1
5	612824	Clip - Rope Insert (Model No. 20441 Only)	1
6	93-0237	Handle - Upper	1
7	92-3134	Bar - Control	1
8	92-5412	Stop - Pivot	1
9	93-0253	Cable - Brake (Model No. 20443 & 20453)	1
10	93-0257	Cable - Brake (Model No. 20441 Only)	1

Ref. No.	Part No.	Description	No. Used
11	93-0252	Cable - Throttle (Model No. 20443 & 20453)	1
12	93-0256	Cable - Throttle (Model No. 20441 Only)	1
13	92-2269	Screw - Handle	1
14	92-2260	Screw - Handle	2
15	19-4050	Knob	2
16	93-0238	Handle - Lower	1
17	3290-378	Tie - Cable (Model No. 20443 & 20453)	1
17	3290-378	Tie - Cable (Model No. 20441 Only)	2




C-2337

## REAR BAGGING ASSEMBLY (Model No. 20453 Only)

Ref. No.	Part No.	Description	No. Used
1	93-0284	Bag - Grass	1
2	93-0281	Frame - Bag Upper	1
3	93-0282	Frame - Bag Lower	1
4	36-6910	Spring	2

Ref. No.	Part No.	Description	No. Used
5	93-0266	Door - Bag	1
6	93-0283	Hinge - Bag Door	1
7	3290-422	Nut - Push	2




## REAR BAGGING ASS'Y (Model No. 20453 Only) (Cont.)

Ref. No.	Part No.	Description	No. Used
1	93-0263	Chute - Discharge	1
2	88-3360	Decal - Caution Door	1
3	93-0273	Discharge Door Assembly	1
4	88-1090	Spring - Door	2
5	93-0267	Plate - Discharge Chute	1
6	46-8090	Screw - Tapping	2

Ref. No.	Part No.	Description	No. Used
7	46-6811	Screw - Washer Hd.	4
8	93-0242	Grommet	4
9	32144-111	Screw - Pan Hd.	1
*	93-0274	Discharge Chute Assembly (Incl. Ref. #1-6)	1

\* Not Illustrated




C-2317

### REAR BAGGING ASS'Y (Model No. 20453 Only) (Cont.)

Ref. No.	Part No.	Description	No. Used
1	93-0264	Door - Discharge	1
2	88-1800	Latch - Door	1
3	33-0450	Spring - Door	1

Ref. No.	Part No.	Description	No. Used
4	33-0441	Cover - Door	1
5	32144-32	Screw - Plastic	2




C-2339

## REAR BAGGING ASS'Y (Model No. 20453 Only) (Cont.)

Ref. No.	Part No.	Description	No. Used
1	93-0279	Shield - Discharge Plug	1
2	93-0280	Cover - Discharge Plug	1
3	32104-122	Screw - Phillips Pan Hd.	3
4	88-6930	Decal - Warning	1

Ref. No.	Part No.	Description	No. Used
5	65-5100	Handle - Hood	1
6	46-8091	Screw - Tapping	2
*	93-0275	Discharge Plug Assembly (Incl. Ref. #1-6)	1

\* Not Illustrated



★ REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL.

1019 LABEL KIT


1058 OWNER'S MANUAL  
Assemblies include all parts shown in frames.

## ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
1	493260	Cylinder Assembly	1
2	293708	Bushing – Cylinder	1
★3	299819	Seal – Oil	1
5	214349	Head – Cylinder	1
★7	272916	Gasket – Cylinder Head	1
8	495786	Breather – Valve Chamber	1
★9	272481	Gasket – Valve Cover	1
★9A	272238	Gasket – Baffle Plate	1
10	94650	Screw – Breather Mtg.	1
11	231933	Tube – Breather	1
13	94547	Screw – Cylinder Head	1
★52	272199	Gasket – Intake Elbow Mounting	1
54	94526	Screw – Intake Elbow	1
227	492349	Lever Assembly – Gov.	1
230	67072	Washer – Gov. Crank	1
284	94511	Screw – Hex. Head	1
306	224324	Shield – Cylinder	1
307	94515	Screw – Hex. Head	1
337	802592	Plug – Spark	1
383	89838	Wrench – Spark Plug	1

Ref. No.	Part No.	Description	No. Used
523	495264	Cap With Dipstick – Oil Filler	1
★524	280393	Seal – Filler Tube	1
525	495265	Tube – Oil Filler	1
562	92613	Bolt – Governor Lever	1
572	224328	Baffle – Cylinder	1
592	231082	Nut – Hex.	1
615	94474	Fastener	1
616	262578	Crank – Governor	1
625	281085	Tube – Fuel Intake	1
635	66538	Elbow – Spark Plug	1
★842	280966	Seal – O-Ring	1
847	495263	Oil Fill Tube Assy.	1
869	213512	Seat – Intake Valve	1
870	213513	Seat – Exhaust Valve	1
871	262001	Guide – Exhaust Valve	1
1019	494256	Label Kit	1
1058	272262	Owner's Manual	1

★ Included in Gasket Set—Part No. 496117.




Assemblies include all parts shown in frames.

## ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
★12	272198	Gasket – Crankcase	1
15	94720	Plug – Oil Drain	1
16	494546	Crankshaft	1
		<b>Note:</b> Order 94388 For Timing Gear Key.	1
18	493279	Sump – Engine	1
★20	399781	Seal – Oil	1
22	94220	Screw – Hex. Head	1
		<b>Note:</b> 94612 Screw – Hex. Head (One (1) Used in Hole Nearest Breather.)	1
24	222698	Key – Flywheel	1
25	493262	Piston Assy. (Standard)	1
	493385	Piston Assy. (.010" O.S.)	1
	493386	Piston Assy. (.020" O.S.)	1
	493387	Piston Assy. (.030" O.S.)	1
26	493261	Ring Set (Standard)	1
	493388	Ring Set (.010" O.S.)	1
	493389	Ring Set (.020" O.S.)	1
	493390	Ring Set (.030" O.S.)	1

Ref. No.	Part No.	Description	No. Used
27	26026	Lock – Piston Pin	1
28	298909	Pin – Piston (Standard)	1
	298908	Pin – Piston (.005" O.S.)	1
29	490566	Rod Assembly – Conn.	1
		<b>Note:</b> For Conn. Rod With .020" Undersize Crankpin Bearing – Order No. 490743.	1
32	94699	Screw – Conn. Rod	1
33	262651	Valve – Exhaust	1
34	262652	Valve – Intake	1
35	262224	Spring – Valve	1
40	93312	Retainer – Valve Spring	1
45	262204	Tappet – Valve	1
46	492828	Gear – Cam	1
47	493737	Slinger – Oil	1
741	262598	Gear – Timing	1

★ Included in Gasket Set—Part No. 496117.



Assemblies include all parts shown in frames.


## ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
95	94098	Screw – Throttle Valve Mounting	1
●104	231371	Pin – Float Hinge	1
●◆116		Gasket–Sealing (Sold in Kit Only).	1
124	94525	Screw – Carburetor Mtg.	1
125	497314	Carburetor Plug – Welch (Sold in Kit Only).	1
●127			1
130	224908	Valve – Throttle	1
131	493267	Shaft – Throttle	1
133	398187	Float Assy. – Carburetor	1

Ref. No.	Part No.	Description	No. Used
●134	398188	Valve – Inlet (Includes Seat)	1
●◆137		Gasket – Bowl (Sold in Kit Only).	1
●◆617	270344	Seal – Fuel Intake Tube	1
●◆634		Washer–Shaft (Sold in Kit Only).	1
955	497315	Screw – Bowl Mtg. (Std.)	1
		<b>Note:</b> 496495 Screw – Bowl Mtg. (High Altitude)	1
975	493640	Bowl Assy. – Carburetor	1

●Included in Carburetor Kit–Part No. 493762.

◆Included in Carburetor Gasket Set–Part No. 490937.





Assemblies include all parts shown in frames.

### ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
188A	94644	Screw - Hex. Head	1
188B	94602	Screw - Hex. Head	1
201	262579	Link - Governor	1
209	262661	Spring - Governor	1
618	262749	Spring - Return	1

Ref. No.	Part No.	Description	No. Used
620	497203	Bracket - Carburetor	1
620A	225152	Bracket - Control	1
621	396847	Switch - Stop	1
670A	493823	Spacer - Bracket	1




Assemblies include all parts shown in frames.

## ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
163	272653	Gasket – Air Cleaner	1
529	281299	Grommet – Breather	1
606	224815	Strap – Bracket	1
966	496116	Base – Air Cleaner	1
967	491588	Filter – Air	1

Ref. No.	Part No.	Description	No. Used
968	281340	Cover – Air Cleaner	1
969	94120	Screw – Cover Mtg.	1
971	94121	Screw – Air Cleaner	1
971A	94749	Screw – Hex. Head	1

\* Included in Gasket Set—Part No. 496117.




Assemblies include all parts shown in frames.

## ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
55	492831	Housing – Rewind Starter	1
56	493824	Pulley – Rewind Starter	1
57	262594	Spring – Rewind Starter	1
58	280399	Rope – Rewind Starter	1
59	396892	Insert – Handle	1
60	393152	Handle – Rewind Starter	1
69	280973	Washer – Rewind Starter	1
69A	224322	Washer – Rewind Starter	1
456	224321	Retainer – Rewind Starter	1

Ref. No.	Part No.	Description	No. Used
459	492833	Pawl – Starter	1
461	262626	Pin – Starter	1
515	262625	Spring – Torsion	1
608	493295	Starter Assy. – Rewind <b>Includes:</b> 94128 Screw – Hex. Hd. 1 92987 Nut – Hex. 1	1
1016	224278	Cover – Rewind Starter	1




Assemblies include all parts shown in frames.

## ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
23	492177	Flywheel	1
37	224511	Guard – Flywheel	1
38	94786	Screw – Hex. Head	1
304	493294	Housing – Blower	1
305	94786	Screw – Sem	1
332	92284	Nut – Flywheel	1

Ref. No.	Part No.	Description	No. Used
333	802574	Armature – Magneto	1
334	94731	Screw – Sem	1
356	398808	Wire – Ground	1
363	19069	Puller – Flywheel	1
455	224250	Cup – Starter	1
851	493880	Terminal – Ignition Cable	1






Assemblies include all parts shown in frames.

## ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
81	223664	Lock - Muffler Screw	1
187	492790	Hose - Fuel	1
188	398540	Screw - Tank Mounting	1
284	94511	Screw - Hex. Head	1
300	490547	Muffler - Exhaust	1
346	93705	Screw - Hex. Head	1
601	93807	Clamp - Hose	1

Ref. No.	Part No.	Description	No. Used
613	94231	Screw - Muffler Mtg.	1
670	280512	Spacer - Fuel Tank	1
676	493871	Deflector - Muffler	1
★883	272253	Gasket - Exhaust	1
957	397974	Cap Assy. - Fuel	1
972	495224	Tank Assembly - Fuel	1



Assemblies include all parts shown in frames.

## ENGINE BRIGGS & STRATTON MODEL 127802-0640-01

Ref. No.	Part No.	Description	No. Used
★3	299819	Seal – Oil	1
★7	272916	Gasket – Cylinder Hd.	1
★9	272481	Gasket – Valve Cover	1
★9A	272238	Gasket – Baffle Plate	1
★12	272198	Gasket – Crankcase	1
★20	399781	Seal – Oil	1
★52	272199	Gasket – Intake Elbow	1
●104	231371	Pin – Float Hinge	1
●◆116		Gasket – Sealing (Sold in Kit Only).	1
121	493762	Carburetor Kit	1
●127		Plug – Welch (Sold in Kit Only).	1

Ref. No.	Part No.	Description	No. Used
●134	398188	Valve – Inlet (Includes Seat)	1
●◆137		Gasket – Bowl (Sold in Kit Only).	1
★163	272653	Gasket – Air Cleaner	1
358	497316	Gasket Set	1
★524	280393	Seal – Filler Tube	1
●◆617	270344	Seal – Fuel Intake Tube	1
●◆634		Washer – Shaft (Sold in Kit Only).	1
★842	280966	Seal – O-Ring	1
★883	272253	Gasket – Exhaust	1
977	490937	Gasket Set – Carburetor	1

● Included in Carburetor Kit—Part No. 493762.

◆ Included in Carburetor Gasket Set—Part No. 490937.

★ Included in Gasket Set—Part No. 496117.

# TORO PART NUMBER INDEX

3318-511

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
130743	Nut	4	19	1	53-4690	Stop - Ground Strap	5	5	1
303712	Ring - Retaining	6	5	2	55-3578	Gas Cap Assembly	3	6	1
316959	Washer - Lock	4	18	1	60-9010	Strap - Ground	5	2	1
602587	Reed - Backup Plate	6	17	1	62-7540	Retainer - Blade	8	16	1
602588	Reed - Carburetor	6	16	1	65-5100	Handle - Hood	13	5	1
602850	Gasket	7	13	1	66-5370	Spring - Compression	3	15	1
603145	Spring	7	12	1	66-7460	Bulb - Primer	4	22	1
606608	Pin - Wrist	6	4	1	68-3632	Line - Fuel	3	8	1
607199	Key	4	13	1	82-8550	Shield - Muffler	8	10	1
607601	Screw	5	8	4	84-7820	Plate - Brake Mount	5	15	1
608850	Screw	7	19	4	85-7060	Decal - Danger	1	4	1
609123	Plug - Core	6	21	4	88-1090	Spring - Door	11	4	2
609471	Screw	5	10	3	88-1800	Latch - Door	12	2	1
609482	Screw	4	9	2	88-3360	Decal - Caution Door	11	2	1
609493	Element - Air Filter	4	3	1	88-6930	Decal - Warning	13	4	1
609629	Dowel	6	20	1	92-1005	Spring Arm Assembly	1	11	2
610165	Retainer - Speed Control	7	2	1	92-1008	Knob - Height Adjust	1	16	4
610834	Collar - Air Vane	7	4	1	92-1156	Wire - Brake Switch Lead	5	6	1
611071	Filter - Fuel	7	15	1	92-1624	Screw - Engine	8	22	3
611393	Screw - Hex. Hd.	6	13	2	92-1701	Rope - Stop	3	5	1
611396	Seal - Oil	6	11	2	92-2260	Screw - Handle	9	14	2
612383	Washer	7	20	1	92-2269	Screw - Handle	9	13	1
612824	Clip - Rope Insert	9	5	1	92-2289	Plate - Logo	8	9	1
612825	Handle - Starter	9	4	1	92-2914	Decal - HOC R.H.	1	9	1
612872	Screw	6	18	2	92-2915	Decal - HOC L.H.	1	8	1
613208	Screw - Hex Washer Hd.	5	16	2	92-2925	Strap - Insulation	5	3	1
613269	Screw	7	8	2	92-3134	Bar - Control	9	7	1
614009	Plug - Spark	5	13	1	92-4881	Plate - Height Adjust	2	26	2
614636	Screw - Hex. Washer Hd.	6	14	3	92-4890	Washer	1	21	4
614637	Bracket - Wheel Height Adj.	1	20	4	92-4921	Connecting Rod Assembly	6	6	1
614640	Hub - Starter	4	17	1	92-4923	Piston & Ring Set	6	3	1
614650	Bolt - Shoulder	1	13	4	92-4925	Piston & Connecting Rod	6	*	1
614654	Plate - Muffler	5	7	1	92-4927	Bearing	6	7	1
614672	Bolt - Shoulder	1	18	4	92-4944	Spring - Governor	7	5	1
614681	Baffle	5	9	1	92-4948	Gasket - Carburetor	4	7	2
614687	Spring Arm Assembly	1	17	2	92-4949	Bracket - Throttle Control	7	7	1
614699	Screw	4	1	3	92-5412	Stop - Pivot	9	8	1
614702	Screw	4	14	4	92-6370	Main Jet	7	21	1
614702	Screw	5	17	1	92-6371	Nozzle	7	14	1
677982	Liner - Split (Set of 2)	6	8	1	92-6373	Disc - Throttle	7	6	1
678113	Float & Arm Assembly	7	16	1	92-6376	Air Vane & Shaft	7	1	1
681678	Lead & Cover Assembly	5	20	1	92-6385	Jet - High Altitude	7	*	1
681737	Set - Rings, Piston	6	1	1	92-6389	Pin	7	17	1
681830	Bearing - Upper Main	6	10	1	92-6396	Shroud - Engine	3	1	1
681831	Bearing - Needle	6	19	1	92-8647	Shield - Trailing	1	14	1
683911	Bearing - Needle	6	12	1	92-9591	Wheel Assembly	1	19	2
684049	Ignition Assembly	5	14	1	92-9592	Wheel Assembly	1	12	2
684743	Flywheel Assembly	4	16	1	92-9691	Float Chamber	7	18	1
12-5450	Screw - Thread Forming	5	4	1	92-9697	Kit - Float Valve, Body	7	10	1
16-9259	Deck Assembly	2	27	1	92-9698	Screw - Shoulder	5	19	1
16-9269	Cover - Recycling	1	1	1	93-0216	Kicker - Front	1	25	1
19-4050	Knob	9	15	2	93-0217	Kicker - Rear	8	14	1
26-0670	Bolt - Blade	8	20	1	93-0218	Kicker - Side	8	21	1
33-0441	Cover - Door	12	4	1	93-0219	Accelerator	8	18	1
33-0450	Spring - Door	12	3	1	93-0222	Baffle - Front	1	24	1
36-6910	Spring	10	4	2	93-0223	Baffle - Rear	8	15	1
39-5770	Decal - Danger	3	14	1	93-0231	Screw - Plastite	1	23	2
40-1940	Washer	1	15	4	93-0235	Bracket - Handle L.H.	1	10	1
44-2750	Body - Primer	4	21	1	93-0236	Bracket - Handle R.H.	1	5	1
44-3172	Hose - Primer	4	5	1	93-0237	Handle - Upper	9	6	1
46-6811	Screw - Washer Hd.	11	7	4	93-0238	Handle - Lower	9	16	1
46-8090	Screw - Tapping	11	6	2	93-0241	Blade - Steel Deck	8	17	1
46-8091	Screw - Tapping	13	6	2	93-0242	Grommet	1	2	4
52-7320	Retainer - Blade	3	12	1	93-0242	Grommet	11	8	4

\*Not Illustrated

# TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
93-0243	Shroud – Qt Wedge	8 5 1	93-4331	Carburetor Assembly	4 10 1
93-0245	Decal – Deck	3 13 1	93-4331	Carburetor Assembly	7 * 1
93-0246	Decal – Engine	3 3 1	93-7383	Guide – Rope	9 2 1
93-0247	Decal – Engine	8 7 1	93-8470	Screw – Clamp (P/W Eng.)	8 2 1
93-0248	Decal – Warning	1 7 1	94-5731	Short Block Assembly	4 12 1
93-0252	Cable – Throttle	9 11 1	94-5733	Crankshaft	6 9 1
93-0253	Cable – Brake	9 9 1	2210-249	Clamp – Casing (P/W Eng.)	8 3 1
93-0256	Cable – Throttle	9 12 1	2210-316	Stop – Rope (P/W Eng.)	8 6 1
93-0257	Cable – Brake	9 10 1	321-51	Screw – Hex Hd. Cap	9 3 1
93-0262	Decal – Warning	1 6 1	322-3	Screw – Hex Hd. Cap	8 12 4
93-0263	Chute – Discharge	11 1 1	3253-22	Washer – Lock	8 19 1
93-0264	Door – Discharge	12 1 1	3290-378	Tie – Cable	9 17 1
93-0266	Door – Bag	10 5 1	3290-378	Tie – Cable	9 17 2
93-0267	Plate – Discharge Chute	11 5 1	3290-422	Nut – Push	10 7 2
93-0273	Discharge Door Assembly	11 3 1	3290-459	Rivet	5 1 2
93-0274	Discharge Chute Assembly	11 * 1	3296-2	Nut – Lock	2 28 1
93-0275	Discharge Plug Assembly	13 * 1	3296-29	Nut – Lock	8 13 4
93-0279	Shield – Discharge Plug	13 1 1	3296-39	Nut – Lock	1 22 4
93-0280	Cover – Discharge Plug	13 2 1	3296-73	Nut – Lock	9 1 2
93-0281	Frame – Bag Upper	10 2 1	32104-118	Screw – Phillips Hd.	3 7 2
93-0282	Frame – Bag Lower	10 3 1	32104-122	Screw – Phillips Pan Hd.	13 3 3
93-0283	Hinge – Bag Door	10 6 1	32105-27	Screw – Hex Washer Hd.	2 29 1
93-0284	Bag – Grass	10 1 1	32144-4	Screw – Tapping	1 3 4
93-1108	Cover – Muffler	5 11 1	32144-32	Screw – Plastic	12 5 2
93-1200	Cover – Strap	3 4 1	32144-73	Screw – Hex Washer Hd.	8 11 3
93-1216	Base – Shroud	4 15 1	32144-111	Screw – Pan Hd.	11 9 1
93-1225	Lever – Speed Adjust	7 3 1	32144-111	Screw – Phillips Pan Hd.	8 1 2
93-1227	Shield – Carburetor	4 6 1	32144-121	Screw	8 8 2
93-1231	Cover – Air Filter	4 2 1			
93-1233	Gasket – Exhaust	5 12 1			
93-1248	Shroud	4 20 1			
93-4302	Screw – Sems	3 2 3			
93-4304	Rope	4 23 1			
93-4306	Spring – Compression	5 21 1			
93-4312	Plate – Brake Assembly	5 18 1			
93-4320	Plug	4 4 1			
93-4320	Shield – Fuel	7 22 1			
93-4324	Carburetor Body	7 9 1			

## OPTIONAL EQUIPMENT

Recycler Side Discharge Kit . . . . Model No. 59291

Recycler Bagging Kit

(Model No. 20441 & 20443 Only)

(Std. Model No. 20453) . . . . . Model No. 59290