

LAWN-BOY®

21" SIDE DISCHARGE WALK-BEHIND MOWER

MODEL NO. 11001B—6900001 & UP

PARTS CATALOG

PRODUCT CHANGES

In an effort to make improvements available to LAWN-BOY owners as quickly as possible, minor changes are incorporated into LAWN-BOY products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your Parts Catalog, see your LAWN-BOY Distributor or his Authorized LAWN-BOY Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Product two identification numbers; a model number and a serial number. The two numbers are stamped on a plate mounted on the deck. In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized Service Dealer, supply the following information:

1. Model and serial number.
2. Part number, description, and the quantity of part(s) desired.


NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
Housing Assembly	1	Engine Assembly	7-8
Gearcase & Wheel Assembly	2	Carburetor Assembly	9
Gear Case Assembly	3	Air Filter Assembly	10
Engine Assembly	4	Numeric Parts Index	11-13
Handle Assembly	5	Maintenance	14
Starter Assembly	6		

Accessories


Description	Model / Parts No.	Description	Model / Parts No.
Side Bagging Kit	Model No. 89814	Leaf Bag w/Chute	Model No. 89811
Rear Bagging Kit	Model No. 89800	Mulch Plate	Model No. 89864
Leaf Bag	Model No. 89804		



C-2512

HOUSING ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	92-7869	Gear Case Assembly	1	19	614637	Bracket - Wheel Height Adj.	2
2	256-251	Bushing - Spacer	2	20	3290-413	Washer - Belleville	2
3	92-7699	Bracket - Actuator	1	21	92-9673	Bolt - Shoulder	2
4	92-7748	Screw	2	22	49-2040	Screw - Hex Hd. Cap	1
5	32144-112	Screw - Thr'd Form	2	24	614677	Screw - Sems Thr'd Form	2
6	92-8852	Cover - Drive	1	25	94-1610	Decal	1
7	94-9438	Housing (Incl. Ref. #10, & 15)	1	26	94-6302	Decal	1
9	607560	Plate - Cover	1	27	40-1940	Washer	2
10	93-7009	Decal - Danger	2	28	92-4856	Bolt - Shoulder	2
11	608175	Toe Bar	1	29	92-8888	Wheel & Tire Assembly - 6"	2
12	46-6811	Screw - Hex Washer Hd.	2	30	603567	Bolt - Wheel	2
14	92-7736	Shield - Trailing	1	31	92-1006	Spring Arm Ass'y - Front	2
15	93-4105	Decal - Warning	1	32	92-1008	Knob - Height Adjust	4
16	32105-15	Screw - Hex Hd. Cap	1	33	610358	Nut - Lock	2
17	3296-39	Nut - Lock	2	34	93-7415	Guard - Plate	1
18	40-1940	Washer	4	35	3296-42	Nut - Lock	2




C-2509

GEARCASE & WHEEL ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92-1057	Bolt – Shoulder	2
2	92-8813	Wheel & Tire Ass'y – 8"	2
3	65-2720	Ring – Retaining	4
4	65-4740	Washer – Thrust Keyed	4
5	66-6050	Key – Rocking L.H.	1
*	66-6040	Key – Rocking R.H.	1
7	65-4710	Ring – Friction	2
8	92-7746	Height Adj. Arm Ass'y – Rear	2
9	32144-70	Screw – Tapping	1
10	60-8821	Lever – Shift	1
11	3272-10	Pin – Cotter	1
12	82-8780	Retainer – Cable	1
13	24-7920	Cover – Drive Shaft	1
14	303259	Washer	1

Ref. No.	Part No.	Description	No. Used
15	605255	Washer – Flat	1
17	92-6535	Cap – End	2
18	32144-85	Screw – Hex Hd. Cap	2
19	92-6540	Spring Arm Ass'y – Rear L.H.	1
*	92-6539	Spring Arm Ass'y – Rear R.H.	1
21	610358	Nut – Lock	2
22	65-4730	Washer – Thrust	2
23	65-4760	Washer	2
24	65-4750	Gear – Pinion	2
25	65-4720	Spring – Compression	2
26	94-1609	Cover – Wheel	2
27	614426	Washer – Stepped	2
28	92-1043	V-Belt	1

*Not Illustrated




C-1322

GEAR CASE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	3285-19	Pin - Groove	1	17	36-4780	Washer	1
2	38-7820	Bearing - Ball	1	18	60-8770	Bushing - Output	1
3	60-8850	Bushing - Output	1	19	60-8750	Bushing - Inter. Shaft	2
4	65-4770	Shaft - Output	1	20	36-4791	Washer - Thrust	2
5	92-5791	Spacer	1	21	49-2040	Screw	6
6	60-8840	Pulley - Half	2	22	60-8730	Gear Case Cover	1
7	3296-5	Nut	1	23	55-3760	Pinion - 15 Tooth	1
8	3256-24	Washer	1	24	55-3780	Pinion - 20 Tooth	1
9	60-8710	Gearcase - Upper	1	25	55-3800	Pinion - 25 Tooth	1
10	60-8870	Yoke - Shift	1	26	60-8800	Shaft - Intermediate	1
11	29-9570	Bushing - Yoke	1	27	92-5790	Pinion - Bevel	1
12	60-8810	Retainer - Shift Fork	1	28	55-3770	Gear - 49 Tooth	1
13	76-0780	Sleeve - Shift Key	1	29	55-3790	Gear - 44 Tooth	1
14	76-0760	Key - Shift	2	30	55-3810	Gear - 39 Tooth	1
15	76-0770	Collar - Shift	1	31	60-8790	Sleeve - Gear	1
16	65-5250	Clip - Spring	1	*	92-7869	Gear Case Complete	1

*Not Illustrated




C-2513A

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	603164	Nut – Blade	1
2	677525	Plate & Collar Assembly	1
3	92-1648	Screw – Engine Mount	3
4	612784	Hose – Gas	1
5	609976	Pulley	1
6	610345	Screw – Set	1
7	47-2480	Rope – Stop	1
†8		Staple	1
10	32144-3	Screw – Hex Washer Hd.	2
11	684622	Housing – Starter	1
12	683638	Shroud Assembly	1
13	611214	Spring	1
14	611509	Actuator – Brake Lever	1
15	611213	Retainer	1
16	612543	Blade – 21"	1
17	94-1618	Guard – Engine	1
18	3296-29	Nut – Lock	3
20	611327	Cap – Fuel	1
21	609150	Foam – Baffle	1
22	607213	Gasket	1
23	145476	Tank – Fuel	1
24	94-4252	Leg & Saddle Assembly	1

Ref. No.	Part No.	Description	No. Used
25	312387	Clamp – Hose	1
26	677052	Valve & Screen	1
27	609830	Spring	2
28	612428	Screw – Sems	4
29	32144-53	Screw – Thr'd Form	4
30	92-8830	Decal – Recoil	1
31		Engine – 2 Cycle	1
32	3229-2	Screw – Carriage	1
36	602315	Nut – Lock	1
37	612754	Applique	1
38	614249	Tie – Strap	1
39	2410-77	Plug – Fuel Valve	1
40	2410-76	Plug – Fuel Line	1
41	93-7153	Plate – Engine	1
42	3256-1	Washer – Flat	1
43	145945	Retainer – Applique	3
44	93-1233	Gasket – Muffler	1
45	92-1054	Plate – Muffler	1
46	682876	Muffler Cover Assembly	1
47	609786	Support – Crankshaft	1
48	609471	Screw	3


† Obtain Locally



C-2514

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	3230-29	Bolt - Carriage	2	23	92-1093	Bail - Engine Control	1
2	94-9440	Handle - Section Lower (Incl. Ref. #25)	1	24	94-6300	Decal - Console Front	1
3	614249	Tie Strap	2	25	93-7266	Decal - Operation	1
5	322-9	Screw - Hex Hd.	2	26	93-3248	Cable - Control	1
6	3296-29	Nut - Lock	4	27	612824	Clip - Rope Insert	1
7	92-9665	Screw - Phillips Hd.	4	28	612825	Handle - Starter	1
8	92-1078	Cam - Brake	1	29	93-7383	Guide - Rope	1
9	92-1094	Bracket - Bail Stop	1	30	92-2268	Screw - Handle	1
12	92-5412	Stop - Pivot	1	31	92-2928	Bracket - Cable Anchor	1
13	92-1617	Bail - SP Control	1	32	3296-73	Nut - Lock	4
14	321-4	Screw - Hex Hd. Cap	1	33	92-1092	Handle - Upper	1
15	613050	Bolt	1	35	609739	Washer	2
16	93-3683	Cable - Throttle	1	36	92-7899	Bracket - Traction Cable	1
18	94-6301	Decal - Control Panel	1	37	92-6518	Cable - Traction	1
20	92-8926	Control - Speed Ground	1	46	321-51	Screw - Hex Hd. Cap	1
21	94-9439	Panel - Control (Incl. Ref. #18, & 24)	1	49	3296-56	Nut - Lock	1
				51	3256-24	Washer - Flat	2



C-1406


STARTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92-8830	Decal	1
2	612949	Hub - Starter	1
3	612825	Handle - Starter	1
4	612824	Insert - Clip, Rope	1
5	684567	Housing - Starter	1
6	92-4935	Recoil Spring & Keeper	1

Ref. No.	Part No.	Description	No. Used
7	612950	Pulley	1
8	612432	Rope	1
9	683899	Assembly - Dog Kit	1
*	612428	Screw-Sems	4
*	684622	Assembly - Starter (Inc. Ref. No. 5-9)	1

*Not Illustrated

ENGINE ASSEMBLY




ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	611213	Retainer	1
2	611509	Actuator – Brake Lever	1
3	611214	Spring – Cable, Return	1
4	93-1240	Case – Switch	1
5	682683	Assembly – Brake	1
6	683821	Wire Lead	1
7	613529	Bolt – Shoulder	1
8	608311	Nut	1
9	683581	Assembly – Brace	1
10	603014	Bolt	1
11	306407	Washer	1
12	602315	Nut	1
13	612427	Shroud – Base	1
14	611191	Clip – "J"	1
15	609947	Screw	3
16	683580	Assembly – Flywheel	1
17	316959	Washer – Lock	1
18	130743	Nut – Flywheel	1
19	609808	Screw	1
20	317893	Tie Strap	1
21	681737	Set – Ring	1
22	303712	Ring – Retaining	2
23	606608	Pin – Wrist	1
24	92-4925	Set – Piston & Ring (Incl. Ref. # 21-23)	1
25	92-4927	Assembly – Bearing	1
26	92-4921	Assembly – Conn. Rod (Incl. Ref. #25, 27, 32, & 33)	1
27	677982	Liner – Pair	1
28	607199	Key – Flywheel	1
29	611396	Seal – Oil	2
30	681830	Bearing – Main	1
31	94-5713	Crankshaft	1
32	611393	Screw	2
33	609754	Strip – Roller	1

Ref. No.	Part No.	Description	No. Used
34	607526	Screw	2
35	614009	Spark Plug	1
37	681678	Wire Lead	1
38	683215	C. D. Ignition Module (Incl. Ref. #37)	1
39	605120	Grommet	1
40	614249	Tie Strap	1
41	613072	Bracket – C. D.	1
42	614343	Screw	2
44	609123	Plug	4
46	612872	Screw	2
47	602587	Plate – Reed	1
48	602588	Reed	1
49	681831	Bearing – Main	1
51	613110	Screw	2
52	611192	Bracket – Brake	1
53	613233	Screw	2
54	611211	Spring – Brake	1
55	93-1239	Spring	1
56	306407	Washer	2
57	321-6	Screw – Hex Hd. Cap	1
59	612842	Shield	1
60	612841	Plate – Contact	1
61	3255-7	Washer – Lock	1
62	306375	Nut	1
*	94-5734	Assembly – Short Block (Incl. Ref. No.21-27, 29-33, & 43-51)	1
63	3229-22	Bolt – Carriage	1
64	252-76	Bearing – Thrust	1
65	252-80	Washer – Thrust	1
66	609900	Nut – Speed	1
*	93-4307	Switch Kit (Incl. Ref. #1, 4, 6, 55, 57, & 59-62)	1

*Not Illustrated




C-2182C

CARBURETOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	610834	Collar — Adjustment	1	15	612383	Washer	1
2	610165	Retainer	1	16	678113	Float & Arm Assembly	1
3	93-1225	Lever — Speed Adjust	1	17	92-6389	Pin	1
4	611545	Plug	1	18	603145	Clip	1
5	609482	Screw — Pan Hd. Sems	2	19	92-9697	Float, Valve, & Body Ass'y	1
6	613269	Screw	4	21	92-4944	Spring — Governor	1
7	94-4341	Body — Carburetor	1	22	93-1226	Bracket — Throttle Control	1
8	93-1232	Bracket — Primer	1	23	94-5701	Disc — Throttle	1
9	602850	Gasket — Float Chamber	1	24	92-6376	Air Vane & Shaft	1
10	608850	Screw	4	25	66-7460	Bulb — Primer	1
11	92-9691	Float Chamber	1	26	44-2750	Body — Primer	1
12	611071	Filter — Fuel	1	27	44-3172	Hose — Primer	1
13	94-5710	Main Jet	1	*	94-5738	Carburetor Complete	1
14	92-6371	Nozzle	1				

*Not Illustrated



C-2184A

AIR FILTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	610383	Retainer – Cover	1
2	93-1231	Cover – Air Filter	1
3	609493	Element – Air Filter	1

Ref. No.	Part No.	Description	No. Used
4	93-1221	Shield – Heat	1
5	92-4948	Gasket – Carb.	2

LAWN-BOY PART NUMBER INDEX

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
130743	Nut – Flywheel	8 18 1	612427	Shroud – Base	8 13 1
145476	Tank – Fuel	4 23 1	612428	Screw – Sems	4 28 4
145945	Retainer – Applique	4 43 3	612428	Screw–Sems	6 * 4
303259	Washer	2 14 1	612432	Rope	6 8 1
303712	Ring – Retaining	8 22 2	612543	Blade – 21	4 16 1
306375	Nut	8 62 1	612754	Applique	4 37 1
306407	Washer	8 11 1	612784	Hose – Gas	4 4 1
306407	Washer	8 56 2	612824	Clip – Rope Insert	5 27 1
312387	Clamp – Hose	4 25 1	612824	Insert – Clip, Rope	6 4 1
316959	Washer – Lock	8 17 1	612825	Handle – Starter	5 28 1
317893	Tie Strap	8 20 1	612825	Handle – Starter	6 3 1
602315	Nut	8 12 1	612841	Plate – Contact	8 60 1
602315	Nut – Lock	4 36 1	612842	Shield	8 59 1
602587	Plate – Reed	8 47 1	612872	Screw	8 46 2
602588	Reed	8 48 1	612949	Hub – Starter	6 2 1
602850	Gasket – Float Chamber	9 9 1	612950	Pulley	6 7 1
603014	Bolt	8 10 1	613050	Bolt	5 15 1
603145	Clip	9 18 1	613072	Bracket – C. D.	8 41 1
603164	Nut – Blade	4 1 1	613110	Screw	8 51 2
603567	Bolt – Wheel	1 30 2	613233	Screw	8 53 2
605120	Grommet	8 39 1	613269	Screw	9 6 4
605255	Washer – Flat	2 15 1	613529	Bolt – Shoulder	8 7 1
606608	Pin – Wrist	8 23 1	614009	Spark Plug	8 35 1
607199	Key – Flywheel	8 28 1	614249	Tie – Strap	4 38 1
607213	Gasket	4 22 1	614249	Tie Strap	5 3 2
607526	Screw	8 34 2	614249	Tie Strap	8 40 1
607560	Plate – Cover	1 9 1	614343	Screw	8 42 2
608175	Toe Bar	1 11 1	614426	Washer – Stepped	2 27 2
608311	Nut	8 8 1	614637	Bracket – Wheel Height Adj.	1 19 2
608850	Screw	9 10 4	614677	Screw – Sems Thr'd Form	1 24 2
609123	Plug	8 44 4	677052	Valve & Screen	4 26 1
609150	Foam – Baffle	4 21 1	677525	Plate & Collar Assembly	4 2 1
609471	Screw	4 48 3	677982	Liner – Pair	8 27 1
609482	Screw – Pan Hd. Sems	9 5 2	678113	Float & Arm Assembly	9 16 1
609493	Element – Air Filter	10 3 1	681678	Wire Lead	8 37 1
609739	Washer	5 35 2	681737	Set – Ring	8 21 1
609754	Strip – Roller	8 33 1	681830	Bearing – Main	8 30 1
609786	Support – Crankshaft	4 47 1	681831	Bearing – Main	8 49 1
609808	Screw	8 19 1	682683	Assembly – Brake	8 5 1
609830	Spring	4 27 2	682876	Muffler Cover Assembly	4 46 1
609900	Nut – Speed	8 66 1	683215	C. D. Ignition Module	8 38 1
609947	Screw	8 15 3	683580	Assembly – Flywheel	8 16 1
609976	Pulley	4 5 1	683581	Assembly – Brace	8 9 1
610165	Retainer	9 2 1	683638	Shroud Assembly	4 12 1
610345	Screw – Set	4 6 1	683821	Wire Lead	8 6 1
610358	Nut – Lock	2 21 2	683899	Assembly – Dog Kit	6 9 1
610358	Nut – Lock	1 33 2	684567	Housing – Starter	6 5 1
610383	Retainer – Cover	10 1 1	684622	Assembly – Starter	6 * 1
610834	Collar – Adjustment	9 1 1	684622	Housing – Starter	4 11 1
611071	Filter – Fuel	9 12 1	24-7920	Cover – Drive Shaft	2 13 1
611191	Clip – J	8 14 1	29-9570	Bushing – Yoke	3 11 1
611192	Bracket – Brake	8 52 1	36-4780	Washer	3 17 1
611211	Spring – Brake	8 54 1	36-4791	Washer – Thrust	3 20 2
611213	Retainer	8 1 1	38-7820	Bearing – Ball	3 2 1
611213	Retainer	4 15 1	40-1940	Washer	1 18 4
611214	Spring	4 13 1	40-1940	Washer	1 27 2
611214	Spring – Cable, Return	8 3 1	44-2750	Body – Primer	9 26 1
611327	Cap – Fuel	4 20 1	44-3172	Hose – Primer	9 27 1
611393	Screw	8 32 2	46-6811	Screw – Hex Washer Hd.	1 12 2
611396	Seal – Oil	8 29 2	47-2480	Rope – Stop	4 7 1
611509	Actuator – Brake Lever	8 2 1	49-2040	Screw	3 21 6
611509	Actuator – Brake Lever	4 14 1	49-2040	Screw – Hex Hd. Cap	1 22 1
611545	Plug	9 4 2	55-3760	Pinion – 15 Tooth	3 23 1
612383	Washer	9 15 1	55-3770	Gear – 49 Tooth	3 28 1

*Not Illustrated

LAWN—BOY PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
55-3780	Pinion - 20 Tooth	3 24 1	92-7748	Screw	1 4 2
55-3790	Gear - 44 Tooth	3 29 1	92-7869	Gear Case Assembly	1 1 1
55-3800	Pinion - 25 Tooth	3 25 1	92-7869	Gear Case Complete	3 * 1
55-3810	Gear - 39 Tooth	3 30 1	92-7899	Bracket - Traction Cable	5 36 1
60-8710	Gearcase - Upper	3 9 1	92-8813	Wheel & Tire Ass'y - 8	2 2 2
60-8730	Gear Case Cover	3 22 1	92-8830	Decal	6 1 1
60-8750	Bushing - Inter. Shaft	3 19 2	92-8830	Decal - Recoil	4 30 1
60-8770	Bushing - Output	3 18 1	92-8852	Cover - Drive	1 6 1
60-8790	Sleeve - Gear	3 31 1	92-8888	Wheel & Tire Assembly - 6	1 29 2
60-8800	Shaft - Intermediate	3 26 1	92-8926	Control - Speed Ground	5 20 1
60-8810	Retainer - Shift Fork	3 12 1	92-9665	Screw - Phillips Hd.	5 7 4
60-8821	Lever - Shift	2 10 1	92-9673	Bolt - Shoulder	1 21 2
60-8840	Pulley - Half	3 6 2	92-9691	Float Chamber	9 11 1
60-8850	Bushing - Output	3 3 1	92-9697	Float, Valve, & Body Ass'y	9 19 1
60-8870	Yoke - Shift	3 10 1	93-1221	Shield - Heat	10 4 1
65-2720	Ring - Retaining	2 3 4	93-1225	Lever - Speed Adjust	9 3 1
65-4710	Ring - Friction	2 7 2	93-1226	Bracket - Throttle Control	9 22 1
65-4720	Spring - Compression	2 25 2	93-1231	Cover - Air Filter	10 2 1
65-4730	Washer - Thrust	2 22 2	93-1232	Bracket - Primer	9 8 1
65-4740	Washer - Thrust Keyed	2 4 4	93-1233	Gasket - Muffler	4 44 1
65-4750	Gear - Pinion	2 24 2	93-1239	Spring	8 55 1
65-4760	Washer	2 23 2	93-1240	Case - Switch	8 4 1
65-4770	Shaft - Output	3 4 1	93-3248	Cable - Control	5 26 1
65-5250	Clip - Spring	3 16 1	93-3683	Cable - Throttle	5 16 1
66-6040	Key - Rocking R.H.	2 * 1	93-4105	Decal - Warning	1 15 1
66-6050	Key - Rocking L.H.	2 5 1	93-4307	Switch Kit	8 * 1
66-7460	Bulb - Primer	9 25 1	93-7009	Decal - Danger	1 10 2
76-0760	Key - Shift	3 14 2	93-7153	Plate - Engine	4 41 1
76-0770	Collar - Shift	3 15 1	93-7266	Decal - Operation	5 25 1
76-0780	Sleeve - Shift Key	3 13 1	93-7383	Guide - Rope	5 29 1
82-8780	Retainer - Cable	2 12 1	93-7415	Guard - Plate	1 34 1
92-1006	Spring Arm Ass'y - Front	1 31 2	94-1609	Cover - Wheel	2 26 2
92-1008	Knob - Height Adjust	1 32 4	94-1610	Decal	1 25 1
92-1043	V-Belt	2 28 1	94-1618	Guard - Engine	4 17 1
92-1054	Plate - Muffler	4 45 1	94-4252	Leg & Saddle Assembly	4 24 1
92-1057	Bolt - Shoulder	2 1 2	94-4341	Body - Carburetor	9 7 1
92-1078	Cam - Brake	5 8 1	94-5701	Disc - Throttle	9 23 1
92-1092	Handle - Upper	5 33 1	94-5710	Main Jet	9 13 1
92-1093	Bail - Engine Control	5 23 1	94-5713	Crankshaft	8 31 1
92-1094	Bracket - Bail Stop	5 9 1	94-5734	Assembly - Short Block	8 * 1
92-1617	Bail - SP Control	5 13 1	94-5738	Carburetor Complete	9 * 1
92-1648	Screw - Engine Mount	4 3 3	94-6300	Decal - Console Front	5 24 1
92-2268	Screw - Handle	5 30 1	94-6301	Decal - Control Panel	5 18 1
92-2928	Bracket - Cable Anchor	5 31 1	94-6302	Decal	1 26 1
92-4856	Bolt - Shoulder	1 28 2	94-9438	Housing	1 7 1
92-4921	Assembly - Conn. Rod	8 26 1	94-9439	Panel - Control	5 21 1
92-4925	Set - Piston & Ring	8 24 1	94-9440	Handle - Section Lower	5 2 1
92-4927	Assembly - Bearing	8 25 1	2410-76	Plug - Fuel Line	4 40 1
92-4935	Recoil Spring & Keeper	6 6 1	2410-77	Plug - Fuel Valve	4 39 1
92-4944	Spring - Governor	9 21 1	252-76	Bearing - Thrust	8 64 1
92-4948	Gasket - Carb.	10 5 2	252-80	Washer - Thrust	8 65 1
92-5412	Stop - Pivot	5 12 1	256-251	Bushing - Spacer	1 2 2
92-5790	Pinion - Bevel	3 27 1	321-4	Screw - Hex Hd. Cap	5 14 1
92-5791	Spacer	3 5 1	321-6	Screw - Hex Hd. Cap	8 57 1
92-6371	Nozzle	9 14 1	321-51	Screw - Hex Hd. Cap	5 46 1
92-6376	Air Vane & Shaft	9 24 1	322-9	Screw - Hex Hd.	5 5 2
92-6389	Pin	9 17 1	3229-2	Screw - Carriage	4 32 1
92-6518	Cable - Traction	5 37 1	3229-22	Bolt - Carriage	8 63 1
92-6535	Cap - End	2 17 2	3230-29	Bolt - Carriage	5 1 2
92-6539	Spring Arm Ass'y -	2 * 1	3255-7	Washer - Lock	8 61 1
92-6540	Spring Arm Ass'y -	2 19 1	3256-1	Washer - Flat	4 42 1
92-7699	Bracket - Actuator	1 3 1	3256-24	Washer	3 8 1
92-7736	Shield - Trailing	1 14 1	3256-24	Washer - Flat	5 51 2
92-7746	Height Adj. Arm Ass'y -	2 8 2	3272-10	Pin - Cotter	2 11 1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
3285-19	Pin - Groove	3 1 1	3296-73	Nut - Lock	5 32 4
3290-413	Washer - Belleville	1 20 2	32105-15	Screw - Hex Hd. Cap	1 16 1
3296-5	Nut	3 7 1	32144-3	Screw - Hex Washer Hd.	4 10 2
3296-29	Nut - Lock	5 6 4	32144-53	Screw - Thr'd Form	4 29 4
3296-29	Nut - Lock	4 18 3	32144-70	Screw - Tapping	2 9 1
3296-39	Nut - Lock	1 17 2	32144-85	Screw - Hex Hd. Cap	2 18 2
3296-42	Nut - Lock	1 35 2	32144-112	Screw - Thr'd Form	1 5 2
3296-56	Nut - Lock	5 49 1			

MAINTENANCE RECORD

[illegible]