



Count on it.

Form No. 3365-875 Rev A

Parts Catalog

Electric Hose Reel Kit

Multi-Pro® 5800 Turf Sprayer

Model No. 41613—Serial No. 311000001 and Up

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquid Propane

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head


Contents

Electric Hose Reel Kit 4

Hose Reel Assembly No. 106-5083 6

Hose Reel Frame Assembly No. 104-8714 7


Spray Gun Assembly No. 100-6733 8



Electric Hose Reel Kit

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1		1	Valve ASM ●	15	100-1535	1	Switch
1:1	117-7969	1	Valve (W/O Bypass)	16	100-8490	1	Switch-Dpdt
1:2	119-4862	1	Fork	17	99-7430	1	Relay
1:3	119-0464	1	Hosebarb	18	99-7435	1	Relay-Power
1:4	119-4868	1	O-Ring	19	3290-378	1	Tie-Cable
2	119-0472	1	Bracket Mounting Kit	20	2412-129	2	Clamp-Hose
2:1	119-4880	4	Screw-HH	21	2412-36	1	Clamp-Hose
2:2	119-4870	1	O-Ring	22	3234-11	10	Screw-HHF
3	119-0563-03	2	Strap-Hose Reel	23	32128-43	10	Nut-Flange
4	106-5083	1	Hose Reel ASM	24	3234-5	2	Screw-HHF
5	106-1233-03	1	Hand Spray Mounting ASM	25	32128-20	2	Nut-HF
6	100-6733	1	Sprayer-Handheld	26	3234-26	4	Screw-HHF
7	110-5065	1	Hosebarb	27	3234-33	3	Screw-HHF
9	119-0487-03	1	Mount-Control	28	32128-33	3	Nut-HF
10	119-0485	1	Enclosure ASM-Control	29	119-4878	1	Decal-Hose Reel
11	119-0491	1	Hose-Supply	30	107-8757	1	Decal-Reel, Hose
12	112-3324	1	Switch-Horn	31	100-8665	1	Gauge-Reducer, Pressure
13	112-3313	1	Cap And Nut ASM	32	2815-16	1	Fitting-HYD, Tee
14	110-5079	1	Gauge-Pressure	33	100-8667	2	Coupler-Reducer

● Not serviced separately




Electric Hose Reel Kit (continued)

Ref.	Part Number	Qty.	Description
37	119-4954	1	Gauge-Pressure, Tube
38	107-8756	1	Hose-Hose Reel ASM
39	119-1765	1	Harness-Wire
39:2	94-8002	1	Fuse-Blade


Ref.	Part Number	Qty.	Description
39:3	32180-033	1	Grommet
40	3-1453	2	Screw-PRH
41	120-0618	1	Decal-Warning, Hose
42	119-0562-03	1	Bracket-Hose Reel

● Not serviced separately



Hose Reel Assembly No. 106-5083


Ref.	Part Number	Qty.	Description
1	104-8714	1	Hose Reel Frame ASM
2	104-8715	1	Chainguard-Reel, Hose
2:1	322-5	4	Screw-HH
2:2	3256-23	4	Washer-Flat
2:3	3296-29	4	Nut-Lock, NI
3	104-8799	1	Guide-Reel, Hose
3:2	104-8820	1	Bracket-Roller Guide, Right
3:3	322-5	8	Screw-HH
3:4	3256-23	8	Washer-Flat
3:5	3296-29	8	Nut-Lock, NI
3:6	104-8821	1	Bracket-Roller Guide, Left



Hose Reel Frame Assembly No. 104-8714

Ref.	Part Number	Qty.	Description
1	104-8803	1	Hose Reel Frame ASM
2	104-8804	1	Disc And Gear ASM
3	104-8805	1	Disc-Crank, Side
4	104-8806	1	Drum-Center
5	104-8807	1	Axle ASM
6	104-8808	1	Swivel ASM
6:1	104-8812	1	Ring-Retainer
6:2	104-8864	1	Swivel Seal Kit
7	104-8809	2	Block-Pillow, Top
8	104-8810	2	Block-Pillow, Bottom
9	104-8811	2	Bearing
10	104-8812	2	Ring-Retainer
11	104-8813	1	Cap-Pipe
12	322-3	8	Screw-HH

Ref.	Part Number	Qty.	Description
13	104-8814	1	Trim-Edge, Drum
14	3296-29	4	Nut-Lock, NI
15	3256-23	8	Washer-Flat
16	3253-21	4	Washer-Lock
17	323-6	4	Screw-HH
18	32128-21	1	Nut-HF
19	104-8815	1	Bracket-12V Dc
20	104-8816	1	Motor-12V Dc
21	104-8817	1	Pinion
22	104-8818	4	Key
23	322-5	4	Screw-HH
24	3253-4	1	Washer-Lock
25	104-8819	4	Screw-Set
26	3256-23	4	Washer-Flat



Spray Gun Assembly No. 100-6733

Ref.	Part Number	Qty.	Description
1	100-6649	3	O-Ring
2	99-0885	1	Extension-Lance
4	99-0884	1	Seal-Valve, On/Off
5	99-0779	1	Repair Kit
6	99-0887	1	Pin
7	99-0890	1	Housing-Nozzle
8	99-0889	1	Nozzle-Ceramic
9	100-6650	1	O-Ring
10	99-0886	1	Housing-Swirl
11	100-6646	1	O-Ring
12	100-6644	1	O-Ring
13	99-0780	1	Swirl
14	99-0772	1	Clamp-Hose
15	107-8734	1	Nut-Swivel

Ref.	Part Number	Qty.	Description
16	99-0883	1	Housing-Valve
17	104-8860	1	Cone
18	104-8861	1	Sleeve-Rubber
19	100-6647	1	O-Ring
20	99-0882	1	Valve ASM
21	99-0877	1	Handle-LH
22	99-0878	1	Stop-Trigger, Rubber
23	99-0880	1	Arm-Trigger
24	99-0879	1	Arm-Safety, Trigger
25	99-0881	1	Handle-RH
26	100-6666	1	Screw
27	100-6648	1	O-Ring
28	106-5093	1	Hosebarb-Brass

Notes:

Notes:

Notes:



Count on it.