




MODEL NO. 51918-690001 & UP

PARTS CATALOG


TRIMMER/BRUSHCUTTER



C-2541

BOOM AND TRIMMER ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	3296-12	Lock Nut	2	15	683295	Handle Bracket Asm. (Incl. 4 Screws & 4 Nuts)	1
2	57-5481	R. H. Housing	1	16	181099	J-Handle Asm. (Incl. Ref. #17-18)	1
3	53-7290	Trough	1	17	612021	Tube Closure	2
4	53-7120	Grip	1	18	612831	Grip	1
5	92-3275	Lead Wire Asm.	1	19	147539	Guard Mount Screws & Nuts	3
6	92-3278	Throttle Cable	1	20	684502	Mount Hardware & Plug	1
7	53-7273	Throttle Lever	1	21	147488	Gear Box Asm.	1
8	218-557	Switch Cap	1	22	147492	Guard Mount	1
9	42-6000	Switch	1	23	92-3236	Flexible Drive Shaft	1
10	57-5491	L.H. Housing	1	24	683304	Guard Mount Screws	3
11	32105-12	Hex Head Screw	2				
13	610327	Shoulder Strap Clamp	1				
14	181528	Drive Shaft Housing Asm.	1				




C-2541

BOOM AND TRIMMER ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
25	683299	Guard and Blade Asm.	1
26	682061	Blade Asm.	1
27	147489	Blade Driver	1
28	614201	Blade Retaining Washer	1
29	613231	Blade Cover	1
30	612031	Blade (Incl. Ref. #29)	1
31	613221	Lock Nut	1
32	612483	Spool Shaft	1
33	147494	Outer Spool & Eyelet Asm.	1
34	145566	Eyelet	1
35	612026	Retainer	1
36	610636	Spring	1
37	147495	Inner Reel	1

Ref. No.	Part No.	Description	No. Used
38	180814	Bump Head Knob Asm.	1
40	92-3328	Decal - Safety Symbols	1
41	92-3323	Decal - Brushcutter Symbol	1
42	92-3325	Decal - Warning	1
*	41-6820	Monoflail Cutting Line, 50 ft	1
*	682075	Shoulder Strap Asm.	1
*	92-3294	Spool and Line (40 ft) Asm.	1
*	147498	Complete Head Asm. (Incl. Ref. #32-38)	1
*	66-2090	Toro 2-Cycle Oil	1
*	613226	Locking Rod Tool (Use For Trimmer Head Removal & Blade Installation)	1

*Not Illustrated




C-2537

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	145888	Screw	4
2	92-3273	Rear Cover	1
3	180211	Heat Shield	1
4	180212	Mounting Screw	4
5	180213	Crankcase Cap	1
36	180249	Crankcase Asm. (Incl. Ref. # 5, 45-46)	1
37	145918	Spacer	1
38	180535	Recoil Pulley	1
39	613102	Recoil Spring	1
40	180929	Flywheel Asm.	1
41	92-3223	Ground Tab	1
42	180238	Module Asm.	1
43	180239	Front Pad -Fuel Tank	1

Ref. No.	Part No.	Description	No. Used
44	180244	Fuel Line Asm.	1
45	180245	Power Shaft Asm.	1
46	180246	Crankcase Cap Gasket	1
47	180236	Cylinder Gasket	1
48	180534	Piston and Rod Asm.	1
49	180240	Fuel Tank Asm.	1
50	180241	Rear Fuel Tank Pad	1
51	180536	Fuel Tank Bracket	1
52	180000	Fuel Tank Cap	1
53	180243	Return Fuel Line	1
55	92-3332	Decal - Warning	1
56	92-3334	Decal - Fuel & Oil Mix	1
57	92-3345	Decal - Carb.	1




C-2538

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
6	180214	Muffler Mounting Screws	2
7	180215	Muffler Asm.	1
8	180216	Muffler Gasket	1
9	181527	Cylinder	1
10	610311	Spark Plug	1
11	180217	Spacer Nut Set	1
12	180218	Spacer Screw Set	1
13	683974	Primer Bulb & Hose	1
14	92-3281	Plug Switch	1
15	180225	Choke Lever	1
16	180226	Wavey Washer	1

Ref. No.	Part No.	Description	No. Used
17	180533	Carburetor Mount Screw Asm.	2
18	180230	Screw	4
19	180229	Air Cleaner Cover	1
20	180228	Air Filter Element	1
21	180223	Air Cleaner Base Asm.	1
22	181526	Carburetor Asm.	1
23	612113	Carburetor Gasket	1
24	180532	Spacer, Carburetor Asm.	1
25	180220	Cylinder/Carburetor Gasket	1
26	180221	Screw	4



C-2539

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
27	610300	Pull Handle	1	*	180090	Carb. Repair Kit (Zama)	1
28	613103	Starter Rope	1	*	181069	Gasket-Diaphragm Repair Kit (Walbro)	1
29	153591	Clutch Rotor Asm.	1	*	180091	Gasket-Diaphragm Repair Kit (Zama)	1
30	180232	Clutch Drum Asm.	1	*	610676	Flywheel Key	1
31	153597	Clamp Asm.	1	*	180537	Piston Ring	1
32	180231	Clutch Housing Asm.	1	*	180248	Short Block Asm. (Incl. Ref. #5,9,10,26,36,45-48)	1
33	92-3274	Starter Housing Asm.	1	*	610676	Flywheel Key	1
34	611061	Rope Guide	1	*	610309	Crankcase Seal	1
35	153644	Pulley Retainer	1				
54	92-3344	Decal - Toro	1				
*	180247	Engine Gasket Kit	1				
*	153308	Carb. Repair Kit (Walbro)	1				

*Not Illustrated

TORO PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
145566	Eyelet	2	34	1	181526	Carburetor Asm.	4	22	1
145888	Screw	3	1	4	181527	Cylinder	4	9	1
145918	Spacer	3	37	1	181528	Drive Shaft Housing Asm.	1	14	1
147488	Gear Box Asm.	1	21	1	610300	Pull Handle	5	27	1
147489	Blade Driver	2	27	1	610309	Crankcase Seal	5	*	1
147492	Guard Mount	1	22	1	610311	Spark Plug	4	10	1
147494	Outer Spool & Eyelet Asm.	2	33	1	610327	Shoulder Strap Clamp	1	13	1
147495	Inner Reel	2	37	1	610636	Spring	2	36	1
147498	Complete Head Asm.	2	*		610676	Flywheel Key	5	*	1
147539	Guard Mount Screws & Nuts	1	19	3	610676	Flywheel Key	5	*	1
153308	Carb. Repair Kit (Walbro)	5	*	1	611061	Rope Guide	5	34	1
153591	Clutch Rotor Asm.	5	29	1	612021	Tube Closure	1	17	2
153597	Clamp Asm.	5	31	1	612026	Retainer	2	35	1
153644	Pulley Retainer	5	35	1	612031	Blade	2	30	1
180000	Fuel Tank Cap	3	52	1	612113	Carburetor Gasket	4	23	1
180090	Carb. Repair Kit (Zama)	5	*	1	612483	Spool Shaft	2	32	1
180091	Gasket-Diaphragm	5	*	1	612831	Grip	1	18	1
180211	Heat Shield	3	3	1	613102	Recoil Spring	3	39	1
180212	Mounting Screw	3	4	4	613103	Starter Rope	5	28	1
180213	Crankcase Cap	3	5	1	613221	Lock Nut	2	31	1
180214	Muffler Mounting Screws	4	6	2	613226	Locking Rod Tool	2	*	1
180215	Muffler Asm.	4	7	1	613231	Blade Cover	2	29	1
180216	Muffler Gasket	4	8	1	614201	Blade Retaining Washer	2	28	1
180217	Spacer Nut Set	4	11	1	682061	Blade Asm.	2	26	1
180218	Spacer Screw Set	4	12	1	682075	Shoulder Strap Asm.	2	*	1
180220	Cylinder/Carburetor Gasket	4	25	1	683295	Handle Bracket Asm.	1	15	1
180221	Screw	4	26	4	683299	Guard and Blade Asm.	2	25	1
180223	Air Cleaner Base Asm.	4	21	1	683304	Guard Mount Screws	1	24	3
180225	Choke Lever	4	15	1	683974	Primer Bulb & Hose	4	13	1
180226	Wavey Washer	4	16	1	684502	Mount Hardware & Plug	1	20	1
180228	Air Filter Element	4	20	1	41-6820	Monoflail Cutting Line, 50 ft	2	*	1
180229	Air Cleaner Cover	4	19	1	42-6000	Switch	1	9	1
180230	Screw	4	18	4	53-7120	Grip	1	4	1
180231	Clutch Housing Asm.	5	32	1	53-7273	Throttle Lever	1	7	1
180232	Clutch Drum Asm.	5	30	1	53-7290	Trough	1	3	1
180236	Cylinder Gasket	3	47	1	57-5481	R. H. Housing	1	2	1
180238	Module Asm.	3	42	1	57-5491	L.H. Housing	1	10	1
180239	Front Pad - Fuel Tank	3	43	1	66-2090	Toro 2-Cycle Oil	2	*	1
180240	Fuel Tank Asm.	3	49	1	92-3223	Ground Tab	3	41	1
180241	Rear Fuel Tank Pad	3	50	1	92-3236	Flexible Drive Shaft	1	23	1
180243	Return Fuel Line	3	53	1	92-3273	Rear Cover	3	2	1
180244	Fuel Line Asm.	3	44	1	92-3274	Starter Housing Asm.	5	33	1
180245	Power Shaft Asm.	3	45	1	92-3275	Lead Wire Asm.	1	5	1
180246	Crankcase Cap Gasket	3	46	1	92-3278	Throttle Cable	1	6	1
180247	Engine Gasket Kit	5	*	1	92-3281	Plug Switch	4	14	1
180248	Short Block Asm.	5	*		92-3294	Spool and Line (40 ft) Asm.	2	*	1
180249	Crankcase Asm.	3	36	1	218-557	Switch Cap	1	8	1
180532	Spacer, Carburetor Asm.	4	24	1	3296-12	Lock Nut	1	1	2
180533	Carburetor Mount	4	17	2	32105-12	Hex Head Screw	1	11	2
180534	Piston and Rod Asm.	3	48	1	92-3323	Decal - Brushcutter Symbol	2	41	1
180535	Recoil Pulley	3	38	1	92-3325	Decal - Warning	2	42	1
180536	Fuel Tank Bracket	3	51	1	92-3328	Decal - Safety Symbols	2	40	1
180537	Piston Ring	5	*	1	92-3332	Decal - Warning	3	55	1
180814	Bump Head Knob Asm.	2	38	1	92-3334	Decal - Fuel & Oil Mix	3	56	1
180929	Flywheel Asm.	3	40	1	92-3344	Decal - Toro	5	54	1
181069	Gasket-Diaphragm	5	*	1	92-3345	Decal - Carb.	3	57	1
181099	J-Handle Asm.	1	16	1					

*Not Illustrated

