FORM NO. 3318–622


TORO®

MODEL NO. 78218–6900001 & UP

PARTS CATALOG

WHEELHORSE

38” Side Discharge Rotary Cutting Unit



C–2546

BLADE, SPINDLE, BELT & IDLER PULLEY


PROTOTYPE

Ref. No.	Part No.	Description	No. Used
1	3296–29	Nut–Lock	11
2	78–8091–03	Brace	1
3	3296–39	Nut–Lock	2
4	109859	Bushing	2
5	92–7082	Pulley–Idler	1
6	3256–24	Washer–Flat	1
7	78–6210	Spring–Extension	1
8	322–6	Screw–Hex. Hd.	1
9	79–5980	”V” Belt	1
10	9150074	Nut–Hex	2
11	92–7081	Pulley	2
12	79–1090	Bearing–Ball	4
13	3217–6	Nut–Hex	1
14	79–2780	Spacer	2
15	322–3	Screw–Hex. Hd.	10

Ref. No.	Part No.	Description	No. Used
16	302–16	Fitting–Grease	2
17	79–1050–03	Housing–Spindle	2
19	57–4700	Blade	2
21	112843	Washer	2
22	26–0671	Bolt–Blade	2
23	80–4351	Shaft–Spindle	2
24	80–4370	Shield–Bearing	2
25	80–4390	Spacer–Hardened	2
27	302–26	Fitting–Grease	1
28	78–3370–03	Arm	1
29	323–10	Screw–Hex. Hd.	1
30	109950	Spacer	1
31	2844	Washer–Flat	2
32	323–16	Screw–Hex. Hd.	1

TPS

©The TORO Company – 1996
All Rights Reserved




C–2547

GAGE WHEELS, DECK & SIDE DISCHARGE DEFLECTOR

Ref. No.	Part No.	Description	No. Used
1	5188	Screw–Hex. Soc. Hd.	2
2	110506	Wheel–Gage	2
3	32146–2	Nut–Lock	2
4	9267154	Screw	6
5	78–6400–03	Clamp	3
6	78–8011–03	Shaft	1
7	92–7063	Pivot Post–Rear	1
8	9335064	Hairpin–Cotter	3
9	78–8071	Link–Rear	1
10	3256–26	Washer–Flat	5
11	3272–21	Pin–Cotter	4
12	110656	Trunnion	1
13	9335044	Hairpin	1
14	121010	Rod–Lift	1
15	3256–24	Washer–Flat	1
16	3272–6	Pin–Cotter	1
17	92–7073–03	Shaft	1

Ref. No.	Part No.	Description	No. Used
19	325–13	Screw–Hex. Hd.	1
21	86–9240	Bracket	1
22	86–9250	Bracket	1
23	3218–5	Nut–Jam	1
24	29–4820	Roller	2
25	3296–42	Nut–Lock	2
26	118960	Shaft–Roller	2
27	321–4	Screw–Hex. Hd.	2
28	94–1579	Asm–Decal	1
29	3296–39	Nut–Lock	1
30	57–6950	Spring–Torsion Deflector	1
33	57–4380	Rod– Hinge Deflector	1
34	3296–16	Nut – Lock	2
35	3256–1	Washer – Flat	2
36	95–2747	Fitting – Wash out	1
37	46–6290	O–Ring	1
38	3229–1	Bolt – Carriage	2

PROTOTYPE




C−2548

BELT COVERS & ROLLER LIFTS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
3	3296−29	Nut−Lock	3
4	93−6679	Decal−Routing	1
6	9335074	Cotter−Hairpin	2
7	3256−28	Washer−Flat	2
8	78−7340	Roller−Lift	2
9	9202394	Washer	2
10	32151−29	Ring−Ext Snap	2

Ref. No.	Part No.	Description	No. Used
12	78−6840−03	Cover−Belt	2
13	32104−76	Screw−Self TAP	6
15	93−7319	Decal−Danger	1
17	322−1	Screw−Hex. Hd.	2
21	322−1	Screw−Hex. Hd.	1
27	93−7009	Decal−Danger	1

PROTOTYPE



C–2549

DEFLECTOR ASSEMBLY NO. 93–7695

Ref. No.	Part No.	Description	No. Used
1	93–7010	Decal – Danger	1
2	93–8595	Deflector	1

Ref. No.	Part No.	Description	No. Used
3	93–7696	Kicker	2
4	93–0231	Screw	4

PROTOTYPE

TORO PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.
2844	Washer–Flat	1	31	2
5188	Screw–Hex. Soc. Hd.	2	1	2
109859	Bushing	1	4	2
109950	Spacer	1	30	1
110506	Wheel–Gage	2	2	2
110656	Trunnion	2	12	1
112843	Washer	1	21	2
118960	Shaft–Roller	2	26	2
121010	Rod–Lift	2	14	1
9150074	Nut–Hex	1	10	2
9202394	Washer	3	9	2
9267154	Screw	2	4	6
9335044	Hairpin	2	13	1
9335064	Hairpin–Cotter	2	8	3
9335074	Cotter–Hairpin	3	6	2
26–0671	Bolt–Blade	1	22	2
29–4820	Roller	2	24	2
57–4380	Rod– Hinge Deflector	2	33	1
57–4700	Blade	1	19	2
57–6950	Spring–Torsion Deflector	2	30	1
78–3370–03	Arm	1	28	1
78–6210	Spring–Extension	1	7	1
78–6400–03	Clamp	2	5	3
78–6840–03	Cover–Belt	3	12	2
78–7340	Roller–Lift	3	8	2
78–8011–03	Shaft	2	6	1
78–8071	Link–Rear	2	9	1
78–8091–03	Brace	1	2	1
79–1050–03	Housing–Spindle	1	17	2
79–1090	Bearing–Ball	1	12	4
79–2780	Spacer	1	14	2
79–5980	V Belt	1	9	1
80–4351	Shaft–Spindle	1	23	2
80–4370	Shield–Bearing	1	24	2
80–4390	Spacer–Hardened	1	25	2
86–9240	Bracket	2	21	1
86–9250	Bracket	2	22	1
92–7063	Pivot Post–Rear	2	7	1
92–7073–03	Shaft	2	17	1
92–7081	Pulley	1	11	2
92–7082	Pulley–Idler	1	5	1
93–0231	Screw	4	4	4
93–6679	Decal–Routing	3	4	1
93–7009	Decal–Danger	3	27	1
93–7010	Decal – Danger	4	1	1
93–7319	Decal–Danger	3	15	1
93–7696	Kicker	4	3	2
93–8595	Deflector	4	2	1
94–1579	Asm–Decal	2	28	1
302–16	Fitting–Grease	1	16	2
302–26	Fitting–Grease	1	27	1
321–4	Screw–Hex. Hd.	2	27	2
322–1	Screw–Hex. Hd.	3	17	2
322–1	Screw–Hex. Hd.	3	21	1
322–3	Screw–Hex. Hd.	1	15	10
322–6	Screw–Hex. Hd.	1	8	1
323–10	Screw–Hex. Hd.	1	29	1
323–16	Screw–Hex. Hd.	1	32	1
325–13	Screw–Hex. Hd.	2	19	1
3217–6	Nut–Hex	1	13	1
3218–5	Nut–Jam	2	23	1
3256–24	Washer–Flat	1	6	1
3256–24	Washer–Flat	2	15	1
3256–26	Washer–Flat	2	10	5
3256–28	Washer–Flat	3	7	2
3272–6	Pin–Cotter	2	16	1
3272–21	Pin–Cotter	2	11	4
3296–29	Nut–Lock	1	1	11
3296–29	Nut–Lock	3	3	3
3296–39	Nut–Lock	1	3	2
3296–39	Nut–Lock	2	29	1
3296–42	Nut–Lock	2	25	2
32104–76	Screw–Self TAP	3	13	6
32146–2	Nut–Lock	2	3	2
32151–29	Ring–Ext Snap	3	10	2

PROTOTYPE

*Not Illustrated

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

Date								

PROTOTYPE

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.

MAINTENANCE RECORD

Date								

PROTOTYPE

MAINTENANCE RECORD

Date								

PROTOTYPE

Litho in U.S.A.