



Count on it.

Form No. 3367-913 Rev A

Parts Catalog

41cm Electric Lawn Mower

Model No. 21190—Serial No. 311000001 and Up

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquid Propane

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping


TTH: torx truss head

Contents

Handle, Cover and Grassbag Assembly..... 4

Height-of-Cut and Wheel Assembly 6


Handle, Cover and Grassbag Assembly



Handle, Cover and Grassbag Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	480088	2	Knob-Handlebar	21	111-0056	1	Bar-Hinge
3	410037	2	Guide-Cable	22	309052	1	Motor-Induction, 1.5Kw
4	HY226024	2	Bolt-Handlebar	23	111-0074	1	Vent Mesh ASM
5	300160	2	Plug-Tube	24	111-0091	1	Handlebars-Electric
6	410030	1	Spring-Deflector	25	HY100017	1	Arm-Bail
7	119-3808	1	Plate-Logo, Toro	26	HY100078	5	Screw
8	111-0031	1	Casting-Chassis	27	111-4070	1	Switch And Lead ASM
9	111-3978	1	Top-Cover	28	HY100510	1	Mount Bail Arm ASM
10	111-3977	1	Motor-Cover	29	111-0094	3	Screw
11	111-1043	1	Moulding-Rear Deflector	30	09575	2	Screw-Taptite
12	111-0040	1	Plate-HOC	31	111-4782	1	Decal-Height Of Cut (China Only)
13	HY100128	1	Screw-PPH, Thread Forming	34	111-0118	2	Screw-Socket
14	111-4025	1	Grassbag	35	111-0115	3	Screw
15	111-4781	1	Decal-Safety Electric (China Only)	36	111-0107	1	Cup-Screw, Electric
16	100105	1	Cleat-Cable	37	111-0960	2	Plug-Handlebar
17	111-0045	1	Frame-Grassbag	38	09438	2	Nut-Nyloc
18	111-4073	1	Decal	39	111-2155	1	Grommet-Rubber
19	111-0051	2	Handlebars-Lower	40	111-4382	1	Plug-Mulching
20	111-0052	1	Moulding-Mount, Electric Motor				

Height-of-Cut and Wheel Assembly



Height-of-Cut and Wheel Assembly (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
3	410069	2	Bearing-Axle, Front	23	111-4036	4	Wheel ASM (Grey)
4	410048	1	Housing-Pivot Bearing, LH	24	111-0066	4	Cap-Wheel, Centre
5	219037	1	Plate-Securing	26	111-0073	1	Spring-Mount
7	410050	1	Spring-Counter Balance	27	111-0100	15	Screw
8	111-0078	1	Spring-HOC	28	09365	6	Screw-Taptite
9	111-0027	1	Axle-Front	29	111-0119	4	Nut-Nyloc
10	111-0068	1	Frame-Wheel	30	09262	2	Washer
11	111-0034	1	Moulding-Fin	31	111-0099	1	Bolt-Fixing, Blade
12	111-0037	1	Moulding-Snail Deck	32	09575	2	Screw-Taptite
13	111-0038	1	Moulding-Access, Snail Deck	33	09565	1	Screw-HH
14	111-0039	1	Moulding-Throw Plate	34	09441	1	Nut-Nyloc
15	111-0050	1	Mount-Bearing	35	09491	2	Washer-Plain
16	111-0053	1	Moulding-Mount, Electric Blade	37	09476	1	Washer-Shakeproof
17	111-0054	1	Cutterbar-Electric	38	09438	1	Nut-Nyloc
18	111-0055	1	Knob-HOC, RH	39	HY100078	2	Screw
21	111-0059	1	Lever-HOC	40	111-0105	1	Knob-HOC, LH
22	111-0063	1	Rod-Connecting Bar	41	111-0116	2	Screw-Taptite
				42	0201086	2	Washer-Starlock



Count on it.