Form No. 3363-813 Rev C

TORO®

Count on it.

Parts Catalog

# TITAN ZX4800 Zero-Turn-Radius Riding Mower

**Model No. 74830—Serial No. 310000001 and Up**

# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

**Understanding Reference Numbers**

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

**Service Assembly Reference Numbers**

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

**Reference Numbers Indicating Quantity**

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# List of Abbreviations

**AR:** as required

**ASM:** assembly

**BBC:** blade brake control

**BHTF:** button head thread forming

**CARR:** carriage

**CCW:** counter clockwise

**CW:** clockwise

**DEG:** degrees

**DPA:** Dual Point Adjustment

**ECM:** electronic control module

**EXT:** external

**FH:** flat head

**GA:** gauge

**HD:** heavy-duty

**HF:** hex flange

**HH:** hex head

**HHF:** hex head flange

**HHFTF:** hex head flange thread forming

**HJ:** hex jam

**HLH:** hex lag head

**HOC:** height-of-cut

**HSBH:** hex socket button head

**HSFH:** hex socket flat head

**HSH:** hex socket head

**HWH:** hex washer head

**HWHTF:** hex washer head thread forming

**HYD:** hydraulic

**LH:** left hand

**LP:** Liquid Propane

**NI:** nylon insert

**NPTF:** national pipe thread fine

**PFH:** phillips flat head

**PPH:** phillips pan head

**PPHTF:** phillips pan head thread forming

**PRH:** phillips round head

**PTH:** phillips truss head

**PTO:** power-take-off

**RH:** right hand

**ROPS:** roll-over protection system

**RRB:** rear roller brush

**SFH:** slotted fillister head

**SHH:** slotted hex head

**SHWH:** slotted hex washer head

**SPH:** slotted pan head

**SQH:** square head

**SRH:** slotted round head

**STD:** standard

**TAP:** self tapping

**TTH:** torx truss head


© 2011—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420



Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved

# Contents


Main Frame and Front Caster Wheel Assembly . . . . . 4
Deck Lift Assembly . . . . . 5
Motion Control Assembly . . . . . 6
Parking Brake Assembly . . . . . 7
Handle Control Assembly . . . . . 8
Traction Drive Assembly . . . . . 9
RH Hydro Assembly No. 115-2550 . . . . . 10
LH Hydro Assembly No. 115-2551 . . . . . 12
Seat Assembly . . . . . 14
Engine, Muffler and Clutch Assembly . . . . . 15
Fuel Delivery System . . . . . 16
Body and Styling Assembly . . . . . 17
Electrical Assembly . . . . . 18
48 Inch Deck Assembly . . . . . 19
48 Inch Deck Decal Assembly No. 119-3383 . . . . . 20
48 Inch Deck Spindle and Belt Drive Assembly . . . . . 21
Attachments and Accessories . . . . . 22




# Main Frame and Front Caster Wheel Assembly


| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 117-7356-01 | 1 | Frame ASM |
| 2 | 115-2531-05 | 1 | Pan-Floor |
| 3 | 32144-70 | 6 | Screw-HWHTF |
| 4 | 109-8965 | 1 | Decal-Safety |
| 5 | 115-2554 | 2 | Wheel And Tire ASM |
| 5:2 | 115-2557 | 1 | Tire-Smooth |
| 5:3 | 114-1640 | 2 | Bushing-Flange |
| 5:4 | 232-27 | 1 | Stem-Valve |
| 5:5 | 302-5 | 1 | Fitting-Grease |
| 5:99 | 117-1234 | 1 | Tube-Inner |
| 6 | 104-3667 | 2 | Spanner-Wheel |
| 7 | 325-22 | 2 | Screw-HH |
| 8 | 3296-45 | 2 | Nut-Lock, NI |
| 9 | 110-6634-01 | 2 | Caster Fork ASM |
| 10 | 10-8110 | 2 | Washer-Thrust |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 11 | 109-3678 | 4 | Bearing-Ball |
| 12 | 109-3724 | 2 | Washer |
| 13 | 3234-47 | 2 | Screw-HHF |
| 14 | 115-2566-03 | 1 | Support-Seat |
| 15 | 322-11 | 2 | Screw-HH |
| 16 | 104-8300 | 4 | Nut-Flange, NI |
| 17 | 115-2632-03 | 1 | Guard-Rear, Shield |
| 18 | 62-5550 | 1 | Decal |
| 19 | 105-8278 | 1 | Decal |
| 20 | 115-2565-01 | 1 | Guard-Rear, Tube |
| 21 | 3230-6 | 2 | Screw-CARR |
| 22 | 115-5061-01 | 1 | Plate-Spacer |
| 23 | 117-1241 | 1 | Cover-Fan, RH |
| 24 | 117-1242 | 1 | Cover-Fan, LH |
| 25 | 46-8560 | 2 | Screw-HHFTF |




# Deck Lift Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 115-2495-03 | 1 | Pivot-Front |
| 2 | 115-2498-03 | 1 | Pivot-Rear |
| 3 | 117-1281 | 1 | Bushing-Mount, HOC |
| 4 | 115-4986 | 3 | Spacer |
| 5 | 115-2503-03 | 2 | Plate-Lift, Foot |
| 6 | 115-2504 | 1 | Plate-Stop, HOC |
| 7 | 65-5950 | 4 | Bushing-Pulley |
| 8 | 115-5033 | 1 | Grip |
| 9 | 115-5065 | 4 | Bushing-Flange |
| 10 | 3231-4 | 7 | Screw-CARR |
| 11 | 104-8301 | 8 | Nut-Flange, NI |
| 12 | 323-7 | 1 | Screw-HH |
| 13 | 322-5 | 8 | Screw-HH |
| 14 | 104-8300 | 8 | Nut-Flange, NI |
| 15 | 117-1280 | 1 | Pin-Keyed |
| 16 | 115-9644 | 1 | Decal-HOC |
| 17 | 117-5344 | 1 | Decal-Lock, Deck |
| 18 | 3231-1 | 1 | Screw-CARR |





# Motion Control Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 115-2546-03 | 1 | Box-Control |
| 2 | 112-4004 | 2 | Screw-Shoulder |
| 3 | 110-6828 | 2 | Activator Arm ASM |
| 3:2 | 105-3455 | 2 | Bushing |
| 4 | 106-2214 | 2 | Bolt-Shoulder |
| 5 | 103-2913 | 2 | Damper-Control, Motion |
| 6 | 3296-42 | 4 | Nut-Lock, NI |
| 7 | 46-8560 | 2 | Screw-HHFTF |
| 8 | 3296-48 | 2 | Nut-Lock, NI |
| 9 | 3256-22 | 2 | Washer-Flat |
| 10 | 32128-23 | 2 | Nut-HF |
| 11 | 3256-5 | 2 | Washer-Flat |
| 12 | 115-2529 | 2 | Link-Bent, Hydro |
| 13 | 1-303105 | 2 | Yoke-Adjustable |
| 14 | 1-808280 | 2 | Pin-Clevis |
| 15 | 1-806003 | 2 | Pin-Cotter, Hair |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 16 | 3220-2 | 2 | Nut-Jam |
| 17 | 110-6783-05 | 1 | Arm-Actuator, LH |
| 18 | 110-6782-05 | 1 | Arm-Actuator, RH ● |
| 19 | 115-5023 | 2 | Tab-Stop |
| 20 | 110-6873 | 2 | Eccentric |
| 21 | 110-6874 | 2 | Screw-Eccentric |
| 22 | 110-6875 | 2 | Bolt-Shoulder |
| 23 | 110-6751 | 2 | Bracket-Return |
| 24 | 110-6750 | 2 | Plate-Return |
| 25 | 110-6752 | 2 | Spring-Compression |
| 26 | 110-6894 | 6 | Washer-Pivot |
| 27 | 323-4 | 2 | Screw-HH |
| 28 | 110-6784 | 2 | Bolt-Shoulder |
| 29 | 37-8771 | 2 | Bolt-Shoulder |
| 30 | 104-8300 | 2 | Nut-Flange, NI |
| 31 | 112-9771 | 2 | Washer-Teflon |

● Not illustrated





# Parking Brake Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 117-7421 | 1 | Brake Handle ASM |
| 2 | 63-2650 | 1 | Screw-Shoulder |
| 3 | 115-5071-03 | 1 | Brake-Bellcrank |
| 4 | 115-5074 | 1 | Link-Brake |
| 5 | 117-7322 | 1 | Rod-Brake, LH |
| 6 | 117-7323 | 1 | Rod-Brake, RH ● |
| 7 | 115-9681 | 2 | Fitting-Rod |
| 8 | 1-633268 | 1 | Grip-Lever |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 9 | 104-8300 | 1 | Nut-Flange, NI |
| 10 | 256-292 | 2 | Bushing-Flange, NI |
| 11 | 1-806003 | 8 | Pin-Cotter, Hair |
| 12 | 3256-23 | 4 | Washer-Flat |
| 13 | 1-603807 | 2 | Spring-Return, Neutral |
| 14 | 3272-11 | 2 | Pin-Cotter |
| 15 | 3256-27 | 2 | Washer-Flat |
| 16 | 40-1940 | 2 | Washer |

● Not illustrated





# Handle Control Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 117-5338 | 1 | LH Control Handle ASM |
| 1:1 | 108-6187 | 1 | Grip ● |
| 2 | 117-5339 | 1 | RH Control Handle ASM ● |
| 2:1 | 108-6187 | 1 | Grip |
| 3 | 323-6 | 4 | Screw-HH |
| 4 | 3256-24 | 4 | Washer-Flat |
| 5 | 117-7490 | 1 | Decal-Titan |
| 6 | 106-9758 | 2 | Screw-CARR |
| 7 | 104-8300 | 4 | Nut-Flange, NI |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 8 | 3234-47 | 2 | Screw-HHF |
| 9 | 99-8936 | 2 | Decal-Control, Motion |
| 10 | 115-9625 | 1 | Decal |
| 11 | 115-2561-03 | 1 | Cover-Control, LH |
| 12 | 46-8560 | 2 | Screw-HHFTF |
| 13 | 117-1255-03 | 1 | Cover-Control, RH ● |
| 14 | 32144-70 | 4 | Screw-HWHTF |
| 15 | 117-7237 | 1 | Strip-Vibration, Anti |
| 16 | 117-7238 | 1 | Strip-Vibration, Anti |

● Not illustrated





# Traction Drive Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 115-2550 | 1 | Hydro-RH |
| 2 | 115-2551 | 1 | Hydro-LH |
| 3 | 110-9981 | 1 | Washer-Plain |
| 4 | 115-4986 | 1 | Spacer |
| 5 | 114-0463 | 2 | Washer-Friction, Composite |
| 6 | 117-5350 | 1 | Arm-Idler |
| 7 | 104-8301 | 3 | Nut-Flange, NI |
| 9 | 109-3397 | 2 | Pulley-Idler, Flat |
| 10 | 1-603402 | 1 | Spring-Extension |
| 11 | 3231-4 | 2 | Screw-CARR |
| 12 | 323-12 | 1 | Screw-HH |
| 13 | 109-3652 | 2 | Spacer-Hydro |
| 14 | 115-2559 | 1 | Shaft-Cross, Hydro |
| 15 | 322-13 | 4 | Screw-HH |
| 16 | 104-8300 | 8 | Nut-Flange, NI |
| 17 | 322-38 | 2 | Screw-HH |
| 18 | 322-11 | 2 | Screw-HH |
| 19 | 323-10 | 2 | Screw-HH |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 20 | 1-806003 | 2 | Pin-Cotter, Hair |
| 21 | 115-4990 | 2 | Rod-Bypass |
| 22 | 3256-22 | 2 | Washer-Flat |
| 23 | 115-2594 | 2 | Tire And Rim ASM |
| 23:2 | 232-27 | 1 | Stem-Valve |
| 23:3 | 115-2590 | 1 | Tire |
| 24 | 242-50 | 8 | Nut-Lug |
| 25 | 115-9613 | 1 | V-Belt |
| 26 | 115-9618 | 1 | HYD Reservior ASM |
| 26:2 | 109-3320 | 1 | Cap-Reservoir, HYD |
| 27 | 115-4969 | 2 | Hose-Overflow |
| 28 | 117-1193 | 4 | Clamp-Hose |
| 29 | 46-8560 | 2 | Screw-HHFTF |
| 30 | 117-1158 | 2 | Decal-Bypass |
| 31 | 3256-23 | 8 | Washer-Flat |
| 32 | 117-5351 | 1 | Spacer |
| 33 | 117-7248-03 | 2 | Plate-Spring |
| 34 | 110769 | 2 | Spring-Extension |


# RH Hydro Assembly No. 115-2550



# RH Hydro Assembly No. 115-2550 (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 117-5357 | 1 | RH Main Housing Kit |
| 2 | 117-5358 | 1 | RH Housing Side Kit |
| 7 | 117-5359 | 16 | Screw-Hfhcs |
| 10 | 114-1678 | 2 | O-Ring |
| 11 | 104-2189 | 1 | Plug-Thread, Straight |
| 22 | 114-1680 | 1 | Plate-Bypass |
| 23 | 109-3321 | 1 | Element-Oil Filter, HYD |
| 26 | 114-1683 | 2 | Seal-Plug |
| 27 | 114-1684 | 3 | Screw-Hfhc |
| 30 | 106-8676 | 1 | Seal-Lip |
| 31 | 106-8677 | 1 | Ring-Retaining, EXT |
| 32 | 114-1685 | 1 | Rod-Bypass |
| 33 | 106-8679 | 1 | Ring-Retaining, Int |
| 34 | 107-2490 | 1 | Arm-Bypass |
| 35 | 106-8681 | 1 | Ring-Retaining, EXT |
| 40 | 104-5304 | 1 | Swashplate-Trunnion |
| 41 | 104-5313 | 1 | Seal-Lip |
| 42 | 104-2116 | 1 | Stud |
| 43 | 112-9853 | 1 | Puck-Friction |
| 44 | 106-8747 | 1 | Arm-Control |
| 45 | 114-8491 | 1 | Washer |
| 46 | 107-2488 | 1 | Screw |
| 47 | 105-1872 | 1 | Nut |
| 52 | 114-1687 | 1 | Shaft-Input |
| 53 | 104-5311 | 1 | Bearing-Ball |
| 54 | 104-5307 | 1 | Ring-Retaining |
| 55 | 104-5308 | 1 | Spacer |
| 56 | 104-5310 | 1 | Seal-Lip |
| 57 | 104-5309 | 1 | Ring-Retaining |
| 60 | 112-4154 | 1 | Bearing-Thrust |
| 64 | 114-1689 | 1 | Motor Cylinder Block Kit |
| 65 | 94-6922 | 1 | Bearing-Thrust |
| 69 | 110-8561 | 1 | Pump Block ASM |
| 70 | 104-5339 | 1 | Washer-Flat |
| 71 | 104-5340 | 1 | Ring-Retaining |
| 72 | 114-1690 | 1 | Gear-14T |
| 73 | 114-1691 | 1 | Shaft-Motor |
| 74 | 104-5360 | 1 | Washer-Shaft, Motor |
| 80 | 94-1933 | 1 | Washer |
| 81 | 114-1692 | 1 | Gear-45T |
| 82 | 114-1693 | 1 | Gear-11T |
| 83 | 104-5329 | 1 | Pin-Jackshaft |
| 90 | 104-2169 | 1 | Ring-Retaining |
| 91 | 114-1694 | 1 | Gear-54T |
| 92 | 114-1695 | 1 | Spacer |
| 93 | 114-1696 | 1 | Bearing-Ball |
| 95 | 104-2143 | 1 | Bearing-Ball |
| 96 | 104-2144 | 1 | Seal |
| 97 | 109-5939 | 1 | Hub Kit |
| 99 | 105-1895 | 1 | Nut |
| 100 | 114-1697 | 1 | Pawl-Brake |
| 101 | 117-5360 | 1 | Shaft-Brake |
| 102 | 114-1699 | 1 | Handle-Brake |
| 103 | 114-8450 | 1 | Clip-Retaining |
| 105 | 104-2120 | 3 | Screw |
| 106 | 114-8473 | 1 | Guard-Filter, LH |
| 111 | 109-3278 | 1 | Adapter-Straight |
| 120 | 114-8453 | 1 | Fan-7.0 |
| 121 | 114-8454 | 1 | Pulley-5.0 Inch |
| 122 | 104-2168 | 1 | Nut-Hex |
| 123 | 107-9122 | 1 | Washer-Slotted |
| 130 | 114-8455 | 2 | Tube-Connecting |
| 131 | 104-2122 | 1 | Gerotor ASM |
| 132 | 109-3540 | 1 | O-Ring-Seal |
| 133 | 114-8457 | 1 | Cover-Charge Pump |
| 134 | 104-2120 | 2 | Screw |
| 200 | 109-3537 | 1 | Complete Seal Kit |
| 201 | 114-8463 | 1 | RH Center Section Kit |
| 202 | 114-8464 | 1 | Charge Relief Kit |
| 203 | 114-8465 | 1 | Charge Kit |
| 207 | 109-5938 | 1 | Fan And Pulley Kit |
| 209 | 114-8467 | 1 | Hub-Puller, 4 Bolt |
| 210 | 117-5361 | 1 | Shaft Input Kit |
| 211 | 117-5362 | 1 | Arm Control Kit |
| 212 | 114-8470 | 1 | Axle Shaft Kit |


# LH Hydro Assembly No. 115-2551




200 = Seal Kit
209 = Hub-Puller, 4 Bolt


# LH Hydro Assembly No. 115-2551 (continued)

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 114-8471 | 1 | LH Main Housing Kit |
| 2 | 114-8472 | 1 | LH Side Cover Kit |
| 7 | 117-5359 | 16 | Screw-Hfhcs |
| 10 | 114-1678 | 2 | O-Ring |
| 11 | 104-2189 | 1 | Plug-Thread, Straight |
| 22 | 114-1680 | 1 | Plate-Bypass |
| 23 | 109-3321 | 1 | Element-Oil Filter, HYD |
| 26 | 114-1683 | 2 | Seal-Plug |
| 27 | 114-1684 | 3 | Screw-Hfhc |
| 30 | 106-8676 | 1 | Seal-Lip |
| 31 | 106-8677 | 1 | Ring-Retaining, EXT |
| 32 | 114-1685 | 1 | Rod-Bypass |
| 33 | 106-8679 | 1 | Ring-Retaining, Int |
| 34 | 107-2490 | 1 | Arm-Bypass |
| 35 | 106-8681 | 1 | Ring-Retaining, EXT |
| 40 | 104-5304 | 1 | Swashplate-Trunnion |
| 41 | 104-5313 | 1 | Seal-Lip |
| 42 | 104-2116 | 1 | Stud |
| 43 | 112-9853 | 1 | Puck-Friction |
| 44 | 106-8747 | 1 | Arm-Control |
| 45 | 114-8491 | 1 | Washer |
| 46 | 107-2488 | 1 | Screw |
| 47 | 105-1872 | 1 | Nut |
| 52 | 114-1687 | 1 | Shaft-Input |
| 53 | 104-5311 | 1 | Bearing-Ball |
| 54 | 104-5307 | 1 | Ring-Retaining |
| 55 | 104-5308 | 1 | Spacer |
| 56 | 104-5310 | 1 | Seal-Lip |
| 57 | 104-5309 | 1 | Ring-Retaining |
| 60 | 114-1688 | 1 | Bearing-Thrust |
| 64 | 114-1689 | 1 | Motor Cylinder Block Kit |
| 65 | 94-6922 | 1 | Bearing-Thrust |
| 69 | 110-8561 | 1 | Pump Block ASM |
| 70 | 104-5339 | 1 | Washer-Flat |
| 71 | 104-5340 | 1 | Ring-Retaining |
| 72 | 114-1690 | 1 | Gear-14T |
| 73 | 114-1691 | 1 | Shaft-Motor |
| 74 | 104-5360 | 1 | Washer-Shaft, Motor |
| 80 | 94-1933 | 2 | Washer |
| 81 | 114-1692 | 1 | Gear-45T |
| 82 | 114-1693 | 1 | Gear-11T |
| 83 | 104-5329 | 1 | Pin-Jackshaft |
| 90 | 104-2169 | 1 | Ring-Retaining |
| 91 | 114-1694 | 1 | Gear-54T |
| 92 | 114-1695 | 1 | Spacer |
| 93 | 114-1696 | 1 | Bearing-Ball |
| 95 | 104-2143 | 1 | Bearing-Ball |
| 96 | 104-2144 | 1 | Seal |
| 97 | 109-5939 | 1 | Hub Kit |
| 99 | 109-3536 | 1 | Nut-Hub |
| 100 | 114-1697 | 1 | Pawl-Brake |
| 101 | 117-5360 | 1 | Shaft-Brake |
| 102 | 114-1699 | 1 | Handle-Brake |
| 103 | 114-8450 | 1 | Clip-Retaining |
| 105 | 104-2120 | 3 | Screw |
| 106 | 114-8473 | 1 | Guard-Filter, LH |
| 111 | 109-3278 | 1 | Adapter-Straight |
| 120 | 114-8453 | 1 | Fan-7.0 |
| 121 | 114-8454 | 1 | Pulley-5.0 Inch |
| 122 | 104-2168 | 1 | Nut-Hex |
| 123 | 107-9122 | 1 | Washer-Slotted |
| 130 | 114-8455 | 2 | Tube-Connecting |
| 131 | 104-2122 | 1 | Gerotor ASM |
| 132 | 109-3540 | 1 | O-Ring-Seal |
| 133 | 114-8457 | 1 | Cover-Charge Pump |
| 134 | 104-2120 | 2 | Screw |
| 200 | 109-3537 | 1 | Complete Seal Kit |
| 201 | 114-8476 | 1 | LH Center Section Kit |
| 202 | 114-8464 | 1 | Charge Relief Kit |
| 203 | 114-8465 | 1 | Charge Kit |
| 207 | 109-5938 | 1 | Fan And Pulley Kit |
| 209 | 114-8467 | 1 | Hub-Puller, 4 Bolt |
| 210 | 117-5361 | 1 | Shaft Input Kit |
| 211 | 117-5362 | 1 | Arm Control Kit |
| 212 | 114-8470 | 1 | Axle Shaft Kit |




# Seat Assembly

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | 117-5320-03 | 1 | Pan-Seat |
| 2 | 115-5053 | 1 | 18 Inch Seat ASM |
| 2:5 | 119-3307 | 1 | Armrest Kit |
| 3 | 701178 | 3 | Cap-Protector |
| 4 | 3234-47 | 3 | Screw-HHF |
| 5 | 92-7054 | 3 | Spring-Compression |
| 6 | 104-8300 | 3 | Nut-Flange, NI |
| 7 | 115-4966 | 1 | Rod-Stop |
| 8 | 3290-250 | 2 | Pin-Hair |
| 9 | 115-9630 | 1 | Decal-Maintenance |
| 10 | 115-9623 | 1 | Latch-Seat |
| 11 | 115-9624 | 1 | Spring-Compression |
| 12 | 1-513658 | 2 | Bumper |
| 13 | 117-5307 | 1 | Washer-Seat |
| 14 | 323-4 | 1 | Screw-HH |





# Engine, Muffler and Clutch Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | | 1 | Engine-Kohler, Ps-Sv820-0015 ●■ |
| 1:1 | 110-6697 | 2 | Gasket-Exhaust |
| 1:3 | 281-2 | 1 | Plug-Pipe, SQH |
| 2 | 3274-10 | 4 | Screw-HSH |
| 3 | 117-7463 | 1 | Muffler-Twin, Kohler |
| 4 | 115-2568 | 1 | Pulley-Engine |
| 5 | 117-1269-03 | 1 | Bracket-Stop, PTO |
| 6 | 117-1252 | 1 | Clutch-PTO |
| 7 | 3253-4 | 4 | Washer-Lock |
| 8 | 3212-11 | 1 | Screw-HH |
| 9 | 32144-109 | 4 | Screw |
| 11 | 104-8300 | 1 | Nut-Flange, NI |
| 12 | 117-1261 | 1 | Oil Drain Hose ASM |
| 14 | 110-9981 | 2 | Washer-Plain |
| 15 | 3234-47 | 1 | Screw-HHF |
| 17 | 117-5330-03 | 1 | Shield-Heat |
| 19 | 32144-70 | 4 | Screw-HWHTF |
| 20 | 614249 | 1 | Strap-Tie |


● Not serviced separately

■ Obtain parts from www.kohlerplus.com





# Fuel Delivery System

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | 115-9620 | 1 | 5 Gallon Fuel Tank ASM |
| 1:1 | 115-2564 | 1 | Tube-Drop |
| 1:2 | 46-6560 | 1 | Bushing |
| 2 | 115-9601 | 1 | Cap-Fuel, Vented |
| 3 | 109-0299 | 1 | Hose-Fuel |
| 4 | 2412-98 | 2 | Clamp |
| 5 | 115-2620 | 1 | Rod-Tank, Gas |
| 6 | 46-8560 | 1 | Screw-HHFTF |
| 7 | 117-1298 | 1 | Seal-Tank |




# Body and Styling Assembly


| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 1 | 115-2581 | 1 | Pod-RH |
| 2 | 115-2582 | 1 | Pod-LH |
| 3 | 115-9631 | 1 | Decal-Panel, Control |
| 4 | 117-1196 | 1 | Cable-Throttle |
| 5 | 3258-166 | 4 | Screw-PRH |
| 6 | 107069 | 4 | Clip |
| 7 | 115-2591-03 | 1 | Panel-Control |
| 8 | 112-4004 | 6 | Screw-Shoulder |
| 12 | 614249 | 1 | Strap-Tie |




# Electrical Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 104-2493 | 1 | Battery |
| 2 | 117-2221 | 1 | Switch-Ignition |
| 3 | 63-8360 | 1 | Key-Ignition |
| 4 | 93-9998 | 1 | Switch-PTO |
| 5 | 110-6765 | 2 | Switch-Single Pole No |
| 6 | 100-3524 | 1 | Switch-Seat |
| 7 | 117-1197 | 1 | Solenoid |
| 8 | 117-5342 | 1 | Cable-Battery, Positive |
| 9 | 117-7240 | 1 | Cable-Battery, Negative |
| 10 | 117-7313-01 | 1 | Strap-Battery |
| 11 | 321-4 | 2 | Screw-HH |
| 12 | 117-7243 | 1 | Harness-Wire |
| 12:1 | 109103 | 1 | Fuse-Blade, 30 Amp |
| 12:2 | 109102 | 1 | Fuse-Blade, 25 Amp |


| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 12:3 | 100-4918 | 1 | Diode |
| 13 | 3256-22 | 2 | Washer-Flat |
| 14 | 32144-1 | 5 | Screw-Taptite |
| 15 | 92-6989 | 1 | Wire-21 Inch |
| 16 | 32128-33 | 3 | Nut-HF |
| 17 | 98-7249 | 1 | Relay |
| 18 | 46-8560 | 2 | Screw-HHFTF |
| 19 | 3220-2 | 2 | Nut-Jam |
| 22 | 1-513374 | 1 | Meter-Hour |
| 23 | 117-7255 | 1 | Switch-Plunger W/Cover |
| 24 | 117-1283-03 | 1 | Tray-Battery |
| 25 | 1-633651 | 1 | Bolt-Holddown |
| 26 | 1-543792 | 1 | Wingnut |




# 48 Inch Deck Assembly


| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 119-3383 | 1 | 48 Inch Deck And Decal ASM |
| 2 | 117-7396-03 | 1 | Cover-Belt, 48 Inch (RH) |
| 3 | 117-7397-03 | 1 | Cover-Belt, 48 Inch (LH) |
| 4 | 32144-70 | 2 | Screw-HWHTF |
| 5 | 115-2622 | 2 | Link-Lift |
| 6 | 3256-26 | 2 | Washer-Flat |
| 7 | 1-806005 | 2 | Pin-Hair |
| 8 | 112-3977 | 3 | Bolt-Shoulder |
| 9 | 104-8301 | 3 | Nut-Flange, NI |
| 10 | 1-603299 | 3 | Roller-Scalp, Anti |
| 11 | 117-7367-03 | 1 | Plate ASM |
| 12 | 115-2470 | 2 | Pin-Latch |
| 13 | 101853 | 2 | Spring-Compression |
| 14 | 3256-24 | 2 | Washer-Flat |
| 15 | 3272-10 | 2 | Pin-Cotter |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 16 | 3256-68 | 2 | Washer-Flat |
| 17 | 114-1648-03 | 1 | Bracket-Deflector, Upper |
| 18 | 117-1270 | 1 | Deflector-Molded |
| 19 | 115-5048-03 | 1 | Plate-Deflector |
| 20 | 117-7418-03 | 1 | Baffle-Cutoff |
| 21 | 3230-3 | 4 | Screw-CARR |
| 22 | 3230-22 | 4 | Screw-CARR |
| 23 | 104-8300 | 8 | Nut-Flange, NI |
| 24 | 109-8854 | 1 | Pin-Chute |
| 25 | 115-9641 | 1 | Spring-Torsion |
| 26 | 95-2747 | 2 | Fitting-Washout |
| 27 | 46-6290 | 2 | O-Ring, Seal |
| 28 | 46-8560 | 4 | Screw-HHFTF |
| 29 | 95-3270 | 1 | Connector-Hose |
| 30 | 119-3382 | 1 | Decal-Deck, 48 Inch |
| 31 | 93-7009 | 1 | Decal-Danger, Deflector |




# 48 Inch Deck Decal Assembly No. 119-3383

| *Ref.* | *Part Number* | *Qty.* | *Description* |
|---|---|---|---|
| 2 | 114-1606 | 2 | Decal-Danger, Pulley |
| 3 | 93-7009 | 1 | Decal-Danger, Deflector |
| 4 | 110-6691 | 2 | Decal-Danger |
| 5 | 112-9840 | 1 | Decal-Scalp, Anti |
| 6 | 117-1194 | 1 | Decal-Routing, Belt |
| 7 | 322-2 | 1 | Screw-HH |
| 8 | 104-8300 | 1 | Nut-Flange, NI |




# 48 Inch Deck Spindle and Belt Drive Assembly

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 1 | 7-4150 | 3 | Washer |
| 2 | 117-1250 | 3 | Spindle ASM |
| 2:2 | 104-6325 | 2 | Bearing-Ball |
| 2:3 | 115-2641 | 1 | Spacer-Bearing |
| 3 | 32144-41 | 18 | Screw-Taptite |
| 4 | 117-7210 | 3 | Shield-Bearing |
| 5 | 115-2642 | 3 | Shaft-Spindle |
| 6 | 117-7326 | 3 | Pulley |
| 7 | 1-603401 | 1 | Spacer-Fender |
| 8 | 117-7277-03 | 3 | Blade-Hi Flow, 16.50 Inch |
| 9 | 22-8520 | 3 | Washer-Belleville |
| 10 | 51-4060 | 3 | Screw-Blade |
| 11 | 3219-7 | 3 | Nut-Hex |

| Ref. | Part Number | Qty. | Description |
|---|---|---|---|
| 12 | 110-9981 | 3 | Washer-Plain |
| 13 | 114-0463 | 2 | Washer-Friction, Composite |
| 14 | 1-413088 | 1 | Bushing-Lever, Lift |
| 15 | 115-5054 | 1 | Idler Arm ASM |
| 16 | 323-10 | 1 | Screw-HH |
| 17 | 104-8301 | 3 | Nut-Flange, NI |
| 18 | 115-2577 | 3 | Bushing-Idler |
| 19 | 1-603843 | 3 | Pulley-Idler |
| 20 | 3231-6 | 1 | Screw-CARR |
| 21 | 80-6990 | 2 | Washer-Hardened |
| 22 | 323-9 | 3 | Screw-HH |
| 23 | 108-4056 | 1 | Spring-Extension |
| 24 | 117-7325 | 1 | V-Belt |

# Attachments and Accessories

## For 74830 TITAN ZX4800 Zero-Turn-Radius Riding Mower

| Product Name | Model/Part |
|---|---|
| Hitch Kit | 117-5315 |
| Step Kit | 117-5316 |
| Light Kit | 117-5317 |
| Sunshade | 117-5318 |
| Transport Seat Hold Down Kit | 117-7251 |
| 48in Bagger Finishing Kit | 119-3319 |
| 48in Recycler Kit | 119-3320 |
| Bagger | 79326 |

## Notes:




**Count on it.**