



Hydrostat Repair Kit

Reelmaster® 5010 Series Traction Unit

Model No. 120-6285

Form No. 3369-808 Rev A

Installation Instructions

If system testing or inspections indicate that the hydrostat has been damaged, perform the following repair steps:

1. Clean all exterior components, mark hydraulic lines and remove the hydrostat assembly as outlined in the the *Toro Service Manual*.
2. Place the hydrostat in a suitable fixture and prepare to disassemble.
3. Use the *Repair Instructions Sauer Danfoss LPV Piston Pumps Manual* to perform the hydrostat repairs.