



Count on it.

Parts Catalog

Drag Mat Carrier System

Sand/Infield Pro® 3040 and 5040 Traction Unit

Model No. 08756—Serial No. 280000001 and Up

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquid Propane

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head


STD: standard

TAP: self tapping

TTH: torx truss head


Contents

- Drag Frame Assembly 4
- Pivot Bar and Lift Arm Assembly 5
- Link Assembly No. 110-8105 6
- Attachments and Accessories 7




Drag Frame Assembly

Ref.	Part Number	Qty.	Description
1	110-1350-03	1	Drag Frame ASM
2	110-1358-03	11	Plate-Retainer, Mat
4	3231-2	8	Screw-CARR
6	104-8301	19	Nut-Flange, NI
7	323-9	11	Screw-HH
8	08758	1	Coco Drag Mat
9	08757	1	Steel Drag Mat
10	3256-24	11	Washer-Flat
13	110-8148-03	1	Plate-Skid, RH
14	114-4389	1	Decal-Regulatory
15	110-8124-03	1	Plate-Skid, LH



Pivot Bar and Lift Arm Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	110-3362	1	Pivot Bar ASM	18:2	106-5517	2	Decal-Warning, Hot Surface
2	112-1405	1	Adapter ASM	19	110-1363	2	Chain-Proof, 32 Link
2:2	27-9080	2	Bearing-Flange	20	110-8135-03	1	Pivot ASM
3	3272-17	3	Pin-Cotter	21	283-10	2	Pin-Clevis
4	99-7984	1	Knob-Soft Grip, Push-On	22	323-7	1	Screw-HH
5	98-8895	2	Spacer	23	3256-25	1	Washer-Flat
6	323-10	1	Screw-HH	24	3256-26	6	Washer-Flat
7	3296-44	5	Nut-Lock, NI	25	3272-10	2	Pin-Cotter
8	112-7695-03	1	Handle	26	3296-25	1	Nut-Lock, NI
9	3256-3	4	Washer-Flat	27	3296-48	1	Nut-Lock, NI
10	112-0038	1	Spacer	28	5-2942	2	Shackle
11	92-2651	1	Washer	29	80-2050	1	Bolt-Shoulder
12	110-8105	1	Link ASM	30	283-8	1	Pin-Clevis
13	112-7686	1	Latch	31	3290-355	1	Pin-Hair
14	283-83	2	Pin-Clevis	32	323-12	1	Screw-HH
15	323-47	2	Screw-HH	33	114-4320	1	Rod-Handle
16	99-2058	1	Spacer-Support, Handle	34	115-2090	1	Pad-Wear
17	3272-11	2	Pin-Cotter	35	3234-24	2	Screw-HHF
18	112-1408	1	Lift Arm ASM	36	104-8301	2	Nut-Flange, NI



Link Assembly No. 110-8105

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	115-6694	1	Yoke-Lift
2	110-8110	1	Spacer
3	110-8114	1	Washer
4	66-7230	1	Spring-Compression
5	3256-3	3	Washer-Flat
6	3211-12	1	Screw-HH
7	3220-3	2	Nut-HJ
8	92-7008	2	End-Rod, Female
9	110-8108	1	Rod-Link
10	32128-12	1	Nut-Lock, Flange

Attachments and Accessories

For 08756 Drag Mat Carrier System Sand/Infield Pro 3040 and 5040 Traction Unit

Product Name	Model/Part
Steel Drag Mat.....	08757
Coco Drag Mat.....	08758



Count on it.