



Count on it.

Parts Catalog

Tooth Rake

Sand Pro® 3040 and 5040

Model No. 08751—Serial No. 260000001 and Up

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquid Propane

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head


Contents

Trowel Plate Assembly 4

Lift Arm and Hanger Assembly..... 5


Link Assembly No. 110-8105 6

Attachments and Accessories 7



Trowel Plate Assembly


Ref.	Part Number	Qty.	Description
8	104-8301	26	Nut-Flange, NI
14	323-8	6	Screw-HH
15	84-2400-03	1	RH Trowel Plate ASM
16	84-2450	6	Chain-Straight, 4 Link
17	3231-22	20	Screw-CARR
18	84-2280-03	5	Rake-Finishing
19	88-8440-03	2	Plate-Tipper
20	88-8450	27	Prong
21	84-2451	4	Chain-Straight, 5 Link
22	84-2550-03	3	Trowel-Smooth
23	84-2360-03	1	LH Trowel Plate ASM
24	3256-24	69	Washer-Flat
25	3253-21	27	Washer-Lock
26	3217-7	27	Nut-Hex
27	66-0561	2	Screw-Shoulder
28	32128-12	2	Nut-Lock, Flange
29	84-2390-03	1	Center Trowel Plate ASM



Lift Arm and Hanger Assembly

Ref.	Part Number	Qty.	Description
1	112-1403	1	Adapter ASM
1:2	27-9080	2	Bearing-Flange
2	112-1408	1	Lift Arm ASM
2:2	106-5517	2	Decal-Warning, Hot Surface
3	110-3362	1	Pivot Bar ASM
4	112-0040-03	1	Handle ASM
5	110-8154	1	Latch ASM
7	104-8301	7	Nut-Flange, NI
8	3272-17	2	Pin-Cotter
9	323-7	1	Screw-HH
10	3272-11	2	Pin-Cotter
11	283-83	2	Pin-Clevis
12	3256-3	10	Washer-Flat
13	112-0038	1	Spacer
14	99-7984	1	Knob-Soft Grip, Push-On
15	110-8116	3	Spacer-Link
16	3296-25	1	Nut-Lock, NI

Ref.	Part Number	Qty.	Description
17	110-8105	1	Link ASM
18	92-2651	1	Washer
19	3296-44	1	Nut-Lock, NI
20	323-11	1	Screw-HH
21	108-2941-03	1	Hanger ASM
22	3256-26	5	Washer-Flat
23	84-2350	2	Spacer-Long
24	323-14	2	Screw-HH
25	323-15	2	Screw-HH
26	3256-25	1	Washer-Flat
27	3296-48	1	Nut-Lock, NI
29	323-10	1	Screw-HH
30	323-47	2	Screw-HH
31	98-8895	2	Spacer
33	112-7100-03	1	Pivot ASM
36	80-2050	1	Bolt-Shoulder
37	110-1364	2	Chain-Proof, 12 Link



Link Assembly No. 110-8105

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	110-8111-01	1	Yoke ASM
2	110-8110	1	Spacer
3	110-8114	1	Washer
4	66-7230	1	Spring-Compression
5	3256-3	3	Washer-Flat
6	3211-12	1	Screw-HH
7	3220-3	2	Nut-HJ
8	92-7008	2	End-Rod, Female
9	110-8108	1	Rod-Link
10	32128-12	1	Nut-Lock, Flange

Attachments and Accessories

For 08751 Tooth Rake Sand Pro 3040 and 5040

Product Name	Model/Part
Spring Rake	08752
Brush Kit	08816
Lift Arm Adapter ASM	108-9427
Weight Kit	115-4333
Hitch Pivot Kit	119-2490
Pivot Trowel	119-7158



Count on it.