
FORM NO. 3315–553 REV D

TORO®

**MODEL NO. 03434–60001 & UP**
**MODEL NO. 03435–60001 & UP**
**MODEL NO. 03436–60001 & UP**

**PARTS CATALOG**

# FIXED SUSPENSION CUTTING UNITS
## For Reelmaster 216G & 216D Traction Units





# CUTTING UNIT ASM. (Model No. 03434 Shown)

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 1 | 323–7 | Screw–HH (Use 2 capscrews on Model No. 03435) | 1 |
| 2 | 3256–26 | Washer–Flat (Use 2 washers on Model No. 03435) | 1 |
| 3 | 61–0900 | Bracket–Tensioner (Use 2 brackets on Model No. 03435) | 1 |
| 4 | 80–4280 | Pulley–Reel, 5 Blade | 1 |
| 5 | 61–3380 | V–Belt | 1 |
| 6 | 323–6 | Screw–HH | 6 |
| 7 | 302–5 | Fitting–Grease | 1 |
| 11 | 32121–36 | Pin–Roll | 4 |
| 12 | 62–5510 | Asm–Rubber Bushing | 2 |
| 13 | 52–2890 | Bushing–Flanged Nylon | 2 |
| 14 | 3296–62 | Nut–Lock | 1 |
| 15 | 57–5270 | Spring–Compression | 1 |
| 16 | 29–8870 | Washer–Flat | 1 |
| 17 | 52–2980 | Pivot–Single Point Adjust. | 1 |
| 18 | 52–3000 | Arm–Spring | 1 |
| 19 | 52–2990 | Screw–Spring Retainer | 1 |
| 20 | 3256–25 | Washer–Flat | 1 |
| 21 | 257–5 | Washer–Thrust | 4 |
| 22 | 253–84 | Seal | 1 |
| 23 | 61–0550 | Shield–Top | 2 |
| 24 | 32144–10 | Screw–HH | 6 |
| 25 | 61–1070 | Asm–Handle | 1 |
| 26 | 257–6 | Bearing–Thrust | 2 |
| 27 | 57–5260 | Pin–Single Point Adjustment | 1 |
| 28 | 93–8849 | Asm–Rear Grass Guard (Incl. Ref. 78–80) | 1 |
| 28 | 93–8817 | Asm–Rear Grass Guard (Model No. 03435 only) | 1 |
| 29 | 61–0940 | Plate–Side | 1 |
| 30 | 3253–5 | Washer–Lock | 2 |

© The TORO Company – 1995, Rev. 1997
*All Rights Reserved*

TPS

* Not Illustrated





# CUTTING UNIT ASM. (Cont.) (Model No. 03434 Shown)

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 31 | 3273−34 | Screw−Hex. Socket Hd. | 1 |
| 32 | 61−0500 | Spacer−Bearing | 1 |
| 33 | 67−9760 | Washer−Flat | 2 |
| 34 | 302−11 | Fitting−Grease | 2 |
| 35 | 3211−4 | Screw−HH | 1 |
| 36 | 3256−3 | Washer−Flat | 5 |
| 37 | 61−0610 | Guard−Side (Used on Model No. 03434 & 03436 Only) | 1 |
| 38 | 3230−20 | Bolt−Carriage | 10 |
| 39 | 76−2490 | Flange−Bearing (Lube) (Incl. Ref. #34) | 2 |
| 40 | 251−331 | Bearing | 2 |
| 41 | 76−2500 | Flange−Bearing | 2 |
| 42 | 3296−29 | Nut−Lock | 11 |
| 43 | 3217−6 | Nut | 1 |
| 44 | 61−0970 | Housing−Bedbar Adj. | 1 |
| 45 | 56−9510 | Asm−Bushing | 2 |
| 46 | 56−9520 | Bushing−Flanged | 2 |
| 47 | 57−4910 | Screw−Special | 10 |
| 48 | 62−5180 | Bedknife−7 In. Reel | 1 |
| 49 | 61−1210 | Bedbar | 1 |
| 50 | 61−1010 | Housing−Bedbar | 1 |
| 51 | 57−5190 | Screw−Adjustment | 2 |
| 52 | 3218−18 | Nut−Jam | 2 |
| 53 | 61−1950 | Washer−Bedbar | 1 |
| 54 | 3256−56 | Washer−Flat | 1 |
| 55 | 3253−4 | Washer−Lock | 1 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 56 | 322−3 | Screw−Hex. Socket Hd. | 1 |
| 57 | 12−7079 | Asm−Reel 5 Blade L.H. (Model No. 03434) | 1 |
| * | 12−7059 | Asm−Ree 5 Blade Center & R.H. (Model No. 03435 & 03436) | 1 |
| 58 | 61−0660 | Frame−Reel | 1 |
| 59 | 323−7 | Screw−HH (Use 5 screws on Model No. 03435) | 2 |
| 60 | 67−5840 | Nut−Jam | 1 |
| 61 | 27−1850 | Washer | 1 |
| 62 | 61−1320 | Plate−Side | 1 |
| 63 | 3296−45 | Nut−Lock (Use 2 nuts on Model No. 03435) | 1 |
| 64 | 302−18 | Fitting−Grease | 2 |
| 65 | 62−7120 | Spacer | 1 |
| 66 | 62−5070 | Decal−Warning (English) | 1 |
| * | 93−8064 | Decal−Warning (European) | 1 |
| 67 | 3296−39 | Nut−Lock (Use 14 nuts on Model No. 03435) | 9 |
| 68 | 76−2290 | Spacer (Use 2 spacers on Model No. 03435) | 1 |

* Not Illustrated





# CUTTING UNIT ASM. (Cont.) (Model No. 03434 Shown)

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 70 | 3229−11 | Bolt−Carriage (Model No. 03435) | 1 |
| 71 | 3255−2 | Washer−Lock E.T.L.W. (Model No. 03435) | 1 |
| 72 | 32128−21 | Nut−Flange Lock (Model No. 03435) | 1 |
| 73 | 76−2430 | Bracket−Debris Cleaner (Model No. 03435) | 1 |
| 74 | 76−2440 | Support−Debris Cleaner (Model No. 03435) | 1 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 75 | 32128−10 | Nut−Flange Lock (Model No. 03435) | 1 |
| 76 | 3247−6 | Screw−Set, Recessed Hex. | 1 |
| 77 | 3218−3 | Nut−Jam | 1 |
| 78 | 61−3290 | Cover−Center | 2 |
| 79 | 61−3280 | Cover−End | 2 |
| 80 | 700382 | Rivet−Pop | 12 |
| * | 13−3649 | Kit−Overhaul (Incl. Ref. #12, 13, 22, 26 40 & 45−47) | 1 |

* Not Illustrated





# FRONT & REAR SUPPORT ASSEMBLY

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 1 | 3−0348 | Bushing | 2 |
| 2 | 323−6 | Screw−HH (Model No. 03434 & 03436) | 2 |
| 2 | 323−6 | Screw (Model No. 03435) | 4 |
| 3 | 3296−39 | Nut−Lock (Model No. 03434 & 03436) | 3 |
| 3 | 3296−39 | Nut−Lock (Model No. 03435) | 4 |
| 4 | 302−5 | Fitting−Grease | 1 |
| 5 | 321−2 | Screw−HH | 2 |
| 6 | 3253−3 | Washer−Lock | 2 |
| 7 | 61−3600 | Tab | 1 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 8 | 92−3159 | Support−Front LH (Incl. Ref. #1 & 4) (Model No. 03434) | 1 |
| *8 | 92−3160 | Support−Front RH (Incl. Ref. #1 & 4) (Model No. 03436) | 1 |
| 9 | 323−12 | Screw−HH (Model No. 03434 & 03436) | 1 |
| 10 | 61−0670 | Support−Rear (Incl. Ref. #1 & 4) (Model No. 03435) | 1 |
| * | 63−5330 | Chain−3 Links (Used on Model No. 03435) | 1 |

* Not Illustrated





# SKID & REAR ROLLER ASM. (Model No. 03434 Shown)

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 1 | 323−7 | Screw−HH | 3 |
| 2 | 323−6 | Screw−HH | 5 |
| 3 | 3290−467 | Cotter−Hairpin | 2 |
| 4 | 61−3810 | Plate−Height of Cut | 2 |
| 5 | 61−0790 | Screw−HH | 2 |
| 6 | 61−0420 | Support−Height of Cut | 2 |
| 7 | 3296−39 | Nut−Lock | 9 |
| 8 | 71−3690 | Pin−Height of Cut | 2 |
| 9 | 3290−55 | Rivet−Pop | 4 |
| 10 | 61−0910 | Bracket−Angle | 2 |
| 11 | 61−0380 | Cap−Roller | 2 |
| 12 | 61−0400 | Shaft−Roller | 1 |
| 13 | 253−152 | Seal−Inner | 2 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 14 | 254−79 | Cup−Bearing | 2 |
| 15 | 3231−25 | Bolt−Carriage | 2 |
| 16 | 61−0430 | Bracket−Rear | 2 |
| 17 | 56−9520 | Bushing−Flanged | 1 |
| 18 | 56−9510 | Asm−Bushing | 2 |
| 19 | 302−5 | Fitting−Grease | 2 |
| 20 | 71−3590 | Nut−Adjustment | 2 |
| 21 | 253−153 | Seal−Outer | 2 |
| 22 | 254−78 | Cone−Bearing | 2 |
| 23 | 61−0650 | Skid | 2 |
| * | 61−0410 | Asm−Roller (Incl. Ref. #11−14,19−22) | 1 |

* Not Illustrated




T−2422

# CUTTING UNIT ROLLER OPTIONS

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 1 | 62−4990 | Shaft−Anti−Scalp Roller | 1 |
| 2 | 76−2380 | Shaft−Sectional Roller | 1 |
| 3 | 82−2400 | Wiehle Roller | 1 |
| 4 | 61−0400 | Shaft−Full/Wiehle Roller | 1 |
| 5 | 254−79 | Cup−Bearing (Outer) | 6 |
| 6 | 254−78 | Cone−Bearing (Outer) | 4 |
| 7 | 253−153 | Seal−Outer | 4 |
| 8 | 71−3590 | Nut−Adjustment | 6 |
| 9 | 302−5 | Fitting−Grease | 6 |
| 10 | 76−2400 | Roller−Sectional | 2 |
| 11 | 252−112 | Cone−Bearing (Inner) | 2 |
| 12 | 3−6498 | Washer−Thrust | 4 |
| 13 | 256−117 | Bushing−Flanged | 4 |
| 14 | 63−5060 | Roller−Anti−Scalp | 2 |
| * | 62−7410 | Asm−Wiehle Roller (Incl. Ref. #2, 4−5 & 7−10) | 1 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| * | 62−4970 | Asm−Sectional Roller (Incl. Ref. #4−5, 7−9, 12, 14 & 18) | 1 |
| * | 63−5090 | Asm−Anti−Scalp Roller (Incl. Ref. #8−9, 11 & 15−17) | 1 |
| * | 03440 | Kit−Full Roller (Incl. 3 No. 61−0410) | 1 |
| * | 03450 | Kit−Wiehle Roller (Incl. 3 No. 92−1846) | 1 |
| * | 03445 | Kit−Sectional Roller (Incl. 3 No. 62−4970) | 1 |
| * | 03447 | Kit−Anti−Scalp Roller (Incl. 3 No. 63−5090) | 1 |
| * | 03446 | Kit−Front Skid (Incl. 3 Assemblies) | 1 |

* Not Illustrated

## PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

## COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

# MAINTENANCE RECORD

| Date | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |

# MAINTENANCE RECORD

| Date | | | | | | | | |
|---|---|---|---|---|---|---|---|---|
| | | | | | | | | |
| | | | | | | | | |
| | | | | | | | | |