



Count on it.

Parts Catalog

Tooth Rake

**Sand Pro®/Infield Pro® 3040 and 5040
Traction Unit**

Model No. 08751—Serial No. 310000001 and Up

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquid Propane

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head


STD: standard

TAP: self tapping

TTH: torx truss head


Contents

- Trowel Plate Assembly 4
- Lift Arm and Hanger Assembly..... 5
- Link Assembly No. 110-8105 6
- Attachments and Accessories 7




Trowel Plate Assembly

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
8	104-8301	26	Nut-Flange, NI	22	84-2550-03	3	Trowel-Smooth
14	323-8	6	Screw-HH	23	84-2360-03	1	LH Trowel Plate ASM
15	84-2400-03	1	RH Trowel Plate ASM	24	3256-24	69	Washer-Flat
16	84-2450	6	Chain-Straight, 4 Link	25	3253-21	27	Washer-Lock
17	3231-22	20	Screw-CARR	26	3217-7	27	Nut-Hex
18	84-2280-03	5	Rake-Finishing	27	66-0561	2	Screw-Shoulder
19	88-8440-03	2	Plate-Tipper	28	32128-12	2	Nut-Lock, Flange
20	88-8450	27	Prong	29	84-2390-03	1	Center Trowel Plate ASM
21	84-2451	4	Chain-Straight, 5 Link				



Lift Arm and Hanger Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	112-1403	1	Adapter ASM	19	3296-44	2	Nut-Lock, NI
1:2	27-9080	2	Bearing-Flange	20	323-10	1	Screw-HH
2	112-1408	1	Lift Arm ASM	21	108-2941-03	1	Hanger ASM
2:2	106-5517	2	Decal-Warning, Hot Surface	22	3256-26	4	Washer-Flat
3	110-3362	1	Pivot Bar ASM	23	84-2350	2	Spacer-Long
4	112-7695-03	1	Handle	24	323-14	2	Screw-HH
5	112-7686	1	Latch	25	323-15	2	Screw-HH
7	104-8301	7	Nut-Flange, NI	26	51-3500	3	Washer
8	3272-17	2	Pin-Cotter	27	104-8301	1	Nut-Flange, NI
9	323-7	1	Screw-HH	29	323-12	1	Screw-HH
10	3272-11	2	Pin-Cotter	30	323-47	2	Screw-HH
11	283-83	2	Pin-Clevis	31	98-8895	2	Spacer
12	3256-3	10	Washer-Flat	33	119-2471-03	1	Hitch-Pivot, Rake
13	112-0038	1	Spacer	34	114-4320	1	Rod-Handle
14	99-7984	1	Knob-Soft Grip, Push-On	36	1-603403	1	Bolt-Shoulder
15	99-2058	1	Spacer-Support, Handle	37	110-1364	2	Chain-Proof, 12 Link
16	3296-25	1	Nut-Lock, NI	39	115-2090	1	Pad-Wear
17	110-8105	1	Link ASM	40	3234-24	2	Screw-HHF
18	92-2651	1	Washer	41	104-8301	2	Nut-Flange, NI



Link Assembly No. 110-8105

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	110-8111-01	1	Yoke ASM
2	110-8110	1	Spacer
3	110-8114	1	Washer
4	66-7230	1	Spring-Compression
5	3256-3	3	Washer-Flat
6	3211-12	1	Screw-HH
7	3220-3	2	Nut-HJ
8	92-7008	2	End-Rod, Female
9	110-8108	1	Rod-Link
10	32128-12	1	Nut-Lock, Flange

Attachments and Accessories

For 08751 Tooth Rake Sand Pro/Infield Pro 3040 and 5040 Traction Unit

Product Name	Model/Part
Spring Rake	08752
Brush Kit	08816
Lift Arm Adapter ASM	108-9427
Weight Kit	115-4333
Hitch Pivot Kit	119-2490
Pivot Trowel	119-7158



Count on it.