

Count on it.

Parts Catalog

SGR-6 Stump Grinder

Model No. 22601—Serial No. 310000001 and Up

Model No. 22610—Serial No. 311000001 and Up

Model No. 22610G—Serial No. 311000001 and Up

Register at www.Toro.com. Original Instructions (EN)

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise
DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external
FH: flat head
GA: gauge
HD: heavy-duty
HF: hex flange
HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread

forming **HJ**: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head HSFH: hex socket flat head HSH: hex socket head HWH: hex washer head

HWHTF: hex washer head thread

forming

HYD: hydraulic
LH: left hand
LP: Liquid Propane

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head **PPH:** phillips pan head

PPHTF: phillips pan head thread

forming

PRH: phillips round head PTH: phillips truss head PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush
SFH: slotted fillister head
SHH: slotted hex head

SHWH: slotted hex washer head


SPH: slotted pan head **SQH**: square head

SRH: slotted round head

STD: standard
TAP: self tapping
TTH: torx truss head

Contents

Engine and Frame Assembly	4
Handle Assembly	5
Cutter Wheel Assembly	
Brake and Wheel Assembly	
Flap Assembly	
Belt Drive Assembly	9
Attachments and Accessories	




Engine and Frame Assembly

Ref.	Part Number	Qty.	Description
1		1	Engine-Honda, Gx200Ut Qxc9 ● ■
2	120-1317-01	1	Frame ASM
3	3256-45	4	Washer-Flat
4	3296-29	4	Nut-Lock, NI
5	3230-4	4	Screw-CARR
6	112-2605	1	Grip-Rubber
7	119-4729	1	Screw-Set, SQH
8	3217-7	1	Nut-Hex
9	120-1795	1	Bar-Axle, Wheel
10	119-4690	1	Decal-Danger
11	119-4693	1	Decal-Caution
12	98-3206	1	Decal
13	120-1887	1	Plug-Engine
17	112228	1	Spring-Extension


Not serviced separately

[■] Obtain parts from www.honda-engines.com



Handle Assembly


	5 (1)	-	5		5 (1)		.
Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	120-1323-01	1	Lower Handle ASM	16	3296-29	2	Nut-Lock, NI
2	120-1322-01	1	Upper Handle ASM	17	322-11	1	Screw-HH
3	120-1324	1	Gasket-Handle	18	107675	2	Washer
4	109-1092	1	Knob	19	1-803071	2	Screw
5	120-1302	3	Plug-Tube	20	1-633181	1	Plate-Tapped
6	120-1355-03	1	Plunger Handle ASM	21	116-0606	1	Screw-Torx
7	120-1359-03	1	Throttle Handle ASM	22	3296-42	1	Nut-Lock, NI
8	120-1333	2	Handle-Grip	23	119-4691	1	Decal-Caution
9	120-1292	1	Switch-Plunger, Nc	24	119-4722	1	Decal-Engage
			(W/Cover)	25	104-7048	1	Cap-Housing
10	120-1375	1	Cable-Throttle	26	104-7050	1	Tube-Manual
11	120-1369	1	Harness-Wire	27	2412-120	2	R-Clamp
12	324-6	2	Screw-HH	28	3269-17	2	Rivet-Pop
13	3256-4	4	Washer-Flat	29	120-0909	1	Screw-HSH
14	3296-48	2	Nut-Lock, NI	30	3218-3	1	Nut-Jam
15	322-10	1	Screw-HH	31	117-2718	1	Decal-Arrester, Spark



Cutter Wheel Assembly


Ref.	Part Number	Qty.	Description
1	120-1373	2	Bearing ASM
2	323-8	12	Screw-HH
3	71-9310	8	Spacer
4	104-8301	12	Nut-Flange, NI
5	120-1372	1	Blade Shaft ASM
6	120-1370-03	1	Plate-Flange, Shaft
7	119-4702-03	4	Blade-Grinder
7:2	119-4705	3	Tip-Carbide

C0




Brake and Wheel Assembly

Ref.	Part Number	Qty.	Description
1	120-1288	2	Tire ASM
2	120-1295	1	Hub
2:1	120-1296	2	Bearing-Wheel
3	120-1304	8	Nut-Wheel
4	120-1296	2	Bearing-Wheel
5	120-1325-03	1	Brake Hub ASM
6	120-1294	2	Collar-Set
7	3246-2	2	Screw-Set, HSH
8	120-1309-01	1	Handle-Brake
9	119-0222	1	Grip
10	32121-6	1	Pin-Roll, Slotted
11	32121-25	1	Pin-Roll
12	119-4741	1	Cap-Lower
13	119-4742	1	Cap-Upper



Flap Assembly

Ref.	Part Number	Qty.	Description
1	120-1311	1	Flap-Rear
2	120-1312	1	Flap-Right
3	120-1313	1	Flap-Wing
4	120-1314	1	Flap-Wing, Rear
5	120-1315-01	4	Plate-Mounting, Flap
6	120-1316-01	1	Plate-Mounting, Flap (Rear)
7	322-5	11	Screw-HH
8	3296-29	11	Nut-Lock, NI



Belt Drive Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	120-1215	1	Clutch-Centrifugal		3256-38	2	Washer-Flat
2	63-8410	1	Washer	12	120-1326-01	1	Plate-Guard, Inner
3	3256-2	1	Washer-Flat	13	120-1332	2	Spacer-Guard, Belt
4	3210-3	1	Screw-HH	14	3234-47	2	Screw-HHF
5	7-0036	2	Key-Square	15	3296-29	2	Nut-Lock, NI
6	120-1303	1	Pulley-Front	16	120-1344-01	1	Outer Belt Guard ASM
6:1	3246-3	1	Screw-HSH	17	119-4692	1	Decal-Caution
7	120-1374	1	Belt-Drive	18	117-4979	1	Decal-Warning, Shields (Ce)
8	323-6	3	Screw-HH	19	120-1815	1	Decal
9	3247-8	1	Screw-Set, HSH	20	119-4723	1	Decal
10	3296-39	1	Nut-Lock, NI	21	3256-8	2	Washer-Flat

Attachments and Accessories

For 22610 SGR-6 Stump Grinder

Product Name	Model/Part
Stump Grinder Blade Tote	
Blade Tote (Set of 6. Sharpened)	



