FORM NO. 3318−857 REV A


TORO®

MODEL NO. 03870−60268 & UP

PARTS CATALOG

DETHATCHING CUTTING UNITS

Reelmaster® 6500D & 6700D




REEL & FRAME ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93−2976	Dethatcher Shaft Assembly (Incl. Ref. #24 & 30)	1
2	94−2710	Bearing & Collar Assembly	2
3	94−2708	Housing − Bearing	2
4	93−7522	Screw − Cap Hex. Hd.	2
5	33105−030	Screw − Cap Hex. Hd.	4
6	93−9783	Seal − O−Ring	2
7	94−2703	Plug	1
8	32121−69	Pin − Spring	4
9	302−5	Fitting − Grease	2
10	94−2719	Plate − Side LH	1
11	33105−025	Screw − Cap Hex. Hd.	8
12	33104−020	Screw − Cap Hex. Hd.	2
13	32121−36	Pin − Roll	4
14	93−2881	Shield − Grass Rear	1
15	94−2709	Frame − Reel	1
16	33025−00	Nut − Lock	8

Ref. No.	Part No.	Description	No. Used
17	94−8942	Front Grass Shield Assembly (Incl. Ref. #18)	1
18	67−7960	Decal − Danger	1
19	94−2718	Plate − Side RH	1
20	94−4347	Weight − End	1
21	93−8717	Plug	1
22	33105−060	Screw − Cap Hex. Hd.	2
23	94−2747	Tab − Stop	1
24	94−2732	Insert − Threaded RH	1
25	93−3038	Blade	16
26	93−3092	Spacer	15
27	94−2720	Spacer	15
28	93−3091	Spacer − End	1
29	3218−17	Nut − Hex.	1
30	94−2733	Insert − Threaded LH	1
*	94−4346	Dethatcher Spacer Kit (Incl. 4 ea. #25 & 26, and 15 ea. #27)	1

*Not Illustrated

© The TORO Company − 1998
All Rights Reserved



T−2305−4

ROLLER ASSEMBLIES

Ref. No.	Part No.	Description	No. Used
1	94−2702	Bolt	2
2	94−2701	Washer	2
3	94−2745	Spacer − Frame	2
4	93−3063	Carrier Frame Assembly (Incl. Ref. #32)	1
5	93−3040	Roller Assembly (Incl. Ref. #18 & 34−42)	2
6	94−6983	Scraper − Roller	2
7	94−4307	Nut − Hex. Lock	4
8	33105−025	Screw − Cap Hex. Hd.	4
9	32128−20	Nut − Flange Lock	4
10	32128−25	Nut − Flange Lock	4
11	94−4332	Bracket − H.O.C. Front LH	1
*	94−4333	Bracket − H.O.C. Front RH	1
12	94−6979	Bracket − Scraper LH	2
*	94−6978	Bracket − Scraper RH	2
13	33105−020	Screw − Cap Hex. Hd.	4
14	93−9757	Screw − Cap Hex. Hd.	4
15	33025−00	Nut − Lock	8
18	302−5	Fitting − Grease	6
19	93−3036	Mount − H.O.C.	2

Ref. No.	Part No.	Description	No. Used
20	93−3034	Bracket − H.O.C. Rear	2
21	93−3039	Knob	2
22	32121−50	Pin − Roll	2
23	256−159	Bushing − Sleeve	2
24	93−3046	Shaft − H.O.C.	2
25	3257−1	Key − Woodruff	2
26	94−2742	Spring − Compression	2
27	33096−00	Washer − Flat	2
31	283−71	Pin − Lynch	1
32	93−2877	Bushing − Flange	2
33	32105−030	Screw − Cap Hex. Hd.	4
34	32120−62	Ring − Retaining	2
35	93−2931	Washer − Roller	2
36	253−70	Seal − Oil	2
37	93−1252	Seal − Outer	2
38	93−1251	Seal − Inner	2
39	109966	Bearing − Ball	2
40	93−3007	Seal − Oil	2
41	93−2887	Shaft − Roller	1
42	93−3041	Roller Tube Assembly	1
43	95−0796	Spacer	2

*Not Illustrated