FORM NO. 3319–108

TORO®

PART NO. 94–9100

PARTS CATALOG


CE COMPLIANCE KIT
GREENS AERATOR

INTERNATIONAL PARTS REFERENCE
EUROPEAN PARTS KIT NO. 94–9100

DESCRIPTION	LOCATION	ENGLISH PART NO.	EUROPEAN PART NO.	QTY.
Decal C.E.	–	–	93–7252	1
Decal Danger	Coring Head Cover	59–9930	93–9884	1
Decal Refueling	Fuel Tank	27–7310	93–7822	1
Decal Shift	Air Cleaner Cover	66–9050	93–9887	1
Decal Start	Air Cleaner Cover	66–9110	93–9888	1
Decal Break–In	Fuel Tank	94–8076	93–9892	1
Decal Danger	Battery	76–1660	93–7276	1
Decal Battery Charging	Battery	–	93–6668	1
Decal Control	Control Panel	80–3910	93–9893	1
Decal Brake	Control Handle	59–9860	93–9890	1
Decal Interlock	Interlock Handle	59–9870	93–9891	2
Decal Warning	Hood Supports	–	94–2586	2
Decal Warning	Hood Supports	–	94–2587	2
Decal Warning	Pulley Guard	94–9111	93–6696	1
Decal Danger	Frame Arms	67–5360	93–9883	2
Decal Danger	Coring Head Frame	67–5360	93–9883	1

© The TORO Company – 1996
All Rights Reserved

3319–108




T–2552

COVER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3230–1	Screw – Carriage	9
2	3256–2	Washer – Flat	9
3	3296–47	Nut – Lock	9
4	94–9123	Support – Hood, LH	1
5	94–9114	Cover – Welded	1
6	65–5100	Handle – Hood	1
7	46–8091	Screw – Tapping	2
8	93–9893	Decal – Control	1
9	322–3	Screw – HH	1
10	3253–4	Washer – Lock	1
11	3256–23	Washer – Flat	1
12	93–7170	Cap – Fuel	1
13	5–1254	Washer	4
14	3290–55	Rivet – Pop	4
15	3234–1	Screw – HFHL	4
16	94–3400	Shield	1
17	94–9124	Support – Hood, RH	1
18	93–7822	Decal – Refueling	1

Ref. No.	Part No.	Description	No. Used
19	94–2586	Decal – Warning	2
20	94–1798	Bracket – Side	2
21	46–6811	Screw – HHF	2
22	321–4	Screw – HH	8
23	94–9118	Rod – Hinge	2
24	323–6	Screw – HH	4
25	3253–5	Washer – Lock	4
26	94–9119	Hinge	2
27	32128–33	Nut – Lock, Flange	8
28	94–9122	Retainer	2
29	94–2587	Decal – Warning	2
30	93–9884	Decal – Danger	1
31	3272–6	Pin – Cotter	2
32	3256–25	Washer – Flat	2
33	94–9115	Lever – Support, Transport	2
34	233–42	Knob	2
35	93–9892	Decal – Break–In	1




T–2553

DECAL PLACEMENT

Ref. No.	Part No.	Description	No. Used
1	93–9887	Decal – Shift	1
2	93–9888	Decal – Start	1
3	93–6696	Decal – Warning	1
4	93–9890	Decal – Brake	1
5	93–9891	Decal – Interlock	2

Ref. No.	Part No.	Description	No. Used
6	93–7276	Decal – Danger	1
7	93–6668	Decal – Instructions, Battery Charging	1
8	93–9883	Decal – Warning	2
9	93–9892	Decal – Break–In	1

3319–108



T–2554

DECAL PLACEMENT – FRAME

Ref. No.	Part No.	Description	No. Used
1	93–9883	Decal – Warning	1

Ref. No.	Part No.	Description	No. Used