




PART NO. 94—9100

PARTS
CATALOG
CE COMPLIANCE KIT
GREENS AERATOR
INTERNATIONAL PARTS REFERENCE
EUROPEAN PARTS KIT NO. 94—9100

DESCRIPTION	LOCATION	ENGLISH PART NO.	EUROPEAN PART NO.	QTY.
Decal C.E.	—	—	93—7252	1
Decal Danger	Coring Head Cover	59—9930	93—9884	1
Decal Refueling	Fuel Tank	27—7310	93—7822	1
Decal Shift	Air Cleaner Cover	66—9050	93—9887	1
Decal Start	Air Cleaner Cover	66—9110	93—9888	1
Decal Break—In	Fuel Tank	94—8076	93—9892	1
Decal Danger	Battery	76—1660	93—7276	1
Decal Battery Charging	Battery	—	93—6668	1
Decal Control	Control Panel	80—3910	93—9893	1
Decal Brake	Control Handle	59—9860	93—9890	1
Decal Interlock	Interlock Handle	59—9870	93—9891	2
Decal Warning	Hood Supports	—	94—2586	2
Decal Warning	Hood Supports	—	94—2587	2
Decal Warning	Pulley Guard	94—9111	93—6696	1
Decal Danger	Frame Arms	67—5360	93—9883	2
Decal Danger	Coring Head Frame	67—5360	93—9883	1




T-2552

COVER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3230-1	Screw - Carriage	9
2	3256-2	Washer - Flat	9
3	3296-47	Nut - Lock	9
4	94-9123	Support - Hood, LH	1
5	94-9114	Cover - Welded	1
6	65-5100	Handle - Hood	1
7	46-8091	Screw - Tapping	2
8	93-9893	Decal - Control	1
9	322-3	Screw - HH	1
10	3253-4	Washer - Lock	1
11	3256-23	Washer - Flat	1
12	93-7170	Cap - Fuel	1
13	5-1254	Washer	4
14	3290-55	Rivet - Pop	4
15	3234-1	Screw - HFHL	4
16	94-3400	Shield	1
17	94-9124	Support - Hood, RH	1
18	93-7822	Decal - Refueling	1

Ref. No.	Part No.	Description	No. Used
19	94-2586	Decal - Warning	2
20	94-1798	Bracket - Side	2
21	46-6811	Screw - HHF	2
22	321-4	Screw - HH	8
23	94-9118	Rod - Hinge	2
24	323-6	Screw - HH	4
25	3253-5	Washer - Lock	4
26	94-9119	Hinge	2
27	32128-33	Nut - Lock, Flange	8
28	94-9122	Retainer	2
29	94-2587	Decal - Warning	2
30	93-9884	Decal - Danger	1
31	3272-6	Pin - Cotter	2
32	3256-25	Washer - Flat	2
33	94-9115	Lever - Support, Transport	2
34	233-42	Knob	2
35	93-9892	Decal - Break-In	1



T-2553

DECAL PLACEMENT

Ref. No.	Part No.	Description	No. Used
1	93-9887	Decal - Shift	1
2	93-9888	Decal - Start	1
3	93-6696	Decal - Warning	1
4	93-9890	Decal - Brake	1
5	93-9891	Decal - Interlock	2

Ref. No.	Part No.	Description	No. Used
6	93-7276	Decal - Danger	1
7	93-6668	Decal - Instructions, Battery Charging	1
8	93-9883	Decal - Warning	2
9	93-9892	Decal - Break-In	1

