



Count on it.

Parts Catalog

Electric Hose Reel Kit

Multi-Pro® 5600/5700 Turf Sprayer

Model No. 41569—Serial No. 310000001 and Up

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquid Propane

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head

Contents

Valve Box Assembly 4

Hardi Ball Valve Assembly No. 106-1268..... 6


Rear Assembly 7

Hose Reel Assembly 8

Spray Gun Assembly No. 100-6733 9

Hose Reel Assembly No. 106-5083 10


Hose Reel Frame Assembly No. 104-8714 11



Valve Box Assembly

Ref.	Part Number	Qty.	Description
1	32128-33	7	Nut-HF
2	106-1322-03	1	Box-Switch
3	3234-4	14	Screw-HHF
4	100-8589	1	Switch-Rocker
5	100-1535	1	Switch
6	106-1278	1	Decal-Panel, Switch
7	106-1277	1	Decal-Control, Valve
8	106-1258-03	1	Cover Plate ASM
9	120-8546	1	Gauge-Pressure
10	100-8665	1	Reducer-Gauge, Pressure
11	100-8666	1	Nut-Reducer
12	100-8667	1	Coupler-Reducer
13	106-1312	1	Tube
14	107-8764	1	Decal
15	106-1294-03	1	Bracket-Valve
16	100-8635	4	Fork
17	100-6708	1	Fork
18	110-5063	1	Hose ASM
18:1	106-4940	1	Hosebarb-90 DEG
18:1:1	100-6712	1	O-Ring
18:2	2412-129	1	Clamp-Hose


Ref.	Part Number	Qty.	Description
18:3	110-5064	1	Hose
19	2412-36	2	Clamp-Hose
20	106-4938	1	Reducer ASM
20:1	100-8637	1	O-Ring
21	104-8859	2	Hose
22	3251-1	2	Screw-PPH
23	3256-21	2	Washer-Flat
24	106-1275-03	1	Bracket-Valve
25	42046	2	Elbow-90 DEG
26	106-1265	1	Valve-Ball, Precision
27	106-1293	1	Washer-Flat
28	106-1263-03	1	Plate-Lever, Valve
29	106-1262-03	1	Valve Lever ASM
30	106-1268	1	Valve-Ball
32	107-8781	1	Hose ASM
32:1	2412-3	2	Clamp-Hose
32:2	106-4932	1	Hosebarb-Straight
32:2:1	100-8637	1	O-Ring
32:3	106-4933	1	Hosebarb ASM
32:3:1	100-8637	1	O-Ring
32:4	107-8780	1	Hose



Valve Box Assembly (continued)


Ref.	Part Number	Qty.	Description
34	92-8564	1	Knob
35	106-1256-03	1	Plate-Mount, Valve
36	3234-5	2	Screw-HHF
37	100-7050	1	Bulkhead
38	106-4932	1	Hosebarb-Straight
38:1	100-8637	1	O-Ring
39	32128-20	2	Nut-HF

Ref.	Part Number	Qty.	Description
42	119-0446	1	Hose-Agitation
43	117-7922	1	O-Ring
44	119-0499	1	Hosebarb
45	119-0516	3	Hose-Drain Valve
46	106-4933	1	Hosebarb ASM
46:1	100-8637	1	O-Ring
99	106-1307	1	Harness-Reel, Hose



Hardi Ball Valve Assembly No. 106-1268


Ref.	Part Number	Qty.	Description
1	100-6644	2	O-Ring
2	100-8671	1	O-Ring
3	100-8637	1	O-Ring
4	100-8693	2	O-Ring
5	100-8694	2	O-Ring
6	104-8857	1	Nut
7	104-8858	1	Nipple
8	100-8687	2	Cover-End, 3-Way Valve
9	100-8686	1	Spindle-Valve, 3-Way
10	100-8697	1	Ball-3 Way Valve
11	106-1323	1	Housing
12	33113-080	4	Screw-HH
13	33023-00	4	Nut-Lock
14	100-8692	8	Washer
15	100-8695	2	Seat-Ball



Rear Assembly


Ref.	Part Number	Qty.	Description
1	32128-49	1	Nut-HHF
2	3234-32	1	Screw-HHF
3	108-3402-03	1	Angle-Mount, Valve
4	106-1320	1	Trim
5	2412-3	8	Clamp-Hose
7	106-4935	4	Hosebarb ASM
7:1	100-6712	1	O-Ring
8	104-9041	2	Tee
9	100-6708	6	Fork
10	106-4934	2	Hosebarb ASM

Ref.	Part Number	Qty.	Description
10:1	100-6712	1	O-Ring
11	2412-36	2	Clamp-Hose
12	100-8674	1	Coupler-Tube
13	100-6712	1	O-Ring
14	104-9029	1	Plug
15	106-4932	1	Hosebarb-Straight
15:1	100-8637	1	O-Ring
16	106-4933	1	Hosebarb ASM
16:1	100-8637	1	O-Ring



Hose Reel Assembly


Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	100-6733	1	Sprayer-Handheld	20	42201	1	Breaker-Circuit
2	106-1233-03	1	Hand Spray Mounting ASM	22	42206	1	Harness-Wire (Solenoid To Breaker)
3	106-5083	1	Hose Reel ASM	23	3219-14	6	Nut-Hex
5	3234-11	10	Screw-HHF	24	42208	1	Harness-Wire (Switch To Solenoid)
6	32128-20	1	Nut-HF	25	107-8756	1	Hose Hose Reel ASM
7	110-5065	1	Hosebarb	26	100-3815	1	Grommet-Rubber
8	2412-36	1	Clamp-Hose	27	3234-17	1	Screw-HHF
9	106-5078	1	Harness-Wire	28	42207	1	Harness-Wire (Solenoid To Switch)
10	3217-5	2	Nut-Hex	29	42397-03	1	Electrical Box ASM
11	106-1228-03	1	Hose Reel Support ASM	31	3256-14	6	Washer-Flat
12	111674	1	Solenoid-Starter	33	32128-20	2	Nut-HF
13	32128-43	10	Nut-Flange	34	106-5089	1	Conduit-12 Inch
14	106-1227-03	2	Strap-Hose Reel	35	3290-378	10	Tie-Cable
15	107-8757	1	Decal-Reel, Hose	36	2412-129	1	Clamp-Hose
16	3250-31	6	Screw-PPH	37	105-0842	1	Spacer
17	42202	1	Switch-Momentary				
18	321-4	2	Screw-HH				
19	95-2495-03	1	Electrical Box Cover ASM				



Spray Gun Assembly No. 100-6733


Ref.	Part Number	Qty.	Description
1	100-6649	3	O-Ring
2	99-0885	1	Extension-Lance
4	99-0884	1	Seal-Valve, On/Off
5	99-0779	1	Repair Kit
6	99-0887	1	Pin
7	99-0890	1	Housing-Nozzle
8	99-0889	1	Nozzle-Ceramic
9	100-6650	1	O-Ring
10	99-0886	1	Housing-Swirl
11	100-6646	1	O-Ring
12	100-6644	1	O-Ring
13	99-0780	1	Swirl
14	99-0772	1	Clamp-Hose
15	107-8734	1	Nut-Swivel

Ref.	Part Number	Qty.	Description
16	99-0883	1	Housing-Valve
17	104-8860	1	Cone
18	104-8861	1	Sleeve-Rubber
19	100-6647	1	O-Ring
20	99-0882	1	Valve ASM
21	99-0877	1	Handle-LH
22	99-0878	1	Stop-Trigger, Rubber
23	99-0880	1	Arm-Trigger
24	99-0879	1	Arm-Safety, Trigger
25	99-0881	1	Handle-RH
26	100-6666	1	Screw
27	100-6648	1	O-Ring
28	106-5093	1	Hosebarb-Brass



Hose Reel Assembly No. 106-5083

Ref.	Part Number	Qty.	Description
1	104-8714	1	Hose Reel Frame ASM
2	104-8715	1	Chainguard-Reel, Hose
2:1	322-5	4	Screw-HH
2:2	3256-23	4	Washer-Flat
2:3	3296-29	4	Nut-Lock, NI
3	104-8799	1	Guide-Reel, Hose
3:2	104-8820	1	Bracket-Roller Guide, Right
3:3	322-5	8	Screw-HH
3:4	3256-23	8	Washer-Flat
3:5	3296-29	8	Nut-Lock, NI
3:6	104-8821	1	Bracket-Roller Guide, Left



Hose Reel Frame Assembly No. 104-8714

Ref.	Part Number	Qty.	Description
1	104-8803	1	Hose Reel Frame ASM
2	104-8804	1	Disc And Gear ASM
3	104-8805	1	Disc-Crank, Side
4	104-8806	1	Drum-Center
5	104-8807	1	Axle ASM
6	104-8808	1	Swivel ASM
6:1	104-8812	1	Ring-Retainer
6:2	104-8864	1	Swivel Seal Kit
7	104-8809	2	Block-Pillow, Top
8	104-8810	2	Block-Pillow, Bottom
9	104-8811	2	Bearing
10	104-8812	2	Ring-Retainer
11	104-8813	1	Cap-Pipe
12	322-3	8	Screw-HH

Ref.	Part Number	Qty.	Description
13	104-8814	1	Trim-Edge, Drum
14	3296-29	4	Nut-Lock, NI
15	3256-23	8	Washer-Flat
16	3253-21	4	Washer-Lock
17	323-6	4	Screw-HH
18	32128-21	1	Nut-HF
19	104-8815	1	Bracket-12V Dc
20	104-8816	1	Motor-12V Dc
21	104-8817	1	Pinion
22	104-8818	4	Key
23	322-5	4	Screw-HH
24	3253-4	1	Washer-Lock
25	104-8819	4	Screw-Set
26	3256-23	4	Washer-Flat



Count on it.