



Count on it.

Form No. 3350-509 Rev A

Parts Catalog

72in Side Discharge Mower

Groundsmaster® 300 Series

Model No. 30722—Serial No. 240000001 and Up

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquid Propane

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head

Contents

Deck Assembly 4

Center Spindle Assembly No. 95-3090..... 5

Right Hand Spindle Assembly No. 95-3095..... 6


Left Hand Spindle Assembly No. 95-3089 7

Carrier Frame Assembly 8

Gear Box Assembly No. 106-4355-03 10


Driveshaft Assembly No. 93-9996..... 11

Attachments and Accessories 12




Deck Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	3234-11	4	Screw-HHF	14	21-0890	3	V-Belt
2	26-1840	3	Pulley-Idler	15	95-3095	1	RH Spindle ASM
4	95-3090	1	Center Spindle ASM	17	95-3089	1	LH Spindle ASM
5	93-7181	1	72 Inch Side Discharge Deck ASM	21	51-1530-01	2	Hinge Bracket ASM
5:2	100-6578	2	Decal-Danger	22	32128-23	2	Nut-HF
5:3	3290-469	4	Nut-Clinch	25	106-6753	1	Decal-Danger, Ce
5:4	107-2908	2	Decal-Danger, Combination	26	51-1470-01	1	Deflector
5:5	57-0280	1	Decal	27	51-1550	2	Spring
5:6	105-7844	1	Decal-Warning	29	26-1820	3	Capscrew
5:7	107-2916	1	Decal-Warning	30	26-1990	3	Washer-Belleville
5:8	93-7817	1	Decal-Torque, Blade Bolt	31	29-5530-03	3	Blade-Standard, 25 Inch, LH
5:9	106-6753	1	Decal-Danger, Ce	33	3256-24	2	Washer-Flat
6	3231-29	2	Screw-CARR	35	325-17	2	Screw-HH
7	26-1860	2	Spacer-Idler Pulley	36	26-1880	1	Spacer-Idler Mount
8	32128-21	33	Nut-HF	37	323-12	1	Screw-HH
9	3231-27	6	Screw-CARR	39	32128-25	2	Nut-HF
10	26-1870-03	1	Mount-Idler	40	36-1740	2	Roller-Deck
11	3290-357	6	Nut-HHF, Whiz	41	68-6840	1	Shaft-Roller
12	26-1850	1	Stud-Idler	42	68-6710	1	Roller
13	3234-1	24	Screw-HHF	43	62-4480	2	Rod-Roller
				45	322-4	2	Screw-HH




Center Spindle Assembly No. 95-3090

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	26-1760-03	1	Pulley ASM
2	3-8514	1	Washer-Thrust
3	3296-49	1	Nut-Lock, NI
4	253-138	2	Seal-Oil
5	285-17	2	Plug-Pipe
6	302-2	1	Fitting-Grease
7	84-5370	1	Spindle
8	49-8320	1	Bearing ASM
9	84-2080	1	Housing-Spindle, Center
10	253-154	1	Seal-Oil




Right Hand Spindle Assembly No. 95-3095

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	26-1760-03	1	Pulley ASM
2	3-8514	1	Washer-Thrust
3	3296-49	1	Nut-Lock, NI
4	84-2090	1	Spacer-Spindle, RH
5	253-138	2	Seal-Oil
6	302-5	1	Fitting-Grease
7	285-17	1	Plug-Pipe
8	84-2070	1	Spindle
9	49-8320	1	Bearing ASM
10	84-2020	1	Housing-Spindle
11	253-154	1	Seal-Oil



Left Hand Spindle Assembly No. 95-3089


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	84-2060-03	1	LH Pulley ASM
2	3-8514	1	Washer-Thrust
3	3296-49	1	Nut-Lock, NI
4	253-138	2	Seal-Oil
5	302-5	1	Fitting-Grease
6	285-17	1	Plug-Pipe
7	84-2070	1	Spindle
8	49-8320	1	Bearing ASM
9	84-2020	1	Housing-Spindle
10	253-154	1	Seal-Oil



Carrier Frame Assembly

Ref.	Part Number	Qty.	Description
1	26-1490	1	RH Castor Arm ASM
1:2	94-1291	4	Bushing
1:3	302-5	2	Fitting-Grease
2	324-12	4	Screw-HH
3	66-6480	4	Washer
4	323-4	4	Screw-HH
5	14-5869	1	RH Cover ASM
5:1	27-4570	1	Knob-Seat
5:2	3269-5	2	Rivet-Pop
5:3	3296-59	1	Nut-Lock, NI
5:8	66-1260	1	Bracket-Knob
6	3253-21	4	Washer-Lock
7	32128-21	4	Nut-HF
8	63-8410	4	Washer
9	93-6697	1	Decal-Lube
10	39-3340-01	1	Bracket-Arm Clamp
11	106-4355-03	1	Gearbox ASM
12	3257-5	1	Key-Woodruff
13	26-1400-03	1	Pulley-Deck
14	66-6310	2	Washer-Cup
15	93-9838-03	1	Shroud-Shaft, Drive
16	21-3770-01	1	Lift Strap-Deck, Rr
17	3290-357	2	Nut-HHF, Whiz
18	32104-82	2	Screw-HHF
19	3231-27	2	Screw-CARR
20	32128-42	4	Nut-HF
21	14-5879	1	LH Cover ASM
21:1	27-4570	1	Knob-Seat


Ref.	Part Number	Qty.	Description
21:2	3269-5	2	Rivet-Pop
21:3	3296-59	1	Nut-Lock, NI
21:8	66-1260	1	Bracket-Knob
22	32128-49	12	Nut-HHF
26	32128-23	8	Nut-HF
27	39-7450-01	1	LH Clamp Bracket
28	39-3330-01	2	Plate-Castor Arm Clamp
29	325-14	4	Screw-HH
30	92-8862	4	HOC Cap ASM
30:1	92-5581	1	Ring-Retaining
30:2	92-5583	1	Washer-Cap
30:3	92-5584	1	Spring-Compression
30:4	92-8861	1	Cap-HOC
31	63-0070	24	Spacer
34	26-1430	1	Castor Arm ASM, LH
34:2	94-1291	4	Bushing
34:3	302-5	2	Fitting-Grease
35	3-6781	8	Washer-Thrust
36	75-9680-01	2	Castor Fork ASM
37	325-18	2	Screw-HH
38	3256-6	8	Washer-Flat
40	63-1770	2	Spanner
42	63-8400	2	Caster Wheel ASM
42:1	62-5580	2	Bearing-Outside
42:2	63-8580	1	Bearing-Roller
42:3	302-40	1	Fitting-Grease
46	3233-2	12	Screw-CARR
47	325-22	2	Screw-HH



Carrier Frame Assembly (continued)


Ref.	Part Number	Qty.	Description
50	92-1655	2	10-Inch Castor Wheel ASM
50:1	83-4740	1	Bearing
50:2	62-5580	2	Bearing-Outside
50:3	302-40	1	Fitting-Grease
51	62-4340	2	Spanner
52	26-1530-01	2	Castor Fork ASM
53	23-1640	1	Bushing-Taperlock
53:1	3247-4	2	Screw-Set
55	3231-26	4	Screw-CARR

Ref.	Part Number	Qty.	Description
56	68-9890-01	1	Cover-Gearbox, Front
57	63-9750	4	Mount
58	68-8560-03	2	Bracket-Gearbox
59	26-1190-01	2	Plate-Reinforcement
60	93-9996	1	Driveshaft ASM
61	32121-34	2	Pin-Roll
62	322-9	2	Screw-HH
63	3296-29	2	Nut-Lock, NI
64	27-4570	2	Knob-Seat



Gear Box Assembly No. 106-4355-03

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	107-2932	1	Cap-Oil
2	107-2933	1	Plug
3	107-2934	2	Seal-Oil
4	107-2935	1	Cap-Oil
5	107-2936	1	Plug-Filler, Dipstick



Driveshaft Assembly No. 93-9996

Ref.	Part Number	Qty.	Description
1	93-9963	1	Shaft-Yoke, Slip
3	62-3800	1	Yoke-End
4	54-9180	2	U-Joint Kit
4:1	62-3820	1	Fitting-Grease
5	302-58	1	Fitting-Straight
6	54-9040	1	Yoke-End

Attachments and Accessories

For 30722 72in Side Discharge Mower Groundsmaster 300 Series

Product Name	Model/Part
25in LH Atomic Blade ASM.....	106-4354
Blade-High Sail, 25in, LH.....	23-2410-03
Spacer	27-1040
Mowers and Boom Quick Attach Adapter Kit	30719
10in Pneumatic Castor Wheel Asm	54-8810
PTO-Male Half	92-4663
10in Foam Filled Wheel	93-5973
10in Caster Wheel Kit	95-3082
Castor Wheel Kit.....	95-3084
72in RD Wheel Set Kit	95-3086
Blade And Belt Kit.....	95-3087
LH Spindle Kit.....	95-3089
Center Spindle Kit.....	95-3090
High Sail Blade and Belt Kit	95-3094
RH Spindle Kit	95-3095
Blade Service Pack, 25in	108-1454

Notes:

Notes:

Notes:



Count on it.