



Count on it.

Parts Catalog

780 Series Golf Sprinkler

Model No. 780 Series

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquid Propane

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping


TTH: torx truss head

Contents

780 Series Golf Sprinklers 4

780 Series Ribless Body Conversion Assembly 6

780 Series Golf Sprinklers



780 Series Golf Sprinklers (continued)

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>	<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	89-1220	1	Plug, Adjustment	21			Pilot Valve Assy. (See Pilot Valve Assembly Section) ◻ ♦
2	363-3150	1	Screw, Set, 10-32 X .250 (Part Circle Only)		363-3125		Plug, 1/2" Npt ● ▲
3	363-4039	1	Nut, 5/16-24, W/ Nylon Lock		102-0840		Nozzle, Inner/Intermediate, Blank, Red ● ▲
4	89-1589	1	Plug, Cap (Black)		89-4651		Nozzle, Inner, 82 Yellow (Pre-November 2003) ● ▲
5	89-1584	1	Cap, 780		89-3942		Nozzle, Inner, 83 Blue (Pre-November 2003) ● ▲
5	89-8288	1	Cap, Effluent		89-4652		Nozzle, Inner, 84 Brown (Pre-November 2003) ● ▲
6	89-1925	1	Nozzle, Main, 62 Yellow		89-3729		Nozzle, Inner, 85 Orange (Pre-November 2003) ● ▲
6	89-1926	1	Nozzle, Main, 63 Blue		89-4653		Nozzle, Inner, 86 Green (Pre-November 2003) ● ▲
6	89-1927	1	Nozzle, Main, 64 Brown		89-1879		Nozzle, Inner, 87 Gray (Pre-November 2003) ● ▲
6	89-1928	1	Nozzle, Main, 65 Orange		89-4654		Nozzle, Inner, 88 Black (Pre-November 2003) ● ▲
6	89-1929	1	Nozzle, Main, 66 Green		89-1878		Nozzle, Inner, 89 Red ● ▲
6	89-1930	1	Nozzle, Main, 67 Gray		89-4649		Restrictor, (82 & 83 Black) (Pre-November 2003) ● ▲
6	89-1931	1	Nozzle, Main, 68 Black		89-4650		Restrictor, (84-89 White) (Pre-November 2003) ● ▲
6	89-4655	1	Nozzle, Main, 89 Red		YARDMARKYEL10		Yardage Marker, Yellow (10-Sheets Per Pack) ● ▲
7	102-2925	1	Nozzle Assy. Intermediate, Blue (Used W/ #82 Yellow & #83 Blue Mains)		YARDMARKLAV10		Yardage Marker, Lavender (For Non-Potable Water Applications) ● ▲
7	102-0608	1	Nozzle, Intermediate, Orange (Used W/ #84 Brown Main)		995-09		Valve Removal Tool ■ ▲
7	102-0609	1	Nozzle, Intermediate, Gray (Used W/ #85 Orange Main)		995-15		Selector Tool (Flag Key) ■ ▲
7	102-0610	1	Nozzle, Intermediate, Red (Use W/ #86 Green & #87 Gray Mains)		995-55		Riser Hold-Up Tool ■ ▲
7	102-2929	1	Nozzle, Intermediate, Beige (Use W/ #88 Black & #89 Red Mains)		995-79		Nut Driver, 7/16" (For Inner And Intermediate Nozzles) ■ ▲
8	102-2980	1	Nozzle Assy. Inner, Red (W/ Restrictor)		995-80		Nut Driver, 1/2" (For 363-4039 Lock Nut) ■ ▲
9	89-1906	1	Nozzle Base Assy., 760/780		995-81		Nut Driver, 9/16" (For Main Nozzle) ■ ▲
9	102-0057	1	Nozzle Base Assy., 760/780 W/Back Nozzle (Includes 89-3729 #85 Inner Nozzle & 89-4650 Restrictor)		995-82		Arc Adjustment Tool, 3/32" (T-Handle Hex Wrench) ■ ▲
10	360-0107	1	O-Ring (0.070 X 0.301 X 0.441)		995-83		Multi-Purpose Tool ■ ▲
11	35-6119	1	Snap Ring, Riser		995-85		Riser Removal Tool ■ ▲
12	102-0136	1	Retainer, Seal, 1.5"		995-101		Valve Insertion Tool ■ ▲
13	363-4103	1	O-Ring, Body		995-100		Valve Snap Ring Pliers With Screen Remover ■ ▲
14	89-6307	1	Spring, Return		118-0954	1	Riser Hold-Up Tool, Red ■ ▲
15	89-6361	1	Riser Assembly, 880S				
16	102-4497	1	Drive Assy., Part Circle (Pc), 12-Pack				
16	102-4496	1	Drive Assy., Full Circle (Fc), 12-Pack				
17	89-1958	1	Stator Support				
18	89-1957	1	Stator, Variable				
19	89-1588	1	Screen				
20		1	Body Assy. (See Sprinkler Golf Body Assembly Section) ◻ ♦				

● SERVICE ITEMS

▲ Not illustrated


◻ See Pilot Valve Assembly Section.

■ SERVICE TOOLS

♦ Not serviced separately

○ See Golf Sprinkler Body Assembly Section.

780 Series Ribless Body Conversion Assembly



780 Series Ribless Body Conversion Assembly (continued)

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	89-1220	1	Plug, Adjustment	17	89-1958	1	Stator Support
2	363-3150	1	Screw, Set, 10-32 X .250 (Part Circle Only)	18	89-1957	1	Stator, Variable
3	363-4039	1	Nut, 5/16-24, W/ Nylon Lock	19	89-1588	1	Screen
4	89-1589	1	Plug, Cap (Black)		363-3125		Plug, 1/2" Npt ●▲
5	89-1584	1	Cap, 780		102-0840		Nozzle, Inner/Intermediate, Blank, Red ●▲
5	89-8288	1	Cap, Effluent		89-4651		Nozzle, Inner, 82 Yellow (Pre-November 2003) ●▲
6	89-1925	1	Nozzle, Main, 62 Yellow		89-3942		Nozzle, Inner, 83 Blue (Pre-November 2003) ●▲
6	89-1926	1	Nozzle, Main, 63 Blue		89-4652		Nozzle, Inner, 84 Brown (Pre-November 2003) ●▲
6	89-1927	1	Nozzle, Main, 64 Brown		89-3729		Nozzle, Inner, 85 Orange (Pre-November 2003) ●▲
6	89-1928	1	Nozzle, Main, 65 Orange		89-4653		Nozzle, Inner, 86 Green (Pre-November 2003) ●▲
6	89-1929	1	Nozzle, Main, 66 Green		89-1879		Nozzle, Inner, 87 Gray (Pre-November 2003) ●▲
6	89-1930	1	Nozzle, Main, 67 Gray		89-4654		Nozzle, Inner, 88 Black (Pre-November 2003) ●▲
6	89-1931	1	Nozzle, Main, 68 Black		89-1878		Nozzle, Inner, 89 Red ●▲
6	89-4655	1	Nozzle, Main, 89 Red		89-4649		Restrictor, (82 & 83 Black) (Pre-November 2003) ●▲
7	102-2925	1	Nozzle Assy. Intermediate, Blue (Use W/ #82 Yellow & #83 Blue Main Nozzles)		89-4650		Restrictor, (84-89 White) (Pre-November 2003) ●▲
7	102-0608	1	Nozzle, Intermediate, Orange (Use W/ #84 Brown Main Nozzle)		995-09		Valve Removal Tool ■▲
7	102-0609	1	Nozzle, Intermediate, Gray (Use W/ #84 Orange Main Nozzle)		995-15		Selector Tool (Flag Key) ■▲
7	102-0610	1	Nozzle, Intermediate, Red (Use W/ #86 Green & #87 Gray Main Nozzles)		995-55		Riser Hold-Up Tool ■▲
7	102-2929	1	Nozzle, Intermediate, Beige (Use W/ #88 Black & #89 Red Main Nozzles)		995-79		Nut Driver, 7/16" (For Inner And Intermediate Nozzles) ■▲
8	102-2980	1	Nozzle Assy. Inner, Red (W/ Restrictor)		995-80		Nut Driver, 1/2" (For 363-4039 Lock Nut) ■ ▲
9	89-1906	1	Nozzle Base Assy., 760/780		995-81		Nut Driver, 9/16" (For Main Nozzle) ■▲
9	102-0057	1	Nozzle Base Assy., 760/780 W/Back Nozzle		995-82		Arc Adjustment Tool, 3/32" (T-Handle Hex Wrench) ■▲
10	360-0107	1	O-Ring (0.070 X 0.301 X 0.441)		995-83		Multi-Purpose Tool ■▲
11	89-7568	1	Sleeve, Retainer, O-Ring, Conversion		995-85		Riser Removal Tool ■▲
12	363-4103	1	O-Ring, Body		995-101		Valve Insertion Tool ■▲
13	89-6307	1	Spring, Return		995-100		Valve Snap Ring Pliers With Screen Remover ■▲
14	89-7569	1	Seal, Riser		118-0954	1	Riser Hold-Up Tool, Red ■▲
15	89-6360	1	Riser Assembly				
16	102-4497	1	Drive Assy., Part Circle (Pc), 12-Pack				
16	102-4496	1	Drive Assy., Full Circle (Fc), 12-Pack				

● SERVICE ITEMS
▲ Not illustrated

■ SERVICE TOOLS



Count on it.