




MODEL NO. 38072-790001 & UP
 MODEL NO. 38073-790001 & UP

PARTS
 CATALOG

724 SNOWTHROWER




C-1278

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	37-6900	Cover - Belt	1	15	63-2420	Decal - Choke (Model No. 38072)	1
2	43-7290	Screw - Special	1	*	63-2430	Decal - Choke (Model No. 38073)	1
3	74-1370	Engine Pulley	1	16	62-5760	Decal - Primer (Model No. 38072)	1
4	66-8060	Molded Brake Asm.	1	*	94-2572	Decal - Primer (Model No. 38073)	1
5	3296-59	Nut - Lock	1	17	63-2450	Decal - Throttle	1
6	3-4244	Idler Pulley	1	18	66-6840	Decal - Hot (Model No. 38072)	1
7	3290-320	Nut - Push On	1	*	94-2576	Decal - Hot (Model No. 38073)	1
8	3256-24	Washer - Flat	1	19	32144-4	Screw - Self Tap.	3
9	3296-56	Nut - Lock	1	20	289-9	Pipe Nipple	1
10	53-7570	Spring - Auger Disengage	1				
11	14-7959	Auger Clutch (Incl. Ref. #4)	1				
12	323-29	Screw	1				
13	42-3560	Bolt - Shoulder	1				
14		Engine	1				

*Not Illustrated




C-1278

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
21	288-2	Cap	1	28	37-9090	V-Belt - Traction	1
22	3296-29	Nut - Lock	4	29	26-9672	V-Belt - Auger	1
23	3256-23	Washer - Flat	5	†30	42-675	Screw	3
24	322-4	Screw	4	†31	36-180	Washer - Lock	3
25	37-8990	Retainer - Belt	1	†32	36-195-1	Washer - Flat	3
26	3255-8	Washer -Lock Ext. Tooth	1	†33	127-19	Guard - Muffler	1
27	3210-3	Screw	1				

PROTOTYPE

† Order these parts from Tecumseh




C-0031

AUGER ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	94-2786	Housing—Auger (Model No. 38072) (Incl. Ref. #3)	1	14	3-0737	Washer	1
*	94-2785	Housing—Auger (Model No. 38073) (Incl. Ref. #3)	1	15	3257-23	Key	1
2	74-1600	Auger — R.H.	1	16	37-6890	Pulley	1
*	74-1590	Auger — L.H.	1	17	3242-4	Screw — Set	2
3	53-7670	Decal — Auger Warning (Model No. 38072)	1	18	56-2680	Deflector	1
*	94-2568	Decal — Auger Warning (Model No. 38073)	1	19	3230-22	Bolt — Carriage	2
4	37-6990	Shaft & Impeller	1	20	56-2670	Chute — Wire	1
5	3230-18	Bolt — Carriage	6	21	94-2793	Chute — Discharge (Model No. 38072) (Incl. Ref. #22)	1
6		Flange — Bearing Front	1	*	94-2792	Chute — Discharge (Model No. 38073) (Incl. Ref. #22)	1
7	63-3450	Bearing — Ball	1	22	53-7660	Decal — Discharge (Model No. 38072)	1
8		Flange — Bearing Rear	1	*	94-2558	Decal — Discharge (Model No. 38073)	1
9	3296-29	Nut — Lock	13	23	3256-23	Washer	3
10	3290-340	Washer — Belleville	2	25	37-6490	Retainer — Chute Ring	3
11	3256-68	Washer — Flat	2	26	32144-70	Screw — Self Tap.	4
12	55-8950	Plate — Friction	2	28	27-0220	Screw — Self Tap.	6
13	20-4320	Washer — Rubber	2				

*Not Illustrated




C-0031

AUGER ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
29	3290-326	Pushnut	1	47	3-8664	Washer	1
30	37-8941	Ring - Chute	1	48	32120-72	Ring - Retaining	1
31	40-8160	Skid	2	49	256-32	Bushing	1
32	32128-20	Nut - Flange	4	50	252-80	Washer - Thrust	1
33	32151-36	Ring - Retaining	2	51	51-0460	Gasket	1
34	5-1550	Washer - Thrust	4	52	14-2449	Gear Case R.H. (Incl. Ref. #53 & 54)	1
35	37-6550	Bearing - Auger	2	53	256-237	Bushing	2
36	74-1420	Blade - Scraper	1	54	7-0045	Seal - Oil	2
37	3296-42	Nut - Lock	2	55	37-6801	Shaft - Auger	1
38	321-10	Screw	2	56	32144-41	Screw - Self Tap.	8
39	3257-33	Key - Woodruff	1	57	37-6560	Bushing - Input	1
40	14-2459	Gear Case L.H. (Incl. Ref. #53 & 54)	1	58	237-87	Seal	1
41	281-1	Pipe - Plug	1	59	3257-23	Key - Woodruff	1
42	252-71	Bearing - Thrust	2	60	3230-1	Bolt - Carriage	9
43	5-7180	Gear	1	*	37-6961	Gear Case Asm.	1
44	257-3	Washer - Thrust	1	*	12-8789	Bearing Assembly (Incl. Ref. #6-8)	1
45	252-76	Bearing - Needle, Thrust	1				
46	5-7170	Gear - Worm	1				


*Not Illustrated



C-2371

TRACTION ASSEMBLY


Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	88-0850	Pulley & Shaft	1	15	3296-29	Nut - Lock	6
2	32151-103	Ring - Snap	1	16	32144-4	Screw - Self Tap.	6
3	252-80	Washer - Thrust	1	17	37-6830	Cover - Bottom	1
4	12-3270	Screw - Tapping	8	18	231-120	Tire	2
5	88-0550	Frame - Friction Plate	1	19	3290-243	Pin - Klik	2
6	256-322	Bushing	1	20	241-131	Rim	2
7	66-6790	Mount - Clutch Rod Front	1	21	232-46	Tube	2
8	32144-70	Screw - Self Tap.	5	22	74-1350	Shaft - Axle	1
9	88-0560	Hub - Frame	1	23	37-6850	Bearing - Axle	2
10	38-7820	Bearing	1	24	32121-31	Pin - Roll	2
11	37-9070	Mount - Clutch Rod Rear	1	25	37-8870	Spring - Friction Plate Frame	1
12	37-8900	Frame - Traction	1	26	322-2	Screw - Hex. Hd.	4
13	38-0800	Plate - Friction	1	27	37-6520	Gear - Axle	1
14	37-8770	Bolt - Shoulder	3	28	3-8664	Washer - Thrust	2



C-2372

TRACTION ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	32144-70	Screw - Self Tap.	4	18	37-6570	Wheel - Friction	1
2	37-6500	Gear - Sliding	1	19	39-1520	Hub - Friction Wheel Mount	1
3	256-86	Bushing	1	20	3296-48	Nut - Lock	1
4	20-1620	Bearing - Friction Wheel	2	21	37-6760	Shaft - Pivot	1
5	39-1230	Bracket - Sliding	1	22	32121-45	Pin - Roll	2
6	37-8880	Spring - Traction Engage	1	23	3257-24	Key	1
7	322-2	Screw - Hex. Hd.	4	24	5-7570	Washer - Thrust	2
8	37-9160	Intermediate Gear & Bushing (Incl. Ref. #4)	1	25	37-6780	Shaft - Hex	1
9	10-9280	Washer - Thrust	2	26	32128-33	Nut - Flange	2
10	37-8790	Mount - Quadrant Gear	1	27	39-3060	Rod - Lower Traction	1
11	3296-29	Nut - Lock	1	28	38-4520	Spring - Compression	1
12	3296-16	Nut - Lock	1	29	32128-32	Nut - Flange	1
13	37-8800	Quadrant - Gear	1	30	38-4490	Bracket - Traction	1
14	37-8770	Bolt - Shoulder	3	31	40-9680	Spacer	1
15	39-1250	Cam - Receiver	1	32	40-8350	Screw - Shoulder	1
16	321-4	Screw - Hex. Hd.	1	33	3296-42	Nut - Lock	1
17	36-4790	Washer - Thrust	2	34	43-7310	Traction Engagement Asm.	1
				35	32151-61	Ring - Retaining	1




HANDLE ASSEMBLY RIGHT SIDE

Ref. No.	Part No.	Description	No. Used
1	52-5561	Handle - Right (Model No. 38072)	1
*	52-5560	Handle - Right (Model No. 38073)	1
2	52-5590	Link - Upper	1
3	74-1490	Rod - Speed Selector	1
4	3272-4	Pin - Cotter	3
5	283-3	Pin - Clevis	1
6	39-3080	Clevis	1
7	3218-1	Nut - Jam	1
8	32115-5	Retainer - Nut	1
9	3256-23	Washer	4
10	43-7360	Panel - Escutcheon	1
11	88-0740	Decal - 724	1
12	32128-13	Nut - Flange Lock	1
13	37-9150	Spring	1

Ref. No.	Part No.	Description	No. Used
14	40-8130	Spacer - Speed Selector	1
15	3229-11	Bolt - Carriage	2
16	233-21	Knob	1
17	37-8821	Selector - Speed	1
18	3234-13	Screw - Hex. Flange Hd.	1
19	32151-73	Ring - Clip	1
20	3256-24	Washer	1
21	63-3640	Handle - Control	1
22	74-1360	Grip - Handle	1
23	47-4990	Post - Linkage Mounting	1
24	52-5600	Pin - Control Lever	1
25	39-1280	Mount - Speed Selector	1
26	322-7	Screw	1
27	32128-33	Nut - Flange Lock	2
*	3290-378	Cable Tie	1

*Not Illustrated




C-2375

HANDLE ASSEMBLY LEFT SIDE

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	40-8270	Rod - Chute Control	1	16	321-9	Screw - Hex. Head	2
2	52-5590	Link - Upper	1	17	3296-42	Nut - Lock	2
3	17-9120	Mount - Wire	3	18	3290-320	Nut - Push	2
4		Panel - Escutcheon Ref.		19	40-8230	Grip - Rod	1
5	66-6830	Decal - Escutcheon Back (Model No. 38072)	1	20	63-3510	Decal - Chute Direction	1
*	94-2563	Decal - Escutcheon Back (Model No. 38073)	1	21	12-7739	Bracket - Chute Control (Incl. Ref.# 20 & 22)	1
6	40-5940	Switch - On/Off	1	22	256-249	Nyliner	1
7	63-8360	Key - Ignition	1	23	322-7	Screw - /Hex. Hd.	1
8	52-5600	Pin - Control Lever	1	24	3296-29	Nut - Lock	2
9	47-4990	Post - Linkage Mounting	1	25	43-7390	Wire Harness Asm. (Incl. Ref.# 3)	1
10	3256-24	Washer	1	26	322-2	Screw - Hex. Hd.	4
12	63-3640	Handle - Control	1	27	3290-456	Washer - Belleville	4
13	3234-13	Screw - Hex. Flange Hd.	1	28	3290-196	Retainer - Nut	4
14	74-1360	Grip - Handle	1	29	3230-22	Bolt - Carriage	1
15	52-5571	Handle - Left (Model No. 38072)	1	30	3290-238	Washer - Pyramidal	1
*	52-5570	Handle - Left (Model No. 38073)	1	31	40-8280	Bracket - Chute Worm	1
				32	40-8250	Gear - Worm	1
				*	3290-378	Cable Tie	1

*Not Illustrated



C-1773

CARBURETOR NO. 632371A

Ref. No.	Part No.	Description	No. Used
1	31834	Shaft & Lever Assembly	1
2	631767	Spring - Throttle Return	1
3	631036	Shutter - Throttle	1
4	650506	Screw	2
5	630766	Spring - Idle Screw	2
5A	630738	Spring	1
6	650417	Screw - Idle	1
7	632373	Shaft & Lever Assy.(Choke)	1
8	630735	Spring - Choke Stop	1
9	632372	Shutter - Choke	1
10	630748	Plug - Welch	1
11	631027	Plug - Welch	1
12	631021	Inlet Needle - Seat & Clip (Incl. Ref. #13)	1
13	631022	Clip - Inlet Needle	1
14	632019	Float - Carburetor	1
15	631024	Shaft - Float	1

Ref. No.	Part No.	Description	No. Used
16	631951	Bowl - Assembly (Incl. Ref. #17 & 18)	1
17	27136A	Drain Assembly - Bowl (Incl. Ref. #18)	1
18	27554	Gasket - Bow Drain	1
20	31839	Screw Adjustment Assembly (Incl. Ref. #5A, 21, 23, & 27)	1
21	27110	Gasket - Bowl-to-Body	1
23	630740	"O" Ring	1
24	631838	Screw - Idle	1
25	631028	Gasket - Bowl-to-Body	1
26	632164	Fitting - Fuel Inlet	1
27	630739	Washer - Flat	2
28	31840	Repair Kit (Incl. Items Marked †)	1
*	632371A	Carburetor (Incl. Ref. #1-28)	1

* Not Illustrated

ENGINE TECUMSEH MODEL HSK70-130282T

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	32586C	Cylinder (Incl. Ref. #2,20 & 72)	1	86	650488	Screw	7
2	27652	Dowel Pin	2	87	650493	Screw	1
15	30699C	Governor Rod (Incl. Ref. #15A & 15B)	1	89	32589	Flywheel Key	1
15A	30700	Governor Yoke	1	90	611085	Flywheel	1
15B	650494	Screw	1	92	650815	Belleville Washer	1
16	33454	Governor Lever	1	93	8116	Flywheel Nut	1
17	29916	Governor Lever Clamp	1	100	34443A	Solid State Ignition	1
18	650548	Screw	1	101	610118	Spark Plug Cover	1
19	34663	Speed Control Spring	1	102	650872	Solid State Mounting Stud	2
20	32630	Oil Seal	1	103	651007	Screw, Torx T-15	2
25	36460	Blower Housing Baffle	1	110	35253	Ground Wire	1
26	650561	Screw	2	*119	36453	Cylinder Head Gasket	1PK
28	30322	Lock Nut	1	120	36446	Cylinder Head (Incl. 3 of 131)	1
30	35272	Crankshaft	1	125	27878A	Exhaust Valve (Std.) (Incl. Ref. #151)	1
35	29826	Screw	1	125	27880A	Exhaust Valve (1/32" OS) (Incl. Ref. #151)	1
36	29918	Lock Washer	1	126	32784	Intake Valve (1/32" OS) (Incl. Ref. #151)	1
37	29216	Lock Nut	1	126	32783	Intake Valve (Std.) (Incl. Ref. #151)	1
38	29642	Retaining Ring	1	127	650691	Washer	3
40	34517	Piston, Pin & Ring Set (.010" OS)	1	128	650690	Belleville Washer	3
40	34518	Piston, Pin & Ring Set (.020" OS)	1	129	650697A	Screw	2
40	34519	Piston, Pin & Ring Set (Std.)	1	130	650697A	Screw	3
41	32592B	Piston & Pin Ass'y (.010" OS) (Incl. Ref. #43)	1	131	650697A	Screw	3
41	32593B	Piston & Pin Ass'y (.020" OS) (Incl. Ref. #43)	1	135	35395	Resistor Spark Plug (RJ19LM)	1
41	32594B	Piston & Pin Ass'y (Std.) (Incl. Ref. #43)	1	139	31843A	Governor Gear Bracket	1
42	34595	Ring Set (Std.)	1	140	650965	Screw, Torx T-25	2
42	34596	Ring Set (.020" OS)	1	149	27882	Valve Spring Cap	2
42	34597	Ring Set (.010" OS)	1	150	27881	Valve Spring	2
43	27888	Piston Pin Retaining Ring	2	151	32581	Valve Spring Keeper	2
45	32591C	Connecting Rod Ass'y (Incl. Ref. #46 & 49)	1	*169	27896A	Valve Cover Gasket	2PK
46	650662C	Connecting Rod Bolt	2	170	28423	Breather Body	1
48	34034	Valve Lifter	2	171	28424	Breather Element	1
49	34242	Oil Dipper	1	172	28425	Valve Cover	1
50	32115	Camshaft (MCR)	1	173	35350	Breather Tube	1
60	30622A	Blower Housing Extension	1	174	650128	Screw	2
61	34126	Grommet Mounting Bracket	1	182	650517	Screw	2
62	650760	Screw	1	183	32398	Choke Bracket	1
63	28545	Grommet	1	*184	31688A	Carburetor To Intake Pipe Gasket	1PK
65	650128	Screw	1	186	34661	Governor Link	1
69	30684	Cylinder Cover Gasket	1PK	200	34677	Control Bracket (Incl. Ref. #203, 204, & 206)	1
*70	31303C	Cylinder Cover (Incl. Ref. #71, 75, & 80)	1	203	31342	Compression Spring	1
71	31546	Crankshaft Bushing	1	204	650549	Screw	1
72	27642	Oil Drain Plug	2	206	610973	Terminal	1
75	28427	Oil Seal	1	207	34662	Throttle Link	1
80	31845	Governor Shaft	1	209	650821	Screw	2
81	30590A	Washer	1	215	35440	Control Knob	1
82	30591	Governor Gear Ass'y	1	220	35439	Control Knob	1
83	30588A	Governor Spool	1	222	28820	Screw	2
84	29193	Retaining Ring	1	*224	27915A	Intake Pipe Gasket	1PK
				260	36254	Blower Housing	1
				262	29747B	Screw, Torx T-40	2
				264A	30196	Screw	1
				265	30939A	Cylinder Head Cover	1
				272	30196	Screw	2


*Included in Gasket Set Ref. #400.

ENGINE TECUMSEH MODEL HSK70-130282T

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
273	34712	Carburetor Flange	1	334	650257	Screw	2
274	35865	Exhaust Manifold Gasket	1PK	335	35060	Carburetor Cover	1
275	32401	Muffler	1	336	650765	Screw	1
277	650694A	Screw	1	338	650760	Screw	1
279B	26073	Washer	1	340	34159	Fuel Tank Bracket	1
281	33013	Starter Bubble Cover	1	341	34158	Fuel Tank Bracket	1
282	650760	Screw	1	342	650561	Screw	1
285	35287B	Starter Cup	1	350	570682	Primer Ass'y	1
287	650926	Screw	3	351	32180C	Primer Line	1
290	29774	Fuel Line	1	355	590574	Starter Handle	1
291	30962	Fule Line	1	370	36261	Instruction Decal	1
292	26460	Fuel Line Clamp	4	370K	36695	Starter Decal	1
295	35857	Fuel Shut-Off Valve	1	380	632371A	Carburetor (Incl. Ref. #184)	1
298	650665	Screw	2	390	590707	Rewind Starter	1
299	650764	"U" Type Nut	1	396	33328D	Electric Starter Motor (Optional)	1
300	34186A	Fuel Tank (Incl. Ref. #292 & 301)	1	400	33239A	Gasket Set	1
301	36246	Fuel Cap	1	420	730225	Sae 30 4-Cycle Engine Oil (Quart)	1
305	35554	Oil Fill Tube	1	453	290538	Engine Mounting Base	1
307	35499	"O" Ring	1	454	650542	Screw	4
308	35540	Fill Tube Clip	1				
310	36205	Dipstick	1				
325	29443	Wire Clip	1				

PROTOTYPE

*Included in Gasket Set Ref. #400.




C-1772

ELECTRIC STARTER KIT NO. 38-7590 (OPTIONAL)

Ref. No.	Part No.	Description	No. Used
1	33842	Ring - Retainer	1
2	33430	Retainer - Spring	1
3	33431	Spring - Anti-Drift	1
4	33432	Gear	1
5	35913	Nut & Retainer (Incl. Ref. #1)	1
6	35449	Cap Assembly - Drive End (Incl. Ref. #7)	1
7	35450	"O" Ring	2
8	35914	Armature	1
9	35457A	Housing Assembly	1
10	35452A	Card Assembly - Brush	1
11	35911	Washer - Thrust	1

Ref. No.	Part No.	Description	No. Used
13	590500	Washer - Thrust	1
14	33441	Screw - Ground	1
15	35453	Cap Assy., Commutator End (Incl. Ref. #7)	1
16	35454	Box Assembly - Switch (Incl. Ref. #26)	1
22	35458	Bolt - Case	2
23	35456	Screw - Grounding	1
24	33451	Cover - Dust	1
26	650819	Screw - Hex. Hd.	2
29	32450B	Cord - Extension, 10' 6"	1
30	30063	Screw - Hex. Hd.	4

Note: Order individual parts from your local Tecumseh dealer.




RECOIL STARTER NO. 590707

Ref. No.	Part No.	Description	No. Used
1	590599A	Spring Pin (Incl. Ref.#4)	1
2	590600	Washer	1
3	590696	Retainer	1
4	590601	Washer	1
5	590697	Brake Spring	1
6	590698	Starter Dog	2

Ref. No.	Part No.	Description	No. Used
7	590699	Dog Spring	2
8	590709	Pulley & Rewind Spring Asm.	1
11	590708	Starter Housing Asm.	1
12	590535	Starter Rope	1
13	590574	Mitten Grip Handle	1

PROTOTYPE



RECOIL STARTER NO. 590742 (OPTIONAL)

Ref. No.	Part No.	Description	No. Used
3	590740	Retainer	1
6	590616	Starter Dog	2
7	590617	Dog Spring	2
8	590645A	Pulley & Rewind Spring Asm.	1

Ref. No.	Part No.	Description	No. Used
11	590647	Starter Housing Asm.	1
12	590535	Starter Rope	1
13	590574	Mitten Grip Handle	1
14	590741	Locking Tab	1

PROTOTYPE

TORO PART NUMBER INDEX

3318-708

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
3-0737	Washer	3	14	1	40-8130	Spacer - Speed Selector	7	14	1
3-4244	Idler Pulley	1	6	1	40-8160	Skid	4	31	2
3-8664	Washer	4	47	1	40-8230	Grip - Rod	8	19	1
3-8664	Washer - Thrust	5	28	2	40-8250	Gear - Worm	8	32	1
5-1550	Washer - Thrust	4	34	4	40-8270	Rod - Chute Control	8	1	1
5-7170	Gear - Worm	4	46	1	40-8280	Bracket - Chute Worm	8	31	1
5-7180	Gear	4	43	1	40-8350	Screw - Shoulder	6	32	1
5-7570	Washer - Thrust	6	24	2	40-9680	Spacer	6	31	1
7-0045	Seal - Oil	4	54	2	42-675	Screw	2	30	3
10-9280	Washer - Thrust	6	9	2	42-3560	Bolt - Shoulder	1	13	1
12-3270	Screw - Tapping	5	4	8	43-7290	Screw - Special	1	2	1
12-7739	Bracket - Chute Control	8	21	1	43-7310	Traction Engagement Asm.	6	34	1
12-8789	Bearing Assembly	4	*	1	43-7360	Panel - Escutcheon	7	10	1
14-2449	Gear Case R.H.	4	52	1	43-7390	Wire Harness Asm.	8	25	1
14-2459	Gear Case L.H.	4	40	1	47-4990	Post - Linkage Mounting	8	9	1
14-7959	Auger Clutch	1	11	1	47-4990	Post - Linkage Mounting	7	23	1
17-9120	Mount - Wire	8	3	3	51-0460	Gasket	4	51	1
20-1620	Bearing - Friction Wheel	6	4	2	52-5560	Handle - Right	7	*	1
20-4320	Washer - Rubber	3	13	2	52-5561	Handle - Right	7	1	1
26-9672	V-Belt - Auger	2	29	1	52-5570	Handle - Left	8	*	1
27-0220	Screw - Self Tap.	3	28	6	52-5571	Handle - Left	8	15	1
36-180	Washer - Lock	2	31	3	52-5590	Link - Upper	7	2	1
36-195-1	Washer - Flat	2	32	3	52-5590	Link - Upper	8	2	1
36-4790	Washer - Thrust	6	17	2	52-5600	Pin - Control Lever	8	8	1
37-6490	Retainer - Chute Ring	3	25	3	52-5600	Pin - Control Lever	7	24	1
37-6500	Gear - Sliding	6	2	1	53-7570	Spring - Auger Disengage	1	10	1
37-6520	Gear - Axle	5	27	1	53-7660	Decal - Discharge	3	22	1
37-6550	Bearing - Auger	4	35	2	53-7670	Decal - Auger Warning	3	3	1
37-6560	Bushing - Input	4	57	1	55-8950	Plate - Friction	3	12	2
37-6570	Wheel - Friction	6	18	1	56-2670	Chute - Wire	3	20	1
37-6760	Shaft - Pivot	6	21	1	56-2680	Deflector	3	18	1
37-6780	Shaft - Hex	6	25	1	62-5760	Decal - Primer	1	16	1
37-6801	Shaft - Auger	4	55	1	63-2420	Decal - Choke	1	15	1
37-6830	Cover - Bottom	5	17	1	63-2430	Decal - Choke	1	*	1
37-6850	Bearing - Axle	5	23	2	63-2450	Decal - Throttle	1	17	1
37-6890	Pulley	3	16	1	63-3450	Bearing - Ball	3	7	1
37-6900	Cover - Belt	1	1	1	63-3510	Decal - Chute Direction	8	20	1
37-6961	Gear Case Asm.	4	*	1	63-3640	Handle - Control	8	12	1
37-6990	Shaft & Impeller	3	4	1	63-3640	Handle - Control	7	21	1
37-8770	Bolt - Shoulder	5	14	3	63-8360	Key - Ignition	8	7	1
37-8770	Bolt - Shoulder	6	14	3	66-6790	Mount - Clutch Rod Front	5	7	1
37-8790	Mount - Quadrant Gear	6	10	1	66-6830	Decal - Escutcheon Back	8	5	1
37-8800	Quadrant - Gear	6	13	1	66-6840	Decal - Hot	1	18	1
37-8821	Selector - Speed	7	17	1	66-8060	Molded Brake Asm.	1	4	1
37-8870	Spring - Friction Plate Frame	5	25	1	74-1350	Shaft - Axle	5	22	1
37-8880	Spring - Traction Engage	6	6	1	74-1360	Grip - Handle	8	14	1
37-8900	Frame - Traction	5	12	1	74-1360	Grip - Handle	7	22	1
37-8941	Ring - Chute	4	30	1	74-1370	Engine Pulley	1	3	1
37-8990	Retainer - Belt	2	25	1	74-1420	Blade - Scraper	4	36	1
37-9070	Mount - Clutch Rod Rear	5	11	1	74-1490	Rod - Speed Selector	7	3	1
37-9090	V-Belt - Traction	2	28	1	74-1590	Auger - L.H.	3	*	1
37-9150	Spring	7	13	1	74-1600	Auger - R.H.	3	2	1
37-9160	Intermediate Gear & Bushing	6	8	1	88-0550	Frame - Friction Plate	5	5	1
38-0800	Plate - Friction	5	13	1	88-0560	Hub - Frame	5	9	1
38-4490	Bracket - Traction	6	30	1	88-0740	Decal - 724	7	11	1
38-4520	Spring - Compression	6	28	1	88-0850	Pulley & Shaft	5	1	1
38-7820	Bearing	5	10	1	94-2558	Decal - Discharge	3	*	1
39-1230	Bracket - Sliding	6	5	1	94-2563	Decal - Escutcheon Back	8	*	1
39-1250	Cam - Receiver	6	15	1	94-2568	Decal - Auger Warning	3	*	1
39-1280	Mount - Speed Selector	7	25	1	94-2572	Decal - Primer	1	*	1
39-1520	Hub - Friction Wheel Mount	6	19	1	94-2576	Decal - Hot	1	*	1
39-3060	Rod - Lower Traction	6	27	1	94-2785	Housing-Auger	3	*	1
39-3080	Clevis	7	6	1	94-2786	Housing-Auger	3	1	1
40-5940	Switch - On/Off	8	6	1	94-2792	Chute - Discharge	3	*	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
94-2793	Chute - Discharge	3	21	1	3257-24	Key	6	23	1
127-19	Guard - Muffler	2	33	1	3257-33	Key - Woodruff	4	39	1
231-120	Tire	5	18	2	3272-4	Pin - Cotter	7	4	3
232-46	Tube	5	21	2	3290-196	Retainer - Nut	4	8	28
233-21	Knob	7	16	1	3290-238	Washer - Pyramidal	8	30	1
237-87	Seal	4	58	1	3290-243	Pin - Klik	5	19	2
241-131	Rim	5	20	2	3290-320	Nut - Push	8	18	2
252-71	Bearing - Thrust	4	42	2	3290-320	Nut - Push On	1	7	1
252-76	Bearing - Needle, Thrust	4	45	1	3290-326	Pushnut	4	29	1
252-80	Washer - Thrust	5	3	1	3290-340	Washer - Belleville	3	10	2
252-80	Washer - Thrust	4	50	1	3290-378	Cable Tie	7	*	1
256-32	Bushing	4	49	1	3290-378	Cable Tie	8	*	1
256-86	Bushing	6	3	1	3290-456	Washer - Belleville	8	27	4
256-237	Bushing	4	53	2	3296-16	Nut - Lock	6	12	1
256-249	Nyliner	8	22	1	3296-29	Nut - Lock	6	11	1
256-322	Bushing	5	6	1	3296-29	Nut - Lock	5	15	6
257-3	Washer - Thrust	4	44	1	3296-29	Nut - Lock	2	22	4
281-1	Pipe - Plug	4	41	1	3296-29	Nut - Lock	8	24	2
283-3	Pin - Clevis	7	5	1	3296-29	Nut - Lock	3	9	13
288-2	Cap	2	21	1	3296-42	Nut - Lock	8	17	2
289-9	Pipe Nipple	1	20	1	3296-42	Nut - Lock	6	33	1
321-4	Screw - Hex. Hd.	6	16	1	3296-42	Nut - Lock	4	37	2
321-9	Screw - Hex. Head	8	16	2	3296-48	Nut - Lock	6	20	1
321-10	Screw	4	38	2	3296-56	Nut - Lock	1	9	1
322-2	Screw - Hex. Hd.	6	7	4	3296-59	Nut - Lock	1	5	1
322-2	Screw - Hex. Hd.	5	26	4	32115-5	Retainer - Nut	7	8	1
322-2	Screw - Hex. Hd.	8	26	4	32120-72	Ring - Retaining	4	48	1
322-4	Screw	2	24	4	32121-31	Pin - Roll	5	24	2
322-7	Screw	7	26	1	32121-45	Pin - Roll	6	22	2
322-7	Screw - Hex. Hd.	8	23	1	32128-13	Nut - Flange Lock	7	12	1
323-29	Screw	1	12	1	32128-20	Nut - Flange	4	32	4
3210-3	Screw	2	27	1	32128-32	Nut - Flange	6	29	1
3218-1	Nut - Jam	7	7	1	32128-33	Nut - Flange	6	26	2
3229-11	Bolt - Carriage	7	15	2	32128-33	Nut - Flange Lock	7	27	2
3230-1	Bolt - Carriage	4	60	9	32144-4	Screw - Self Tap.	5	16	6
3230-18	Bolt - Carriage	3	5	6	32144-4	Screw - Self Tap.	1	19	3
3230-22	Bolt - Carriage	3	19	2	32144-41	Screw - Self Tap.	4	56	8
3230-22	Bolt - Carriage	8	29	1	32144-70	Screw - Self Tap.	3	26	4
3234-13	Screw - Hex. Flange Hd.	8	13	1	32144-70	Screw - Self Tap.	6	1	4
3234-13	Screw - Hex. Flange Hd.	7	18	1	32144-70	Screw - Self Tap.	5	8	5
3242-4	Screw - Set	3	17	2	32151-36	Ring - Retaining	4	33	2
3255-8	Washer - Lock Ext. Tooth	2	26	1	32151-61	Ring - Retaining	6	35	1
3256-23	Washer	7	9	4	32151-73	Ring - Clip	7	19	1
3256-23	Washer	3	23	3	32151-103	Ring - Snap	5	2	1
3256-23	Washer - Flat	2	23	5	<div style="text-align: center;">  <p>OPTIONAL EQUIPMENT</p> <p>110 Vac Electric Starter Kit Part No. 38-7590</p> <p>Drift Breaker Part No. 37-7021</p> <p>Tire Chain Kit Part No. 56-2700</p> <p>Snow Cab Kit Part No. 88-0600</p> </div>				
3256-24	Washer	8	10	1					
3256-24	Washer	7	20	1					
3256-24	Washer - Flat	1	8	1					
3256-68	Washer - Flat	3	11	2					
3257-23	Key	3	15	1					
3257-23	Key - Woodruff	4	59	1					

*Not Illustrated

