

LAWN-BOY®

21" SIDE DISCHARGE WALK—BEHIND MOWER

MODEL NO. 22241—7900001 & UP

PARTS CATALOG

PRODUCT CHANGES

In an effort to make improvements available to LAWN–BOY owners as quickly as possible, minor changes are incorporated into LAWN–BOY products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your Parts Catalog, see your LAWN–BOY Distributor or his Authorized LAWN–BOY Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Product two identification numbers; a model number and a serial number. The two numbers are stamped on a plate mounted on the deck. In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized Service Dealer, supply the following information:

1. Model and serial number.
2. Part number, description, and the quantity of part(s) desired.


NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
Housing Assembly	1	Engine Assembly	7–8
Gearcase & Wheel Assembly	2	Carburetor Assembly	9
Gear Case Assembly	3	Air Filter Assembly	10
Engine Assembly	4	Numeric Parts Index	11–13
Handle Assembly	5	Maintenance	14
Starter Assembly	6		

Accessories


Description	Model / Parts No.	Description	Model / Parts No.
Side Bagging Kit	Model No. 89814	Leaf Shredder Kit	Model No. 89860
Rear Bagging Kit	Model No. 89800	Mulch Plate	Model No. 89864
Leaf Bag	Model No. 89804		



C-2508

HOUSING ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	92-7869	Gear Case Assembly	1	18	40-1940	Washer	4
2	256-251	Bushing - Spacer	2	19	614637	Bracket - Wheel Height Adj.	2
3	92-7699	Bracket - Actuator	1	20	3290-413	Washer - Belleville	2
4	92-7748	Screw	2	21	92-9673	Bolt - Shoulder	2
5	12-5450	Screw - Thr'd Form	2	22	614682	Knob - Cover Plate	1
6	92-8852	Cover - Drive	1	24	614677	Screw - Sems Thr'd Form	2
7	17-4629	Housing (Incl. Ref. #10 & 15)	1	25	94-1610	Grommet	3
9	607560	Plate - Cover	1	26	94-6303	Decal - Deck	1
10	39-5770	Decal - Danger	1	27	40-1940	Washer	2
11	608175	Toe Bar	1	28	92-4856	Bolt - Shoulder	2
12	46-6811	Screw - Hex Washer Hd.	2	29	684159	Wheel & Tire Assembly - 6"	2
14	92-7736	Shield - Trailing	1	30	603567	Bolt - Wheel	2
15	93-7250	Decal - Warning	1	31	92-1006	Spring Arm Ass'y - Front	2
17	3296-39	Nut - Lock	2	32	92-1008	Knob - Height Adjust	4
				33	610358	Nut - Lock	2




C-2509

GEARCASE & WHEEL ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92-1057	Bolt – Shoulder	2
2	95-1714	Wheel & Tire Ass'y – 8"	2
3	65-2720	Ring – Retaining	4
4	65-4740	Washer – Thrust Keyed	4
5	66-6050	Key – Rocking L.H.	1
*	66-6040	Key – Rocking R.H.	1
7	65-4710	Ring – Friction	2
8	92-7746	Height Adj. Arm Ass'y – Rear	2
9	32144-70	Screw – Tapping	1
10	60-8821	Lever – Shift	1
11	3272-10	Pin – Cotter	1
12	82-8780	Retainer – Cable	1
13	24-7920	Cover – Drive Shaft	1
14	303259	Washer	1

Ref. No.	Part No.	Description	No. Used
15	605255	Washer – Flat	1
17	92-6535	Cap – End	2
18	32144-85	Screw – Hex Hd. Cap	2
19	92-6540	Spring Arm Ass'y – Rear L.H.	1
*	92-6539	Spring Arm Ass'y – Rear R.H.	1
21	610358	Nut – Lock	2
22	65-4730	Washer – Thrust	2
23	65-4760	Washer	2
24	65-4750	Gear – Pinion	2
25	65-4720	Spring – Compression	2
26	94-1609	Cover – Wheel	2
27	614426	Washer – Stepped	2
28	92-1043	V-Belt	1

*Not Illustrated




C-1322

GEAR CASE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	3285-19	Pin - Groove	1	17	36-4780	Washer	1
2	38-7820	Bearing - Ball	1	18	60-8770	Bushing - Output	1
3	60-8850	Bushing - Output	1	19	60-8750	Bushing - Inter. Shaft	2
4	65-4770	Shaft - Output	1	20	36-4791	Washer - Thrust	2
5	92-5791	Spacer	1	21	49-2040	Screw	6
6	60-8840	Pulley - Half	2	22	60-8730	Gear Case Cover	1
7	3296-5	Nut	1	23	55-3760	Pinion - 15 Tooth	1
8	3256-24	Washer	1	24	55-3780	Pinion - 20 Tooth	1
9	60-8710	Gearcase - Upper	1	25	55-3800	Pinion - 25 Tooth	1
10	60-8870	Yoke - Shift	1	26	60-8800	Shaft - Intermediate	1
11	29-9570	Bushing - Yoke	1	27	92-5790	Pinion - Bevel	1
12	60-8810	Retainer - Shift Fork	1	28	55-3770	Gear - 49 Tooth	1
13	76-0780	Sleeve - Shift Key	1	29	55-3790	Gear - 44 Tooth	1
14	76-0760	Key - Shift	2	30	55-3810	Gear - 39 Tooth	1
15	76-0770	Collar - Shift	1	31	60-8790	Sleeve - Gear	1
16	65-5250	Clip - Spring	1	*	92-7869	Gear Case Complete	1

*Not Illustrated




C-2510A

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	603164	Nut — Blade	1
2	677525	Plate & Collar Assembly	1
3	95—1727	Screw — Engine Mount	3
4	612784	Hose — Gas	1
5	609976	Pulley	1
6	610345	Screw — Set	1
7	47—2480	Rope — Stop	1
†8		Staple	1
10	32144—3	Screw — Hex Washer Hd.	2
11	684622	Housing — Starter	1
12	683638	Shroud Assembly	1
13	611214	Spring	1
14	611509	Actuator — Brake Lever	1
15	611213	Retainer	1
16	612543	Blade — 21"	1
17	94—1618	Guard — Engine	1
18	3296—29	Nut — Lock	3
20	611327	Cap — Fuel	1
21	609150	Foam — Baffle	1
22	607213	Gasket	1
23	609829	Tank — Fuel	1

Ref. No.	Part No.	Description	No. Used
24	94-4252	Leg & Saddle Assembly	1
25	312387	Clamp - Hose	1
26	677052	Valve & Screen	1
27	609830	Spring	2
28	612428	Screw - Sems	4
29	32144-53	Screw - Thr'd Form	4
30	93-0296	Decal - Recoil	1
31		Engine - 2 Cycle	1
33	612753	Decal - Oil	1
36	3229-22	Screw - Carriage	1
37	612754	Applique	1
39	2410-77	Plug - Fuel Valve	1
40	2410-76	Plug - Fuel Line	1
41	602315	Nut - Lock	1
42	3256-1	Washer - Flat	1
43	145945	Retainer - Applique	3
44	93-1233	Gasket - Muffler	1
45	92-1054	Plate - Muffler	1
46	682876	Muffler Cover Assembly	1
47	609786	Support - Crankshaft	1
48	609471	Screw	3


†Obtain Locally



C-2511

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	3230-29	Bolt - Carriage	2	23	92-1093	Bail - Engine Control	1
2	92-6537	Handle - Section Lower	1	24	93-0297	Decal - Console Front	1
3	614249	Tie Strap	3	26	93-3248	Cable - Control	1
5	322-9	Screw - Hex Hd.	2	27	612824	Clip - Rope Insert	1
6	3296-29	Nut - Lock	4	28	612825	Handle - Starter	1
7	92-9665	Screw - Phillips Hd.	4	29	93-7383	Guide - Rope	1
8	92-1078	Cam - Brake	1	30	92-2268	Screw - Handle	1
9	92-1094	Bracket - Bail Stop	1	31	92-2928	Bracket - Cable Anchor	1
12	92-5412	Stop - Pivot	1	32	3296-73	Nut - Lock	4
13	92-1617	Bail - SP Control	1	33	92-1092	Handle - Upper	1
14	321-4	Screw - Hex Hd. Cap	1	35	609739	Washer	2
15	613050	Bolt	1	36	92-7899	Bracket - Traction Cable	1
16	93-3683	Cable - Throttle	1	37	92-6518	Cable - Traction	1
18	95-1701	Decal - Control Panel	1	46	321-51	Screw - Hex Hd. Cap	1
20	92-8926	Control - Speed Ground	1	49	3296-56	Nut - Lock	1
21	16-8929	Panel - Control (Incl. Ref. #18)	1	51	3256-23	Washer - Flat	2



C-1406


STARTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93-0296	Decal	1
2	612949	Hub - Starter	1
3	612825	Handle - Starter	1
4	612824	Insert - Clip, Rope	1
5	684567	Housing - Starter	1
6	92-4935	Recoil Spring & Keeper	1

Ref. No.	Part No.	Description	No. Used
7	612950	Pulley	1
8	612432	Rope	1
9	683899	Assembly - Dog Kit	1
*	612428	Screw-Sems	4
*	684622	Assembly - Starter (Inc. Ref. No. 5-9)	1

*Not Illustrated

ENGINE ASSEMBLY




ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	611213	Retainer	1
2	611509	Actuator – Brake Lever	1
3	611214	Spring – Cable, Return	1
4	93-1240	Case – Switch	1
5	682683	Assembly – Brake	1
6	683821	Wire Lead	1
7	613529	Bolt – Shoulder	1
8	608311	Nut	1
9	683581	Assembly – Brace	1
10	603014	Bolt	1
11	306407	Washer	1
12	602315	Nut	1
13	612427	Shroud – Base	1
14	611191	Clip – "J"	1
15	609947	Screw	3
16	683580	Assembly – Flywheel	1
17	316959	Washer – Lock	1
18	130743	Nut – Flywheel	1
19	609808	Screw	1
20	317893	Tie Strap	1
21	681737	Set – Ring	1
22	303712	Ring – Retaining	2
23	606608	Pin – Wrist	1
24	92-4925	Set – Piston & Ring (Incl. Ref. # 21-23)	1
25	92-4927	Assembly – Bearing	1
26	92-4921	Assembly – Conn. Rod (Incl. Ref. #25, 27, 32, & 33)	1
27	677982	Liner – Pair	1
28	607199	Key – Flywheel	1
29	611396	Seal – Oil	2
30	681830	Bearing – Main	1
31	94-5713	Crankshaft	1
32	611393	Screw	2
33	609754	Strip – Roller	1

Ref. No.	Part No.	Description	No. Used
34	607526	Screw	2
35	614009	Spark Plug	1
37	681678	Wire Lead	1
38	683215	C. D. Ignition Module (Incl. Ref. #37)	1
39	605120	Grommet	2
40	614249	Tie Strap	1
41	613072	Bracket – C. D.	1
42	614343	Screw	2
44	609123	Plug	4
46	612872	Screw	2
47	602587	Plate – Reed	1
48	602588	Reed	1
49	681831	Bearing – Main	1
51	613110	Screw	2
52	611192	Bracket – Brake	1
53	613233	Screw	2
54	611211	Spring – Brake	1
55	93-1239	Spring	1
56	306407	Washer	2
57	321-6	Screw – Hex Hd. Cap	1
59	612842	Shield	1
60	612841	Plate – Contact	1
61	3255-7	Washer – Lock	1
62	306375	Nut	1
*	94-5734	Assembly – Short Block (Incl. Ref. No.21-27, 29-33, & 43-51)	1
63	3229-22	Bolt – Carriage	1
64	252-76	Bearing – Thrust	1
65	252-80	Washer – Thrust	1
66	609900	Nut – Speed	1
*	93-4307	Switch Kit (Incl. Ref. #1, 4, 6, 55, 57, & 59-62)	1

*Not Illustrated




C-2182C

CARBURETOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	610834	Collar — Adjustment	1	15	612383	Washer	1
2	610165	Retainer	1	16	678113	Float & Arm Assembly	1
3	93-1225	Lever — Speed Adjust	1	17	92-6389	Pin	1
4	611545	Plug	1	18	603145	Clip	1
5	609482	Screw — Pan Hd. Sems	2	19	92-9697	Float, Valve, & Body Ass'y	1
6	613269	Screw	4	21	92-4944	Spring — Governor	1
7	93-4341	Body — Carburetor	1	22	93-1226	Bracket — Throttle Control	1
8	93-1232	Bracket — Primer	1	23	94-5704	Disc — Throttle	1
9	602850	Gasket — Float Chamber	1	24	92-6376	Air Vane & Shaft	1
10	608850	Screw	4	25	66-7460	Bulb — Primer	1
11	92-9691	Float Chamber	1	26	44-2750	Body — Primer	1
12	611071	Filter — Fuel	1	27	44-3172	Hose — Primer	1
13	94-5710	Main Jet	1	*	94-5738	Carburetor Complete	1
14	92-6371	Nozzle	1				

*Not Illustrated



C-2184A

AIR FILTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	610383	Retainer – Cover	1
2	93-1231	Cover – Air Filter	1
3	609493	Element – Air Filter	1

Ref. No.	Part No.	Description	No. Used
4	93-1221	Shield – Heat	1
5	92-4948	Gasket – Carb.	2

LAWN-BOY PART NUMBER INDEX

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
130743	Nut – Flywheel	8 18 1	612383	Washer	9 15 1
145945	Retainer – Applique	4 43 3	612427	Shroud – Base	8 13 1
303259	Washer	2 14 1	612428	Screw – Sems	4 28 4
303712	Ring – Retaining	8 22 2	612428	Screw–Sems	6 * 4
306375	Nut	8 62 1	612432	Rope	6 8 1
306407	Washer	8 11 1	612543	Blade – 21	4 16 1
306407	Washer	8 56 2	612753	Decal – Oil	4 33 1
312387	Clamp – Hose	4 25 1	612754	Applique	4 37 1
316959	Washer – Lock	8 17 1	612784	Hose – Gas	4 4 1
317893	Tie Strap	8 20 1	612824	Clip – Rope Insert	5 27 1
602315	Nut	8 12 1	612824	Insert – Clip, Rope	6 4 1
602315	Nut – Lock	4 41 1	612825	Handle – Starter	5 28 1
602587	Plate – Reed	8 47 1	612825	Handle – Starter	6 3 1
602588	Reed	8 48 1	612841	Plate – Contact	8 60 1
602850	Gasket – Float Chamber	9 9 1	612842	Shield	8 59 1
603014	Bolt	8 10 1	612872	Screw	8 46 2
603145	Clip	9 18 1	612949	Hub – Starter	6 2 1
603164	Nut – Blade	4 1 1	612950	Pulley	6 7 1
603567	Bolt – Wheel	1 30 2	613050	Bolt	5 15 1
605120	Grommet	8 39 2	613072	Bracket – C. D.	8 41 1
605255	Washer – Flat	2 15 1	613110	Screw	8 51 2
606608	Pin – Wrist	8 23 1	613233	Screw	8 53 2
607199	Key – Flywheel	8 28 1	613269	Screw	9 6 4
607213	Gasket	4 22 1	613529	Bolt – Shoulder	8 7 1
607526	Screw	8 34 2	614009	Spark Plug	8 35 1
607560	Plate – Cover	1 9 1	614249	Tie Strap	5 3 3
608175	Toe Bar	1 11 1	614249	Tie Strap	8 40 1
608311	Nut	8 8 1	614343	Screw	8 42 2
608850	Screw	9 10 4	614426	Washer – Stepped	2 27 2
609123	Plug	8 44 4	614637	Bracket – Wheel Height Adj.	1 19 2
609150	Foam – Baffle	4 21 1	614677	Screw – Sems Thr'd Form	1 24 2
609471	Screw	4 48 3	614682	Knob – Cover Plate	1 22 1
609482	Screw – Pan Hd. Sems	9 5 2	677052	Valve & Screen	4 26 1
609493	Element – Air Filter	10 3 1	677525	Plate & Collar Assembly	4 2 1
609739	Washer	5 35 2	677982	Liner – Pair	8 27 1
609754	Strip – Roller	8 33 1	678113	Float & Arm Assembly	9 16 1
609786	Support – Crankshaft	4 47 1	681678	Wire Lead	8 37 1
609808	Screw	8 19 1	681737	Set – Ring	8 21 1
609829	Tank – Fuel	4 23 1	681830	Bearing – Main	8 30 1
609830	Spring	4 27 2	681831	Bearing – Main	8 49 1
609900	Nut – Speed	8 66 1	682683	Assembly – Brake	8 5 1
609947	Screw	8 15 3	682876	Muffler Cover Assembly	4 46 1
609976	Pulley	4 5 1	683215	C. D. Ignition Module	8 38 1
610165	Retainer	9 2 1	683580	Assembly – Flywheel	8 16 1
610345	Screw – Set	4 6 1	683581	Assembly – Brace	8 9 1
610358	Nut – Lock	2 21 2	683638	Shroud Assembly	4 12 1
610358	Nut – Lock	1 33 2	683821	Wire Lead	8 6 1
610383	Retainer – Cover	10 1 1	683899	Assembly – Dog Kit	6 9 1
610834	Collar – Adjustment	9 1 1	684159	Wheel & Tire Assembly – 6	1 29 2
611071	Filter – Fuel	9 12 1	684567	Housing – Starter	6 5 1
611191	Clip – J	8 14 1	684622	Assembly – Starter	6 * 1
611192	Bracket – Brake	8 52 1	684622	Housing – Starter	4 11 1
611211	Spring – Brake	8 54 1	12-5450	Screw – Thr'd Form	1 5 2
611213	Retainer	8 1 1	16-8929	Panel – Control	5 21 1
611213	Retainer	4 15 1	17-4629	Housing	1 7 1
611214	Spring	4 13 1	24-7920	Cover – Drive Shaft	2 13 1
611214	Spring – Cable, Return	8 3 1	29-9570	Bushing – Yoke	3 11 1
611327	Cap – Fuel	4 20 1	36-4780	Washer	3 17 1
611393	Screw	8 32 2	36-4791	Washer – Thrust	3 20 2
611396	Seal – Oil	8 29 2	38-7820	Bearing – Ball	3 2 1
611509	Actuator – Brake Lever	8 2 1	39-5770	Decal – Danger	1 10 1
611509	Actuator – Brake Lever	4 14 1	40-1940	Washer	1 18 4
611545	Plug	9 4 2	40-1940	Washer	1 27 2

*Not Illustrated

LAWN-BOY PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
44-2750	Body - Primer	9 26 1	92-6518	Cable - Traction	5 37 1
44-3172	Hose - Primer	9 27 1	92-6535	Cap - End	2 17 2
46-6811	Screw - Hex Washer Hd.	1 12 2	92-6537	Handle - Section Lower	5 2 1
47-2480	Rope - Stop	4 7 1	92-6539	Spring Arm Ass'y -	2 * 1
49-2040	Screw	3 21 6	92-6540	Spring Arm Ass'y -	2 19 1
55-3760	Pinion - 15 Tooth	3 23 1	92-7699	Bracket - Actuator	1 3 1
55-3770	Gear - 49 Tooth	3 28 1	92-7736	Shield - Trailing	1 14 1
55-3780	Pinion - 20 Tooth	3 24 1	92-7746	Height Adj. Arm Ass'y -	2 8 2
55-3790	Gear - 44 Tooth	3 29 1	92-7748	Screw	1 4 2
55-3800	Pinion - 25 Tooth	3 25 1	92-7869	Gear Case Assembly	1 1 1
55-3810	Gear - 39 Tooth	3 30 1	92-7869	Gear Case Complete	3 * 1
60-8710	Gearcase - Upper	3 9 1	92-7899	Bracket - Traction Cable	5 36 1
60-8730	Gear Case Cover	3 22 1	92-8852	Cover - Drive	1 6 1
60-8750	Bushing - Inter. Shaft	3 19 2	92-8926	Control - Speed Ground	5 20 1
60-8770	Bushing - Output	3 18 1	92-9665	Screw - Phillips Hd.	5 7 4
60-8790	Sleeve - Gear	3 31 1	92-9673	Bolt - Shoulder	1 21 2
60-8800	Shaft - Intermediate	3 26 1	92-9691	Float Chamber	9 11 1
60-8810	Retainer - Shift Fork	3 12 1	92-9697	Float, Valve, & Body Ass'y	9 19 1
60-8821	Lever - Shift	2 10 1	93-0296	Decal	6 1 1
60-8840	Pulley - Half	3 6 2	93-0296	Decal - Recoil	4 30 1
60-8850	Bushing - Output	3 3 1	93-0297	Decal - Console Front	5 24 1
60-8870	Yoke - Shift	3 10 1	93-1221	Shield - Heat	10 4 1
65-2720	Ring - Retaining	2 3 4	93-1225	Lever - Speed Adjust	9 3 1
65-4710	Ring - Friction	2 7 2	93-1226	Bracket - Throttle Control	9 22 1
65-4720	Spring - Compression	2 25 2	93-1231	Cover - Air Filter	10 2 1
65-4730	Washer - Thrust	2 22 2	93-1232	Bracket - Primer	9 8 1
65-4740	Washer - Thrust Keyed	2 4 4	93-1233	Gasket - Muffler	4 44 1
65-4750	Gear - Pinion	2 24 2	93-1239	Spring	8 55 1
65-4760	Washer	2 23 2	93-1240	Case - Switch	8 4 1
65-4770	Shaft - Output	3 4 1	93-3248	Cable - Control	5 26 1
65-5250	Clip - Spring	3 16 1	93-3683	Cable - Throttle	5 16 1
66-6040	Key - Rocking R.H.	2 * 1	93-4307	Switch Kit	8 * 1
66-6050	Key - Rocking L.H.	2 5 1	93-4341	Body - Carburetor	9 7 1
66-7460	Bulb - Primer	9 25 1	93-7250	Decal - Warning	1 15 1
76-0760	Key - Shift	3 14 2	93-7383	Guide - Rope	5 29 1
76-0770	Collar - Shift	3 15 1	94-1609	Cover - Wheel	2 26 2
76-0780	Sleeve - Shift Key	3 13 1	94-1610	Grommet	1 25 3
82-8780	Retainer - Cable	2 12 1	94-1618	Guard - Engine	4 17 1
92-1006	Spring Arm Ass'y - Front	1 31 2	94-4252	Leg & Saddle Assembly	4 24 1
92-1008	Knob - Height Adjust	1 32 4	94-5704	Disc - Throttle	9 23 1
92-1043	V-Belt	2 28 1	94-5710	Main Jet	9 13 1
92-1054	Plate - Muffler	4 45 1	94-5713	Crankshaft	8 31 1
92-1057	Bolt - Shoulder	2 1 2	94-5734	Assembly - Short Block	8 * 1
92-1078	Cam - Brake	5 8 1	94-5738	Carburetor Complete	9 * 1
92-1092	Handle - Upper	5 33 1	94-6303	Decal - Deck	1 26 1
92-1093	Bail - Engine Control	5 23 1	95-1701	Decal - Control Panel	5 18 1
92-1094	Bracket - Bail Stop	5 9 1	95-1714	Wheel & Tire Ass'y - 8	2 2 2
92-1617	Bail - SP Control	5 13 1	95-1727	Screw - Engine Mount	4 3 3
92-2268	Screw - Handle	5 30 1	2410-76	Plug - Fuel Line	4 40 1
92-2928	Bracket - Cable Anchor	5 31 1	2410-77	Plug - Fuel Valve	4 39 1
92-4856	Bolt - Shoulder	1 28 2	252-76	Bearing - Thrust	8 64 1
92-4921	Assembly - Conn. Rod	8 26 1	252-80	Washer - Thrust	8 65 1
92-4925	Set - Piston & Ring	8 24 1	256-251	Bushing - Spacer	1 2 2
92-4927	Assembly - Bearing	8 25 1	321-4	Screw - Hex Hd. Cap	5 14 1
92-4935	Recoil Spring & Keeper	6 6 1	321-6	Screw - Hex Hd. Cap	8 57 1
92-4944	Spring - Governor	9 21 1	321-51	Screw - Hex Hd. Cap	5 46 1
92-4948	Gasket - Carb.	10 5 2	322-9	Screw - Hex Hd.	5 5 2
92-5412	Stop - Pivot	5 12 1	3229-22	Bolt - Carriage	8 63 1
92-5790	Pinion - Bevel	3 27 1	3229-22	Screw - Carriage	4 36 1
92-5791	Spacer	3 5 1	3230-29	Bolt - Carriage	5 1 2
92-6371	Nozzle	9 14 1	3255-7	Washer - Lock	8 61 1
92-6376	Air Vane & Shaft	9 24 1	3256-1	Washer - Flat	4 42 1
92-6389	Pin	9 17 1	3256-23	Washer - Flat	5 51 2

*Not Illustrated

LAWN-BOY PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
3256-24	Washer	3 8 1	3296-56	Nut - Lock	5 49 1
3272-10	Pin - Cotter	2 11 1	3296-73	Nut - Lock	5 32 4
3285-19	Pin - Groove	3 1 1	32144-3	Screw - Hex Washer Hd.	4 10 2
3290-413	Washer - Belleville	1 20 2	32144-53	Screw - Thr'd Form	4 29 4
3296-5	Nut	3 7 1	32144-70	Screw - Tapping	2 9 1
3296-29	Nut - Lock	5 6 4	32144-85	Screw - Hex Hd. Cap	2 18 2
3296-29	Nut - Lock	4 18 3			
3296-39	Nut - Lock	1 17 2			

MAINTENANCE RECORD

[illegible]