FORM NO. 3319–240 REV.A


TORO®

MODEL NO. 53002–790001 & UP

PARTS CATALOG

PROLINE STRING TRIMMER

Industrial 26cc



C–2640


CLUTCH AND HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	M214592	Bearing Case	1
2	M214161	Bearing	2
3	M054676	Snap Ring	1
4	M214162	Buffer	1
5	M214163	Washer	1
6	M092033	Screw	4
7	M214593	Driveshaft Tube Adapter	1
8	M092561	Bolt	1
9	M054677	Clutch Drum	1
10	M221434	Shaft Grip	1
11	M221465	Throttle Trigger	1
12	M214083	Outer Guide	1
13	M054691	Hanging Bracket Assembly (Incl. Ref. #14)	1
14	M089738	Bolt	1
16	M219032	Loop Handle	1
17	M213171	Packing	1
18	M092088	Screw	4
19	M081027	Nut	4
20	M817002	Bolt	4
21	M213444	Throttle Cable	1
22	M213548	Plastic Tube	1
*	M215512	Clutch Case Assembly (Incl. Ref. #1–7)	1
*	95–6122	Safety Glasses	1

* Not Illustrated

©The TORO Company – 1997, Rev. 1998
All Rights Reserved

TPS




C−2636

HEAD, SHAFT AND SHIELD ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	M219268	Driveshaft Assembly	1
2	M221753	Driveshaft Tube Assembly (Incl. Ref. # 14,15)	1
5	M221436	Safety Cover Assembly (Incl. Ref. # 6−13)	1
6	M221403	Safety Cover	1
8	M221438	String Cutter	1
9	M092560	Bolt	2
10	M012501	Spring Washer	2
11	M081027	Nut	2
12	M221469	Plate	1
13	M092579	Bolt	4
14	M221502	Decal − Caution	1
15	M221501	Decal − Caution	1

Ref. No.	Part No.	Description	No. Used
16	M221500	Decal − Toro	1
17	95−7468	Bolt	1
18	95−7460	Housing	1
19	95−7450	Eyelet	2
20	95−7464	Spool With Line	1
*	95−7461	Spool	1
21	95−7467	Spring	1
22	95−7462	Button	1
23	95−7463	Cover	1
*	95−4425	5” Head Assembly (Incl. Ref. #17−23)	1
*	M221437	String Cutter Assembly (Incl. Ref. #8−11)	1

* Not Illustrated



C−2637


GEARCASE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
2	M219077	Gearcase	1
3	M089884	Bolt	1
4	M210554	Bearing	1
5	M210555	Gear	1
6	M215762	Blade Shaft	1
7	M212999	Bearing	1
8	M055185	Snap Ring	1
9	M215544	Pinion Gear	1
10	M210560	Bearing	1

Ref. No.	Part No.	Description	No. Used
11	M140268	Bearing	1
12	M140269	Snap Ring	1
13	M140270	Snap Ring	1
14	M092561	Bolt	1
15	M221467	Boss Adapter	1
16	M221998	Bolt	1
17	M089737	Bolt	1
*	M221435	Gearcase Assembly	1

* Not Illustrated

ENGINE ASSEMBLY




ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
2	M261472	Cylinder	1
3	M262200	Gasket	1
4	M261250	Cap Screw	11
5	M266317	Insulator	1
6	M266124	Air Duct	1
7	M261171	Gasket	2
8	M265924	Cap Screw	2
9	M262438	Muffler Body	1
10	M261986	Deflector Plate	1
11	M261368	Deflector	1
12	M261968	Gasket	1
13	M261246	Cap Screw	2
14	M261607	Cap Screw	3
15	M262440	Muffler Cover	1
16	M262442	Muffler Trail	1
17	M262443	Spark Arrestor	1
18	M262446	Gasket	1
19	M263743	Washer	2
21	M266068	Top Cover	1
22	M261018	Knob	1
23	M261020	Spacer	1
24	M261734	Snap Ring	1
25	M261486	Crankcase	1
26	M261491	Bearing	2
27	M261492	Oil Seal	1
28	M261386	Oil Seal	1
29	M055185	Snap Ring	1
30	M261612	Cap Screw	3
31	M265012	Piston	1
32	M261496	Piston Ring	2
33	M261497	Piston Pin	1
34	M261037	Bearing − Needle	1
35	M261576	Clip − Piston	2
36	M265197	Crankshaft − Connector Rod Assembly	1
38	M264504	Clutch Shoe	2
39	M263614	Spring − Clutch	1
40	M261189	Washer	2
41	M261777	Wave Washer	2
42	M264505	Bolt	2
43	M266319	Fan Cover	1
45	M261356	Rotor − Fan	1
46	M261301	Ignition Coil Assembly (Incl. Ref. #47−53)	1
47	M261302	Coil	1
49	M261071	Spark Plug Wire	1
50	M261074	Plug Boot	1
51	M261075	Connector	1
52	M261072	Cap	1
53	M261073	Insulator	1
54	M261076	Woodruff Key	1
55	M261417	Nut − Rotor	1
56	M261078	Spacer	2
57	M261256	Cap Screw	2
58	M261200	Spark Plug (NGK BPM6Y)	1
59	M261772	Wire − Coil Ground	2
60	M261202	Grommet	1
62	M262039	Recoil Assembly (Incl. Ref. #63−70)	1
64	M261725	Starter Grip	1
65	M261724	Starter Rope	1
68	M261721	Spiral Spring	1
69	M261720	Pulley	1
70	M262922	Screw	1
72	M263477	Pawl	1
73	M261728	Return Spring	1
74	M263476	Pawl Case	1
75	M261257	Cap Screw	4
76	M266099	Stand	1
79	M261999	Cap Screw	2
80	M266322	Decal − Toro	1
81	M266211	Decal − Toro (Round)	1
82	25−9150	Decal − Serial	1
*	M261910	Liquid Gasket	1
*	M266237	Engine Assembly	1

* Not Illustrated

CARBURETOR AND FUEL ASSEMBLY



C−2644

CARBURETOR AND FUEL ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	M266153	Carburetor Assembly (Incl. Ref. # 2−19)	1
2	M261871	O−Ring	1
3	M262120	Main Jet	1
4	M262995	Gasket	1
5	M262994	Diaphragm	1
6	M263739	Pump Body	1
7	M262993	Gasket	1
8	M261873	Diaphragm	1
9	M262991	Purge Body	1
10	M261874	Primer Bulb	1
11	M262992	Cover Plate	1
12	M262996	Screw	4
13	M261876	E−Ring	1
14	M261658	Swivel	1
15	M261875	Screw	2
16	M264677	Bracket	1
17	M261878	Nut	1
18	M263994	Adapter	1
19	M261657	Packing	1
20	M261864	Gasket	1
22	M261594	Bracket	1
23	M266330	Choke Valve	1
24	M263097	Packing	1
25	M261597	Bolt	1
26	M263984	Washer	1
27	M261660	Nut	1
28	M262720	Cap Screw	2
30	M261598	Foam Element	1
31	M261734	Snap Ring	1
32	M266493	Air Filter Cover	1
33	M263129	Knob	1
34	M261993	Screen	1
35	M261352	Decal	1
37	M266071	Fuel Tank	1
38	M264784	Fuel Tank Cap Assembly (Incl. Ref. # 39)	1
39	M261105	Gasket	1
40	M261696	Breather Assembly	1
42	M264031	Fuel Pipe Assembly (Incl. Ref. # 43−45)	1
43	M261115	Grommet	1
44	M261690	Fuel Pipe	1
45	M263038	Return Pipe	1
46	M261797	Fuel Filter Assembly	1
47	M261117	Clip	2
48	M261118	Pad	2
49	M261119	Pad	1
50	M266291	Decal	1

TORO PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.
M012501	Spring Washer	2	10	2
M054676	Snap Ring	1	3	1
M054677	Clutch Drum	1	9	1
M054691	Hanging Bracket Assembly	1	13	1
M055185	Snap Ring	3	8	1
M055185	Snap Ring	5	29	1
M081027	Nut	2	11	2
M081027	Nut	1	19	4
M089737	Bolt	3	17	1
M089738	Bolt	1	14	1
M089884	Bolt	3	3	1
M092033	Screw	1	6	4
M092088	Screw	1	18	4
M092560	Bolt	2	9	2
M092561	Bolt	1	8	1
M092561	Bolt	3	14	1
M092579	Bolt	2	13	4
M140268	Bearing	3	11	1
M140269	Snap Ring	3	12	1
M140270	Snap Ring	3	13	1
M210554	Bearing	3	4	1
M210555	Gear	3	5	1
M210560	Bearing	3	10	1
M212999	Bearing	3	7	1
M213171	Packing	1	17	1
M213444	Throttle Cable	1	21	1
M213548	Plastic Tube	1	22	1
M214083	Outer Guide	1	12	1
M214161	Bearing	1	2	2
M214162	Buffer	1	4	1
M214163	Washer	1	5	1
M214592	Bearing Case	1	1	1
M214593	Driveshaft Tube Adapter	1	7	1
M215512	Clutch Case Assembly	1	*	1
M215544	Pinion Gear	3	9	1
M215762	Blade Shaft	3	6	1
M219032	Loop Handle	1	16	1
M219077	Gearcase	3	2	1
M219268	Driveshaft Assembly	2	1	1
M221403	Safety Cover	2	6	1
M221434	Shaft Grip	1	10	1
M221435	Gearcase Assembly	3	*	1
M221436	Safety Cover Assembly	2	5	1
M221437	String Cutter Assembly	2	*	1
M221438	String Cutter	2	8	1
M221465	Throttle Trigger	1	11	1
M221467	Boss Adapter	3	15	1
M221469	Plate	2	12	1
M221500	Decal − Toro	2	16	1
M221501	Decal − Caution	2	15	1
M221502	Decal − Caution	2	14	1
M221753	Driveshaft Tube Assembly	2	2	1
M221998	Bolt	3	16	1
M261018	Knob	5	22	1
M261020	Spacer	5	23	1
M261037	Bearing − Needle	5	34	1
M261071	Spark Plug Wire	5	49	1
M261072	Cap	5	52	1
M261073	Insulator	5	53	1
M261074	Plug Boot	5	50	1
M261075	Connector	5	51	1
M261076	Woodruff Key	5	54	1
M261078	Spacer	5	56	2
M261105	Gasket	7	39	1
M261115	Grommet	7	43	1
M261117	Clip	7	47	2
M261118	Pad	7	48	2
M261119	Pad	7	49	1
M261171	Gasket	5	7	2
M261189	Washer	5	40	2
M261200	Spark Plug (NGK BPM6Y)	5	58	1
M261202	Grommet	5	60	1
M261246	Cap Screw	5	13	2
M261250	Cap Screw	5	4	11
M261256	Cap Screw	5	57	2
M261257	Cap Screw	5	75	4
M261301	Ignition Coil Assembly	5	46	1
M261302	Coil	5	47	1
M261352	Decal	7	35	1
M261356	Rotor − Fan	5	45	1
M261368	Deflector	5	11	1
M261386	Oil Seal	5	28	1
M261417	Nut − Rotor	5	55	1
M261472	Cylinder	5	2	1
M261486	Crankcase	5	25	1
M261491	Bearing	5	26	2
M261492	Oil Seal	5	27	1
M261496	Piston Ring	5	32	2
M261497	Piston Pin	5	33	1
M261576	Clip − Piston	5	35	2
M261594	Bracket	7	22	1
M261597	Bolt	7	25	1
M261598	Foam Element	7	30	1
M261607	Cap Screw	5	14	3
M261612	Cap Screw	5	30	3
M261657	Packing	7	19	1
M261658	Swivel	7	14	1
M261660	Nut	7	27	1
M261690	Fuel Pipe	7	44	1
M261696	Breather Assembly	7	40	1
M261720	Pulley	5	69	1
M261721	Spiral Spring	5	68	1
M261724	Starter Rope	5	65	1
M261725	Starter Grip	5	64	1
M261728	Return Spring	5	73	1
M261734	Snap Ring	5	24	1
M261734	Snap Ring	7	31	1
M261772	Wire − Coil Ground	5	59	2
M261777	Wave Washer	5	41	2
M261797	Fuel Filter Assembly	7	46	1
M261864	Gasket	7	20	1
M261871	O−Ring	7	2	1
M261873	Diaphragm	7	8	1
M261874	Primer Bulb	7	10	1
M261875	Screw	7	15	2
M261876	E−Ring	7	13	1
M261878	Nut	7	17	1
M261910	Liquid Gasket	5	*	1
M261968	Gasket	5	12	1
M261986	Deflector Plate	5	10	1
M261993	Screen	7	34	1
M261999	Cap Screw	5	79	2
M262039	Recoil Assembly	5	62	1
M262120	Main Jet	7	3	1
M262200	Gasket	5	3	1
M262438	Muffler Body	5	9	1
M262440	Muffler Cover	5	15	1
M262442	Muffler Trail	5	16	1
M262443	Spark Arrestor	5	17	1
M262446	Gasket	5	18	1
M262720	Cap Screw	7	28	2
M262922	Screw	5	70	1
M262991	Purge Body	7	9	1
M262992	Cover Plate	7	11	1
M262993	Gasket	7	7	1
M262994	Diaphragm	7	5	1
M262995	Gasket	7	4	1
M262996	Screw	7	12	4
M263038	Return Pipe	7	45	1
M263097	Packing	7	24	1
M263129	Knob	7	33	1
M263476	Pawl Case	5	74	1
M263477	Pawl	5	72	1
M263614	Spring − Clutch	5	39	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.
M263739	Pump Body	7	6	1
M263743	Washer	5	19	2
M263984	Washer	7	26	1
M263994	Adapter	7	18	1
M264031	Fuel Pipe Assembly	7	42	1
M264504	Clutch Shoe	5	38	2
M264505	Bolt	5	42	2
M264677	Bracket	7	16	1
M264784	Fuel Tank Cap Assembly	7	38	1
M265012	Piston	5	31	1
M265197	Crankshaft − Connector	5	36	1
M265924	Cap Screw	5	8	2
M266068	Top Cover	5	21	1
M266071	Fuel Tank	7	37	1
M266099	Stand	5	76	1
M266124	Air Duct	5	6	1
M266153	Carburetor Assembly	7	1	1
M266211	Decal − Toro (Round)	5	81	1
M266237	Engine Assembly	5	*	1
M266291	Decal	7	50	1
M266317	Insulator	5	5	1
M266319	Fan Cover	5	43	1
M266322	Decal − Toro	5	80	1
M266330	Choke Valve	7	23	1
M266493	Air Filter Cover	7	32	1
M817002	Bolt	1	20	4
25−9150	Decal − Serial	5	82	1
95−4425	5” Head Assembly	2	*	1
95−6122	Safety Glasses	1	*	1
95−7450	Eyelet	2	19	2
95−7460	Housing	2	18	1
95−7461	Spool	2	*	1
95−7462	Button	2	22	1
95−7463	Cover	2	23	1
95−7464	Spool With Line	2	20	1
95−7467	Spring	2	21	1
95−7468	Bolt	2	17	1

OPTIONAL EQUIPMENT

Brushcutter Accessory Kit	53050
Single Strap Harness	46−2951
Deluxe Strap Harness	46−2961
Original Strap Harness	M220952

*Not Illustrated

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Lawnmower has two identification numbers; a model number and a serial number. The two numbers are stamped on a decal which is located on the rear of the housing. In any correspondence concerning the lawnmower, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Service Dealer, supply the following information:
1. Model and serial number of the lawnmower.
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

Date								

MAINTENANCE RECORD

Date								

3319–240A

MAINTENANCE RECORD

Date								

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.

Litho in U.S.A.