




MODEL NO. 53021-790001 & UP

PARTS CATALOG

PROLINE BRUSH CUTTER Industrial 32cc




C-2647

CLUTCH AND HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	M215532	Shaft Grip	1	14	M215512	Clutch Case Assembly (Incl. Ref. #2-8)	1
2	M054691	Hanging Bracket Assembly (Incl. Ref. #3)	1	15	M214592	Bearing Case	1
3	M089738	Bolt	1	16	M214161	Bearing	2
4	M220952	Hanging Strap Assembly	1	17	M054676	Snap Ring	1
5	M215418	Bracket Assembly (Incl. Ref. #6)	1	18	M214162	Buffer	1
6	M092561	Bolt	6	19	M214163	Washer	1
8	M221441	Handle	1	20	M092033	Screw	4
9	M218467	Handle Grip	1	21	M214593	Driveshaft Tube Adapter	1
11	M221443	Handle	1	22	M092561	Bolt	1
12	M218468	Handle Grip	1	23	M054677	Clutch Drum	1
13	M221599	Throttle Trigger	1	24	M817002	Bolt	4
				*	95-6122	Safety Glasses	1

* Not Illustrated




C-2648

SHAFT ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	M219268	Driveshaft Assembly	1
2	M221753	Driveshaft Tube Assembly (Incl. Ref. # 6, 7)	1
3	M219129	Safety Cover	1
4	M092579	Bolt	4

Ref. No.	Part No.	Description	No. Used
5	M220534	Blade Cover	1
6	M221502	Decal - Caution	1
7	M221501	Decal - Caution	1
8	M221500	Decal - Toro	1

* Not Illustrated




C-2649

GEARCASE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	M220577	Gearcase Assembly (Incl. Ref. 2-18)	1	11	M140268	Bearing	1
2	M219077	Gearcase	1	12	M140269	Snap Ring	1
3	M089884	Bolt	1	13	M140270	Snap Ring	1
4	M210554	Bearing	1	14	M092561	Bolt	1
5	M210555	Gear	1	15	M212986	Boss Adapter	1
6	M215762	Blade Shaft	1	16	M140275	Clamping Washer	1
7	M212999	Bearing	1	17	M215547	Stabilizer	1
8	M055185	Snap Ring	1	18	M215610	Bolt	1
9	M215544	Pinion Gear	1	19	M089737	Bolt	1
10	M210560	Bearing	1	20	M212662	8 Tooth Blade	1

ENGINE ASSEMBLY




ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
2	M261360	Cylinder	1
3	M262201	Gasket	1
4	M261250	Cap Screw	11
5	M266317	Insulator	1
6	M266125	Air Duct	1
7	M261171	Gasket	2
8	M265924	Cap Screw	2
9	M262448	Muffler Body	1
10	M261986	Deflector Plate	1
11	M261368	Deflector	1
12	M261869	Gasket	1
13	M261246	Cap Screw	2
14	M261607	Cap Screw	3
15	M262450	Muffler Cover	1
16	M262442	Muffler Trail	1
17	M262443	Spark Arrestor	1
18	M262446	Gasket	1
19	M263743	Washer	2
21	M266069	Top Cover	1
22	M261018	Knob	1
23	M261020	Spacer	1
24	M261734	Snap Ring	1
25	M261379	Crankcase	1
26	M261384	Bearing	2
27	M261385	Oil Seal	1
28	M261386	Oil Seal	1
29	M016732	Snap Ring	1
30	M261612	Cap Screw	3
31	M261388	Piston	1
32	M261390	Piston Ring	2
33	M261555	Piston Pin	1
34	M261392	Bearing – Needle	1
35	M261393	Clip – Piston	2
36	M261395	Crankshaft – Connector	
		Rod Assembly	1
38	M264504	Clutch Shoe	2
39	M263614	Spring – Clutch	1
40	M261189	Washer	2

Ref. No.	Part No.	Description	No. Used
41	M261777	Wave Washer	2
42	M264505	Bolt	2
43	M266319	Fan Cover	1
45	M261356	Rotor – Fan	1
46	M261301	Ignition Coil Assembly (Incl. Ref. #47–53)	1
47	M261302	Coil	1
49	M261071	Spark Plug Wire	1
50	M261074	Plug Boot	1
51	M261075	Connector	1
52	M261072	Cap	1
53	M261073	Insulator	1
54	M261076	Woodruff Key	1
55	M261417	Nut – Rotor	1
56	M261078	Spacer	2
57	M261256	Cap Screw	2
58	M261200	Spark Plug (NGK BPM6Y)	1
59	M261772	Wire – Coil Ground	2
60	M261202	Grommet	1
62	M262039	Recoil Assembly (Incl. Ref. #63–68)	1
64	M261725	Starter Grip	1
65	M261724	Starter Rope	1
66	M261721	Spiral Spring	1
67	M261720	Pulley	1
68	M262922	Screw	1
70	M263477	Pawl	1
71	M261728	Return Spring	1
72	M263476	Pawl Case	1
73	M261257	Cap Screw	4
74	M266100	Stand	1
75	M261999	Cap Screw	2
76	M266322	Decal – Toro	1
77	M266211	Decal – Toro (Round)	1
78	25–9150	Decal – Serial	1
*	M261910	Liquid Gasket	1
*	M266224	Engine Assembly	1

* Not Illustrated

CARBURETOR AND FUEL ASSEMBLY



CARBURETOR AND FUEL ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	M266154	Carburetor Assembly (Incl. Ref. # 2–19)	1
2	M261871	O–Ring	1
3	M266175	Main Jet	1
4	M262995	Gasket	1
5	M262994	Diaphragm	1
6	M263739	Pump Body	1
7	M262993	Gasket	1
8	M261873	Diaphragm	1
9	M262991	Purge Body	1
10	M261874	Primer Bulb	1
11	M262992	Cover Plate	1
12	M262996	Screw	4
13	M261876	E–Ring	1
14	M261658	Swivel	1
15	M261875	Screw	2
16	M264677	Bracket	1
17	M261878	Nut	1
18	M263994	Adapter	1
19	M261657	Packing	1
20	M261864	Gasket	1
22	M261594	Bracket	1
23	M266330	Choke Valve	1
24	M263097	Packing	1

Ref. No.	Part No.	Description	No. Used
25	M261597	Bolt	1
26	M263984	Washer	1
27	M261660	Nut	1
28	M262720	Cap Screw	2
30	M261598	Foam Element	1
31	M261734	Snap Ring	1
32	M266493	Air Filter Cover	1
33	M263129	Knob	1
34	M261993	Screen	1
35	M261352	Decal	1
37	M266072	Fuel Tank	1
38	M264784	Fuel Tank Cap Assembly (Incl. Ref. #39)	1
39	M261105	Gasket	1
40	M261696	Breather Assembly	1
43	M261115	Grommet	1
44	M261690	Fuel Pipe	1
45	M263038	Return Pipe	1
46	M261797	Fuel Filter Assembly	1
47	M261117	Clip	2
48	M261118	Pad	2
49	M261119	Pad	1
50	M266291	Decal	1

TORO PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
M016732	Snap Ring	5	29	1	M261256	Cap Screw	5	57	2
M054676	Snap Ring	1	17	1	M261257	Cap Screw	5	73	4
M054677	Clutch Drum	1	23	1	M261301	Ignition Coil Assembly	5	46	1
M054691	Hanging Bracket Assembly	1	2	1	M261302	Coil	5	47	1
M055185	Snap Ring	3	8	1	M261352	Decal	7	35	1
M089737	Bolt	3	19	1	M261355	Magneto Assembly	5	44	1
M089738	Bolt	1	3	1	M261356	Rotor – Fan	5	45	1
M089884	Bolt	3	3	1	M261360	Cylinder	5	2	1
M092033	Screw	1	20	4	M261368	Deflector	5	11	1
M092561	Bolt	1	6	6	M261379	Crankcase	5	25	1
M092561	Bolt	3	14	1	M261384	Bearing	5	26	2
M092561	Bolt	1	22	1	M261385	Oil Seal	5	27	1
M092579	Bolt	2	4	4	M261386	Oil Seal	5	28	1
M140268	Bearing	3	11	1	M261388	Piston	5	31	1
M140269	Snap Ring	3	12	1	M261390	Piston Ring	5	32	2
M140270	Snap Ring	3	13	1	M261392	Bearing – Needle	5	34	1
M140275	Clamping Washer	3	16	1	M261393	Clip – Piston	5	35	2
M210554	Bearing	3	4	1	M261395	Crankshaft – Connector	5	36	1
M210555	Gear	3	5	1	M261417	Nut – Rotor	5	55	1
M210560	Bearing	3	10	1	M261555	Piston Pin	5	33	1
M212662	Mowing Blade	3	20	1	M261594	Bracket	7	22	1
M212986	Boss Adapter	3	15	1	M261597	Bolt	7	25	1
M212999	Bearing	3	7	1	M261598	Foam Element	7	30	1
M214161	Bearing	1	16	2	M261607	Cap Screw	5	14	3
M214162	Buffer	1	18	1	M261612	Cap Screw	5	30	3
M214163	Washer	1	19	1	M261657	Packing	7	19	1
M214592	Bearing Case	1	15	1	M261658	Swivel	7	14	1
M214593	Driveshaft Tube Adapter	1	21	1	M261660	Nut	7	27	1
M215418	Bracket Assembly	1	5	1	M261690	Fuel Pipe	7	44	1
M215512	Clutch Case Assembly	1	14	1	M261696	Breather Assembly	7	40	1
M215532	Shaft Grip	1	1	1	M261720	Pulley	5	67	1
M215544	Pinion Gear	3	9	1	M261721	Spiral Spring	5	66	1
M215547	Stabilizer	3	17	1	M261723	Rope Assembly	5	63	1
M215610	Bolt	3	18	1	M261724	Starter Rope	5	65	1
M215762	Blade Shaft	3	6	1	M261725	Starter Grip	5	64	1
M218467	Handle Grip	1	9	1	M261728	Return Spring	5	71	1
M218468	Handle Grip	1	12	1	M261734	Snap Ring	5	24	1
M219077	Gearcase	3	2	1	M261734	Snap Ring	7	31	1
M219129	Safety Cover	2	3	1	M261744	Spark Plug Wire Assembly	5	48	1
M219268	Driveshaft Assembly	2	1	1	M261772	Wire – Coil Ground	5	59	2
M220534	Blade Cover	2	5	1	M261777	Wave Washer	5	41	2
M220577	Gearcase Assembly	3	1	1	M261797	Fuel Filter Assembly	7	46	1
M220952	Hanging Strap Assembly	1	4	1	M261864	Gasket	7	20	1
M221440	Handle Assembly	1	7	1	M261869	Gasket	5	12	1
M221441	Handle	1	8	1	M261871	O–Ring	7	2	1
M221442	Handle Assembly	1	10	1	M261873	Diaphragm	7	8	1
M221443	Handle	1	11	1	M261874	Primer Bulb	7	10	1
M221500	Decal – Toro	2	8	1	M261875	Screw	7	15	2
M221501	Decal – Caution	2	7	1	M261876	E–Ring	7	13	1
M221502	Decal – Caution	2	6	1	M261878	Nut	7	17	1
M221599	Throttle Trigger	1	13	1	M261910	Liquid Gasket	5	*	1
M221753	Driveshaft Tube Assembly	2	2	1	M261986	Deflector Plate	5	10	1
M261018	Knob	5	22	1	M261993	Screen	7	34	1
M261020	Spacer	5	23	1	M261999	Cap Screw	5	75	2
M261071	Spark Plug Wire	5	49	1	M262006	Recoil Starter Assembly	5	61	1
M261072	Cap	5	52	1	M262039	Recoil Assembly	5	62	1
M261073	Insulator	5	53	1	M262201	Gasket	5	3	1
M261074	Plug Boot	5	50	1	M262442	Muffler Trail	5	16	1
M261075	Connector	5	51	1	M262443	Spark Arrestor	5	17	1
M261076	Woodruff Key	5	54	1	M262446	Gasket	5	18	1
M261078	Spacer	5	56	2	M262448	Muffler Body	5	9	1
M261105	Gasket	7	39	1	M262450	Muffler Cover	5	15	1
M261115	Grommet	7	43	1	M262720	Cap Screw	7	28	2
M261117	Clip	7	47	2	M262922	Screw	5	68	1
M261118	Pad	7	48	2	M262991	Purge Body	7	9	1
M261119	Pad	7	49	1	M262992	Cover Plate	7	11	1
M261171	Gasket	5	7	2	M262993	Gasket	7	7	1
M261189	Washer	5	40	2	M262994	Diaphragm	7	5	1
M261200	Spark Plug (NGK BPM6Y)	5	58	1	M262995	Gasket	7	4	1
M261202	Grommet	5	60	1	M262996	Screw	7	12	4
M261246	Cap Screw	5	13	2	M263038	Return Pipe	7	45	1
M261250	Cap Screw	5	4	11	M263097	Packing	7	24	1

*Not Illustrated

TORO PART NUMBER INDEX (Cont.)

3319-243

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
M263129	Knob	7 33 1	M266175	Main Jet	7 3 1
M263475	Starter Pawl Assembly	5 69 1	M266211	Decal – Toro (Round)	5 77 1
M263476	Pawl Case	5 72 1	M266224	Engine Assembly	5 * 1
M263477	Pawl	5 70 1	M266227	Top Cover Assembly	5 20 1
M263614	Spring – Clutch	5 39 1	M266230	Fuel Tank Assembly	7 36 1
M263739	Pump Body	7 6 1	M266291	Decal	7 50 1
M263743	Washer	5 19 2	M266317	Insulator	5 5 1
M263800	Fuel Pipe Pick-up Assembly	7 41 1	M266319	Fan Cover	5 43 1
M263984	Washer	7 26 1	M266322	Decal – Toro	5 76 1
M263994	Adapter	7 18 1	M266330	Choke Valve	7 23 1
M264031	Fuel Pipe Assembly	7 42 1	M266424	Bracket Assembly	7 21 1
M264503	Clutch Assembly	5 37 1	M266492	Air Filter Assembly	7 29 1
M264504	Clutch Shoe	5 38 2	M266493	Air Filter Cover	7 32 1
M264505	Bolt	5 42 2	M817002	Bolt	1 24 4
M264677	Bracket	7 16 1	25-9150	Decal – Serial	5 78 1
M264784	Fuel Tank Cap Assembly	7 38 1	95-6122	Safety Glasses	1 * 1
M265924	Cap Screw	5 8 2	OPTIONAL EQUIPMENT		
M266069	Top Cover	5 21 1	String Trimmer Conversion Kit	53051	
M266072	Fuel Tank	7 37 1	10" – 4 Tooth Blade	M214463	
M266100	Stand	5 74 1	10" – 80 Tooth Blade	M210844	
M266125	Air Duct	5 6 1			
M266154	Carburetor Assembly	7 1 1			

*Not Illustrated

PRODUCT CHANGES

In an effort to make improvements available to TORO owners as quickly as possible, minor changes are incorporated into Toro's products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your manual, see your TORO Distributor or his Authorized TORO Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Lawnmower has two identification numbers; a model number and a serial number. The two numbers are stamped on a decal which is located on the rear of the housing. In any correspondence concerning the lawnmower, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized TORO Service Dealer, supply the following information:

1. Model and serial number of the lawnmower.
2. Part number, description, and the quantity of part(s) desired.

NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

COUNTRIES OTHER THAN THE UNITED STATES OR CANADA

Customers who have purchased TORO products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province or state. If for any

reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the TORO importer. If all other remedies fail, you may contact us at The Toro Company.

MAINTENANCE RECORD

[illegible]

[illegible]

MAINTENANCE RECORD

[illegible]

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.

Litho in U.S.A.