

LAWN-BOY®

SILVER SERIES 2 CYCLE WALK-BEHIND MOWER

MODEL NO.10227-7900001 & UP
MODEL NO.10304-7900001 & UP

PARTS CATALOG

PRODUCT CHANGES

In an effort to make improvements available to LAWN-BOY owners as quickly as possible, minor changes are incorporated into LAWN-BOY products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your Parts Catalog, see your LAWN-BOY Distributor or his Authorized LAWN-BOY Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Product two identification numbers; a model number and a serial number. The two numbers are stamped on a plate mounted on the deck. In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized Service Dealer, supply the following information:

1. Model and serial number.
2. Part number, description, and the quantity of part(s) desired.


NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
Housing Assembly (Model No. 10227)	1	Handle Assembly	8
Housing Assembly (Model No. 10304)	2	Engine Assembly	9-12
Cover Assembly (Model No. 10227)	3	Recoil Starter Assembly	13
Cover Assembly (Model No. 10304)	4	Carburetor Assembly	14
Gear Cas Assembly (Model No. 10304)	5	Lawn-Boy Part Number Index	15-16
Rear Axle Assembly (Model No. 10304)	6	Maintenance	17-18
Engine Assembly	7		

Accessories


Description	Model / Parts No.	Description	Model / Parts No.
Side Bagging Kit	Model No. 89814	Leaf Shredder Kit	Model No. 89860
Rear Bagging Kit	Model No. 89800	Leaf Bag Kit w/Chute	Model No. 89811
Leaf Bag	Model No. 89804	Mow & Feed Fertilizer Spreader .	Model No. 52070



C-2493

HOUSING ASSEMBLY (MODEL NO. 10227)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	614650	Bolt – Shoulder	2	14	92-4881	Plate – Height Adjust	2
2	684777	Wheel & Tire Ass'y 8"	2	15	92-4890	Washer	4
3	92-1005	Spring Arm Assembly	2	16	92-7731	Plate – Baffle	2
4	92-7743	Bracket – Handle L.H.	1	17	614637	Bracket – Wheel Height Adj.	4
5	16-4359	Housing Assembly	1	18	40-1940	Washer	4
6	92-7742	Bracket – Handle R.H.	1	19	684776	Wheel – Tire Assembly 6"	2
7	614682	Knob – Cover Plate	1	20	92-1099	Bolt – Shoulder	2
8	92-8630	Plate – Mulch 21"	1	21	614672	Bolt – Shoulder	4
9	614677	Screw – Sems Thr'd Form	2	22	614687	Spring Arm Ass'y – Front	2
10	94-1610	Grommet – Plastic	2	23	92-1008	Knob – Height Adjust.	4
11	613765	Nut – Cage	1	24	3296-39	Nut – Lock	2




C-2494

HOUSING ASSEMBLY (MODEL NO. 10304)

Ref. No.	Part No.	Description	No. Used
7	614682	Knob – Cover Plate	1
8	92-8630	Plate – Mulch 21"	1
9	614677	Screw – Sem Thr'd Form	2
10	94-1610	Grommet – Plastic	2
11	613765	Nut – Cage	1
14	92-4881	Plate – Height Adjust	2
15	92-4890	Washer	2
16	92-7731	Plate – Baffle	2

Ref. No.	Part No.	Description	No. Used
17	614637	Bracket – Wheel Height Adj.	2
18	40-1940	Washer	2
19	684776	Wheel & Tire Ass'y 6"	2
20	92-1099	Bolt – Shoulder	2
21	614672	Bolt – Shoulder Height Adj.	2
22	614687	Spring Arm Ass'y – Front	2
23	92-1008	Knob – Height Adjust	4




C-2495

COVER ASSEMBLY (MODEL NO. 10227)

Ref. No.	Part No.	Description	No. Used
1	92-2915	Decal - H.O.C.	2
2	92-2914	Decal - H.O.C.	2
10	93-7250	Decal - Warning	1
14	607560	Plate - Cover	1
15	39-5770	Decal - Danger	1

Ref. No.	Part No.	Description	No. Used
16	92-1097	Decal - Discharge	1
19	3296-29	Nut - Lock	4
20	92-8647	Shield - Trailing	1
21	322-3	Screw - Hex Hd. Cap	4




C-2496

COVER ASSEMBLY (MODEL NO. 10304)

Ref. No.	Part No.	Description	No. Used
1	92-2915	Decal - H.O.C.	2
2	92-2914	Decal - H.O.C.	2
3	92-7724	Bracket - Handle L.H.	1
4	92-7735	Gear Case Assembly	1
5	605120	Grommet	1
6	92-7728	Guide - Transmission	1
7	49-2040	Screw - Hex Hd.	2
8	92-9662	Screw - Phillips Hd.	1
9	614671	Cover - Drive	1


Ref. No.	Part No.	Description	No. Used
10	93-7250	Decal - Warning	1
12	92-7723	Bracket - Handle R.H.	1
14	607560	Plate - Cover	1
15	39-5770	Decal - Danger	1
16	92-1097	Decal - Discharge	1
17	16-4369	Housing Assembly	1
19	3296-29	Nut - Lock	6
20	92-8647	Shield - Trailing	1
21	322-3	Screw - Hex Hd. Cap	6



C-1292

GEAR CASE ASSEMBLY (Model No. 10304)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	32144-4	Screw - Taptite	4	10	92-7727	Gearcase	1
2	614668	Cover - Gear Case	1	11	62-6660	Spacer	1
3	55-3760	Pinion - 15 Tooth	1	12	614669	Pulley - Half	2
4	614696	Shaft - Intermediate	1	13	3256-24	Washer	1
5	36-4791	Washer	2	14	3296-5	Nut	1
6	60-8750	Bushing	2	15	38-7820	Bearing - Ball	1
7	93-0239	Shaft - Output	1	16	60-8890	Gear - Bevel Pinion	1
8	3285-19	Pin - Groove	2	17	36-4780	Washer - Thrust	2
9	60-8850	Bushing - Output	2	18	614596	Gear 34 Tooth	1




C-2497

REAR AXLE ASSEMBLY (MODEL NO. 10304)

Ref. No.	Part No.	Description	No. Used
1	92-1057	Bolt - Shoulder	2
2	92-1042	Wheel & Tire Ass'y 8"	2
3	65-2720	Ring - Retaining	4
4	65-4740	Washer - Thrust Keyed	4
5	66-6050	Key - Rocking L.H.	1
*	66-6040	Key - Rocking R.H.	1
7	65-4710	Ring - Friction	2
8	92-7746	Height Adj. Arm - Rear	2
9	614447	Spacer - Axle Shaft	2
10	93-7381	V-Belt	1

Ref. No.	Part No.	Description	No. Used
11	32144-85	Screw - Hex Hd.	2
12	92-1004	Spring Arm Ass'y	2
13	610358	Nut - Lock	2
14	65-4730	Washer - Thrust	2
15	65-4760	Washer	2
16	65-4750	Gear - Pinion	2
17	65-4720	Spring - Compression	2
18	94-1609	Cover - Wheel	2
19	614426	Washer - Stepped	2


*Not Illustrated



C-2498A

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	677525	Plate & Collar Assembly	1	13	93-4306	Spring - Compression	1
2	92-6542	Pulley - Engine (Model No. 10304 Only)	1	14		Engine Assembly	1
3	95-1726	Screw - Engine	3	15	613227	Screw - Set (Model No. 10304 Only)	1
5	92-6380	Tank & Shroud Assembly	1	16	612543	Blade - 21"	1
7	93-3660	Fuel/Oil Cap Assembly	1	17	92-1630	Fan - Mulching	1
8	93-4302	Screw - Sems	3	18	603164	Nut - Blade	1
9	92-1701	Rope - Stop	1	19	66-7460	Bulb - Primer	1
10	93-0295	Decal - Recoil (Model No. 10227 Only)	1	20	44-2750	Body - Primer	1
11	93-0294	Decal - Recoil (Model No. 10304 Only)	1	22	612782	Line - Gas	1
12	92-8615	Applique - Shroud	1	23	93-4196	Shield - Grass (Model No. 10304 Only)	1




C-2499

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
2	614697	Screw – Handle	2
3	614243	Knob	2
4	3296-73	Nut – Lock	2
5	321-48	Screw – Hex Hd. Cap (Model No. 10227 Only)	1
5	321-49	Screw – Hex Hd. Cap (Model No. 10304 Only)	1
6	92-7729	Anchor – Cable Upper (Model No. 10304 Only)	1
7	92-7726	Cable – Traction (Model No. 10304 Only)	1
8	92-5412	Stop – Pivot (Model No. 10227 Only)	1
8	92-5412	Stop – Pivot (Model No. 10304 Only)	2
9	92-1001	Bail – SP Control (Model No. 10304 Only)	1


Ref. No.	Part No.	Description	No. Used
12	93-4184	Bail – Flywheel Brake	1
13	95-1713	Handle – Section Upper	1
14	612825	Handle – Starter	1
15	321-50	Screw – Hex Hd. Cap	1
16	93-7383	Guide – Rope	1
17	92-7734	Cable – Throttle 2 Cycle	1
18	92-7738	Cable – Flywheel Brake	1
19	614673	Handle Section – Lower	1
20	93-7380	Anchor – Cable SP Lower (Model No. 10304 Only)	1
21	612824	Clip – Rope Insert	1
30	92-8632	Washer (Model No. 10227 Only)	1
31	93-3653	Handle – Guard (Model No. 10227 Only)	2
31	93-3653	Handle – Guard (Model No. 10304 Only)	1



C-2128A

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	614699	Screw	3	6	607199	Key	1
2	130743	Nut	1	7	614702	Screw	4
3	614640	Hub - Starter	1	8	93-4304	Shroud Assembly	1
4	684743	Flywheel	1	9	316959	Washer - Lock	1
5	93-1216	Base - Shroud	1				




C-2379

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
2	609482	Screw	2
3	610383	Retainer – Filter	1
4	93-1231	Cover – Air Cleaner	1
5	609493	Element – Filter Air	1
6	93-4320	Shield – Fuel	1

Ref. No.	Part No.	Description	No. Used
7	44-3174	Hose – Primer	1
8	93-4331	Carburetor Assembly (Incl. Ref. #9)	1
9	92-4948	Gasket – Carburetor	2
10	93-1221	Shield – Carburetor	1




C-1296A

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
1	94-5737	Short Block	1
2	93-1233	Gasket - Exhaust	1
3	684049	CD Ignition	1
4	614009	Plug - Spark	1
6	613208	Screw - Hex. Washer Hd.	2
8	93-4312	Brake Plate Assembly	1
9	92-9698	Screw - Shoulder	1
10	614702	Screw	1
11	3290-459	Rivet - Plastic	2
12	92-2925	Strap - Insulation	1

Ref. No.	Part No.	Description	No. Used
13	60-9010	Strap - Ground	1
14	92-1156	Wire - Brake Switch Lead	1
15	53-4690	Stop - Ground Strap	1
16	12-5450	Screw - Thread Forming	1
17	84-7820	Mounting Plate	1
18	614654	Plate - Muffler	1
19	607601	Screw	4
20	93-4343	Baffle	1
21	609471	Screw	3
22	614674	Cover - Muffler	1

*Not Illustrated




C-1295A

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
1	681737	Set – Ring	1
3	92-4923	Piston & Ring Set	1
*	92-4925	Piston & Connecting Rod (Incl. Ref. #1-8, 12, & 13)	1
4	606608	Pin – Wrist	1
5	303712	Ring – Retaining	2
6	92-4921	Connecting Rod Assembly (Incl. Ref. #6-8, 12, & 13)	1
7	92-4927	Bearing	1
8	677982	Liner – Split (Set of 2)	1
9	94-5713	Crankshaft	1
10	681830	Bearing – Upper Main	1
11	611396	Seal – Oil	2
12	683911	Bearing – Needle	1

Ref. No.	Part No.	Description	No. Used
13	611393	Screw – Hex. Hd.	2
14	614636	Screw – Torx. Washer Hd.	3
16	602588	Reed – Carburetor	1
17	602587	Reed – Backup Plate	1
18	612872	Screw	2
19	681831	Bearing – Needle	1
20	609629	Dowel	1
21	609123	Plug – Core	4
22	252-76	Bearing – Thrust	1
23	252-80	Washer – Thrust	1
*	684725	Cylinder & Crankcase Ass'y (Incl. Ref. #14, 16-18 & 20-21)	1
*	610372	Sealer	1

*Not Illustrated




C-1309

RECOIL STARTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93-4304	Housing Assembly	1
2	93-4305	Rope - Starter	1
3	92-4929	Pulley Assembly	1
4	92-4930	Spring - Dog	2
5	92-4931	Dog	2

Ref. No.	Part No.	Description	No. Used
6	92-9692	Retainer	1
7	92-4933	Screw	1
8	92-4934	Spring	1
9	92-4935	Spring Keeper Assembly	1



C-2130A

CARBURETOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	92-6376	Air Vane & Shaft	1	12	603145	Spring	1
2	610165	Retainer - Speed Control	1	13	602850	Gasket	1
3	93-1225	Lever - Speed Adjust	1	14	92-6371	Nozzle	1
4	610834	Collar - Air Vane	1	15	611071	Filter - Fuel	1
5	92-4944	Spring - Governor	1	16	678113	Float & Arm Assembly	1
6	92-6373	Disc - Throttle	1	17	92-6389	Pin	1
7	92-4949	Bracket - Throttle Control	1	18	92-9691	Float Chamber	1
8	613269	Screw	2	19	608850	Screw	4
9	93-4324	Carburetor Body	1	20	612383	Washer	1
10	92-9697	Kit - Float Valve, Body & Seat (Incl. Ref. #12)	1	21	92-6370	Main Jet	1
				*	92-6385	Jet - High Altitude	1
				*	93-4331	Carburetor Assembly	1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
130743	Nut	9 2 1	614697	Screw - Handle	8 2 2
303712	Ring - Retaining	12 5 2	614699	Screw	9 1 3
316959	Washer - Lock	9 9 1	614702	Screw	9 7 4
602587	Reed - Backup Plate	12 17 1	614702	Screw	11 10 1
602588	Reed - Carburetor	12 16 1	677525	Plate & Collar Assembly	7 1 1
602850	Gasket	14 13 1	677982	Liner - Split (Set of 2)	12 8 1
603145	Spring	14 12 1	678113	Float & Arm Assembly	14 16 1
603164	Nut - Blade	7 18 1	681737	Set - Ring	12 1 1
605120	Grommet	4 5 1	681830	Bearing - Upper Main	12 10 1
606608	Pin - Wrist	12 4 1	681831	Bearing - Needle	12 19 1
607199	Key	9 6 1	683911	Bearing - Needle	12 12 1
607560	Plate - Cover	3 14 1	684049	CD Ignition	11 3 1
607560	Plate - Cover	4 14 1	684725	Cylinder & Crankcase Ass'y	12 * 1
607601	Screw	11 19 4	684743	Flywheel	9 4 1
608850	Screw	14 19 4	684776	Wheel & Tire Ass'y 6	2 19 2
609123	Plug - Core	12 21 4	684776	Wheel - Tire Assembly 6	1 19 2
609471	Screw	11 21 3	684777	Wheel & Tire Ass'y 8	1 2 2
609482	Screw	10 2 2	12-5450	Screw - Thread Forming	11 16 1
609493	Element - Filter Air	10 5 1	16-4359	Housing Assembly	1 5 1
609629	Dowel	12 20 1	16-4369	Housing Assembly	4 17 1
610165	Retainer - Speed Control	14 2 1	36-4780	Washer - Thrust	5 17 2
610358	Nut - Lock	6 13 2	36-4791	Washer	5 5 2
610372	Sealer	12 * 1	38-7820	Bearing - Ball	5 15 1
610383	Retainer - Filter	10 3 1	39-5770	Decal - Danger	3 15 1
610834	Collar - Air Vane	14 4 1	39-5770	Decal - Danger	4 15 1
611071	Filter - Fuel	14 15 1	40-1940	Washer	1 18 4
611393	Screw - Hex. Hd.	12 13 2	40-1940	Washer	2 18 2
611396	Seal - Oil	12 11 2	44-2750	Body - Primer	7 20 1
612383	Washer	14 20 1	44-3174	Hose - Primer	10 7 1
612543	Blade - 21	7 16 1	49-2040	Screw - Hex Hd.	4 7 2
612782	Line - Gas	7 22 1	53-4690	Stop - Ground Strap	11 15 1
612824	Clip - Rope Insert	8 21 1	55-3760	Pinion - 15 Tooth	5 3 1
612825	Handle - Starter	8 14 1	60-8750	Bushing	5 6 2
612872	Screw	12 18 2	60-8850	Bushing - Output	5 9 2
613208	Screw - Hex. Washer Hd.	11 6 2	60-8890	Gear - Bevel Pinion	5 16 1
613227	Screw - Set	7 15 1	60-9010	Strap - Ground	11 13 1
613269	Screw	14 8 2	62-6660	Spacer	5 11 1
613765	Nut - Cage	1 11 1	65-2720	Ring - Retaining	6 3 4
613765	Nut - Cage	2 11 1	65-4710	Ring - Friction	6 7 2
614009	Plug - Spark	11 4 1	65-4720	Spring - Compression	6 17 2
614243	Knob	8 3 2	65-4730	Washer - Thrust	6 14 2
614426	Washer - Stepped	6 19 2	65-4740	Washer - Thrust Keyed	6 4 4
614447	Spacer - Axle Shaft	6 9 2	65-4750	Gear - Pinion	6 16 2
614596	Gear 34 Tooth	5 18 1	65-4760	Washer	6 15 2
614636	Screw - Torx. Washer Hd.	12 14 3	66-6040	Key - Rocking R.H.	6 * 1
614637	Bracket - Wheel Height Adj.	1 17 4	66-6050	Key - Rocking L.H.	6 5 1
614637	Bracket - Wheel Height Adj.	2 17 2	66-7460	Bulb - Primer	7 19 1
614640	Hub - Starter	9 3 1	84-7820	Mounting Plate	11 17 1
614650	Bolt - Shoulder	1 1 2	92-1001	Bail - SP Control	8 9 1
614654	Plate - Muffler	11 18 1	92-1004	Spring Arm Ass'y	6 12 2
614668	Cover - Gear Case	5 2 1	92-1005	Spring Arm Assembly	1 3 2
614669	Pulley - Half	5 12 2	92-1008	Knob - Height Adjust	2 23 4
614671	Cover - Drive	4 9 1	92-1008	Knob - Height Adjust.	1 23 4
614672	Bolt - Shoulder	1 21 4	92-1042	Wheel & Tire Ass'y 8	6 2 2
614672	Bolt - Shoulder Height Adj.	2 21 2	92-1057	Bolt - Shoulder	6 1 2
614673	Handle Section - Lower	8 19 1	92-1097	Decal - Discharge	3 16 1
614674	Cover - Muffler	11 22 1	92-1097	Decal - Discharge	4 16 1
614677	Screw - Sem Thr'd Form	2 9 2	92-1099	Bolt - Shoulder	1 20 2
614677	Screw - Sems Thr'd Form	1 9 2	92-1099	Bolt - Shoulder	2 20 2
614682	Knob - Cover Plate	1 7 1	92-1156	Wire - Brake Switch Lead	11 14 1
614682	Knob - Cover Plate	2 7 1	92-1630	Fan - Mulching	7 17 1
614687	Spring Arm Ass'y - Front	1 22 2	92-1701	Rope - Stop	7 9 1
614687	Spring Arm Ass'y - Front	2 22 2	92-2914	Decal - H.O.C.	3 2 2
614696	Shaft - Intermediate	5 4 1	92-2914	Decal - H.O.C.	4 2 2

*Not Illustrated

LAWN-BOY PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
92-2915	Decal - H.O.C.	3	1	2	92-9698	Screw - Shoulder	11	9	1
92-2915	Decal - H.O.C.	4	1	2	93-0239	Shaft - Output	5	7	1
92-2925	Strap - Insulation	11	12	1	93-0294	Decal - Recoil	7	11	1
92-4881	Plate - Height Adjust	1	14	2	93-0295	Decal - Recoil	7	10	1
92-4881	Plate - Height Adjust	2	14	2	93-1216	Base - Shroud	9	5	1
92-4890	Washer	1	15	4	93-1221	Shield - Carburetor	10	10	1
92-4890	Washer	2	15	2	93-1225	Lever - Speed Adjust	14	3	1
92-4921	Connecting Rod Assembly	12	6	1	93-1231	Cover - Air Cleaner	10	4	1
92-4923	Piston & Ring Set	12	3	1	93-1233	Gasket - Exhaust	11	2	1
92-4925	Piston & Connecting Rod	12	*	1	93-3653	Handle - Guard	8	31	1
92-4927	Bearing	12	7	1	93-3653	Handle - Guard	8	31	2
92-4929	Pulley Assembly	13	3	1	93-3660	Fuel/Oil Cap Assembly	7	7	1
92-4930	Spring - Dog	13	4	2	93-4184	Bail - Flywheel Brake	8	12	1
92-4931	Dog	13	5	2	93-4196	Shield - Grass	7	23	1
92-4933	Screw	13	7	1	93-4302	Screw - Sems	7	8	3
92-4934	Spring	13	8	1	93-4304	Housing Assembly	13	1	1
92-4935	Spring Keeper Assembly	13	9	1	93-4304	Shroud Assembly	9	8	1
92-4944	Spring - Governor	14	5	1	93-4305	Rope - Starter	13	2	1
92-4948	Gasket - Carburetor	10	9	2	93-4306	Spring - Compression	7	13	1
92-4949	Bracket - Throttle Control	14	7	1	93-4312	Brake Plate Assembly	11	8	1
92-5412	Stop - Pivot	8	8	1	93-4320	Shield - Fuel	10	6	1
92-5412	Stop - Pivot	8	8	2	93-4324	Carburetor Body	14	9	1
92-6370	Main Jet	14	21	1	93-4331	Carburetor Assembly	14	*	1
92-6371	Nozzle	14	14	1	93-4331	Carburetor Assembly	10	8	1
92-6373	Disc - Throttle	14	6	1	93-4343	Baffle	11	20	1
92-6376	Air Vane & Shaft	14	1	1	93-7250	Decal - Warning	3	10	1
92-6380	Tank & Shroud Assembly	7	5	1	93-7250	Decal - Warning	4	10	1
92-6385	Jet - High Altitude	14	*	1	93-7380	Anchor - Cable SP Lower	8	20	1
92-6389	Pin	14	17	1	93-7381	V-Belt	6	10	1
92-6542	Pulley - Engine	7	2	1	93-7383	Guide - Rope	8	16	1
92-7723	Bracket - Handle R.H.	4	12	1	94-1609	Cover - Wheel	6	18	2
92-7724	Bracket - Handle L.H.	4	3	1	94-1610	Grommet - Plastic	1	10	2
92-7726	Cable - Traction	8	7	1	94-1610	Grommet - Plastic	2	10	2
92-7727	Gearcase	5	10	1	94-5713	Crankshaft	12	9	1
92-7728	Guide - Transmission	4	6	1	94-5737	Short Block	11	1	1
92-7729	Anchor - Cable Upper	8	6	1	95-1713	Handle - Section Upper	8	13	1
92-7731	Plate - Baffle	1	16	2	95-1726	Screw - Engine	7	3	3
92-7731	Plate - Baffle	2	16	2	252-76	Bearing - Thrust	12	22	1
92-7734	Cable - Throttle 2 Cycle	8	17	1	252-80	Washer - Thrust	12	23	1
92-7735	Gear Case Assembly	4	4	1	321-48	Screw - Hex Hd. Cap	8	5	1
92-7738	Cable - Flywheel Brake	8	18	1	321-49	Screw - Hex Hd. Cap	8	5	1
92-7742	Bracket - Handle R.H.	1	6	1	321-50	Screw - Hex Hd. Cap	8	15	1
92-7743	Bracket - Handle L.H.	1	4	1	322-3	Screw - Hex Hd. Cap	3	21	4
92-7746	Height Adj. Arm - Rear	6	8	2	322-3	Screw - Hex Hd. Cap	4	21	6
92-8615	Applique - Shroud	7	12	1	3256-24	Washer	5	13	1
92-8630	Plate - Mulch 21	1	8	1	3285-19	Pin - Groove	5	8	2
92-8630	Plate - Mulch 21	2	8	1	3290-459	Rivet - Plastic	11	11	2
92-8632	Washer	8	30	1	3296-5	Nut	5	14	1
92-8647	Shield - Trailing	3	20	1	3296-29	Nut - Lock	3	19	4
92-8647	Shield - Trailing	4	20	1	3296-29	Nut - Lock	4	19	6
92-9662	Screw - Phillips Hd.	4	8	1	3296-39	Nut - Lock	1	24	2
92-9691	Float Chamber	14	18	1	3296-73	Nut - Lock	8	4	2
92-9692	Retainer	13	6	1	32144-4	Screw - Taptite	5	1	4
92-9697	Kit - Float Valve, Body	14	10	1	32144-85	Screw - Hex Hd.	6	11	2

*Not Illustrated

