

LAWN-BOY®

21" SILVER SERIES WALK BEHIND MOWER

Model No. 10236-7900001 & Up

Parts Catalog

ORDERING REPLACEMENT PARTS

To order replacement parts, please supply: the part number, the quantity, and the description of each part desired.

Contents

Description	Page	Description	Page
Housing Assembly	1	Carburetor No. 640026	9
Cover Assembly	2	Recoil Starter Assembly 590702	10
Engine Assembly	3	Recoil Starter Assembly 590739 (Optional)	11
Handle Assembly	4	Lawn-Boy Part Number Index	12-13
Bag Assembly	5		
Engine Tecumseh Model			
LEV115-350024B	6-8		

Note:

Accessories

Description	Model / Parts No.	Description	Model / Parts No.
Side Bagging Kit	Model No. 89814	Leaf Shredder Kit	Model No. 89860
Rear Bagging Kit	Model No. 89800	Leaf Bag Kit w/Chute	Model No. 89811
Leaf Bag	Model No. 89804	Mow & Feed Fertilizer Spreader	Model No. 52079

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.

Abbreviation	Meaning	Abbreviation	Meaning
AR	as required	HWHTF	hex washer head thread forming
ASM	assembly	INC	incorporated
CARR	carriage	LH	left hand
DEG	degrees	PH	pan head
FH	flat head	PPH	Phillips pan head
GA	gauge	PTO	power take off
HF	hex flange	RH	right hand
HFV	hex flange washer	SFH	slotted fillister head
HH	hex head	SH	square head
HHF	hex head flange	SHWH	slotted hex washer head
HHST	hex head self tapping	SPH	slotted pan head
HJ	hex jam	STD	standard
HOC	height-of-cut	TAP	self tapping
HS	hex socket	TH	truss head
HSBH	hex socket button head	TTH	Torx truss head
HSFH	hex socket flat head	WH	wing head
HSR	hex socket head		
HWH	hex washer head		

Important Format Explanations

This catalog uses special formats to convey information in illustrations and parts lists. Specifically, one format is used in conjunction with service assemblies and another with quantities associated with reference numbers.

Service Assemblies

Parts within service assemblies have reference numbers in the form $X:Y$. X is the reference number of the service assembly and Y is a sequential number unique to each part within the service assembly.


For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually.

Reference numbers of this type appear in part lists and as callouts in illustrations.

Reference Numbers with Quantities

Illustrations may have a quantity in parentheses next to a reference number, in the form $X (Y)$. X is the reference number. Y in parentheses is the quantity of the part identified by the reference number.

For example, the illustration callout 4 (2) indicates that two parts are used in that instance.




Sheet No.:2

Housing Assembly

Ref. No.	Part No.	Qty.	Description
1	614650	2	Bolt–Shoulder
2	684777	2	ASM–Wheel
3	92–1005	2	ASM–Spring Arm
4	92–7743	1	ASM–Handle Brkt
5	16–5659	1	ASM–Housing & Baffle
6	92–7742	1	ASM–Handle Brkt
7	614682	1	Knob–Cover Plate
8	92–8630	1	Mulch Plate–21”
9	614677	2	Screw–Sems
10	94–1610	2	Grommet–Plastic
11	613765	1	Nut–Cage
14	92–4881	2	Plate–Height Adjust
15	92–4890	4	Washer
16	92–7731	2	Plate–Baffle
17	614637	4	Bracket–Wheel Height Adj
18	40–1940	4	Washer
19	684776	2	ASM–Wheel & Tire 6”
20	92–1099	2	Bolt–Shoulder 6” Wheel
21	614672	4	Bolt–Shoulder
22	614687	2	Spring Arm–Front
23	92–1008	4	Knob–Height Adjust
24	3296–39	2	Nut–Lock

Ref. No.	Part No.	Qty.	Description




Sheet No.:3

Cover Assembly

Ref. No.	Part No.	Qty.	Description
1	92-2915	2	Decal-HOC
2	92-2914	2	Decal-HOC
3	93-7250	1	Decal-Warning
6	607560	1	Plate-Cover
7	39-5770	1	Decal-Danger
8	92-1097	1	Decal-Discharge
10	3296-29	4	Nut-Lock
11	92-8647	1	Shield-Trailing
12	322-3	4	Screw-HH


Ref. No.	Part No.	Qty.	Description



Sheet No.:4

Engine Assembly


Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	95-1747	1	ASM-Plate & Collar				
2	95-1726	3	Screw-Engine Mount				
3	94-6083	1	Engine ASM (4-Cyc)				
4	2210-316	1	Rope-Stop (P/W Eng)				
5	92-8644	1	Decal-Shroud Top				
6	92-4852	4	Screw-Recoil Cover				
7	92-4854	1	Cover-Starter				
8	94-6088	1	Shroud-Engine				
9	32144-85	1	Screw-HSH				
10	65-2690	1	Decal-Warning				
11	94-6066	1	Guard-Muffler				
12	612543	1	Blade-21" Whirl				
13	92-1630	1	Fan-Mulching				
14	95-1748	1	Bolt-Blade				
15	94-8083	1	Decal-Primer				
16	92-4851	1	Decal-Oil Instruction				
17	3253-22	1	Washer				
18	95-1712	1	Spacer				



Sheet No.:5

Handle Assembly

Ref. No.	Part No.	Qty.	Description
1	614697	2	Screw-Handle
2	614243	2	Knob
3	3296-73	1	Nut-Lock
4	92-5412	1	Stop-Pivot
6	93-4184	1	Bail-Flywheel Brake
7	95-1713	1	Handle Section-Upper
8	92-4853	1	Handle-Starter
9	321-49	1	Screw-HH
10	93-7383	1	Guide-Rope
11	92-1045	1	Cable-Throttle
12	92-9589	1	ASM-Brake Cable
13	614643	1	Handle Section-Lower
14	92-5424	1	Staple-Handle
22	93-3653	1	Handle-Guard



Sheet No.:6


Bag Assembly

Ref. No.	Part No.	Qty.	Description
1	684729	1	Chute & Support Assembly (Incl. Ref. #2, 3, & 9)
2	614589	1	Nut–Cap
3	614591	1	Chute Support
4	684727	1	Adaptor Assembly
5	614700	1	Tie Strap
6	*	1	Bag Assembly
7	613462	2	Hanger Clamp
8	613455	1	Wide Hanger
9	92–2919	1	Decal–Danger

Ref. No.	Part No.	Qty.	Description

* Not Illustrated

ENGINE TECUMSEH MODEL LEV115-350024B




ENGINE TECUMSEH MODEL LEV115-350024B

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	36774	Cylinder (Incl. Ref. #2 & 20)	1	126	36781	(Incl. Ref. #151) Intake Valve (Std.)	1
2	26727	Dowel Pin	2			(Incl. Ref. #151)	1
6	33734	Breather Element	1	126	36782	Intake Valve (1/32" OS)	1
7	36557	Breather Ass'y (Incl. Ref. #6 & 12A)	1			(Incl. Ref. #151)	1
12	36775	Breather Tube	1	130	6021A	Screw	8
12A	36558	Breather Cover & Tube (Incl. Ref. #12B)	1	135	35395	Resistor Spark Plug (RJ19LM)	1
12B	36694	Breather Tube Elbow	1	150	35991	Valve Spring	2
14	28277	Washer	1	151	31673	Valve Spring Cap	2
15	30589	Governor Rod (Incl. Ref. #14)	1	151A	40017	Intake Valve Seal	1
16	34839A	Governor Lever	1	169	36783	Valve Cover Gasket	1P
17	31335	Governor Lever Clamp	1	172	36784	Valve Cover	1
18	651018	Screw — Torx T-15	1	174	30200	Screw	2
19	36796	Extension Spring	1	178	29752	Nut & Lock Washer	2
20	32600	Oil Seal	1	182	6201	Screw	2
30	36998	Crankshaft	1	184	26756	Carburetor To Intake Pipe Gasket	1P
40	40004	Piston, Pin & Ring Set (Std.)	1	185	36785	Intake Pipe	1
40	40005	Piston, Pin & Ring Set (.010" OS)	1	186	36255	Governor Link	1
41	36070	Piston & Pin Ass'y (Std.) (Incl. Ref. #43)	1	189	650839	Screw	2
41	36071	Piston & Pin Ass'y (.010" OS) (Incl. Ref. #43)	1	191	36559	S.E. Brake Bracket (Incl. Ref. #195)	1
42	40006	Ring Set (Std.)	1	195	610973	Terminal	1
42	40007	Ring Set (.010" OS)	1	200	35999	Control Bracket	1
43	20381	Piston Pin Retaining Ring	2	207	36200	Throttle Link	1
45	36777	Connecting Rod Ass'y (Incl. Ref. #46)	1	209	30200	Screw	2
46	32610A	Connecting Rod Bolt	2	223	650451	Screw	2
48	27241	Valve Lifter	2	224	36786	Intake Pipe Gasket	1P
50	36778	Camshaft (MCR)	1	238	650932	Screw	2
52	29914	Oil Pump Ass'y	1	239	34338	Air Cleaner Gasket	1P
69	35261	Mounting Flange Gasket	1	241	35797	Air Cleaner Collar	1
70	34311D	Mounting Flange (Incl. Ref. #72-83)	1	245	35066	Air Cleaner Filter	1
72	36083	Oil Drain Plug	1	250	35986	Air Cleaner Cover	1
75	27897	Oil Seal	1	260	36999	Blower Housing	1
80	30574A	Governor Shaft	1	261	30200	Screw	2
81	30590A	Washer	1	262	650831	Screw	2
82	30591	Governor Gear Ass'y (Incl. Ref. #81)	1	275	36790	Muffler (Incl. Ref. #277)	1
83	30588A	Governor Spool	1	277	650988	Screw	2
86	650488	Screw	6	285	35000A	Starter Cup	1
89	611004	Flywheel Key	1	287	650926	Screw	2
90	611112	Flywheel	1	290	34357	Fuel Line	1
92	650815	Belleville Washer	1	292	26460	Fuel Line Clamp	2
93	650816	Flywheel Nut	1	300	35586	Fuel Tank (Incl. Ref. #292 & 301)	1
100	34443A	Solid State Ignition	1	301	35355	Fuel Cap	1
101	610118	Spark Plug Cover	1	305	35819A	Oil Fill Tube	1
103	651007	Screw — Torx T-15	2	306	36832	O-Ring	1P
110	34961	Ground Wire	1	307	35499	O-Ring	1
119	36787	Cylinder Head Gasket	1P	309	651014	Screw	1
120	36788	Cylinder Head	1	310	36259	Dipstick	1
125	36779	Exhaust Valve (Std.) (Incl. Ref. #151)	1	313	34080	Spacer	1
125	36780	Exhaust Valve (1/32" OS)	1	370A	36261	Lubrication Decal	1
				380	640026	Carburetor (Incl. Ref. #184)	1
				390	590702	Rewind Starter (Note: This engine could have been built with 590739 starter)	1

ENGINE TECUMSEH MODEL LEV115—350024B


Ref. No.	Part No.	Description	No. Used
400	36792	Gasket Set (Incl. items marked P in notes) (Incl. part #'s 26756, (1) 28833 (1), 36832 (1), 34338 (1), 35261 (1), 36783 (1), 36786 (1), & 36787 (1).	1

Ref. No.	Part No.	Description	No. Used
416	36085	Spark Arrestor Kit (Incl. Ref. #417) (Optional)	1
417	650760	Screw (Optional)	1
420	730225	SAE 30 4—Cycle Engine Oil (Quart)	1




CARBURETOR NO. 640026

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	631615	Throttle Shaft & Lever Assembly	1	28	632019	Float	1
2	631767	Throttle Return Spring	1	29	631028	Float Bowl O-Ring	1
4	631184	Dust Seal Washer	1	30	631021	Inlet Needle, Seat, & Clip (Incl. Ref. #31)	1
5	631183	Dust Seal (Throttle)	1	31	631022	Spring Clip	1
6	631036	Throttle Shutter	1	35	36045	Primer Bulb/Retainer Ring	1
7	650506	Shutter Screw	1	36	632735	Main Nozzle Tube	1
16	631775	Fuel Fitting	1	37	632547	O-Ring, Main Nozzle Tube	2
17	650417	Throttle Crack Screw/ Idle Speed Screw	1	40	640028	High Speed Bowl Nut	1
18	630766	Tension Spring	1	44	27110	Bowl Nut Washer	1
20	640027	Idle Restrictor Screw	1	47	630748	Welch Plug, Idle Mixture Well	1
20A	640053	Idle Restrictor Screw Cap	1	48	631027	Welch Plug Atmospheric Vent	1
25	631867	Float Bowl	1				
27	631024	Float Shaft	1				



RECOIL STARTER ASSEMBLY 590702

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
0	590702	Recoil Starter	1	8	590700	Pulley & Rewind Spring Ass'y.	1
1	590599A	Spring Pin (Incl. 4)	1	11	590703	Starter Housing Ass'y (40 degree grommet)	1
2	590600	Washer	1	12	590535	Starter Rope (98" X 9/64" dia.)	1
3	590696	Retainer	1	13	590701	Starter Handle	1
4	590601	Washer	2				
5	590697	Brake Spring	1				
6	590698	Starter Dog	2				
7	590699	Dog Spring	2				



RECOIL STARTER ASSEMBLY 590739 (Optional)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
0	590739	Rewind Starter	1	11	590638	Starter Housing Ass'y (40 degree grommet)	1
3	590740	Retainer	1	12	590535	Starter Rope (Length 98" x 9/64" dia.)	1
6	590616	Starter Dog	2	13	590701	Starter Handle	1
7	590617	Dog Spring	2	14	590741	Locking Tab	1
8	590618A	Pulley & Rewind Spring Ass'y	1				

Lawn—Boy Part Number Index

Part No.	Page No.	Ref. No.	Qty.	Description
*	5	6	1	Bag Assembly
607560	2	6	1	Plate—Cover
612543	3	12	1	Blade—21" Whirl
613455	5	8	1	Wide Hanger
613462	5	7	2	Hanger Clamp
613765	1	11	1	Nut—Cage
614243	4	2	2	Knob
614589	5	2	1	Nut—Cap
614591	5	3	1	Chute Support
614637	1	17	4	Bracket—Wheel Height Adj
614643	4	13	1	Handle Section—Lower
614650	1	1	2	Bolt—Shoulder
614672	1	21	4	Bolt—Shoulder
614677	1	9	2	Screw—Sems
614682	1	7	1	Knob—Cover Plate
614687	1	22	2	Spring Arm—Front
614697	4	1	2	Screw—Handle
614700	5	5	1	Tie Strap
684727	5	4	1	Adaptor Assembly
684729	5	1	1	Chute & Support Assembly (Incl. Ref. #2, 3, & 9)
684776	1	19	2	ASM—Wheel & Tire 6"
684777	1	2	2	ASM—Wheel
16-5659	1	5	1	ASM—Housing & Baffle
39-5770	2	7	1	Decal—Danger
40-1940	1	18	4	Washer
65-2690	3	10	1	Decal—Warning
92-1005	1	3	2	ASM—Spring Arm
92-1008	1	23	4	Knob—Height Adjust
92-1045	4	11	1	Cable—Throttle
92-1097	2	8	1	Decal—Discharge
92-1099	1	20	2	Bolt—Shoulder 6" Wheel
92-1630	3	13	1	Fan—Mulching
92-2914	2	2	2	Decal—HOC
92-2915	2	1	2	Decal—HOC
92-2919	5	9	1	Decal—Danger
92-4851	3	16	1	Decal—Oil Instruction
92-4852	3	6	4	Screw—Recoil Cover
92-4853	4	8	1	Handle—Starter
92-4854	3	7	1	Cover—Starter
92-4881	1	14	2	Plate—Height Adjust
92-4890	1	15	4	Washer
92-5412	4	4	1	Stop—Pivot
92-5424	4	14	1	Staple—Handle
92-7731	1	16	2	Plate—Baffle
92-7742	1	6	1	ASM—Handle Brkt
92-7743	1	4	1	ASM—Handle Brkt
92-8630	1	8	1	Mulch Plate—21"
92-8644	3	5	1	Decal—Shroud Top
92-8647	2	11	1	Shield—Trailing
92-9589	4	12	1	ASM—Brake Cable
93-3653	4	22	1	Handle—Guard
93-4184	4	6	1	Bail—Flywheel Brake
93-7250	2	3	1	Decal—Warning
93-7383	4	10	1	Guide—Rope
94-1610	1	10	2	Grommet—Plastic
94-6066	3	11	1	Guard—Muffler
94-6083	3	3	1	Engine ASM (4—Cyc)
94-6088	3	8	1	Shroud—Engine
94-8083	3	15	1	Decal—Primer
95-1712	3	18	1	Spacer
95-1713	4	7	1	Handle Section—Upper
95-1726	3	2	3	Screw—Engine Mount

*Not Illustrated

Lawn-Boy Part Number Index (Cont.)

Part No.	Page No.	Ref. No.	Qty.	Description
95-1747	3	1	1	ASM-Plate & Collar
95-1748	3	14	1	Bolt-Blade
2210-316	3	4	1	Rope-Stop (P/W Eng)
321-49	4	9	1	Screw-HH
322-3	2	12	4	Screw-HH
3253-22	3	17	1	Washer
3296-29	2	10	4	Nut-Lock
3296-39	1	24	2	Nut-Lock
3296-73	4	3	1	Nut-Lock
32144-85	3	9	1	Screw-HSH