

**LAWN-BOY®**

**COMMERCIAL SERIES  
SIDE DISCHARGE MOWER**

**MODEL NO. 11000-7900001 & UP**

---

**PARTS CATALOG**

## PRODUCT CHANGES

In an effort to make improvements available to LAWN-BOY owners as quickly as possible, minor changes are incorporated into LAWN-BOY products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your Parts Catalog, see your LAWN-BOY Distributor or his Authorized LAWN-BOY Service Dealer for information and part numbers.

## IDENTIFICATION AND ORDERING

### MODEL AND SERIAL NUMBERS

The Product two identification numbers; a model number and a serial number. The two numbers are stamped on a plate mounted on the deck. In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized Service Dealer, supply the following information:

1. Model and serial number.
2. Part number, description, and the quantity of part(s) desired.


**NOTE:** Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

# TABLE OF CONTENTS

Description	Page	Description	Page
Housing Assembly .....	1	Carburetor Assembly .....	7
Engine Assembly .....	2	Air Filter Assembly .....	8
Handle Assembly .....	3	Numeric Parts Index .....	9-10
Engine Assembly .....	4-5		
Starter Assembly .....	6		

## Accessories


Description	Model / Parts No.	Description	Model / Parts No.
Side Bagging Kit .....	Model No. 89814	Mulching Plate .....	Model No. 89864
Leaf Bag .....	Model No. 89804	Leaf Bag w/Chute .....	Model No. 89811
Rear Bagging Kit .....	Model No. 89800		



T-0XXX

## HOUSING ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	16-9619	Housing Assembly (Incl. Ref. #34, & 40)	1	20	603567	Bolt - Wheel	4
2	608175	Bar - Toe 21"	1	21	93-7164	Guard - Engine Assembly	1
3	46-6811	Screw - Hex Washer Hd.	2	22	145875	Washer	1
4	604604	Grommet - Plastic	3	23	3296-29	Nut - Lock	5
5	614677	Screw - Sems Thr'd Form.	2	24	684583	Bracket - Tank	1
6	607560	Plate - Cover	1	25	609829	Tank - Fuel	1
7	49-2040	Screw - Hex Hd. Cap	1	26	682755	Cap - Gas	1
8	611016	Shield - Trailing	1	27	609830	Spring	2
9	608174	Rod - 21"	1	28	312387	Clamp - Hose	1
10	608161	Clamp - Rod	2	29	677052	Valve & Screen	1
11	321-3	Screw - Hex Hd. Cap	3	30	677525	Plate & Collar Assembly	1
12	3296-42	Nut - Hex Lock	2	31	612543	Blade - 53cm	1
13	608834	Washer	4	32	603164	Nut - Blade	1
14	608833	Bracket - Height Wheel	4	33	92-8838	Decal - Deck 550C	1
15	153444	Knob & Spring Arm	4	34	93-6657	Decal - Danger	1
16	610646	Bolt - Adjustment Height	4	40	93-6667	Decal - Danger	2
17	3296-39	Nut - Lock	4	41	93-7415	Guard - Plate	1
18	684159	Wheel & Tire	2	42	32105-15	Screw - Hex Hd. Cap	2
19	683464	Wheel & Tire Assembly	2	43	3296-42	Nut - lock	2




T-0XXX

## ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1		Engine Assembly	1
3	95-1727	Screw - Engine Mount	3
4	611214	Spring	1
5	611509	Actuator - Brake Lever	1
6	611213	Retainer	1
10	612784	Line - Gas	1
11	609900	Nut - Speed	1
12	683638	Shroud Assembly	1
13	145945	Retainer - Applique	3
14	612754	Applique	1
15	46-6811	Screw - Hex Washer Hd.	1

Ref. No.	Part No.	Description	No. Used
16	611504	Clamp	1
17	3296-42	Nut - Lock	1
18	611395	Screw	4
19	684622	Recoil Assembly	1
20	612428	Screw - Sems	4
21	612825	Handle - Starter	1
22	612824	Clip - Rope Insert	1
23	92-8830	Decal - Recoil	1
25	93-7153	Plate - Engine	2




T-0XXX

## HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	684057	Bracket & Pin Assembly	1
2	684058	Bracket & Pin Assembly	1
3	607188	Screw	4
4	613048	Handle – Lower Section	1
5	800358	Bolt – Carriage	2
6	3296-29	Nut – Lock	4
7	614515	Handle – Top Section	1
8	322-9	Screw – Hex Hd. Cap	2
9	609739	Washer	2
10	611799	Screw	2
11	611777	Case – Control	1
12	611541	Column	1
13	611542	Pin	1
14	683478	Lever – Control	1
15	605546	Nut – Pal	1
16	612564	Pulley	1

Ref. No.	Part No.	Description	No. Used
17	93-3694	Cable – Control	1
18	612168	Nut – Acorn	1
19	612633	Case – Control	1
20	611543	Screw	2
21	93-4135	Lever & Knob Assembly	1
22	612586	Washer – Spring	2
23	93-3778	Cable – Throttle	1
24	612634	Case – Throttle	1
25	3296-12	Nut – Lock	2
26	92-8893	Decal – Throttle Control	1
27	153254	Guide – Rope	1
28	611233	Screw	2
29	602945	Washer – Plain	2
30	3296-42	Nut – Lock	2
31	614249	Strap – Tie	2

# ENGINE ASSEMBLY




# ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	613529	Bolt- Shoulder	1
2	682683	Brake Assembly	1
3	130743	Nut - Flywheel	1
4	316959	Lockwasher	1
5	683580	Flywheel Assembly	1
6	612427	Base - Shroud	1
7	609947	Screw	3
8	611191	Clip - "J"	1
9	609808	Screw	1
10	611214	Spring - Cable Return	1
11	611396	Oil Seal	2
12	681830	Bearing - Main - Upper	1
13	607199	Key - Flywheel	1
*	92-4925	Piston & Connecting Rod Assembly (Inc. 14-22)	1
14	92-4921	Connecting Rod Assy. (Inc 15-18)	1
15	611393	Screw - Cap	2
16	677982	Liner - Pair	1
17	609754	Strip - Roller	1
18	92-4927	Bearing Assembly	1
19	92-4923	Piston & Ring Set (Inc 20-22)	1
20	606608	Wrist Pin	1
21	303712	Retaining Ring	2
22	609900	Nut - Speed	1
23	681831	Bearing - Main - Lower	1
25	613110	Screw - Cover to Crankcase	1
26	609123	Plug	4
27	612872	Screw - Reed to Crankcase Cover	2
28	602587	Plate - Reed Hold Down	1
29	602588	Reed	1

Ref. No.	Part No.	Description	No. Used
30	613233	Screw - Brake Mounting Bracket	2
32	614009	Spark Plug	1
33	683215	C. D. Ignition Module & Lead Assy (Incl. Ref. #34)	1
34	681678	High Tension Lead & Cover	1
36	605120	Grommet	2
37	607526	Screw - C. D. Mounting	2
38	611211	Spring - Brake	1
40	608311	Nut	1
42	614343	Screw	2
43	611509	Actuator - Brake Lever	1
44	94-5713	Crankshaft	1
45	611192	Bracket - Brake	1
46	93-1239	Spring	1
47	317893	Tie Strap	1
48	306407	Washer	2
49	321-6	Screw - Hex Hd. Cap	1
50	683821	Lead Assembly	1
51	611213	Retainer	1
52	93-1240	Case - Switch	1
54	683581	Brace Assembly	1
55	602315	Nut	1
56	603014	Bolt	1
59	612842	Shield	1
60	612841	Plate - Contact	1
61	3255-7	Washer - Lock	1
62	146254	Nut	1
63	609629	Dowel	1
64	252-76	Bearing - Thrust	1
65	252-80	Washer - Thrust	1
*	94-5734	Short Block Assembly	1

\*Not Illustrated




C-1406

## STARTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92-8830	Decal	1
2	612949	Hub - Starter	1
3	612825	Handle - Starter	1
4	612824	Insert - Clip, Rope	1
5	684567	Housing - Starter	1
6	92-4935	Recoil Spring & Keeper	1

Ref. No.	Part No.	Description	No. Used
7	612950	Pulley	1
8	612432	Rope	1
9	683899	Assembly - Dog Kit	1
*	612428	Screw-Sems	4
*	684622	Assembly - Starter (Inc. Ref. No. 5-9)	1

\*Not Illustrated




C-2295A

## CARBURETOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	610834	Collar – Adjustment	1	15	612383	Washer	1
2	610165	Retainer	1	16	678113	Float & Arm Assembly	1
3	93-1225	Lever – Speed Adjust	1	17	92-6389	Pin	1
4	603145	Spring	1	19	678278	Float, Valve, & Body Ass'y (Incl. Ref. #4)	1
5	609482	Screw – Pan Hd. Sems	2	21	92-4944	Spring – Governor	1
6	613269	Screw	4	22	93-1226	Bracket – Throttle Control	1
7	93-4341	Body – Carburetor	1	23	94-5704	Disc – Throttle	1
8	93-1232	Bracket – Primer	1	24	92-6376	Air Vane & Shaft	1
9	602850	Gasket – Float Chamber	1	25	66-7460	Bulb – Primer	1
10	608850	Screw	4	26	44-2750	Body – Primer	1
11	92-9691	Float Chamber	1	27	44-3172	Hose – Primer	1
12	611071	Filter – Fuel	1	*	94-5738	Carburetor Complete	1
13	94-5710	Main Jet	1	28	612784	Line – Gas	1
14	92-6371	Nozzle	1				

\*Not Illustrated



C-2296A

## AIR FILTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	610383	Retainer – Cover	1
2	93-1231	Cover – Air Filter	1
3	609493	Element – Air Filter	1
4	93-4315	Shield – Carburetor (Int'l)	1
5	92-4948	Gasket – Carb.	2

Ref. No.	Part No.	Description	No. Used
6	93-4317	Shield – Governor F (Int'l)	1
7	613269	Screw	2
8	93-4320	Shield – Fuel	1
9	609482	Screw	2

# LAWN-BOY PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
130743	Nut – Flywheel	5	3	1	611396	Oil Seal	5	11	2
145875	Washer	1	22	1	611504	Clamp	2	16	1
145945	Retainer – Applique	2	13	3	611509	Actuator – Brake Lever	2	5	1
146254	Nut	5	62	1	611509	Actuator – Brake Lever	5	43	1
153254	Guide – Rope	3	27	1	611541	Column	3	12	1
153444	Knob & Spring Arm	1	15	4	611542	Pin	3	13	1
303712	Retaining Ring	5	21	2	611543	Screw	3	20	2
306407	Washer	5	48	2	611777	Case – Control	3	11	1
312387	Clamp – Hose	1	28	1	611799	Screw	3	10	2
316959	Lockwasher	5	4	1	612168	Nut – Acorn	3	18	1
317893	Tie Strap	5	47	1	612383	Washer	7	15	1
602315	Nut	5	55	1	612427	Base – Shroud	5	6	1
602587	Plate – Reed Hold Down	5	28	1	612428	Screw – Sems	2	20	4
602588	Reed	5	29	1	612428	Screw – Sems	6	*	4
602850	Gasket – Float Chamber	7	9	1	612432	Rope	6	8	1
602945	Washer – Plain	3	29	2	612543	Blade – 53cm	1	31	1
603014	Bolt	5	56	1	612564	Pulley	3	16	1
603145	Spring	7	4	1	612586	Washer – Spring	3	22	2
603164	Nut – Blade	1	32	1	612633	Case – Control	3	19	1
603567	Bolt – Wheel	1	20	4	612634	Case – Throttle	3	24	1
604604	Grommet – Plastic	1	4	3	612754	Applique	2	14	1
605120	Grommet	5	36	2	612784	Line – Gas	2	10	1
605546	Nut – Pal	3	15	1	612784	Line – Gas	7	28	1
606608	Wrist Pin	5	20	1	612824	Clip – Rope Insert	2	22	1
607188	Screw	3	3	4	612824	Insert – Clip, Rope	6	4	1
607199	Key – Flywheel	5	13	1	612825	Handle – Starter	2	21	1
607526	Screw – C. D. Mounting	5	37	2	612825	Handle – Starter	6	3	1
607560	Plate – Cover	1	6	1	612841	Plate – Contact	5	60	1
608161	Clamp – Rod	1	10	2	612842	Shield	5	59	1
608174	Rod – 21	1	9	1	612872	Screw – Reed to Crankcase	5	27	2
608175	Bar – Toe 21	1	2	1	612949	Hub – Starter	6	2	1
608311	Nut	5	40	1	612950	Pulley	6	7	1
608833	Bracket – Height Wheel	1	14	4	613048	Handle – Lower Section	3	4	1
608834	Washer	1	13	4	613110	Screw – Cover to	5	25	1
608850	Screw	7	10	4	613233	Screw – Brake Mounting	5	30	2
609123	Plug	5	26	4	613269	Screw	7	6	4
609482	Screw	8	9	2	613269	Screw	8	7	2
609482	Screw – Pan Hd. Sems	7	5	2	613529	Bolt – Shoulder	5	1	1
609493	Element – Air Filter	8	3	1	614009	Spark Plug	5	32	1
609629	Dowel	5	63	1	614249	Strap – Tie	3	31	2
609739	Washer	3	9	2	614343	Screw	5	42	2
609754	Strip – Roller	5	17	1	614515	Handle – Top Section	3	7	1
609808	Screw	5	9	1	614677	Screw – Sems Thr'd Form.	1	5	2
609829	Tank – Fuel	1	25	1	677052	Valve & Screen	1	29	1
609830	Spring	1	27	2	677525	Plate & Collar Assembly	1	30	1
609900	Nut – Speed	2	11	1	677982	Liner – Pair	5	16	1
609900	Nut – Speed	5	22	1	678113	Float & Arm Assembly	7	16	1
609947	Screw	5	7	3	678278	Float, Valve, & Body Ass'y	7	19	1
610165	Retainer	7	2	1	681678	High Tension Lead & Cover	5	34	1
610383	Retainer – Cover	8	1	1	681830	Bearing – Main – Upper	5	12	1
610646	Bolt – Adjustment Height	1	16	4	681831	Bearing – Main – Lower	5	23	1
610834	Collar – Adjustment	7	1	1	682683	Brake Assembly	5	2	1
611016	Shield – Trailing	1	8	1	682755	Cap – Gas	1	26	1
611071	Filter – Fuel	7	12	1	683215	C. D. Ignition Module &	5	33	1
611191	Clip – J	5	8	1	683464	Wheel & Tire Assembly	1	19	2
611192	Bracket – Brake	5	45	1	683478	Lever – Control	3	14	1
611211	Spring – Brake	5	38	1	683580	Flywheel Assembly	5	5	1
611213	Retainer	2	6	1	683581	Brace Assembly	5	54	1
611213	Retainer	5	51	1	683638	Shroud Assembly	2	12	1
611214	Spring	2	4	1	683821	Lead Assembly	5	50	1
611214	Spring – Cable Return	5	10	1	683899	Assembly – Dog Kit	6	9	1
611233	Screw	3	28	2	684057	Bracket & Pin Assembly	3	1	1
611393	Screw – Cap	5	15	2	684058	Bracket & Pin Assembly	3	2	1
611395	Screw	2	18	4	684159	Wheel & Tire	1	18	2

\*Not Illustrated

# LAWN-BOY PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
684567	Housing - Starter	6 5 1	93-3694	Cable - Control	3 17 1
684583	Bracket - Tank	1 24 1	93-3778	Cable - Throttle	3 23 1
684622	Assembly - Starter	6 * 1	93-4135	Lever & Knob Assembly	3 21 1
684622	Recoil Assembly	2 19 1	93-4315	Shield - Carburetor (Int'l)	8 4 1
800358	Bolt - Carriage	3 5 2	93-4317	Shield - Governor F (Int'l)	8 6 1
16-9619	Housing Assembly	1 1 1	93-4320	Shield - Fuel	8 8 1
44-2750	Body - Primer	7 26 1	93-4341	Body - Carburetor	7 7 1
44-3172	Hose - Primer	7 27 1	93-6657	Decal - Danger	1 34 1
46-6811	Screw - Hex Washer Hd.	1 3 2	93-6667	Decal - Danger	1 40 2
46-6811	Screw - Hex Washer Hd.	2 15 1	93-7153	Plate - Engine	2 25 2
49-2040	Screw - Hex Hd. Cap	1 7 1	93-7164	Guard - Engine Assembly	1 21 1
66-7460	Bulb - Primer	7 25 1	93-7415	Guard - Plate	1 41 1
92-4921	Connecting Rod Assy.	5 14 1	94-5704	Disc - Throttle	7 23 1
92-4923	Piston & Ring Set	5 19 1	94-5710	Main Jet	7 13 1
92-4925	Piston & Connecting Rod	5 * 1	94-5713	Crankshaft	5 44 1
92-4927	Bearing Assembly	5 18 1	94-5734	Short Block Assembly	5 * 1
92-4935	Recoil Spring & Keeper	6 6 1	94-5738	Carburetor Complete	7 * 1
92-4944	Spring - Governor	7 21 1	95-1727	Screw - Engine Mount	2 3 3
92-4948	Gasket - Carb.	8 5 2	252-76	Bearing - Thrust	5 64 1
92-6371	Nozzle	7 14 1	252-80	Washer - Thrust	5 65 1
92-6376	Air Vane & Shaft	7 24 1	321-3	Screw - Hex Hd. Cap	1 11 3
92-6389	Pin	7 17 1	321-6	Screw - Hex Hd. Cap	5 49 1
92-8830	Decal	6 1 1	322-9	Screw - Hex Hd. Cap	3 8 2
92-8830	Decal - Recoil	2 23 1	3255-7	Washer - Lock	5 61 1
92-8838	Decal - Deck 550C	1 33 1	3296-12	Nut - Lock	3 25 2
92-8893	Decal - Throttle Control	3 26 1	3296-29	Nut - Lock	3 6 4
92-9691	Float Chamber	7 11 1	3296-29	Nut - Lock	1 23 5
93-1225	Lever - Speed Adjust	7 3 1	3296-39	Nut - Lock	1 17 4
93-1226	Bracket - Throttle Control	7 22 1	3296-42	Nut - Hex Lock	1 12 2
93-1231	Cover - Air Filter	8 2 1	3296-42	Nut - Lock	2 17 1
93-1232	Bracket - Primer	7 8 1	3296-42	Nut - Lock	3 30 2
93-1239	Spring	5 46 1	3296-42	Nut - lock	1 43 2
93-1240	Case - Switch	5 52 1	32105-15	Screw - Hex Hd. Cap	1 42 2

\*Not Illustrated