
FORM NO. 3319–197

TORO®

MODEL NO. 20913–7900001 & UP

PARTS CATALOG

# 48cm RECYCLER®
## REAR BAGGER MOWER




C–2623


# DECK ASSEMBLY

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 1 | 32144–4 | Screw – Hex Head Tap | 8 |
| 2 | 71–8830 | Retainer Shaft Assembly | 2 |
| 3 | 32112–11 | Nut – Push | 1 |
| 4 | 71–7990 | Ramp – Discharge | 1 |
| 5 | 16–5979 | Housing – Deck | 1 |
| 7 | 71–8580 | Spacer – Door | 2 |
| 8 | 17–1569 | Door – Discharge | 1 |
| 9 | 71–9840 | Spring – Door | 2 |
| 10 | 71–7900 | Cap – Bolt LH | 1 |
| 11 | 322–29 | Screw – Hex Head | 2 |
| 12 | 32144–97 | Screw – Phillips Pan Head | 2 |
| 13 | 71–7860 | Grip – Upper | 1 |
| 14 | 65–5210 | Screw – Thread Forming | 2 |
| 15 | 71–7910 | Cap – Bolt RH | 1 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 16 | 71–7930 | Trigger – Height of Cut | 1 |
| 17 | 3284–5 | Pin – Groove | 1 |
| 18 | 71–7870 | Grip – Lower | 1 |
| 19 | 32144–70 | Screw – Tap | 1 |
| 20 | 71–7920 | Cover – Belt | 1 |
| 21 | 71–9860 | Decal – Deck | 1 |
| 22 | 27–6230 | Bolt – Wheel | 2 |
| 23 | 46–1113 | Wheel & Tire Assembly 7” (Incl. Ref.# 29) | 2 |
| 24 | 40–1940 | Washer | 2 |
| 25 | 3296–5 | Nut – Lock (Nylon) | 2 |
| 26 | 71–7820 | Pivot – Front | 1 |
| 28 | 93–4105 | Decal – Danger | 1 |
| 29 | 27–6250 | Bushing | 2 |

TPS

©The TORO Company – 1996
*All Rights Reserved*





C–2624

# HANDLE ASSEMBLY

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 1 | 3290–378 | Tie – Cable | 1 |
| 2 | 3296–73 | Nut – Lock Insert | 3 |
| 3 | 19–4050 | Knob | 2 |
| 4 | 71–8100 | Mount – Handle RH | 1 |
| 5 | 71–8090 | Mount – Handle LH | 1 |
| 6 | 93–1116 | Cable – Brake | 1 |
| 7 | 92–7729 | Anchor – Cable | 1 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 8 | 95–4453 | Screw – Handle | 1 |
| 9 | 3256–1 | Washer – Flat | 1 |
| 10 | 95–4457 | Rope – Guide | 1 |
| 11 | 94–4375 | Handle | 1 |
| 12 | 95–5924 | Bail – Brake | 1 |
| 13 | 93–1118 | Control – Throttle | 1 |
| 14 | 321–48 | Screw – Hex Head | 1 |





# DECK SUSPENSION ASSEMBLY

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 1 | 27–6230 | Bolt – Wheel | 2 |
| 2 | 32112–13 | Nut – Push | 1 |
| 3 | 63–8590 | Screw | 2 |
| 4 | 71–8080 | Saddle – Height of Cut | 1 |
| 5 | 71–8060 | Spring – Trigger | 2 |
| 6 | 32144–31 | Screw | 1 |
| 7 | 3296–5 | Nut – Lock (Nylon) | 2 |
| 8 | 71–7800 | Arm – Pivot | 1 |
| 9 | 71–7840 | Rod – Trigger | 1 |
| 10 | 71–7770 | Plate – Securing | 2 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 11 | 32144–4 | Screw – Hex Head Tap | 4 |
| 12 | 71–7980 | Indicator – Height of Cut | 1 |
| 13 | 71–7970 | Rod – Link | 1 |
| 14 | 71–8450 | Cover – Spring | 1 |
| 15 | 32151–93 | Ring – Grip | 1 |
| 16 | 71–7740 | Spring – Counterbalance | 1 |
| 17 | 14–9949 | Rear Wheel & Tire Assembly (Incl. Ref. # 19) | 2 |
| 18 | 40–1940 | Washer | 2 |
| 19 | 27–6250 | Bushing | 2 |

3319–197





C–2626

# BAG AND COMPONENTS ASSEMBLY

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 1 | 32144–111 | Screw – Phillips Pan Head | 5 |
| 2 | 71–9480 | Handle Door | 1 |
| 3 | 71–9470 | Door – Bag | 1 |
| 4 | 71–9900 | Frame | 1 |
| 5 | 71–9460 | Bag – Grass | 1 |

* Not Illustrated





C–2627

# ENGINE ASSEMBLY

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 1 | 32144–73 | Screw | 3 |
| 2 | 3290–378 | Tie – Cable | 1 |
| 3 | 2210–249 | Clamp – Casting | 1 |
| 4 | 93–8470 | Screw – Clamp | 1 |
| 5 | 32144–102 | Screw | 3 |
| 6 | 82–8550 | Shield – Muffler | 1 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 7 | 93–4354 | Decal – Engine | 1 |
| 8 | | Engine | 1 |
| 9 | 2210–316 | Rope – Stop | 1 |
| 10 | 93–0243 | Shroud | 1 |
| 11 | 32144–121 | Screw | 2 |
| 12 | 92–2289 | Plate – Logo | 1 |





# BLADE ASSEMBLY

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 1 | 71–7940 | Retainer – Blade | 1 |
| 2 | 26–0672 | Bolt – Blade | 1 |
| 3 | 3253–22 | Washer – Lock | 1 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 4 | 92–9813 | Blade | 1 |
| 5 | 92–9812 | Stiffener – Blade | 1 |

Obtain Parts From Briggs & Stratton




★ REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL.

**1019 LABEL KIT**


Assemblies include all parts shown in frames.

# ENGINE BRIGGS & STRATTON MODEL 12F802-0667–01

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 1 | 493260 | Cylinder Assembly | 1 |
| 2 | 293708 | Bushing – Cylinder | 1 |
| ★3 | 299819 | Seal – Oil | 1 |
| 5 | 214349 | Head – Cylinder | 1 |
| ★7 | 272916 | Gasket – Cylinder Head | 1 |
| 8 | 495786 | Breather – Valve Chamber | 1 |
| ★9 | 272481 | Gasket – Breather | 1 |
| ★9A | 272238 | Gasket – Baffle Plate | 1 |
| 10 | 94650 | Screw – Breather Mtg. | 1 |
| 11 | 231933 | Tube – Breather | 1 |
| 13 | 94547 | Screw – Cylinder Head | 1 |
| ★52 | 272199 | Gasket – Intake Elbow | 1 |
| 54 | 94526 | Screw – Intake Elbow Mtg. | |
| 227 | 492349 | Lever Assembly – Gov. | 1 |
| 230 | 67072 | Washer – Gov. Crank | 1 |
| 284 | 94511 | Screw – Hex. Head | 1 |
| 306 | 224324 | Shield – Cylinder | 1 |
| 307 | 94515 | Screw – Hex. Head | 1 |
| 337 | 802592 | Plug – Spark | 1 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 383 | 89838 | Wrench – Spark Plug | 1 |
| 523 | 495264 | Cap With Dipstick – Oil Filler | 1 |
| ★524 | 280393 | Seal – Filler Tube | 1 |
| 525 | 495265 | Tube – Oil Filler | 1 |
| 562 | 94852 | Bolt – Carriage | 1 |
| 572 | 224328 | Baffle – Cylinder | 1 |
| 592 | 231082 | Nut – Hex. | 1 |
| 615 | 94474 | Fastener | 1 |
| 616 | 262578 | Crank – Governor | 1 |
| 625 | 497465 | Tube – Fuel Intake | 1 |
| 635 | 66538 | Elbow – Spark Plug | 1 |
| ★842 | 280966 | Seal – O-Ring | 1 |
| 847 | 495263 | Oil Fill Tube Assy. | 1 |
| 869 | 213512 | Seat – Intake Valve | 1 |
| 870 | 213513 | Seat – Exhaust Valve | 1 |
| 871 | 262001 | Guide – Exhaust Valve **Note:** 63709 Guide – Intake Valve | 1 |
| 1019 | 494256 | Label Kit | 1 |

★ Included in Gasket Set–Part No. 496316.





Assemblies include all parts shown in frames.

# ENGINE BRIGGS & STRATTON MODEL 12F802-0667—01

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| ★12 | 272198 | Gasket — Crankcase | 1 |
| 15 | 94720 | Plug — Oil Drain | 1 |
| 16 | 494546 | Crankshaft | |
| | | **Note:** Order 94388 For Timing Gear Key. | 1 |
| 18 | 493279 | Sump — Engine | 1 |
| ★20 | 399781 | Seal — Oil | 1 |
| 22 | 94220 | Screw — Hex. Head | 1 |
| | | **Note:** 94612 Screw — Hex. Head (One (1) Used in Hole Nearest Breather) | 1 |
| 24 | 222698 | Key — Flywheel | 1 |
| 25 | 493262 | Piston Assy. (Standard) | 1 |
| | 493385 | Piston Assy. (.010” O.S.) | 1 |
| | 493386 | Piston Assy. (.020” O.S.) | 1 |
| | 493387 | Piston Assy. (.030” O.S.) | 1 |
| 26 | 493261 | Ring Set (Standard) | 1 |
| | 493388 | Ring Set (.010” O.S.) | 1 |
| | 493389 | Ring Set (.020” O.S.) | 1 |
| | 493390 | Ring Set (.030” O.S.) | 1 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 27 | 26026 | Lock — Piston Pin | 1 |
| 28 | 298909 | Pin — Piston (Standard) | 1 |
| | 298908 | Pin — Piston (.005” O.S.) | 1 |
| 29 | 490566 | Rod Assembly — Connecting | 1 |
| | | **Note:** For Connecting Rod With .020” Undersize Crankpin Bearing — Order No. 490743. | 1 |
| 32 | 94699 | Screw — Connecting Rod | 1 |
| 33 | 262651 | Valve — Exhaust | 1 |
| 34 | 262652 | Valve — Intake | 1 |
| 35 | 262224 | Spring — Valve | 1 |
| 40 | 93312 | Retainer — Valve Spring | 1 |
| 45 | 262204 | Tappet — Valve | 1 |
| 46 | 492830 | Gear — Cam | 1 |
| 47 | 493737 | Slinger — Oil | 1 |
| 741 | 262598 | Gear — Timing | 1 |

★ Included in Gasket Set—Part No. 496316.





Assemblies include all parts shown in frames.

# ENGINE BRIGGS & STRATTON MODEL 12F802-0667–01

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 95 | 94098 | Screw – Throttle Valve Mtg. | 1 |
| ●104 | 231371 | Pin – Float Hinge | 1 |
| ●◆116 | | Gasket–Sealing (Sold in Kit Only) | 1 |
| 124 | 94525 | Screw – Carburetor Mtg. | 1 |
| 125 | 497314 | Carburetor | 1 |
| ●127 | | Plug – Welch (Sold in Kit Only) | 1 |
| 130 | 224908 | Valve – Throttle | 1 |
| 131 | 493267 | Shaft – Throttle | 1 |
| 133 | 398187 | Float Assy. – Carburetor | 1 |
| ●134 | 398188 | Valve – Inlet (Includes Seat) | 1 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| ●◆137 | | Gasket – Bowl | 1 |
| | | (Sold in Kit Only) | 1 |
| ●◆617 | 270344 | Seal – Fuel Intake Tube | 1 |
| ●◆634 | | Washer–Shaft (Sold in Kit Only) | 1 |
| 955 | 497315 | Screw – Bowl Mtg. (Std.) | |
| | | **Note:** 496495 Screw – Bowl Mtg. (High Altitude) | 1 |
| 975 | 493640 | Bowl Assy. – Carburetor | 1 |

●Included in Carburetor Kit–Part No. 493762.
◆ Included in Carburetor Gasket Set–Part No. 490937.





Assemblies include all parts shown in frames.

# ENGINE BRIGGS & STRATTON MODEL 12F802-0667–01

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 188 | 94644 | Screw – Hex. Head | 1 |
| 188A | 94602 | Screw – Hex. Head | 1 |
| 201 | 262579 | Link – Governor | 1 |
| 209 | 263046 | Spring – Governor | 1 |
| 258 | 94512 | Screw–Hex. Head | 1 |
| 620 | 497203 | Bracket – Carburetor | 1 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 620A | 225152 | Bracket – Control | 1 |
| 621 | 396847 | Switch – Stop | 1 |
| 670A | 493823 | Spacer – Bracket | 1 |
| 922 | 262640 | Spring–Brake | 1 |
| 923 | 493442 | Brake Assembly | 1 |





Assemblies include all parts shown in frames.

# ENGINE BRIGGS & STRATTON MODEL 12F802-0667—01

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 163 | 272653 | Gasket — Air Cleaner | 1 |
| 387 | 496115 | Primer—Carburetor | 1 |
| 529 | 281299 | Grommet — Breather | 1 |
| 606 | 224815 | Strap — Bracket | 1 |
| 966 | 496116 | Base — Air Cleaner | 1 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 967 | 491588 | Filter — Air | 1 |
| 968 | 281340 | Cover — Air Cleaner | 1 |
| 969 | 94120 | Screw — Cover Mtg. | 1 |
| 971 | 94121 | Screw — Air Cleaner | 1 |
| 971A | 94749 | Screw — Hex. Head | 1 |

★Included in Gasket Set—Part No. 496316.





Assemblies include all parts shown in frames.

# ENGINE BRIGGS & STRATTON MODEL 12F802-0667–01

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 55 | 497440 | Housing – Rewind Starter | 1 |
| 56 | 498144 | Pulley – Rewind Starter | 1 |
| 58 | 280399 | Rope – Rewind Starter (Cut to Required Length) | 1 |
| 59 | 224467 | Insert – Starter Grip | 1 |
| 60 | 493926 | Handle – Rewind Starter | 1 |
| 456 | 281503 | Retainer – Rewind Starter | 1 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 459 | 281505 | Pawl – Starter | 1 |
| 461 | 94943 | Pin – Starter | 1 |
| 515 | 263073 | Spring – Torsion | 1 |
| 608 | 497680 | Starter Assy. – Rewind | 1 |
| | | **Includes:** | |
| | | 94128 Screw – Hex. Hd. | 1 |
| | | 92987 Nut – Hex. | 1 |





Assemblies include all parts shown in frames.

# ENGINE BRIGGS & STRATTON MODEL 12F802-0667—01

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 23 | 492177 | Flywheel | 1 |
| 37 | 224511 | Guard — Flywheel | 1 |
| 304 | 493293 | Housing — Blower | 1 |
| 305 | 94744 | Screw — Sem | 1 |
| 332 | 92284 | Nut — Flywheel | 1 |
| 333 | 802574 | Armature — Magneto | 1 |

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 334 | 94731 | Screw — Sem | 1 |
| 356 | 398808 | Wire — Ground | 1 |
| 363 | 19069 | Flywheel Puller | 1 |
| 455 | 225121 | Cup — Starter | 1 |
| 851 | 493880 | Terminal — Ignition Cable | 1 |





Assemblies include all parts shown in frames.


# ENGINE BRIGGS & STRATTON MODEL 12F802-0667—01

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 81 | 223664 | Lock — Muffler Screw | 1 |
| 187 | 492790 | Hose — Fuel | 1 |
| 188 | 398540 | Screw — Tank Mounting | 1 |
| 284 | 94511 | Screw — Shoulder | 1 |
| 300 | 496106 | Muffler — Exhaust | 1 |
| 346 | 93705 | Screw — Hex. Head | 1 |
| 601 | 93053 | Clamp — Hose | 1 |


| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| 613 | 94231 | Screw — Shoulder | 1 |
| 670 | 280512 | Spacer — Fuel Tank | 1 |
| 676 | 493871 | Deflector — Muffler | 1 |
| ★883 | 272253 | Gasket — Exhaust | 1 |
| 957 | 397974 | Cap Assy. — Fuel | 1 |
| 972 | 495224 | Tank Assembly — Fuel | 1 |




358 GASKET SET




977 CARBURETOR GASKET SET




121 CARBURETOR KIT

Assemblies include all parts shown in frames.

# ENGINE BRIGGS & STRATTON MODEL 12F802-0667—01

| Ref. No. | Part No. | Description | No. Used |
|---|---|---|---|
| ★3 | 299819 | Seal — Oil | 1 |
| ★7 | 272916 | Gasket — Cylinder Hd. | 1 |
| ★9 | 272481 | Gasket — Breather | 1 |
| ★9A | 272238 | Gasket — Baffle Plate | 1 |
| ★12 | 272198 | Gasket — Crankcase | 1 |
| ★20 | 399781 | Seal — Oil | 1 |
| ★52 | 272199 | Gasket — Intake Elbow | 1 |
| ●104 | 231371 | Pin — Float Hinge | 1 |
| ●◆116 | | Gasket — Sealing (Sold in Kit Only) | 1 |
| 121 | 493762 | Carburetor Kit | 1 |
| ●127 | | Plug — Welch (Sold in Kit Only) | 1 |
| ●134 | 398188 | Valve — Inlet (Includes Seat) | 1 |
| ●◆137 | | Gasket — Bowl (Sold in Kit Only) | 1 |
| ★163 | 272653 | Gasket — Air Cleaner | 1 |
| 358 | 497316 | Gasket Set | 1 |
| ★524 | 280393 | Seal — Filler Tube | 1 |
| ●◆617 | 270344 | Seal — Fuel Intake Tube | 1 |
| ●◆634 | | Washer — Shaft (Sold in Kit Only) | 1 |
| ★842 | 280966 | Seal — O-Ring | 1 |
| ★883 | 272253 | Gasket — Exhaust | 1 |
| 977 | 490937 | Gasket Set — Carburetor | 1 |

●Included in Carburetor Kit—Part No. 493762.
◆Included in Carburetor Gasket Set—Part No. 490937.
★ Included in Gasket Set—Part No. 496316.

# TORO PART NUMBER INDEX

| Part No. | Description | Pg. No. | Ref. No. | Qty. |
|---|---|---|---|---|
| 14–9949 | Rear Wheel & Tire Assembly 8” | 3 | 17 | 2 |
| 16–5979 | Housing – Deck | 1 | 5 | 1 |
| 17–1569 | Door – Discharge | 1 | 8 | 1 |
| 19–4050 | Knob | 2 | 3 | 2 |
| 26–0672 | Bolt – Blade | 6 | 2 | 1 |
| 27–6230 | Bolt – Wheel | 3 | 1 | 2 |
| 27–6230 | Bolt – Wheel | 1 | 22 | 2 |
| 27–6250 | Bushing | 3 | 19 | 2 |
| 27–6250 | Bushing | 1 | 29 | 2 |
| 40–1940 | Washer | 3 | 18 | 2 |
| 40–1940 | Washer | 1 | 24 | 2 |
| 46–1113 | Wheel & Tire Assembly 7” | 1 | 23 | 2 |
| 63–8590 | Screw | 3 | 3 | 2 |
| 65–5210 | Screw – Thread Forming | 1 | 14 | 2 |
| 71–7740 | Spring – Counterbalance | 3 | 16 | 1 |
| 71–7770 | Plate – Securing | 3 | 10 | 2 |
| 71–7800 | Arm – Pivot | 3 | 8 | 1 |
| 71–7820 | Pivot – Front | 1 | 26 | 1 |
| 71–7840 | Rod – Trigger | 3 | 9 | 1 |
| 71–7860 | Grip – Upper | 1 | 13 | 1 |
| 71–7870 | Grip – Lower | 1 | 18 | 1 |
| 71–7900 | Cap – Bolt LH | 1 | 10 | 1 |
| 71–7910 | Cap – Bolt RH | 1 | 15 | 1 |
| 71–7920 | Cover – Belt | 1 | 20 | 1 |
| 71–7930 | Trigger – Height of Cut | 1 | 16 | 1 |
| 71–7940 | Retainer – Blade | 6 | 1 | 1 |
| 71–7970 | Rod – Link | 3 | 13 | 1 |
| 71–7980 | Indicator – Height of Cut | 3 | 12 | 1 |
| 71–7990 | Ramp – Discharge | 1 | 4 | 1 |
| 71–8060 | Spring – Trigger | 3 | 5 | 2 |
| 71–8080 | Saddle – Height of Cut | 3 | 4 | 1 |
| 71–8090 | Mount – Handle LH | 2 | 5 | 1 |
| 71–8100 | Mount – Handle RH | 2 | 4 | 1 |
| 71–8450 | Cover – Spring | 3 | 14 | 1 |
| 71–8580 | Spacer – Door | 1 | 7 | 2 |
| 71–8830 | Retainer Shaft Assembly | 1 | 2 | 2 |
| 71–9460 | Bag – Grass | 4 | 5 | 1 |
| 71–9470 | Door – Bag | 4 | 3 | 1 |
| 71–9480 | Handle Door | 4 | 2 | 1 |
| 71–9840 | Spring – Door | 1 | 9 | 2 |
| 71–9860 | Decal – Deck | 1 | 21 | 1 |
| 71–9900 | Frame | 4 | 4 | 1 |
| 82–8550 | Shield – Muffler | 5 | 6 | 1 |
| 92–2289 | Plate – Logo | 5 | 12 | 1 |
| 92–7729 | Anchor – Cable | 2 | 7 | 1 |
| 92–9812 | Stiffener – Blade | 6 | 5 | 1 |
| 92–9813 | Blade | 6 | 4 | 1 |
| 93–0243 | Shroud | 5 | 10 | 1 |
| 93–1116 | Cable – Brake | 2 | 6 | 1 |
| 93–1118 | Control – Throttle | 2 | 13 | 1 |
| 93–4105 | Decal – Danger | 1 | 28 | 1 |
| 93–4354 | Decal – Engine | 5 | 7 | 1 |
| 93–8470 | Screw – Clamp | 5 | 4 | 1 |
| 94–4375 | Handle | 2 | 11 | 1 |
| 95–4453 | Screw – Handle | 2 | 8 | 1 |
| 95–4457 | Rope – Guide | 2 | 10 | 1 |
| 95–5924 | Bail – Brake | 2 | 12 | 1 |
| 2210–249 | Clamp – Casting | 5 | 3 | 1 |
| 2210–316 | Rope – Stop | 5 | 9 | 1 |
| 321–48 | Screw – Hex Head | 2 | 14 | 1 |
| 322–29 | Screw – Hex Head | 1 | 11 | 2 |
| 3253–22 | Washer – Lock | 6 | 3 | 1 |
| 3256–1 | Washer – Flat | 2 | 9 | 1 |
| 3284–5 | Pin – Groove | 1 | 17 | 1 |
| 3290–378 | Tie – Cable | 2 | 1 | 1 |
| 3290–378 | Tie – Cable | 5 | 2 | 1 |
| 3296–5 | Nut – Lock (Nylon) | 3 | 7 | 2 |
| 3296–5 | Nut – Lock (Nylon) | 1 | 25 | 2 |
| 3296–73 | Nut – Lock Insert | 2 | 2 | 3 |
| 32112–11 | Nut – Push | 1 | 3 | 1 |
| 32112–13 | Nut – Push | 3 | 2 | 1 |
| 32144–4 | Screw – Hex Head Tap | 1 | 1 | 8 |
| 32144–4 | Screw – Hex Head Tap | 3 | 11 | 4 |
| 32144–31 | Screw | 3 | 6 | 1 |
| 32144–70 | Screw – Tap | 1 | 19 | 1 |
| 32144–73 | Screw | 5 | 1 | 3 |
| 32144–97 | Screw – Phillips Pan Head | 1 | 12 | 2 |
| 32144–102 | Screw | 5 | 5 | 3 |
| 32144–111 | Screw – Phillips Pan Head | 4 | 1 | 5 |
| 32144–121 | Screw | 5 | 11 | 2 |
| 32151–93 | Ring – Grip | 3 | 15 | 1 |

*Not Illustrated