
STAND-ON AERATOR

Model No. SAR481KA30—Serial No. 312000000 and Up

Picture below may not reflect actual product.



Parts Manual

Part No. 4501-143 Rev. B

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LPG: Liquid Propane Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head

Touch Up Paint

Exmark black touch up spray paint – gloss black.

Exmark red touch up paint (spray paint – P/N 1-850337 - .6 oz liquid bottle – P/N 103-9140).

© 2012—Exmark Mfg. Co., Inc.
Industrial Park Box 808
Beatrice, NE 68310


Contact us at www.Exmark.com.
Printed in the USA.
All Rights Reserved



If your Exmark dealer does not have the Exmark part in stock, Exmark will get the parts to the dealer the next business day or the part will be FREE Guaranteed!! (Some restrictions apply. See your participating Exmark Dealer for details.)

Contents

Main Frame Assembly 4
Main Frame W/Decals Assembly No. 116-6938 5
Caster Wheel and Fork Assembly 6
Tower Assembly 7
Motion Controls Assembly 8
Ground Drive Assembly 9
LH and RH Transaxle Assembly Nos. 116-6614 and 116-6615 11
Axle and Bearing Assembly No. 116-7645 12
Auxiliary Hydraulic Assembly 13
Tine Assembly 15
RH Tine Wheel Assembly No. 116-6738 16
LH Tine Wheel Assembly No. 116-6739 17
Fuel Assembly 18
Engine Assembly 19
Electrical Assembly 20




Main Frame Assembly

Ref.	Part Number	Qty.	Description
1	116-6938	1	Main Frame And Decal ASM
2		2	Front Caster ASM W/Fork ●
3	116-6536-01	1	Weight
4	116-6940	1	Platform ASM W/Decals
4:2	116-6460	1	Decal-Tine Ground Engagement
5	116-6939	1	Access Cover ASM
5:2	116-6459	1	Decal-Tine Ground Operation
6	116-6968	1	Weight Mount Plate ASM
6:2	103-2076	2	Decal-Caution
7	3256-26	4	Washer-1/2 Sae
8	99-5107	4	Nut-Lock 1/2-13
10	116-6612-01	1	Guard-Chain, RH
11	116-6611-01	1	Guard-Chain, LH


Ref.	Part Number	Qty.	Description
12	116-6763-03	1	Guard-Muffler
14	325-14	4	Screw-HH 1/2-13 X 3 1/2
17	116-6767	3	Spring-Compression
18	104-8301	9	Nut-Nyloc 3/8-16 Flg
19	3256-24	9	Washer-3/8 Sae
20	323-16	3	Screw-HH 3/8-16 X 4
21	323-6	6	Screw-HH 3/8-16 X 1
22	614672	2	Screw-Shoulder 3/8-16 X 1.295
23	1-811010	2	Plug
24	3256-6	2	Washer
32	116-6952	1	Decal-Stand-On Aerator 30
33	116-6605	3	Retainer-Spring
34	104-7201	6	Nut-Nyloc 1/4-20 Flg
35	3229-1	6	Bolt-Carriage 1/4-20 X 3/4

● Not serviced separately



Main Frame W/Decals Assembly No. 116-6938

Ref.	*Part Number*	*Qty.*	*Description*
2	116-6455	1	Decal-Danger Rotating Tines
3	98-5954	1	Decal-Cover, Missing
4	116-6456	2	Decal-Danger Chain Drive
5	116-6462	1	Decal-Belt Routing
6	32148-10	2	Insert-Nut




Caster Wheel and Fork Assembly

Ref.	Part Number	Qty.	Description
1	116-1963-01	1	Caster
2	109-9126	1	Wheel And Tire ASM
2:1	103-2768	2	Guard-Seal
2:2		1	Wheel And Tire ASM ●
2:2:1	1-633585	2	Bearing-Cone Tapered Roller
2:2:2	103-0063	2	Seal-Double Lip
2:2:3	103-3051	2	Spacer-Nut ■
2:2:4	103-3155	1	Axle-Caster
2:2:5		1	Wheel And Tire ASM ●

Ref.	Part Number	Qty.	Description
2:2:5:1	1-633584	1	Bearing-Cup
2:3	325-42	1	Screw-HH 1/2-13 X 8
2:4	3296-23	1	Nut-Nyloc 1/2-13
3	1-543511	1	Seal-Grease
4	1-543509	2	Cone-Bearing Tapered Roller
5	1-633508	3	Washer-Spring Disc
6	3296-51	1	Nut-Nyloc 3/4-10
7	103-4882	1	Cap-Grease


● Not serviced separately
■ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.



Tower Assembly


Ref.	Part Number	Qty.	Description
1	116-7203	1	Panel-Side, LH W/Decals -Black
1:2	116-7709	1	Decal-Service Aid
1:3	32148-7	1	Nut-Insert
2	116-7658	1	ASM-Panel,Side RH (Black)
2:2	32148-7	1	Nut-Insert
3	116-6783	1	ASM-Plate W/Decal
3:2	116-7027	1	Decal-Control Panel Warning
3:3	116-6457	1	Decal-Warning Stored Energy
3:4	32148-7	2	Nut-Insert
4	116-6937	1	Bracket-Knee Pad W/ Decals
4:2	116-7029	1	Decal-Slope Warning
5	116-7618	1	ASM-Console W/Decal
5:2	116-7611	1	Decal-Control Panel Danger
6	3231-1	8	Bolt-Carriage 3/8-16 X 3/4
7	104-8301	12	Nut-Nyloc 3/8-16 Flg

Ref.	Part Number	Qty.	Description
8	3231-2	4	Bolt-Carriage 3/8-16 X 1
9	116-6765	1	Cushion, Grey
10	3234-5	4	Screw-HH Flg 5/16-18 X 3/4
11	109-9147	1	Control-Choke
12	109-3958	1	Control, Throttle
13	116-6630	1	Bracket-Brake Cable
14	116-7504	1	Link-Brake Cable
15	116-7503	1	Cable-Brake
17	3234-29	4	Screw-HH Flg 5/16-18 X 1
18	3229-1	2	Bolt-Carriage 1/4-20 X 3/4
19	104-7201	2	Nut-Nyloc 1/4-20 Flg
20	116-7607	1	Knob, Tee
21	1-807513	4	Bolt-Carriage #10-24 X 1/2
22	3296-2	4	Nut-Nyloc #10-24
23	103-2882	1	Decal,Exmark Logo
24	116-7034	2	Decal-Exmark X-Logo 3.85
25	1-303335	2	Tie-Plastic
26	3256-2	2	Washer-Flat



Motion Controls Assembly


Ref.	Part Number	Qty.	Description
1	116-6567	1	Control Handle-ASM, RH
1:2	116-4279	2	Bearing-Flange
2	116-6566	1	Control Handle-ASM, LH
2:2	116-4279	2	Bearing-Flange
3	116-6573-03	2	Bellcrank-W/ Arm [black]
4	116-6617-03	2	Bellcrank-W/Arm [black]
5	116-6722	2	Link-Hydro Control
6	116-6726	2	Link-Bellcrank Control
7	116-6730	2	Link-Bellcrank Control
8	116-6608-03	1	Bar-Reference
9	116-6607	1	Shaft-Control Pivot
10	1-633131	2	Yoke-Linkage, Brake
11	103-2399	2	Pin-Clevis Spring 3/8
12	3219-3	2	Nut-Hex 3/8-24
13	3256-24	14	Washer-3/8 Sae
14	1-806003	10	Hairpin-Cotter
15	116-6576-03	1	Bracket-Pivot, RH
16	116-6577-03	1	Bracket-Pivot LH
17	116-7224	4	Spacer
18	104-7201	4	Nut-Nyloc 1/4-20 Flg
19	3256-2	4	Washer-1/4 Std
20	321-14	4	Screw-HH 1/4-20 X 2 3/4
21	116-0027	2	Damper-Control, Motion
22	104-8300	4	Nut-Nyloc 5/16-18 Flg
23	104-8301	8	Nut-Nyloc 3/8-16 Flg
24	323-6	4	Screw-HH 3/8-16 X 1
25	3231-2	4	Bolt-Carriage 3/8-16 X 1
26	103-8153	2	Grip,Control Lever
27	32112-14	2	Nut-Push



Ground Drive Assembly

Ref.	Part Number	Qty.	Description
1	116-6740	1	Hook-J
2	116-6624	2	Hub-Chain Drive
3	116-6627	2	Jackshaft
4	116-6735-03	1	Pivot-Idler [black]
5	116-6895	2	Links-#50 Roller Chain, 65
6	116-6896	2	Link-#50 Roller Chain, 47
7	1-653333	1	Belt, Blower 48"dk
8	116-6771	1	Spring-Comp .72 X 3.00
9	116-6572-03	2	Mount-Transmission
10	116-7588-03	1	Guard-Transmission
11	3230-7	2	Bolt-Carriage 5/16-18 X 2 1/4
13	116-6596-01	2	Plate-Jackshaft
14	116-6619	2	Plate-Trans Adjustment
15	116-7597	1	Yoke, Park Brake
17	116-6723	2	Bracket-Hydro Adjust
18	116-6568	1	Idler Arm-ASM
19	116-6724	1	Bracket-Idler Spring
20	116-6756	2	Bearing,Pillow Block 1.00
21	116-2839	4	Nut-Lock
22	242-50	8	Nut-Lug 1/2-20


Ref.	Part Number	Qty.	Description
26	104-8300	6	Nut-Nyloc 5/16-18 Flg
27	116-6719	2	Sprocket-Idler 17T 50
28	104-8417	2	Washer
29	104-8301	33	Nut-Nyloc 3/8-16 Flg
30	3231-25	6	Bolt-Carriage 3/8-16 X 1 1/4
31	109-2250	1	Vent-Tank, Hydro
31:1	109-3320	1	Cap-Reservoir, HYD
32	49-0390	2	Spacer
33	116-6897	4	Link-#50 Connecting
34	116-6614	1	ASM-Zt3400 RH
35	116-6615	1	ASM-Zt3400 LH
36	116-6760	2	Pulley-Idler Flat
37	116-6932	2	ASM,Tire 16X6.50-8 K500
37:1	116-6977	1	Rim 8 X 5.375
37:2	116-6978	1	Tire, K500 16 X 6.50-8 4P
37:3	232-27	1	Stem-Valve
38	3230-9	4	Bolt-Carriage 5/16-18 X 2 3/4
39	116-6777	4	Bearing, Flange -2 Bolt
40	3231-2	14	Bolt-Carriage 3/8-16 X 1
41	323-9	1	Screw-HH 3/8-16 X 1 3/4



Ground Drive Assembly (continued)

Ref.	Part Number	Qty.	Description
42	116-7645	2	ASM-Axle And Bearing
43	116-3872	2	Hub-Offset
44	3296-45	2	Nut-Nyloc 1/2-13 Thin
45	3233-14	2	Screw-CARR
46	104-7201	2	Nut-Nyloc 1/4-20 Flg
47	3256-22	2	Washer-1/4 Sae
48	321-9	2	Screw-HH 1/4-20 X 1 1/2
49	116-7598	1	Spacer-Idler
50	323-14	1	Screw-HH 3/8-16 X 3
51	3217-7	4	Nut-Hex 3/8-16
52	99-8664	2	Bolt-HH 3/8-16 X 3 Tap
53	116-6775	1	Hose-Hydraulic
54	116-6776	1	Hose-Hydraulic
55	109-3322	4	Clamp-Hose
56	323-10	2	Screw-HH 3/8-16 X 2
57	109-7033	1	Nut-Flange 5/8-18 Centerlock


Ref.	Part Number	Qty.	Description
58	3296-48	8	Nut-Nyloc 7/16-14
59	3256-25	4	Washer-7/16 Sae
60	324-6	4	Screw-HH 7/16-14 X 1 1/2
61	3232-3	4	Bolt-Carriage 7/16-14 X 1 1/2
62	116-7109	4	Screw-HH
63	116-7596	1	Pin, Park Brake
65	76-4660	1	Spring-Door
66	3256-24	2	Washer-3/8 Sae
67	107-3154	6	Nut-Push 3/8-16
68	116-7253	1	Spacer
69	116-7254	1	Spacer
70	302-61	1	Zerk-45° 1/4-28
71	52-2860	1	Washer



LH and RH Transaxle Assembly Nos. 116-6614 and 116-6615

Ref.	*Part Number*	*Qty.*	*Description*
1	109-3540	1	O-Ring-Charge Seal Cover
2	116-6743	1	Kit-Fan And Pulley
3	109-3321	1	Filter-Hydraulic
4	109-3278	1	Adapter-Straight
4:1	1-603921	1	O-Ring
5	109-5592	1	Spring
6	116-6742	1	Fan-Hydrogear Offset
99	109-3537	1	Complete Seal Kit ●


● Not illustrated



Axle and Bearing Assembly No. 116-7645

Ref.	*Part Number*	*Qty.*	*Description*
1	116-6746-01	1	Mount,Wheel Bearing [red]
2	1-543509	2	Cone-Bearing Tapered Roller
3	116-6758	2	Spacer,1.250 X 1.000 X .330
4	1-543511	2	Seal-Grease
5	323-7	4	Screw-HH 3/8-16 X 1 1/4
6		1	Axle ●
7	99-3139	1	Nut
8	1-806800	1	Pin-Cotter

● Not serviced separately




Auxiliary Hydraulic Assembly

Ref.	Part Number	Qty.	Description
1	116-6894	1	Belt-A, 37
2	116-6618-03	1	Bracket-HYD Tank
3	116-7556	1	ASM-Reservoir W/Decal
3:1		1	Tank-Hydraulic ●
3:1:1	103-1948	1	Cap-Reservoir, HYD
3:1:2	103-1949	1	Gasket-Cap
3:2	116-6990	1	Decal-Hydro Oil Aw-32
4	116-6752	1	Valve
5	3245-1	2	Screw-Set, HSH
6	116-6969	1	Cylinder-HYD
6:1	116-7290	2	Pin-Clevis 1" X 2.00
6:2	92-1298	2	Pin-Lynch
7	116-6753	1	Gauge-Pressure
8	353-388	3	Fitting-Straight
8:1	237-79	1	O-Ring
11	3296-29	4	Nut-Nyloc 5/16-18
12	3231-4	1	Bolt-Carriage 3/8-16 X 1 1/2
13	3296-59	1	Nut-Nyloc 3/8-16 Thin
14	22-7810	4	Spacer

Ref.	Part Number	Qty.	Description
15	110-9361	4	Screw-PPH, Sems
16	104-8300	2	Nut-Nyloc 5/16-18 Flg
17	3256-2	2	Washer-1/4 Std
18	322-5	6	Screw-HH 5/16-18 X 1
19	3231-2	4	Bolt-Carriage 3/8-16 X 1
20	104-8301	4	Nut-Nyloc 3/8-16 Flg
21	116-6993	1	ASM-Hydraulic Hose
22	116-6667	1	Pulley
23	116-6760	1	Pulley-Idler Flat
24	103-2156	5	Adapter-Straight
24:1	1-603921	1	O-Ring-Sae #6
24:2	103-1020	1	O-Ring-37 Flare #6
25	104-7836	1	Filter-Head
26	109-4180	1	Filter,25 Micron Bi-Directional
28	353-877	1	Fitting-HYD, Tee (Swivel)
29	116-6751	1	Pump-Gear
32	116-6781	5	Spacer
34	116-6679	1	Hose ASM-HYD Hp

● Not serviced separately




Auxiliary Hydraulic Assembly (continued)

Ref.	Part Number	Qty.	Description
36	116-6675	1	Hose ASM-HYD Lp
37	116-6676	1	Hose ASM-HYD Hp
38	116-6680	1	ASM-Hydrualic Hose
39	116-6677	1	ASM-Hydrualic Hose
40	116-6678	1	Hose ASM-HYD Hp 3/8X28
41	116-6686	1	Fitting-Elbow-90

Ref.	Part Number	Qty.	Description
42	321-3	2	Screw-HH 1/4-20 X 5/8
43	1-805004	2	Washer-Lock 1/4 Heavy
45	3256-24	1	Washer-3/8 Sae
46	116-7307-01	1	Stop-Cylinder
47	283-82	1	Pin-Clevis
48	1-806003	1	Hairpin-Cotter


● Not serviced separately



Tine Assembly


Ref.	Part Number	Qty.	Description
1	116-6553-03	1	Trail Arm ASM
2	116-6738	1	RH Tine Wheel ASM
3	116-6739	1	LH Tine Wheel ASM
4	116-6895	2	Links-#50 Roller Chain, 65
5	116-6897	2	Link-#50 Connecting
6	87-7270	2	Washer-Thrust
7	116-6719	2	Sprocket-Idler 17T 50
8	116-6777	2	Bearing, Flange -2 Bolt
9	3233-14	2	Screw-CARR
10	3296-45	2	Nut-Nyloc 1/2-13 Thin

Ref.	Part Number	Qty.	Description
11	116-7109	4	Screw-HH
12	3296-48	6	Nut-Nyloc 7/16-14
13	324-8	2	Screw-HH
14	116-6629	1	Shaft-1.00 X 4.00
15	116-6756	2	Bearing,Pillow Block 1.00
16	3256-25	4	Washer-7/16 Sae
17	324-6	2	Screw-HH 7/16-14 X 1 1/2
18	324-7	2	Screw-HH
19	116-7327-01	1	Plate-Downstop [red]




RH Tine Wheel Assembly No. 116-6738

Ref.	*Part Number*	*Qty.*	*Description*
1	116-6727	1	Tine Shaft-RH
2	116-6731	1	Float Tine Shaft-ASM
2:2	94-8949	2	Bushing-Flange
3	121-4894	24	Tine-Coring
4	323-8	24	Screw-HH 3/8-16 X 1 1/2
5	3296-39	24	Nut-Nyloc 3/8-16
6	116-7271	1	Collar-Locking 1.00"




LH Tine Wheel Assembly No. 116-6739

Ref.	*Part Number*	*Qty.*	*Description*
1	116-6728	1	Tine Shaft-LH
2	116-6731	1	Float Tine Shaft-ASM
2:2	94-8949	2	Bushing-Flange
3	121-4894	24	Tine-Coring
4	323-8	24	Screw-HH 3/8-16 X 1 1/2
5	3296-39	24	Nut-Nyloc 3/8-16
6	116-7271	1	Collar-Locking 1.00"



Fuel Assembly


Ref.	Part Number	Qty.	Description
1	116-7243-01	1	Support-Fuel Tank
2	116-3656	1	ASM, Fuel Tank
2:2	120-5461	1	Cap-Fuel, Ratcheting
2:3	114-0284	1	Grommet
2:4	114-0285	1	Valve-Rollover
2:5	103-2605	1	Fitting-Fuel Bulkhead W/Strainer
3	107-4543	2	Clamp
4	116-4346	1	Hose-Emissions
5	3256-3	2	Washer-5/16 Std
6	322-10	2	Screw-HH 5/16-18 X 2
7	104-8300	2	Nut-Nyloc 5/16-18 Flg
8	3231-2	4	Bolt-Carriage 3/8-16 X 1
9	104-8301	4	Nut-Nyloc 3/8-16 Flg
10	2412-98	4	Clamp-Hose
11	119-7856	1	Hose-Fuel
12	1-603770	1	Valve-Fuel
13	105-8342	1	Hose-Fuel
14	115-7872	1	Hose-Fuel
15	116-5464	1	Tee And Check ASM
16	120-2235	1	Filter-Air
17	1-303335	3	Tie-Cable 7 15/16 (Large)
18	116-4769	1	Decal-Filter, Emissions



Engine Assembly

Ref.	*Part Number*	*Qty.*	*Description*
1	116-3735	1	Muffler,Horizontal
2		1	Engine-Kawasaki, Fs730V ●■
3	116-6666	1	Pulley
4	103-4177	1	Key
5	1-543610	1	Washer
6	1-603610	2	Washer-Spring Disc 7/16
7	109-9761	1	Screw-HH 7/16-20 X 1 1/2 W/Loctite ◆
8	98-5975	4	Washer-Spring Disc 3/8
9	323-7	4	Screw-HH 3/8-16 X 1 1/4
10	116-4924	1	Asm-Hose Oil Drain W/Plug ▲
10:1	353-508	1	Plug-W/O-Ring
10:1:1	237-42	1	O-Ring

● Not serviced separately
▲ Use a Teflon Pipe Sealant or equivalent on threads.
◆ Use Pro-Lock, Nut Type (P/N 1-840022, .5ml tube) on threads.
■ Obtain parts from www.kawpowerepc.com



Electrical Assembly

Ref.	Part Number	Qty.	Description
1	1-603511	1	Key-Ignition
1	103-2106	1	Key-Exmark Logo
2	3230-2	2	Bolt-Carriage 5/16-18 X 1
3	117-2221	1	Switch-Ignition
4	1-643275	2	Relay-12Vdc 40 Amp
5	1-513374	1	Meter-Engine Hours
6	3234-5	2	Screw-HH Flg 5/16-18 X 3/4
8	117-6422	1	Cable-Battery, Black
9	109-7630	1	Positive Battery Cable ASM
9:1	109-2407	1	Insulator-Battery
9:2	1-543393	1	Insulator-Solenoid
10	116-6673	1	Battery Box ASM U1 Pn03188
11	116-6890	1	Harness-30 Aerator ●
12	116-7589	1	Mount-Switch
13	116-6609-03	1	Tray-Battery
14	3231-2	6	Bolt-Carriage 3/8-16 X 1
15	104-8301	6	Nut-Nyloc 3/8-16 Flg
16	110-6765	1	Switch-Single Pole No
17	116-6768-03	1	Guard-Harness
18	92-6282	1	Switch-Seat
19	3296-2	2	Nut-Nyloc #10-24
20	3229-1	2	Bolt-Carriage 1/4-20 X 3/4
21	3290-321	2	Screw-HWH
22	104-8300	4	Nut-Nyloc 5/16-18 Flg
23	1-303287	9	Tie-Cable 5 1/2 (Small)
24	1-816001	2	Fuse-Blade Type, 20 Amp
25	33114-016	1	Screw-HH M8-1.25 X 16Mm
26	33094-00	1	Washer
27	109-9190	4	Nut, Push .375
28	104-7201	1	Nut-Nyloc 1/4-20 Flg
29	116-7502	1	Jumper-Switch
30	116-7505	1	Plug-Neutral Switch

● Use dielectric grease on all unsealed connectors and terminals only. Do not apply in sealed connectors.

Notes:

Notes:

EXMARK® MAINTENANCE

MAXIMIZE THE PERFORMANCE OF YOUR EXMARK.

4-CYCLE PREMIUM ENGINE OIL
Part No. 116-3373

Both SAE 30 and SAE 10W-30 in one bottle.

Contains increased levels of zinc and phosphorus for better lubricity.

No Viscosity Index Improvers that tend to shear down in high heat.

Synthetic formulation.

Gas & Diesel compatible.

Anti-corrosion additives.


API 'SL' and JASO rated with wet clutch compatibility for other machines.

PREMIUM HYDRO OIL
Part No. 109-9828

Commercial quality for tough, high-heat conditions.

Designed specifically for zero-turn mower hydraulic systems.

Superior shear resistance under heavy loads.



Available from your local Exmark dealer. Find your closest dealer at exmark.com

EXMARK ACCESSORIES AND OPTIONS*

MID-MOUNT RIDING ACCESSORIES AND OPTIONS

CUSTOM RIDE SEAT SUSPENSION SYSTEM
FULL SUSPENSION SEAT
DECK LIFT ASSIST KIT
HITCH KIT
LIGHT KIT
12V POWER PORT
MICRO-MULCH SYSTEM
OPERATOR CONTROLLED DISCHARGE
SUN SHADE
TRASH CONTAINER
TURF STRIPER
ULTRA VAC COLLECTION SYSTEM
ULTRA VAC QUICK DISPOSAL SYSTEM

OUT-FRONT RIDING ACCESSORIES AND OPTIONS

CUSTOM RIDE SEAT SUSPENSION SYSTEM
DUAL-TAIL WHEEL
FLOOR PAN EXTENDER
HITCH KIT
LIGHT KIT
MICRO-MULCH SYSTEM
ROLL OVER PROTECTION SYSTEM (ROPS)
SNOW BLADE
SNOWBLOWER
SUN SHADE
TRASH CONTAINER
ULTRA VAC COLLECTION SYSTEM
ULTRA VAC QUICK DISPOSAL SYSTEM
WEATHER CAB

WALK-BEHIND ACCESSORIES AND OPTIONS

GRASS CATCHER
MICRO-MULCH SYSTEM
TURF STRIPER
STANDON

*Some accessories and options not available for some models.

Place Model No. and Serial No. Label Here (Included in the Literature Pack) or Fill in Below

Model No. _____

Serial No. _____

Date Purchased _____

Engine Model No. and Spec. No. _____

Engine Serial No. (E/No) _____

© 2012 Exmark Mfg. Co., Inc.
All Rights Reserved

Industrial Park Box 808
Beatrice, NE 68310
(402) 223-6300
Fax (402) 223-5489

Part No. 4501-143 Rev. B
Printed in the USA.

www.exmark.com