




MODEL NO. 20803-7900001 & UP


**PARTS
CATALOG**
48cm RECYCLER[®]
REAR BAGGER MOWER


C-2627

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	32144-73	Screw	3
2	3290-378	Tie - Cable	1
3	2210-249	Clamp - Casting	1
4	93-8470	Screw - Clamp	1
5	32144-102	Screw	3
6	82-8550	Shield - Muffler	1

Ref. No.	Part No.	Description	No. Used
7	93-4354	Decal - Engine	1
8		Engine	1
9	2210-316	Rope - Stop	1
10	93-0243	Shroud	1
11	32144-121	Screw	2
12	92-2289	Plate - Logo	1




C-2624

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3290-378	Tie - Cable	1
2	3296-73	Nut - Lock Insert	3
3	19-4050	Knob	2
4	71-8100	Mount - Handle RH	1
5	71-8090	Mount - Handle LH	1
6	93-1116	Cable - Brake	1
7	92-7729	Anchor - Cable	1

Ref. No.	Part No.	Description	No. Used
8	95-4453	Screw - Handle	1
9	3256-1	Washer - Flat	1
10	95-4457	Rope - Guide	1
11	94-4375	Handle	1
12	95-5924	Bail - Brake	1
13	93-1118	Control - Throttle	1
14	321-48	Screw - Hex Head	1




C-2630

DECK SUSPENSION ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	27-6230	Bolt - Wheel	2
2	32112-13	Nut - Push	1
3	63-8590	Screw	2
4	71-8080	Saddle - Height of Cut	1
5	71-8060	Spring - Trigger	2
6	32144-31	Screw	1
7	3296-5	Nut - Lock (Nylon)	2
8	71-7800	Arm - Pivot	1
9	71-7840	Rod - Trigger	1
10	71-7770	Plate - Securing	2
11	32144-4	Screw - Hex Head Tap	4

Ref. No.	Part No.	Description	No. Used
12	71-7980	Indicator - Height of Cut	1
13	71-7970	Rod - Link	1
14	71-8450	Cover - Spring	1
15	32151-93	Ring - Grip	1
16	71-7740	Spring - Counterbalance	1
17	14-9949	Rear Wheel & Tire Assembly (Incl. Ref. # 19)	2
18	40-1940	Washer	2
19	27-6250	Bushing	2
20	92-7663	Cover - Wheel	1




C-2626

BAG AND COMPONENTS ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	32144-111	Screw – Phillips Pan Head	5
2	71-9480	Handle Door	1
3	71-9470	Door – Bag	1

Ref. No.	Part No.	Description	No. Used
4	71-9900	Frame	1
5	71-9460	Bag - Grass	1

* Not Illustrated




C-2629

DECK ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	32144-4	Screw – Hex Head Tap	8
2	71-8830	Retainer Shaft Assembly	2
3	32112-11	Nut – Push	1
4	71-7990	Ramp – Discharge	1
5	95-6134	Housing Assembly (Incl. Ref.# 6-8,10,21,25 & 32-34)	1
6	95-2747	Fitting – Washout	1
7	46-6290	O-Ring	1
8	32144-111	Screw – Phillips Pan Head	8
9	71-8580	Spacer – Door	2
10	71-8920	Kicker – Front Right	1
11	71-9840	Spring – Door	2
12	71-7900	Cap – Bolt LH	1
13	322-29	Screw – Hex Head	2
14	32144-97	Screw – Phillips Pan Head	2
15	71-7860	Grip – Upper	1
16	65-5210	Screw – Thread Forming	2
17	71-7910	Cap – Bolt RH	1
18	71-7930	Trigger – Height of Cut	1

Ref. No.	Part No.	Description	No. Used
19	3284-5	Pin – Groove	1
20	71-7870	Grip – Lower	1
21	71-9230	Kicker – Rear Right	1
22	32144-70	Screw – Tap	1
24	71-7920	Cover – Belt	1
25	92-7863	Decal – Deck	1
26	27-6230	Bolt – Wheel	2
27	46-1113	Wheel & Tire Assembly 7” (Incl. Ref.# 36)	2
28	40-1940	Washer	2
29	3296-5	Nut – Lock (Nylon)	2
30	71-7820	Pivot – Front	1
31	17-1569	Door – Discharge	1
32	46-6811	Screw – Hex Washer Head	2
33	71-9250	Kicker – Rear Left	1
34	71-9440	Kicker – Front Left	1
35	93-4105	Decal – Danger	1
36	27-6250	Bushing	2
37	71-9990	Plug – Recycler	1




C-2628

BLADE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	71-7940	Retainer - Blade	1
2	26-0672	Bolt - Blade	1
3	3253-22	Washer - Lock	1


Ref. No.	Part No.	Description	No. Used
4	71-9260	Blade	1
5	80-0510	Stiffener - Blade	1



ENGINE BRIGGS & STRATTON MODEL 12F802-0667-01

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	493260	Cylinder Assembly	1	383	89838	Wrench — Spark Plug	1
2	293708	Bushing — Cylinder	1	523	495264	Cap With Dipstick — Oil Filler	1
★3	299819	Seal — Oil	1	★524	280393	Seal — Filler Tube	1
5	214349	Head — Cylinder	1	525	495265	Tube — Oil Filler	1
★7	272916	Gasket — Cylinder Head	1	562	94852	Bolt — Carriage	1
8	495786	Breather — Valve Chamber	1	572	224328	Baffle — Cylinder	1
★9	272481	Gasket — Breather	1	592	231082	Nut — Hex.	1
★9A	272238	Gasket — Baffle Plate	1	615	94474	Fastener	1
10	94650	Screw — Breather Mtg.	1	616	262578	Crank — Governor	1
11	231933	Tube — Breather	1	625	497465	Tube — Fuel Intake	1
13	94547	Screw — Cylinder Head	1	635	66538	Elbow — Spark Plug	1
★52	272199	Gasket — Intake Elbow	1	★842	280966	Seal — O-Ring	1
54	94526	Screw — Intake Elbow Mtg.	1	847	495263	Oil Fill Tube Assy.	1
227	492349	Lever Assembly — Gov.	1	869	213512	Seat — Intake Valve	1
230	67072	Washer — Gov. Crank	1	870	213513	Seat — Exhaust Valve	1
284	94511	Screw — Hex. Head	1	871	262001	Guide — Exhaust Valve	1
306	224324	Shield — Cylinder	1			Note: 63709 Guide — Intake Valve	1
307	94515	Screw — Hex. Head	1	1019	494256	Label Kit	1
337	802592	Plug — Spark	1				

★ Included in Gasket Set—Part No. 496316.




Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F802-0667-01

Ref. No.	Part No.	Description	No. Used
★12	272198	Gasket — Crankcase	1
15	94720	Plug — Oil Drain	1
16	494546	Crankshaft	
		Note: Order 94388 For Timing Gear Key.	
18	493279	Sump — Engine	1
★20	399781	Seal — Oil	1
22	94220	Screw — Hex. Head	1
		Note: 94612 Screw — Hex. Head (One (1) Used in Hole Nearest Breather)	1
24	222698	Key — Flywheel	1
25	493262	Piston Assy. (Standard)	1
	493385	Piston Assy. (.010" O.S.)	1
	493386	Piston Assy. (.020" O.S.)	1
	493387	Piston Assy. (.030" O.S.)	1
26	493261	Ring Set (Standard)	1
	493388	Ring Set (.010" O.S.)	1
	493389	Ring Set (.020" O.S.)	1
	493390	Ring Set (.030" O.S.)	1

Ref. No.	Part No.	Description	No. Used
27	26026	Lock — Piston Pin	1
28	298909	Pin — Piston (Standard)	1
	298908	Pin — Piston (.005" O.S.)	1
29	490566	Rod Assembly — Connecting	1
		Note: For Connecting Rod With .020" Undersize Crankpin Bearing — Order No. 490743.	
32	94699	Screw — Connecting Rod	1
33	262651	Valve — Exhaust	1
34	262652	Valve — Intake	1
35	262224	Spring — Valve	1
40	93312	Retainer — Valve Spring	1
45	262204	Tappet — Valve	1
46	492830	Gear — Cam	1
47	493737	Slinger — Oil	1
741	262598	Gear — Timing	1

★ Included in Gasket Set—Part No. 496316.




Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F802-0667—01

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
95	94098	Screw — Throttle Valve Mtg.	1	◆◆137		Gasket — Bowl	1
◆104	231371	Pin — Float Hinge	1	◆◆617	270344	(Sold in Kit Only)	1
◆◆116		Gasket—Sealing	1	◆◆634		Seal — Fuel Intake Tube	1
		(Sold in Kit Only)				Washer—Shaft	
124	94525	Screw — Carburetor Mtg.	1			(Sold in Kit Only)	1
125	497314	Carburetor	1	955	497315	Screw — Bowl Mtg. (Std.)	
◆127		Plug — Welch	1			Note: 496495 Screw — Bowl Mtg. (High Altitude)	1
		(Sold in Kit Only)				Bowl Assy. — Carburetor	1
130	224908	Valve — Throttle	1				
131	493267	Shaft — Throttle	1				
133	398187	Float Assy. — Carburetor	1				
◆134	398188	Valve — Inlet	1				
		(Includes Seat)					

◆ Included in Carburetor Kit—Part No. 493762.

◆ Included in Carburetor Gasket Set—Part No. 490937.




Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F802-0667-01

Ref. No.	Part No.	Description	No. Used
188	94644	Screw – Hex. Head	1
188A	94602	Screw – Hex. Head	1
201	262579	Link – Governor	1
209	263046	Spring – Governor	1
258	94512	Screw–Hex. Head	1
620	497203	Bracket – Carburetor	1

Ref. No.	Part No.	Description	No. Used
620A	225152	Bracket – Control	1
621	396847	Switch – Stop	1
670A	493823	Spacer – Bracket	1
922	262640	Spring–Brake	1
923	493442	Brake Assembly	1




Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F802-0667—01

Ref. No.	Part No.	Description	No. Used
163	272653	Gasket — Air Cleaner	1
387	496115	Primer—Carburetor	1
529	281299	Grommet — Breather	1
606	224815	Strap — Bracket	1
966	496116	Base — Air Cleaner	1

Ref. No.	Part No.	Description	No. Used
967	491588	Filter — Air	1
968	281340	Cover — Air Cleaner	1
969	94120	Screw — Cover Mtg.	1
971	94121	Screw — Air Cleaner	1
971A	94749	Screw — Hex. Head	1


★ Included in Gasket Set—Part No. 496316.



Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F802-0667-01





Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
55	497440	Housing – Rewind Starter	1	459	281505	Pawl – Starter	1
56	498144	Pulley – Rewind Starter	1	461	94943	Pin – Starter	1
58	280399	Rope – Rewind Starter (Cut to Required Length)	1	515	263073	Spring – Torsion	1
59	224467	Insert – Starter Grip	1	608	497680	Starter Assy. – Rewind	1
60	493926	Handle – Rewind Starter	1			Includes:	
456	281503	Retainer – Rewind Starter	1			94128 Screw – Hex. Hd.	1
						92987 Nut – Hex.	1



Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F802-0667-01

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
23	492177	Flywheel	1	334	94731	Screw – Sem	1
37	224511	Guard – Flywheel	1	356	398808	Wire – Ground	1
304	493293	Housing – Blower	1	363	19069	Flywheel Puller	1
305	94744	Screw – Sem	1	455	225121	Cup – Starter	1
332	92284	Nut – Flywheel	1	851	493880	Terminal – Ignition Cable	1
333	802574	Armature – Magneto	1				






Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F802-0667-01

Ref. No.	Part No.	Description	No. Used
81	223664	Lock – Muffler Screw	1
187	492790	Hose – Fuel	1
188	398540	Screw – Tank Mounting	1
284	94511	Screw – Shoulder	1
300	496106	Muffler – Exhaust	1
346	93705	Screw – Hex. Head	1
601	93053	Clamp – Hose	1

Ref. No.	Part No.	Description	No. Used
613	94231	Screw – Shoulder	1
670	280512	Spacer – Fuel Tank	1
676	493871	Deflector – Muffler	1
★883	272253	Gasket – Exhaust	1
957	397974	Cap Assy. – Fuel	1
972	495224	Tank Assembly – Fuel	1



Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F802-0667—01

Ref. No.	Part No.	Description	No. Used
★3	299819	Seal — Oil	1
★7	272916	Gasket — Cylinder Hd.	1
★9	272481	Gasket — Breather	1
★9A	272238	Gasket — Baffle Plate	1
★12	272198	Gasket — Crankcase	1
★20	399781	Seal — Oil	1
★52	272199	Gasket — Intake Elbow	1
●104	231371	Pin — Float Hinge	1
◆116		Gasket — Sealing (Sold in Kit Only)	1
121	493762	Carburetor Kit	1
●127		Plug — Welch (Sold in Kit Only)	1

Ref. No.	Part No.	Description	No. Used
●134	398188	Valve — Inlet (Includes Seat)	1
◆137		Gasket — Bowl (Sold in Kit Only)	1
★163	272653	Gasket — Air Cleaner	1
358	497316	Gasket Set	1
★524	280393	Seal — Filler Tube	1
◆617	270344	Seal — Fuel Intake Tube	1
◆634		Washer — Shaft (Sold in Kit Only)	1
★842	280966	Seal — O-Ring	1
★883	272253	Gasket — Exhaust	1
977	490937	Gasket Set — Carburetor	1

● Included in Carburetor Kit—Part No. 493762.

◆ Included in Carburetor Gasket Set—Part No. 490937.

★ Included in Gasket Set—Part No. 496316.

TORO PART NUMBER INDEX

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
14-9949	Rear Wheel & Tire Assembly 8"	3 17 2	71-9900	Frame	4 4 1
17-1569	Door - Discharge	5 31 1	80-0510	Stiffener - Blade	6 5 1
19-4050	Knob	2 3 2	82-8550	Shield - Muffler	1 6 1
26-0672	Bolt - Blade	6 2 1	92-2289	Plate - Logo	1 12 1
27-6230	Bolt - Wheel	3 1 2	92-7663	Cover - Wheel	3 20 1
27-6230	Bolt - Wheel	5 26 2	92-7729	Anchor - Cable	2 7 1
27-6250	Bushing	3 19 2	92-7863	Decal - Deck	5 25 1
27-6250	Bushing	5 36 2	93-0243	Shroud	1 10 1
40-1940	Washer	3 18 2	93-1116	Cable - Brake	2 6 1
40-1940	Washer	5 28 2	93-1118	Control - Throttle	2 13 1
46-1113	Wheel & Tire Assembly 7"	5 27 2	93-4105	Decal - Danger	5 35 1
46-6290	O-Ring	5 7 1	93-4354	Decal - Engine	1 7 1
46-6811	Screw - Hex Washer Head	5 32 2	93-8470	Screw - Clamp	1 4 1
63-8590	Screw	3 3 2	94-4375	Handle	2 11 1
65-5210	Screw - Thread Forming	5 16 2	95-2747	Fitting - Washout	5 6 1
71-7740	Spring - Counterbalance	3 16 1	95-4453	Screw - Handle	2 8 1
71-7770	Plate - Securing	3 10 2	95-4457	Rope - Guide	2 10 1
71-7800	Arm - Pivot	3 8 1	95-5924	Bail - Brake	2 12 1
71-7820	Pivot - Front	5 30 1	95-6134	Housing Assembly	5 5 1
71-7840	Rod - Trigger	3 9 1	2210-249	Clamp - Casting	1 3 1
71-7860	Grip - Upper	5 15 1	2210-316	Rope - Stop	1 9 1
71-7870	Grip - Lower	5 20 1	321-48	Screw - Hex Head	2 14 1
71-7900	Cap - Bolt LH	5 12 1	322-29	Screw - Hex Head	5 13 2
71-7910	Cap - Bolt RH	5 17 1	3253-22	Washer - Lock	6 3 1
71-7920	Cover - Belt	5 24 1	3256-1	Washer - Flat	2 9 1
71-7930	Trigger - Height of Cut	5 18 1	3284-5	Pin - Groove	5 19 1
71-7940	Retainer - Blade	6 1 1	3290-378	Tie - Cable	2 1 1
71-7970	Rod - Link	3 13 1	3290-378	Tie - Cable	1 2 1
71-7980	Indicator - Height of Cut	3 12 1	3296-5	Nut - Lock (Nylon)	3 7 2
71-7990	Ramp - Discharge	5 4 1	3296-5	Nut - Lock (Nylon)	5 29 2
71-8060	Spring - Trigger	3 5 2	3296-73	Nut - Lock Insert	2 2 3
71-8080	Saddle - Height of Cut	3 4 1	32112-11	Nut - Push	5 3 1
71-8090	Mount - Handle LH	2 5 1	32112-13	Nut - Push	3 2 1
71-8100	Mount - Handle RH	2 4 1	32144-4	Screw - Hex Head Tap	5 1 8
71-8450	Cover - Spring	3 14 1	32144-4	Screw - Hex Head Tap	3 11 4
71-8580	Spacer - Door	5 9 2	32144-31	Screw	3 6 1
71-8830	Retainer Shaft Assembly	5 2 2	32144-70	Screw - Tap	5 22 1
71-8920	Kicker - Front Right	5 10 1	32144-73	Screw	1 1 3
71-9230	Kicker - Rear Right	5 21 1	32144-97	Screw - Phillips Pan Head	5 14 2
71-9250	Kicker - Rear Left	5 33 1	32144-102	Screw	1 5 3
71-9260	Blade	6 4 1	32144-111	Screw - Phillips Pan Head	4 1 5
71-9440	Kicker - Front Left	5 34 1	32144-111	Screw - Phillips Pan Head	5 8 8
71-9460	Bag - Grass	4 5 1	32144-121	Screw	1 11 2
71-9470	Door - Bag	4 3 1	32151-93	Ring - Grip	3 15 1
71-9480	Handle Door	4 2 1			
71-9840	Spring - Door	5 11 2			

*Not Illustrated