




MODEL NO. 03776-60001 & UP


**PARTS
CATALOG**
**LIGHT KIT
REELMASTER® 4500D**


T-2577

LIGHT INSTALLATION ASSEMBLY – FRONT

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	92-9234	Bracket	1	12	63-7590	Relay	1
2	60-4350	Grommet	4	13	218-589	Washer – Lock	1
3	60-2380	Grommet	1	14	218-498	Nut – Hex.	2
4	218-489	Holder – Fuse	2	15	56-6380	Screw – Taptite	1
5	218-588	Screw – Binding Head	2	16	92-9237	Decal – Lights	1
6	3253-19	Washer – Lock	2	17	92-9241	Fuse – 30 Amp	1
7	75-1010	Switch – Reels (Incl. Ref. #5, 6, 14, & 15)	1	18	218-469	Fuse – 15 Amp	1
8	3290-378	Tie – Cable	9	19	48-8000	Washer – Lock	4
9	92-9240	Switch – Turn Signal (Incl. cable & mounting hardware)	1	20	48-7880	Nut	4
10	218-456	Relay – Flasher	1	21	60-2370	Grommet	2
11	2412-104	R-Clamp	1	22	3253-7	Washer – Lock	2
				23	325-14	Screw – Cap, Hex. Head	2
				24	92-9239	Harness – Wiring, Front	1

†Not Serviceable.



T-2578

LIGHT INSTALLATION ASSEMBLY – REAR


Ref. No.	Part No.	Description	No. Used
1	60-0930	Clip – Edge	4
2	60-4680	Plate – Bumper, Rear	1
3	52-6450	Screw	2
†4		Plate – Registration (Obtain Locally)	1
5	56-6380	Screw – Taptite	4
6	3296-39	Nut – Lock	4
7	60-6910	Screw	6
8	46-0670	Screw	4
9	92-9235	Bracket – Rear, LH	1
*	92-9236	Bracket – Rear, RH	1

Ref. No.	Part No.	Description	No. Used
10	43-5920	Washer – Lock	4
11	48-7870	Nut	4
12	48-8000	Washer – Lock	4
13	48-7880	Nut	6
14	323-6	Screw – Hex. Hd.	4
15	3256-24	Washer – Flat	4
16	60-2380	Grommet	2
17	250-5	Tiestrap – Plastic	2
18	93-1436	Grommet	2
19	92-9238	Asm. – Wire Harness, Main	1

*Not Illustrated

† Not Serviceable

ELECTRICAL SCHEMATIC



MAINTENANCE RECORD

[illegible]