



**Count on it.**

# Parts Catalog

## 24in Crumber Kit

**Trencher for Pro Sneak 360 Vibratory Plow**

**Model No. 25404**

**Model No. 25404E**



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# List of Abbreviations

**AR:** as required

**ASM:** assembly

**BBC:** blade brake control

**BHTF:** button head thread forming

**CARR:** carriage

**CCW:** counter clockwise

**CW:** clockwise

**DEG:** degrees

**DPA:** Dual Point Adjustment

**ECM:** electronic control module

**EXT:** external

**FH:** flat head

**GA:** gauge

**HD:** heavy-duty

**HF:** hex flange

**HH:** hex head

**HHF:** hex head flange

**HHFTF:** hex head flange thread forming

**HJ:** hex jam

**HLH:** hex lag head

**HOC:** height-of-cut

**HSBH:** hex socket button head

**HSFH:** hex socket flat head

**HSH:** hex socket head

**HWH:** hex washer head

**HWHTF:** hex washer head thread forming

**HYD:** hydraulic

**LH:** left hand

**LP:** Liquefied Petroleum Gas

**LPG:** Liquefied Petroleum Gas

**NI:** nylon insert

**NPTF:** national pipe thread fine

**PFH:** phillips flat head

**PPH:** phillips pan head

**PPHTF:** phillips pan head thread forming

**PRH:** phillips round head

**PTH:** phillips truss head

**PTO:** power-take-off

**RH:** right hand

**ROPS:** roll-over protection system

**RRB:** rear roller brush

**SFH:** slotted fillister head

**SHH:** slotted hex head

**SHWH:** slotted hex washer head

**SPH:** slotted pan head

**SQH:** square head

**SRH:** slotted round head

**STD:** standard

**TAP:** self tapping


**TTH:** torx truss head

# Contents

24 Inch Crumber Assembly. . . . . 4

Crumber Assembly No. AU107246. . . . . 6


# 24 Inch Crumber Assembly



## 24 Inch Crumber Assembly (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>        |
|-------------|--------------------|-------------|---------------------------|
| 1           | AU107246           | 1           | Crumber ASM               |
| 2           | AU107258           | 1           | Plate-Crumbershoe, 4 Inch |
| 3           | AU107372           | 1           | Plate-Crumbershoe, 6 Inch |

# Crumber Assembly No. AU107246



## Crumber Assembly No. AU107246 (continued)

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> | <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>                |
|-------------|--------------------|-------------|--------------------|-------------|--------------------|-------------|-----------------------------------|
| 1           | AU107244           | 1           | Plate-Crumber      | 9           | AU100339           | 4           | Screw-Flange, Metric              |
| 2           | AU106945           | 1           | Linkage-Front      | 10          | AU419470A1         | 1           | Decal-Danger, Entangle<br>Hazzard |
| 3           | AU106926           | 2           | Link-Rear          | 11          | AU100570           | 2           | Bolt-Carriage, Metric             |
| 4           | AU107250           | 1           | Plate-Blade        | 12          | AU107375           | 1           | Spacer                            |
| 5           | AU107284           | 1           | Plate-Clamp        | 13          | AU100528           | 2           | Nut-Hfh                           |
| 6           | AU106947           | 4           | Pin-Linkage        | 14          | 103-9511           | 4           | Nut-Lock                          |
| 7           | AU106933           | 1           | Pin-Retaining      |             |                    |             |                                   |
| 8           | 3272-17            | 4           | Pin-Cotter         |             |                    |             |                                   |



**Count on it.**