

20in Mulching/Rear Bagging Lawn Mower

Model No. 10634—Serial No. 313000001 and Up

Parts Catalog



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwiseDEG: degrees

DPA: Dual Point Adjustment **ECM:** electronic control module

EXT: external
FH: flat head
GA: gauge
HD: heavy-duty
HF: hex flange
HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread

forming

HJ: hex jam

HLH: hex lag head **HOC:** height-of-cut

HSBH: hex socket button head HSFH: hex socket flat head HSH: hex socket head HWH: hex washer head

HWHTF: hex washer head thread

forming

HYD: hydraulic **LH:** left hand

LP: Liquefied Petroleum Gas **LPG:** Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head **PPH:** phillips pan head

PPHTF: phillips pan head thread

forming

PRH: phillips round head **PTH:** phillips truss head

PTO: power-take-off RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush
SFH: slotted fillister head
SHH: slotted hex head

SHWH: slotted hex washer head


SPH: slotted pan head **SQH:** square head

SRH: slotted round head

STD: standard
TAP: self tapping
TTH: torx truss head

Contents


Housing and Rear Height-of-Cut Assembly	4
Grass Bag and Frame Assembly	5
Engine and Blade Assembly	6
Front Wheel and Height-of-Cut Assembly	
Fransmission, Rear Wheel and Height-of-Cut Assembly	
Handle Assembly	9
Battery and Electric Start Assembly	
Attachments and Accessories	



Housing and Rear Height-of-Cut Assembly


Ref.	Part Number	Otv	Description	Ref.	Part Number	Otv	Description
Nei.		Qιy.				Qιy.	
1	117-4153	1	Housing ASM	9	125-2517	1	Shield-Trailing
1:2	94-8072	1	Decal-Danger	10	3296-16	2	Nut-Lock, NI
1:3	117-4131	1	Decal	11	117-1092	2	Screw-PTH
1:4	104-9373	1	Plug-Dome	19	322-3	4	Screw-HH
2	112-8845	1	Chute-Rear	20	3229-11	2	Screw-CARR
3	112-8821	1	Baffle-Rear	21	3296-29	4	Nut-Lock, NI
4	46-8091	5	Screw-HWH	22	112-8822-03	1	Plate-HOC, LH
5	119-7029	1	Rear Deflector ASM	23	112-8823-03	1	Plate-HOC, RH
6	119-7015	1	Spring-Torsion, LH	24	121-5684	1	Decal-Service Dealer
7	119-7016	1	Spring-Torsion, RH				Location
8	46-8093	3	Screw-Plastite				

A2



Grass Bag and Frame Assembly

Ref.	Part Number	Qty.	Description	
1	120-7031	1	Grass Bag ASM	
2	120-7029-03	1	Bag Frame ASM	




Engine and Blade Assembly

Ref.	Part Number	Qty.	Description
1	125-2466	1	Bolt-Blade, Sems
2	108-3766-03	1	Support-Blade
3	112-8841-03	1	Blade-20 Inch
4	106-3987	1	Blade Driver ASM
5	106-3999	1	Spacer-Driver
6	95-1726	3	Screw-Taptite
7	105-3030-03	1	Guide-Belt
8	112-8829	1	Cover-Belt
9	46-8091	3	Screw-HWH
22	3256-24	2	Washer-Flat
23	117-2718	1	Decal-Arrester, Spark
26		1	Engine-B & S, 122M050109F1 ● ■
27	125-2519	1	Decal-Shroud


Not serviced separately

[■] Obtain parts from www.briggsandstratton.com




Front Wheel and Height-of-Cut Assembly

Ref.	Part Number	Qty.	Description
1	614650	2	Bolt-Shoulder
2	117-5964	2	7 Inch Wheel And Tire ASM
3	117-5996	2	Bolt-Shoulder
4	40-1940	2	Washer
5	107-3877	1	Arm-Pivot, RH
6	117-5997	2	Spacer-Arm, Pivot
7	112-8828	2	Arm-Spring, Front
8	105-3042	2	Knob-Lever, HOC
9	3296-39	2	Nut-Lock, NI
10	108-1044	1	Arm-Pivot, LH
11	119-7082	1	Baffle-Throw, Front
12	117-5992	2	Spacer-Baffle, Front




Transmission, Rear Wheel and Height-of-Cut Assembly

Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	614650	2	Bolt-Shoulder	9	108-9779	2	Retainer-Bushing, HOC
2	119-0321	2	8 Inch Wheel Gear ASM	10	108-9782	2	Bushing-Sleeve
3	32151-61	2	Ring-Retaining	11	104-8699	2	Bearing-Ball
4	115-4668	2	Gear-Pinion, 12T	12	121-9181	1	Transmission ASM
5	117-4197	2	Wheel Cover ASM	13	110-9429	1	V-Belt
5:2	614426	1	Washer-Stepped	14	114-7977-03	1	Bracket-Transmission
6	108-9781	2	Arm-Pivot, Rear	15	108-7476	3	Screw-Plastite
7	108-9780	2	Arm-Spring	16	110-7191	2	Washer-Thrust
8	105-3042	2	Knob-Lever, HOC				



Handle Assembly

Ref.	Part Number	Qty.	Description
2	86-9671	1	Guide-Rope
3	3256-1	1	Washer-Flat
4	3296-73	2	Nut-Lock, NI
5	117-5940-02	1	Bail-Brake
7	114-7988	1	Guide-Cable
8	112-8818	1	Cable-Brake
9	117-5976	2	Knob-Handle, Locking
10	3230-6	2	Screw-CARR
11	112-8835-02	1	Bail-Traction, 2-Bail Flat
12	112-8817	1	Cable-Traction
14	120-9528-05	1	Handle



Battery and Electric Start Assembly

Ref.	Part Number	Qty.	Description
1	108-4844	1	Battery Box ASM
2	105-6849	2	Screw-Thread Forming
3	106-8397	1	Battery-12 Volt
4	321-57	1	Screw-HH
5	107-3774	1	Foam-Battery, Top
6	614249	3	Tie-Cable
7	106-8378	1	Harness-Wire
7:1	99-6124	1	Fuse-Blade, 40 Amp
8	46-5780	1	Starter Switch ASM
8:1	3254-5	1	Washer-Tooth, Internal
8:2	218-461	1	Nut-HH
9	114-1588	1	Charger-Battery
10	104-7953	1	Decal
11	108-9760	1	Mount-Switch
13	700918	1	Key

Attachments and Accessories

For 10634 20in Mulching/Rear Bagging Lawn Mower

Product Name	Model/Part
Replacement Bag, 2009 and After 20 inch Steel Deck Lawnmowers	89701
Replacement Bag and Frame Kit, 2009 and After 20 inch Steel Deck Lawnmowers	89702
20in Blade	89963P
Rear-Discharge Deflector, 2009 and After 20in Steel Deck Mower	89964

