



Count on it.

Parts Catalog

Commercial Walk-Behind Traction Unit

18HP Pistol-Grip Hydro Drive

Model No. 30069—Serial No. 313000001 and Up



Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquefied Petroleum Gas

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head

Contents

Engine and Muffler Assembly 4

Muffler Shield Assembly No. 120-3238 6

Fuel System Assembly 7

Rear Wheel and Hydraulic Drive Assembly 8

Hydraulic Wheel Motor Assembly No. 1-603718..... 9

LH Hydraulic Pump Assembly No. 116-0942..... 10

RH Hydraulic Pump Assembly No. 116-0943 11

Parking Brake Assembly 12

Frame and Linkage Assembly 13

Hydraulic System Assembly 14

Control Linkage Assembly 15


Control Handle Assembly 17

Handle Decal Assembly 18

Drive Control Assembly..... 19

Electrical Assembly 20

Attachments and Accessories 21




Engine and Muffler Assembly

Ref.	Part Number	Qty.	Description
1		1	Engine-Kawasaki-Fs541V ●
1:1	114-3550	4	Washer-Lock, Spring
1:2	114-3549	4	Nut
1:3	1-653313	2	Gasket-Exhaust
1:4	119-7800	1	Muffler
1:5	119-7801	1	Clamp-Muffler
1:6	119-7802	1	Manifold-Exhaust
2	117-8561-03	1	Bracket-Muffler
3	33103-012	1	Screw-HHF
4	33104-016	2	Screw-HHF
5	120-3238	1	Muffler Shield ASM
6	3290-357	11	Nut-HHF, Whiz
7	33104-025	4	Screw-HHF
8	98-5975	12	Washer-Belleville
9	32128-21	1	Nut-HF
10	1-653035	1	Pulley
11	323-14	1	Screw-HH

Ref.	Part Number	Qty.	Description
12	323-7	4	Screw-HH
13	1-523157	2	Washer-Spacer
14	110-4891	1	Pulley
15	1-807259	2	Key
16	1-373034	1	Washer
17	1-603610	2	Washer-Spring
18	116-3702	1	Screw-HH
19	323-11	1	Screw-HH
20	33114-016	1	Screw-HH
21	1-303334	4	Washer-Spring
22	117-1350	4	Nut-HF, Lock
24	81-1690	1	Clamp-Cable
25	3253-4	1	Washer-Lock
26	120-3245	1	Muffler Bracket ASM
26:2	120-3244	1	Foil-Shield, Bracket
27	120-4321	1	Valve-Drain, Oil
28	103-1966	1	Adapter
29	321-4	1	Screw-HH

● Not serviced separately

■ Obtain parts from www.kawpowerepc.com




Engine and Muffler Assembly (continued)

Ref.	Part Number	Qty.	Description
30	2412-87	1	Clamp-Cable
31	3256-22	1	Washer-Flat

Ref.	Part Number	Qty.	Description
32	3296-42	1	Nut-Lock, NI
99	103-1964	1	Hose-Drain, Oil

● Not serviced separately


■ Obtain parts from www.kawpowerepc.com



Muffler Shield Assembly No. 120-3238

Ref.	Part Number	Qty.	Description
1		1	Shield-Muffler ●
2	120-3239	1	Foil-Shield, Left
3	120-3240	1	Foil-Shield, Side
4	120-3241	1	Foil-Shield, Front
5	120-3242	1	Foil-Shield, Right
6	120-3243	1	Foil-Shield, Top


● Not serviced separately



Fuel System Assembly

Ref.	Part Number	Qty.	Description
2	119-7899	1	Fuel Tank ASM
2:2	114-0284	1	Grommet
2:3	114-0285	1	Valve-Rollover
2:4	103-2605	1	Fitting-Fuel, Bulkhead
2:5	120-5461	1	Cap-Fuel, Ratcheting
3	322-10	2	Screw-HH
4	3256-3	2	Washer-Flat
5	107-4543	2	Clamp
6	104-8300	2	Nut-Flange, NI


Ref.	Part Number	Qty.	Description
7	3290-378	4	Tie-Cable
8	115-7872	1	Hose-Fuel
9	109-0650	1	Hose-Fuel
10	1-603770	1	Valve-Fuel
11	2412-98	4	Clamp-Hose
12	99-9415	1	Hose-Fuel
13	116-5464	1	Tee And Check
14	116-4346	1	Hose-Emissions
15	120-2235	1	Filter-Fuel



Rear Wheel and Hydraulic Drive Assembly


Ref.	Part Number	Qty.	Description
1	242-50	8	Nut-Lug
2	1-413473	2	Wheel And Tire ASM
2:1	1-413474	1	Tire-Turfmaster
2:2	1-603715	1	Wheel-Rim
3	112-9049	2	Wheel Hub ASM
4	115-3805-01	2	Guard-Debris
5	323-6	12	Screw-HH
6	98-5975	16	Washer-Belleville
7	103-2289-01	2	Mount-Motor
9	116-2839	2	Nut-Lock
10	1-807019	2	Key-Woodruff
11	1-603718	2	HYD Motor ASM
13	32128-21	1	Nut-HF
14	3256-24	1	Washer-Flat
15	109-4077	1	Pulley-Idler, Flat
16	323-7	4	Screw-HH
17	32128-20	2	Nut-HF
19	1-603496	1	Bushing-Idler
20	1-602521	1	Idler Arm ASM

Ref.	Part Number	Qty.	Description
20:1	103-4681	2	Sleeve-Bearing
21	3231-29	1	Screw-CARR
24	323-12	1	Screw-HH
25	3253-21	1	Washer-Lock
26	1-373034	1	Washer
27	1-603044	1	Bushing
28	1-413010	2	Sheave ASM
29	1-807272	2	Key
30	120-6474	4	Screw-Set, SQH
31	322-5	1	Screw-HH
32	1-603801	1	Anchor-Spring
33	1-603402	1	Spring-Extension
34	116-0942	1	LH HYD Pump ASM
35	116-0943	1	RH HYD Pump ASM
36	32128-43	4	Nut-Flange
39	302-19	1	Fitting-Grease
40	106-2740	1	V-Belt
42	115-1023	4	Bar-Nut




Hydraulic Wheel Motor Assembly No. 1-603718

<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	1-000119	1	Seal Kit
2	1-000138	1	Bearing And Seal Kit



LH Hydraulic Pump Assembly No. 116-0942


<i>Ref.</i>	<i>Part Number</i>	<i>Qty.</i>	<i>Description</i>
1	103-2664	1	Input Shaft Kit
2	94-6922	1	Bearing-Thrust
3	103-2666	1	Cylinder Block Kit
4	105-6184	1	Seal Overhaul Kit



4 SEAL OVERHAUL KIT


RH Hydraulic Pump Assembly No. 116-0943

Ref.	Part Number	Qty.	Description
1	103-2664	1	Input Shaft Kit
2	94-6922	1	Bearing-Thrust
3	103-2666	1	Cylinder Block Kit
4	105-6184	1	Seal Overhaul Kit



Parking Brake Assembly


Ref.	Part Number	Qty.	Description	Ref.	Part Number	Qty.	Description
1	321-23	2	Screw-HH	17	1-633131	1	Yoke-Linkage, Brake
2	3256-22	2	Washer-Flat	18	103-2399	1	Pin-Spring, Clevis
3	323-10	1	Screw-HH	19	103-2085-03	1	Brake ASM
4	3256-24	2	Washer-Flat	20	3296-29	1	Nut-Lock, NI
5	1-413344	1	Bushing-Pivot	21	116-3515	1	Screw-HH, Special
6	1-414504	1	Bracket ASM	22	3218-3	1	Nut-Jam
6:2	1-413347	2	Sleeve-Bushing	23	1-323161	1	Spring-Idler
7	3290-500	2	Screw-PPH	24	1-633181	1	Plate-Tapped
8	119-6675-03	1	Park Brake Lever	26	1-323549	2	Spacer
9	1-303020	1	Grip-Lever	27	103-2191	2	Spacer
10	1-806003	3	Pin-Cotter, Hair	28	323-9	2	Screw-HH
11	1-413496	1	Linkage-Upper	29	1-413489	1	Linkage-Lower
12	1-414508	1	Bellcrank ASM	30	1-303548	1	Bushing-Plastic
13	32128-21	2	Nut-HF	31	32128-20	1	Nut-HF
14	323-6	5	Screw-HH	32	115-1039	1	Decal-Brake, Park
15	1-413497	1	Bellcrank	33	32128-33	2	Nut-HF
16	3296-39	7	Nut-Lock, NI				



Frame and Linkage Assembly

Ref.	Part Number	Qty.	Description
1	116-6086-01	1	Frame
6	3296-29	1	Nut-Lock, NI
8	1-633181	2	Plate-Tapped
10	1-323213	1	Bracket-Switch, Blade
11	32128-33	2	Nut-HF
12	3290-500	4	Screw-PPH
14	1-806003	3	Pin-Cotter, Hair
16	1-303105	1	Yoke-Adjustable
17	1-808280	1	Pin-Clevis
18	1-322108	1	Bellcrank ASM

Ref.	Part Number	Qty.	Description
18:3	302-40	1	Fitting-Grease
19	32128-21	1	Nut-HF
20	321-3	2	Screw-HH
21	1-809062	1	Screw
22	1-323172	1	Linkage-Engage, Blade
23	116-1737-01	1	Bellcrank
24	322-6	1	Screw-HH
25	3256-23	2	Washer-Flat
31	1-543296	1	Grommet
32	1-303287	3	Tie-Cable




Hydraulic System Assembly

Ref.	Part Number	Qty.	Description
1	107-8433	1	HYD Reservoir ASM
1:1		1	Reservoir-HYD ●
1:1:1	103-1948	1	Cap-Reservoir, HYD
1:1:2	103-1949	1	Gasket-Cap
1:2	115-4212	1	Decal-Warning
2	103-1801	1	Adapter-Straight
2:1	237-42	1	O-Ring
3	103-1807	1	Fitting-Barbed, 45 DEG
3:1	237-42	1	O-Ring
4	103-1716	3	Clamp-Hose
5	103-1988	3	Clamp-Hose
6	119-7827	2	HYD Hose ASM
7	119-7826	2	HYD Hose ASM
8	1-603991	4	Fitting-Straight
8:1	237-80	1	O-Ring
8:2	1-603992	1	O-Ring

Ref.	Part Number	Qty.	Description
9	321-3	2	Screw-HH
10	1-805004	2	Washer-Lock
11	103-2889	1	Filter Head ASM
11:2	103-1912	2	Adapter-Straight
11:2:1	237-42	1	O-Ring
12	1-633750	1	Filter-Oil, HYD
13	116-0918	1	Case Drain Hose ASM
14	103-1799	2	Elbow-90 DEG
14:1	237-42	1	O-Ring
15	103-1802	2	Fitting-HYD, 90 DEG
15:1	1-603921	1	O-Ring
16	116-2123	1	Charge Hose ASM
17	103-2959	1	Hose-Charge
18	1-603990	4	Fitting-Straight
18:1	1-603920	1	O-Ring
18:2	1-603992	1	O-Ring


● Not serviced separately



Control Linkage Assembly


Ref.	Part Number	Qty.	Description
1	110-4897-01	2	Shield-Control
4	1-323197-01	4	Spacer-Shield
5	32128-20	18	Nut-HF
6	103-4796-01	1	Shaft-Control, RH
7	3246-4	2	Screw-Set
8	1-413350	2	Link-Control, Speed
9	1-403180	2	Screw-HH
10	3219-2	7	Nut-Hex
11	3256-23	7	Washer-Flat
12	1-323245	1	Spring-Compression
13	1-603676	2	Swivel-Adjustable, Short
14	1-603903	1	Spacer
15	3272-5	2	Pin-Cotter
16	103-3060	1	Knob-Tracking
17	1-412203-01	1	Crank-Control, Speed
18	105-4109	1	Decal-Tracking
19	1-603737	2	Bolt-Return, Neutral
20	3290-357	8	Nut-HHF, Whiz
21	3256-24	2	Washer-Flat
22	1-809056	2	Screw
23	1-603807	2	Spring-Return, Neutral

Ref.	Part Number	Qty.	Description
24	1-603735	2	Bushing-Flanged
25	103-1190-01	1	Shaft-Control, LH
26	32151-47	2	Ring-Retaining
27	103-1235	2	Swivel-Lever, Drive
28	3256-2	6	Washer-Flat
29	3220-2	2	Nut-Jam
30	1-303105	2	Yoke-Adjustable
31	1-808280	2	Pin-Clevis
32	1-806003	2	Pin-Cotter, Hair
33	3218-2	2	Nut-Jam
34	116-3515	2	Screw-HH, Special
35	3296-29	2	Nut-Lock, NI
36	1-613089	2	Tab-Spring, Extension
37	1-603693	2	Spring-Extension
38	1-633102	2	Bearing-Flange, Side
39	1-800016	2	Bolt-TAP, HH
40	1-805005	4	Washer-Lock
41	323-16	8	Screw-HH
42	322-3	4	Screw-HH
43	1-323195-01	4	Spacer-Shield



Control Linkage Assembly (continued)


Ref.	Part Number	Qty.	Description
44	302-19	2	Fitting-Grease
45	1-413219	2	Rod-Lever, Drive



Control Handle Assembly


Ref.	Part Number	Qty.	Description
1	106-5486	1	RH Operator Presence Control Lever ASM
2	1-803322	2	Screw-Set
3	106-2717-03	1	Rod-Control, Operator Presence
4	1-303363	1	Spring-Extension
5	1-303365	2	Bushing-Nylon
6	119-6671	1	Handle ASM
7	119-6680	1	Cable-Control
8	1-807513	2	Bolt-CARR
9	1-603175	2	Knob-Ball
10	119-6679	1	Control, Choke
12	32128-17	2	Nut-Lock, Flange
13	1-323143	1	Bearing-Nylon
14	3218-2	1	Nut-Jam
15	1-323134	1	Knob-Push / Pull
16	106-5485	1	LH Operator Presence Control Lever ASM
17	104-9838	2	Grip-Foam
18	3234-11	4	Screw-HHF

Ref.	Part Number	Qty.	Description
19	32128-21	4	Nut-HF
20	321-3	2	Screw-HH
21	322-10	2	Screw-HH
22	1-603716	1	Washer-Friction
23	1-323244	2	Washer-Friction
24	1-603730	1	Plate-Lever, Shifter
25	1-806003	3	Pin-Cotter, Hair
26	32128-33	2	Nut-HF
28	106-2748	1	Lever-Shift
29	1-323245	2	Spring-Compression
30	3296-29	2	Nut-Lock, NI
31	1-323522	1	Rod-Control, Speed
32	3220-2	1	Nut-Jam
33	1-303105	1	Yoke-Adjustable
34	1-808280	1	Pin-Clevis
35	3256-23	1	Washer-Flat
38	1-323181	1	Linkage-Blade
39	1-323142	1	Nut-Push
40	110-5547	1	Lever-Control
41	1-303287	3	Tie-Cable



Handle Decal Assembly


Ref.	Part Number	Qty.	Description
2	105-4110	2	Decal-Lock, Neutral
3	119-6672	1	Decal-Control Panel
4	106-2733	1	Decal-Throttle
5	110-6917	1	Decal
6	95-5537	1	Decal-Engage, Deck



Drive Control Assembly

Ref.	Part Number	Qty.	Description
5	3290-500	2	Screw-PPH
6	3256-14	1	Washer-Flat
8	1-633181	1	Plate-Tapped
9	321-10	2	Screw-HH
10	1-303435	6	Washer-Spring
11	3256-2	2	Washer-Flat
12	3296-42	2	Nut-Lock, NI
13	103-0219	1	RH Drive Lever ASM
13:2	1-413152	2	Bushing-Sleeve
14	1-603749	2	Bushing-Lever, Drive

Ref.	Part Number	Qty.	Description
15	32128-33	2	Nut-HF
16	1-613055	2	Pin-Clevis
17	1-806003	2	Pin-Cotter, Hair
18	321-9	2	Screw-HH
19	103-0218	1	LH Drive Lever ASM
19:2	1-413152	2	Bushing-Sleeve
20	1-612168	1	RH Latch And Grip ASM
20:1	1-303019	1	Grip-Latch
21	1-612167	1	LH Latch Grip ASM
21:1	1-303019	1	Grip-Latch



Electrical Assembly

Ref.	Part Number	Qty.	Description
1	119-6667	1	Harness-Wire
1:1	109103	1	Fuse-Blade, 30 Amp
1:2	109102	1	Fuse-Blade, 25 Amp
2	104-8162	1	Battery
3	119-6666-03	1	Tray-Battery
4	1-513051	4	Switch-Open, Normally
5	63-8360	1	Key-Ignition (W/Shield)
6	117-2221	1	Switch-Ignition
7	1-543792	2	Wingnut
8	3256-23	2	Washer-Flat
9	109-5715	2	Nut-HHF, Smooth
10	322-3	2	Screw-HH
11	1-633651	2	Bolt-Holddown
12	117-1197	1	Solenoid
13	117-0543-01	1	Cover-Battery
15	32144-4	2	Screw-HWH
16	3220-2	2	Nut-Jam

Ref.	Part Number	Qty.	Description
17	3253-4	2	Washer-Lock
18	98-7249	1	Relay
19	3290-500	1	Screw-PPH
20	99-3058	1	Washer
21	3296-2	1	Nut-Lock, NI
24	321-4	2	Screw-HH
25	2412-87	2	Clamp-Cable
26	3256-22	2	Washer-Flat
27	104-7201	2	Nut-HF
28	1-303287	1	Tie-Cable
29	117-6422	1	Cable-Battery, Black
30	109-7653	1	Positive Battery Cable ASM
30:1	109-2407	1	Insulator-Battery
30:2	1-543393	1	Insulator-Solenoid
31	106-8268	1	Cable-Battery, Red
32	32128-33	1	Nut-HF

Attachments and Accessories

For 30069 Commercial Walk-Behind Traction Unit 18HP Pistol-Grip Hydro Drive

Product Name	Model/Part
32in (82cm) Mid-Size Rear-Discharge Deck	02710
36in (92cm) Mid-Size Rear-Discharge Deck	02711
48in (122cm) Mid-Size Rear-Discharge Deck	02712
36in (92cm) Mid-Size Flail Attachment	02720
Cleated Tire Kit	02930
Dual Wheel Kit	02931
Narrow Wheel Kit	02932
Weight Kit	110-2085
Sulky	30109

Notes:

Notes:



Count on it.