



**Count on it.**

# Parts Catalog

## **Commercial Walk-Behind Mower** **Floating Deck, T-Bar, Gear Drive with 36in** **TURBO FORCE® Cutting Unit**

**Model No. 30074—Serial No. 313000001 and Up**



# Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

## Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

## Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

## Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

# List of Abbreviations

**AR:** as required

**ASM:** assembly

**BBC:** blade brake control

**BHTF:** button head thread forming

**CARR:** carriage

**CCW:** counter clockwise

**CW:** clockwise

**DEG:** degrees

**DPA:** Dual Point Adjustment

**ECM:** electronic control module

**EXT:** external

**FH:** flat head

**GA:** gauge

**HD:** heavy-duty

**HF:** hex flange

**HH:** hex head

**HHF:** hex head flange

**HHFTF:** hex head flange thread forming

**HJ:** hex jam

**HLH:** hex lag head

**HOC:** height-of-cut

**HSBH:** hex socket button head

**HSFH:** hex socket flat head

**HSH:** hex socket head

**HWH:** hex washer head

**HWHTF:** hex washer head thread forming

**HYD:** hydraulic

**LH:** left hand

**LP:** Liquefied Petroleum Gas

**LPG:** Liquefied Petroleum Gas

**NI:** nylon insert

**NPTF:** national pipe thread fine

**PFH:** phillips flat head

**PPH:** phillips pan head

**PPHTF:** phillips pan head thread forming

**PRH:** phillips round head

**PTH:** phillips truss head

**PTO:** power-take-off

**RH:** right hand

**ROPS:** roll-over protection system

**RRB:** rear roller brush

**SFH:** slotted fillister head

**SHH:** slotted hex head

**SHWH:** slotted hex washer head

**SPH:** slotted pan head

**SQH:** square head

**SRH:** slotted round head

**STD:** standard

**TAP:** self tapping

**TTH:** torx truss head

# Contents

Engine and Clutch Assembly ..... 4

Power-Take-Off Idler and Weight Assembly..... 5

Fuel System Assembly ..... 6

Lower Control Assembly..... 7

Transmission Drive Assembly ..... 8

Wheel Drive and Brake Assembly ..... 9

Handle Assembly ..... 10

Control Panel Assembly ..... 11

Carrier Frame Assembly ..... 12

Deck Drive and Baffle Assembly ..... 13

Deck Decal Assembly No. 112-7080..... 14


Spindle Assembly No. 110-0730 ..... 15

Spindle Assembly No. 110-0728 ..... 16

Outer Deck Assembly ..... 17

Deflector Assembly No. 110-0790..... 18

Attachments and Accessories ..... 19




## Engine and Clutch Assembly

| Ref. | Part Number | Qty. | Description                   |
|------|-------------|------|-------------------------------|
| 1    |             | 1    | Engine-Kawasaki, Fs481V<br>●■ |
| 1:1  | 114-3550    | 4    | Washer-Lock, Spring           |
| 1:2  | 114-3549    | 4    | Nut                           |
| 1:3  | 1-653313    | 2    | Gasket-Exhaust                |
| 4    | 106-0699    | 1    | Decal-Warning                 |
| 5    | 33104-025   | 4    | Screw-HHF                     |
| 6    | 103-1966    | 1    | Adapter                       |
| 7    | 120-4321    | 1    | Valve-Drain, Oil              |
| 8    | 119-3629-03 | 1    | Shield-Muffler                |
| 9    | 119-3635-03 | 1    | Bracket-Shield, Muffler       |
| 10   | 32128-20    | 2    | Nut-HF                        |
| 11   | 117-1350    | 4    | Nut-HF, Lock                  |
| 12   | 1-303334    | 4    | Washer-Spring                 |
| 13   | 104-6373    | 1    | Tube-Retainer                 |
| 14   | 1-613235    | 4    | Washer                        |
| 15   | 1-633630    | 2    | Grommet                       |
| 16   | 1-633545    | 2    | Spacer                        |

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 17   | 1-633543-03 | 1    | Strap-Clutch, Brake |
| 18   | 322-11      | 1    | Screw-HH            |
| 19   | 3256-23     | 3    | Washer-Flat         |
| 20   | 322-7       | 1    | Screw-HH            |
| 21   | 33104-016   | 2    | Screw-HHF           |
| 22   | 3212-9      | 1    | Screw-HH            |
| 23   | 107-4136    | 1    | Washer              |
| 24   | 105-2635    | 1    | Clutch / Brake ASM  |
| 25   | 107-4112    | 1    | Pulley-Drive        |
| 26   | 608006      | 1    | Key-Square          |
| 27   | 98-5975     | 4    | Washer-Belleville   |
| 28   | 323-7       | 4    | Screw-HH            |
| 30   | 1-603610    | 2    | Washer-Spring       |
| 31   | 81-1690     | 1    | Clamp-Cable         |
| 32   | 98-0776     | 1    | Decal-Caution       |
| 34   | 117-8561-03 | 1    | Bracket-Muffler     |
| 36   | 33103-012   | 1    | Screw-HHF           |
| 99   | 103-1964    | 1    | Hose-Drain, Oil     |

● Not serviced separately


■ Obtain parts from [www.kawpowerepc.com](http://www.kawpowerepc.com)



## Power-Take-Off Idler and Weight Assembly

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 2    | 3296-39     | 1    | Nut-Lock, NI      |
| 4    | 52-2860     | 3    | Washer            |
| 5    | 104-6377    | 1    | Tube-Idler        |
| 6    | 112-7055    | 1    | Idler Arm ASM     |
| 6:1  | 1-513034    | 2    | Sleeve-Bearing    |
| 6:2  | 302-5       | 1    | Fitting-Grease    |
| 7    | 323-42      | 1    | Screw-HH          |
| 8    | 323-6       | 1    | Screw-HH          |
| 9    | 98-5975     | 1    | Washer-Belleville |
| 10   | 3256-24     | 1    | Washer-Flat       |


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 11   | 116-4666    | 1    | Idler-Pulley, Flat |
| 12   | 105-8443    | 1    | Spring-Extension   |
| 13   | 323-10      | 1    | Screw-HH           |
| 14   | 3290-357    | 1    | Nut-HHF, Whiz      |
| 15   | 32128-21    | 1    | Nut-HF             |
| 16   | 112-7059-01 | 1    | Weight-Cast        |
| 17   | 322-9       | 2    | Screw-HH           |
| 18   | 3256-23     | 2    | Washer-Flat        |
| 19   | 3296-29     | 2    | Nut-Lock, NI       |



## Fuel System Assembly

| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 2    | 119-7899    | 1    | Fuel Tank ASM          |
| 2:2  | 114-0284    | 1    | Grommet                |
| 2:3  | 114-0285    | 1    | Valve-Rollover         |
| 2:4  | 103-2605    | 1    | Fitting-Fuel, Bulkhead |
| 2:5  | 120-5461    | 1    | Cap-Fuel, Ratcheting   |
| 9    | 109-0650    | 1    | Hose-Fuel              |
| 10   | 1-603770    | 1    | Valve-Fuel             |
| 11   | 2412-98     | 4    | Clamp-Hose             |
| 12   | 322-10      | 2    | Screw-HH               |


| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 13   | 3256-3      | 2    | Washer-Flat       |
| 14   | 107-4543    | 2    | Clamp             |
| 15   | 104-8300    | 2    | Nut-Flange, NI    |
| 23   | 99-9415     | 1    | Hose-Fuel         |
| 25   | 3290-378    | 4    | Tie-Cable         |
| 31   | 115-7872    | 1    | Hose-Fuel         |
| 32   | 116-5464    | 1    | Tee And Check ASM |
| 33   | 116-4346    | 1    | Hose-Emissions    |
| 36   | 120-2235    | 1    | Filter-Fuel       |



## Lower Control Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 32103-25    | 2    | Nut-Wing            |
| 2    | 3256-23     | 6    | Washer-Flat         |
| 3    | 3290-307    | 4    | Pin-Hair            |
| 4    | 52-2890     | 2    | Bushing-Nylon       |
| 5    | 74-0521     | 2    | Fitting-Rod         |
| 6    | 283-6       | 2    | Pin-Clevis          |
| 7    | 74-0040     | 4    | Spacer-Pivot, Idler |
| 8    | 108-2725-01 | 1    | Support-Idler, LH   |
| 9    | 108-2724-01 | 1    | Support-Idler, RH   |
| 10   | 323-16      | 2    | Screw-HH            |
| 11   | 323-7       | 4    | Screw-HH            |
| 12   | 3296-23     | 2    | Nut-Lock, NI        |


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 13   | 95-2800     | 2    | Pulley-Idler       |
| 14   | 95-2801     | 2    | Spacer-Pulley      |
| 15   | 108-2740-01 | 1    | LH Idler Arm ASM   |
| 16   | 108-2741-01 | 1    | RH Idler Arm ASM   |
| 17   | 51-4450     | 2    | Screw-Leveler      |
| 18   | 68-9690     | 2    | Fitting-Rod        |
| 19   | 51-4380     | 1    | Spring-Torsion, LH |
| 20   | 51-4370     | 1    | Spring-Torsion, RH |
| 21   | 3296-39     | 6    | Nut-Lock, NI       |
| 22   | 117-3525-01 | 1    | Gear Frame ASM     |
| 23   | 3234-32     | 6    | Screw-HHF          |
| 24   | 32128-23    | 6    | Nut-HF             |



## Transmission Drive Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 47-1970     | 1    | Grip                |
| 2    | 98-3274-03  | 1    | Lever-Shift         |
| 3    | 3296-6      | 2    | Nut-Lock            |
| 4    | 98-5975     | 1    | Washer-Belleville   |
| 5    | 1-323379    | 1    | Washer              |
| 6    | 1-323500    | 1    | Transmission        |
| 7    | 302-5       | 2    | Fitting-Grease      |
| 8    | 1-323680    | 2    | Coupler             |
| 9    | 51-4220     | 2    | Guard-Coupler       |
| 10   | 1-323254    | 2    | Flange-Output       |
| 11   | 321-4       | 4    | Screw-HH            |
| 12   | 3257-5      | 3    | Key-Woodruff        |
| 13   | 121-5989    | 2    | Screw-Set, HSH      |
| 14   | 32151-62    | 2    | Ring-Retaining      |
| 15   | 105-2698    | 2    | Pulley-Transmission |
| 16   | 104-1102    | 2    | Shaft-Output        |
| 17   | 1-323252    | 2    | Bearing-Shaft       |
| 18   | 95-1529     | 1    | Rod-Shield          |
| 19   | 95-1526     | 1    | Shield-Trailing     |
| 20   | 105-5646    | 1    | Pulley-Driven       |


| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 21   | 3245-41     | 1    | Screw-HSH            |
| 22   | 32120-64    | 1    | Ring-Snap, External  |
| 23   | 105-5668    | 1    | V-Belt               |
| 24   | 80-6610     | 1    | Spring-Extension     |
| 25   | 27-6230     | 1    | Bolt-Wheel           |
| 26   | 323-9       | 1    | Screw-HH             |
| 27   | 16-7509     | 1    | Lever-Idler          |
| 27:1 | 256-155     | 2    | Bushing-Flange       |
| 28   | 62-4540     | 1    | Pulley               |
| 29   | 3296-39     | 1    | Nut-Lock, NI         |
| 30   | 322-2       | 4    | Screw-HH             |
| 31   | 3253-4      | 4    | Washer-Lock          |
| 32   | 3296-42     | 4    | Nut-Lock, NI         |
| 33   | 1-323389-03 | 2    | Bracket-Plate, Shift |
| 34   | 32144-11    | 4    | Screw-HWHTF          |
| 35   | 104-8300    | 2    | Nut-Flange, NI       |
| 36   | 1-323387-03 | 1    | Plate-Shift          |
| 37   | 3230-1      | 2    | Bolt-CARR            |
| 38   | 98-3256     | 1    | Decal-Speed, Ground  |



## Wheel Drive and Brake Assembly

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 1    | 32151-72    | 4    | Ring-Retaining           |
| 2    | 32151-56    | 2    | Ring-Retaining, External |
| 3    | 106-8792    | 2    | Plate-Link, Brake        |
| 4    | 110-5010-01 | 2    | Brake Arm ASM            |
| 6    | 3290-307    | 2    | Pin-Hair                 |
| 7    | 108-2730    | 2    | Rod-Brake                |
| 8    | 32151-40    | 2    | Ring-Retaining           |
| 9    | 106-8773    | 2    | Brake Link ASM           |
| 10   | 110-5004    | 2    | Belt-V, Banded           |
| 13   | 1-543509    | 4    | Bearing-Roller, Tapered  |
| 14   | 1-523157    | 2    | Washer-Spacer            |
| 15   | 1-809082    | 2    | Nut-SHH                  |
| 16   | 106-0892    | 2    | Wheel And Tire ASM       |
| 16:1 | 104-6322    | 1    | Tire                     |
| 16:2 | 106-0893    | 1    | Wheel                    |


| Ref. | Part Number | Qty. | Description      |
|------|-------------|------|------------------|
| 16:3 | 232-27      | 1    | Stem-Valve       |
| 17   | 242-50      | 8    | Nut-Lug          |
| 18   | 241-119     | 2    | Cap-Dust         |
| 19   | 107-4090    | 2    | Wheel Hub ASM    |
| 19:2 | 1-543508    | 2    | Cup-Bearing      |
| 19:3 | 302-5       | 1    | Fitting-Grease   |
| 19:4 | 10-6830     | 4    | Stud-Type, Drive |
| 22   | 1-323262    | 2    | Band-Brake       |
| 24   | 1-543511    | 2    | Seal-Grease      |
| 25   | 110-5006    | 2    | Spacer-Wheel     |
| 26   | 110-4983-01 | 1    | Axle ASM         |
| 27   | 1-806800    | 2    | Pin-Cotter       |
| 28   | 32128-21    | 6    | Nut-HF           |
| 29   | 3234-11     | 6    | Screw-HHF        |



## Handle Assembly

| Ref. | Part Number | Qty. | Description       |
|------|-------------|------|-------------------|
| 1    | 105-4677    | 2    | Rod-Control       |
| 2    | 3272-4      | 2    | Pin-Cotter        |
| 3    | 237-141     | 2    | Grommet-Rubber    |
| 4    | 82-2290     | 1    | Decal             |
| 5    | 82-7680-03  | 1    | Bail ASM          |
| 6    | 82-7690-03  | 1    | Bar-Control       |
| 7    | 82-2280     | 1    | Decal             |
| 8    | 106-5477-03 | 1    | Control Pivot ASM |
| 9    | 3272-11     | 2    | Pin-Cotter        |
| 10   | 105-3158-03 | 1    | Upper Handle ASM  |


| Ref. | Part Number | Qty. | Description           |
|------|-------------|------|-----------------------|
| 11   | 283-55      | 2    | Pin-Clevis            |
| 12   | 3290-378    | 3    | Tie-Cable             |
| 13   | 32128-21    | 4    | Nut-HF                |
| 14   | 3234-11     | 4    | Screw-HHF             |
| 15   | 98-4387     | 1    | Decal-Protection, Ear |
| 16   | 32105-1     | 1    | Screw-SHH             |
| 17   | 51-4850-03  | 1    | Lever-Brake, Parking  |
| 18   | 52-2010     | 1    | Decal-Lever, Parking  |
| 19   | 3296-2      | 1    | Nut-Lock, NI          |



## Control Panel Assembly

| Ref. | Part Number | Qty. | Description             |
|------|-------------|------|-------------------------|
| 1    | 105-0884    | 1    | Decal-Danger            |
| 2    | 63-8360     | 1    | Key-Ignition (W/Shield) |
| 3    | 119-6539    | 1    | Cable-Throttle          |
| 4    | 32104-76    | 4    | Screw-Thd Cutting, HWH  |
| 5    | 32105-14    | 4    | Screw-SHH               |
| 6    | 3296-42     | 1    | Nut-Lock, NI            |
| 7    | 104-8141    | 1    | Module-Delay            |
| 8    | 93-1187-03  | 1    | Panel-Bottom            |
| 9    | 321-2       | 1    | Screw-HH                |
| 12   | 3296-2      | 4    | Nut-Lock, NI            |
| 13   | 29-5560     | 1    | Switch-On / Off         |
| 13:1 | 218-461     | 1    | Nut-HH                  |
| 13:2 | 3254-5      | 1    | Washer-Tooth, Internal  |
| 16   | 104-8140    | 1    | Switch-PTO              |


| Ref. | Part Number | Qty. | Description            |
|------|-------------|------|------------------------|
| 17   | 110-4982-03 | 1    | Panel-Control          |
| 18   | 110-4971    | 1    | Decal-Panel, Control   |
| 20   | 110-4995    | 1    | Cable-Choke            |
| 21   | 2412-72     | 1    | Clip-Closed, Insulated |
| 22   | 112-7069    | 1    | Grommet                |
| 23   | 2412-134    | 1    | Clamp-R                |
| 24   | 32144-4     | 2    | Screw-HWH              |
| 27   | 119-6508    | 1    | Harness-Wire           |
| 27:1 | 114241      | 1    | Fuse-Blade, 7.5 Amp    |
| 28   | 82-2190     | 1    | Switch-Bail            |
| 29   | 218-595     | 1    | Connector-Body         |
| 30   | 33114-016   | 1    | Screw-HH               |
| 31   | 3253-4      | 1    | Washer-Lock            |
| 32   | 1-303287    | 1    | Tie-Cable              |



## Carrier Frame Assembly

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 1    | 110-6960    | 1    | Carrier Frame ASM    |
| 1:2  | 32148-9     | 2    | Insert-Nut           |
| 1:3  | 94-1291     | 4    | Bushing              |
| 1:4  | 302-5       | 2    | Fitting-Grease       |
| 2    | 110-6970    | 1    | Cover-Frame, Carrier |
| 3    | 112-9710    | 1    | Decal                |
| 4    | 1-804254    | 3    | Nut-Lock, HH         |
| 5    | 106-6778    | 3    | Bushing-Latch, Swell |
| 6    | 99-3058     | 3    | Washer               |
| 7    | 106-6777    | 3    | Handle-Latch, Swell  |
| 8    | 119-7858-01 | 1    | Shield-Belt          |
| 10   | 104-1105    | 4    | Spacer-Support, Deck |
| 11   | 1-513336    | 2    | Bushing-Deck         |
| 12   | 323-6       | 2    | Screw-HH             |


| Ref. | Part Number | Qty. | Description        |
|------|-------------|------|--------------------|
| 13   | 3256-24     | 2    | Washer-Flat        |
| 14   | 32120-33    | 2    | Ring-Retaining     |
| 15   | 1-323539    | 4    | Spacer             |
| 16   | 106-0635    | 2    | Decal-HOC          |
| 17   | 105-3159-01 | 2    | Fork-Castor        |
| 18   | 32153-5     | 2    | Nut-Hex            |
| 19   | 110-5024    | 2    | Wheel And Tire ASM |
| 19:2 | 112-7066    | 1    | Bearing-Roller     |
| 19:3 | 1-513810    | 2    | Bushing            |
| 19:4 | 302-61      | 1    | Fitting-Grease     |
| 20   | 100-6453    | 2    | Bushing-Spanner    |
| 21   | 325-19      | 2    | Screw-HH           |
| 22   | 283-71      | 2    | Pin-Lynch          |
| 23   | 3-6781      | 8    | Washer-Thrust      |



## Deck Drive and Baffle Assembly


| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 112-7080    | 1    | Deck ASM            |
| 2    | 104-8301    | 22   | Nut-Flange, NI      |
| 3    | 109-6658    | 1    | Nut-Flange, NI      |
| 4    | 323-8       | 1    | Screw-HH            |
| 5    | 1-633166    | 1    | Pulley-Idler        |
| 6    | 3256-24     | 2    | Washer-Flat         |
| 7    | 98-5975     | 1    | Washer-Belleville   |
| 8    | 323-6       | 1    | Screw-HH            |
| 9    | 3296-39     | 1    | Nut-Lock, NI        |
| 10   | 51-3660     | 1    | Pulley-Idler        |
| 11   | 105-2673    | 1    | Spring-Extension    |
| 12   | 32128-21    | 1    | Nut-HF              |
| 13   | 105-0889    | 1    | Idler Arm ASM       |
| 14   | 51-3641     | 1    | Sleeve-Pivot, Idler |
| 15   | 110-6953    | 1    | Belt-V              |

| Ref. | Part Number | Qty. | Description              |
|------|-------------|------|--------------------------|
| 16   | 110-6954    | 1    | Belt-V                   |
| 17   | 110-2037-01 | 1    | Plate-Skid               |
| 18   | 3231-2      | 7    | Bolt-CARR                |
| 20   | 110-6903-03 | 1    | Baffle-Front, LH         |
| 21   | 110-0730    | 1    | Spindle ASM              |
| 22   | 323-12      | 1    | Screw-HH                 |
| 23   | 92-1624     | 14   | Screw-HWH                |
| 24   | 51-4060     | 2    | Screw-Blade              |
| 25   | 103-0865    | 2    | Washer-Blade Bolt, Heavy |
| 26   | 108-2727    | 2    | Stiffener-Blade          |
| 27   | 105-7781-03 | 2    | Blade-18 Inch, Hi Flow   |
| 28   | 110-0728    | 1    | Spindle ASM              |
| 29   | 121-1779-03 | 1    | Baffle ASM               |
| 30   | 110-0754-01 | 1    | Baffle-Discharge         |
| 31   | 323-4       | 2    | Screw-HH                 |




## Deck Decal Assembly No. 112-7080

| Ref. | Part Number | Qty. | Description                 |
|------|-------------|------|-----------------------------|
| 2    | 104-8569    | 1    | Decal-Warning               |
| 3    | 1-403005    | 1    | Decal-Danger                |
| 4    | 104-8185    | 1    | Decal                       |
| 5    | 98-5954     | 2    | Decal-Cover, Missing        |
| 6    | 68-8340     | 1    | Decal-Torque                |
| 7    | 66-1340     | 1    | Decal-Danger, Thrown Object |
| 8    | 105-7798    | 1    | Decal-Scalp, Anti           |
| 9    | 110-2068    | 1    | Decal-Adjustment, Baffle    |
| 10   | 110-2067    | 1    | Decal-Setting, Baffle       |




## Spindle Assembly No. 110-0730

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 3219-7             | 1           | Nut-Hex            |
| 2           | 7-4150             | 1           | Washer             |
| 3           | 108-6627           | 1           | Pulley And Hub ASM |
| 4           | 106-0873           | 1           | Shield-Bearing     |
| 5           | 116-0720           | 2           | Bearing-Ball       |
| 6           | 108-6696           | 1           | Housing-Spindle    |
| 7           | 110-0727           | 1           | Spacer-Bearing     |
| 8           | 110-0725           | 1           | Shaft-Spindle      |



## Spindle Assembly No. 110-0728


| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i> |
|-------------|--------------------|-------------|--------------------|
| 1           | 3219-7             | 1           | Nut-Hex            |
| 2           | 7-4150             | 1           | Washer             |
| 3           | 104-1181           | 1           | Pulley ASM         |
| 4           | 106-0873           | 1           | Shield-Bearing     |
| 5           | 116-0720           | 2           | Bearing-Ball       |
| 6           | 108-6696           | 1           | Housing-Spindle    |
| 7           | 110-0727           | 1           | Spacer-Bearing     |
| 8           | 110-0726           | 1           | Shaft-Spindle      |



## Outer Deck Assembly

| Ref. | Part Number | Qty. | Description         |
|------|-------------|------|---------------------|
| 1    | 110-0790    | 1    | Deflector ASM       |
| 2    | 105-4622    | 1    | Spacer              |
| 3    | 108-4052    | 1    | Spring-Torsion      |
| 4    | 3296-29     | 1    | Nut-Lock, NI        |
| 5    | 119-6512-01 | 1    | Deck Belt Cover ASM |
| 6    | 3296-47     | 1    | Nut-Lock, NI        |
| 7    | 106-6777    | 2    | Handle-Latch, Swell |
| 8    | 99-3058     | 2    | Washer              |
| 9    | 108-2674    | 2    | Front Pin ASM       |
| 10   | 3220-3      | 2    | Nut-HJ              |
| 11   | 3296-39     | 4    | Nut-Lock, NI        |

| Ref. | Part Number | Qty. | Description          |
|------|-------------|------|----------------------|
| 12   | 1-613204    | 2    | Balljoint            |
| 13   | 104-1156    | 2    | Spacer               |
| 14   | 323-8       | 2    | Screw-HH             |
| 15   | 110-2086    | 2    | Rear Pin ASM         |
| 16   | 3290-256    | 6    | Pin-Hair             |
| 17   | 323-10      | 2    | Screw-HH             |
| 18   | 1-603299    | 2    | Roller-Scalp, Anti   |
| 19   | 98-5967     | 1    | Spacer-Wheel         |
| 20   | 322-50      | 2    | Screw-HH             |
| 21   | 1-804254    | 2    | Nut-Lock, HH         |
| 22   | 106-6778    | 2    | Bushing-Latch, Swell |



## Deflector Assembly No. 110-0790

| <i>Ref.</i> | <i>Part Number</i> | <i>Qty.</i> | <i>Description</i>          |
|-------------|--------------------|-------------|-----------------------------|
| 1           | 3231-4             | 4           | Screw-CARR                  |
| 2           | 110-0792-01        | 1           | Deflector                   |
| 3           | 110-0793-03        | 1           | Strap-Discharge             |
| 4           | 110-0791           | 1           | Deflector-Rubber            |
| 5           | 107-4164-01        | 1           | Bracket-Mounting, Deflector |
| 6           | 104-8301           | 4           | Nut-Flange, NI              |

## Attachments and Accessories

### For 30074 Commercial Walk-Behind Mower Floating Deck, T-Bar, Gear Drive with 36in TURBO FORCE Cutting Unit

| Product Name                                  | Model/Part  |
|-----------------------------------------------|-------------|
| Blade-Recycler, 18in.....                     | 105-7779-03 |
| Blade-Med Flow, 18in .....                    | 105-7794-03 |
| Blade-Low Flow, 18in.....                     | 105-7795-03 |
| Blade-Atomic, 18in .....                      | 105-7796-03 |
| Blade-Hi Flow, 18in (6 Pack).....             | 108-1117    |
| Blade-Atomic, 18in (6 Pack) .....             | 108-1118    |
| Blade-Lo Flow, 18in (6 Pack) .....            | 110-0406    |
| Blade-Recycler, 18in (6 Pack).....            | 110-0408    |
| Blade-Med Flow, 18in (6 Pack) .....           | 110-0409    |
| 36in Bagger Enhancement Kit .....             | 110-2026    |
| 36in Recycler Kit.....                        | 110-2080    |
| Weight-Cast.....                              | 112-7059-01 |
| Weight Kit .....                              | 112-9971    |
| Operator-Controlled Discharge Chute Kit ..... | 115-4190    |
| Soft Bag (3 Bushel).....                      | 30104       |
| Tru Trak Sulky.....                           | 30110       |



**Count on it.**