




MODEL NO. 30504-70121 & UP


**PARTS
CATALOG**
KIT – 9 CU. FT. HOPPER


T-0603-2

9 CU. FT. HOPPER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	43-1000	Pin – Hinge, Hood	1
2	43-0610	Hinge – Half	1
3	3256-14	Washer – Flat	5
4	3296-2	Nut – Lock	5
5	3290-134	Screw – Mach. Hex. Hd.	5
6	3290-412	Rivet – Pop	14
7	43-1100	Decal – Caution	2
8	13-1649	Asm-Hood (Incl. Ref. #7)	1
9	67-1730	Plate – Nut	2
10	3274-31	Screw – Button Head	4
11	77-0680	Extension – Snout	1
12	43-0600	Screen – Left Hand	1
13	43-0570	Screen – Right Hand	1
14	43-0990	Bag – Cloth 32” (7 bushel capacity)	1

Ref. No.	Part No.	Description	No. Used
*14	43-0980	Bag – Cloth 38” (10 bushel capacity) (Optional)	1
15	67-7500	Asm-Upper Support Tube (Incl. Ref. #25 & 28)	1
16	32152-2	Nut – Lock	12
17	3256-3	Washer – Flat	8
18	323-11	Screw – HH	4
19	322-11	Screw – HH	2
20	95-6293	Bracket – Frame (For use with 52” Blower)	4
21	323-7	Screw – HH	7
22	32152-1	Nut – Lock	6
23	43-0720	Asm-Lower Support Tube (Incl. Ref. #25 & 27)	1
24	323-10	Screw – HH	1



T-0603-2

9 CU. FT. HOPPER ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
25	3290-409	Rivet - Pop	21
26	3-2781	Retainer - Cord	1
*†	36-7770	Retainer - Cord (Optional)	1
27		Tray - Lower	1
28		Skirt - Bagging Frame	1
29	43-1020	Spacer - Pivot Arm	2
30	322-3	Screw - HH	2
31	322-4	Screw - HH	2

Ref. No.	Part No.	Description	No. Used
32	3256-23	Washer - Flat	2
33	3256-57	Washer - Fender	4
34	43-1051	Stop - Hood	2
35	76-1990	Bracket - Frame (For use with 62" Blower)	4
36	3253-21	Washer - Lock	2
*	44-9720	Template - Bracket	1

*Not Illustrated

† For use with 30 gallon plastic bag & 38" cloth bag.