




MODEL NO. 62060-790001 & UP


**PARTS
CATALOG**
TURF SEEDER


C-2697

SEEDER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	T9117	Cover Asm. w/Decals	1
2	T9118	Decal – Seed Application	1
3	T9213	Control Rod Asm.	1
4	T9232	Bracket Asm.	1
5	T9214	Slide Activator Rod Asm.	1
6	T9216	Bolt Asm. – Seeder to Unit	1
7	T9137	Wheel Asm.	2
8	T9126	Stamping Asm.	2

Ref. No.	Part No.	Description	No. Used
9	T9127	Bearing w/Locking Collar	2
10	T9125	Axle – Agitator	1
11	T9121	Dial – Cam Control	1
12	T9234	Hopper w/Decals	1
13	T9229	Gate – Slide	1
14	T9120	Bracket – Stop	1
15	T9130	Agitator	1




C-2698

COVER, HOPPER AND WHEEL ASSEMBLY

Ref. No.	Part No.	Description	No. Used
16	T0026	Knob	1
17	T5145	Lever – Height Adjustment	1
18	T5151	Knob w/Screw	1
19	T5150	Height Adjustment Asm.	1
20	T5155	Push Rod Asm.	1
21	T5190	Torque Arm – Height Adj.	1
22	T5193	Plate – Engine Bolt, Top	2
*	T5198	Bolt Kit – Engine	1
23	T5154	Spring – Torsion	1
24	T5053	Wheel Asm.	2
	T5054	Bolt Kit – Wheel, Rear	2
25	T5163	Handle Asm. (Incl. Ref. #25.1, 25.2, 25.3)	1
25.1	T5165	Handle	1
25.2	T5171	Clutch – Handle	1
25.3	T5089	Cable – Clutch w/Hardware	1

Ref. No.	Part No.	Description	No. Used
26	T0330	V–Pulley 3/4" Bore	1
*	T0331	V–Pulley 1" Bore	1
27	T0339	V–Belt B–36"	1
*	T0340	V–Belt B–38"	1
*	T5140	Belt Keeper Asm.	1
28	T5168	Trunnion Rod Asm.	1
29	T5121	Mounting Arm – Idler Pulley	1
30	T0343	Pulley – Idler	1
31	T5027	Pulley Asm. w/Hardware (Incl. Ref. #29, 32, 30)	1
32	T5129	Spring – Clutch Rod	1
33	T5025	Shield Asm. w/Hardware	1
34	T5110	Housing	1
35	T5161	Deflector	1
36	T5167	Bolt Kit – Handle	1
37	T5162	Strap–Deflector w/Hardware	1

* Not Illustrated




C-2699

REEL ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
38	T5049	Delta Reel Asm. without Blades	1	44	T0347	Bushing 3/4" w/Screws	1
*	T5940	Delta Reel Asm. Complete without Bearings	1	45	T0349	V-Pulley without Bushing	1
*	T5942	Delta Reel Asm. Complete w/Bearings	1	46	T5169	V-Pulley w/Bushing	1
39	T5005	Cap	1	47	T5061	Shaft - Delta w/Hardware	1
40	T5970	Blade Set - Delta	1	48	T5064	Spacer - Carrier	9
41	T5075	Bolt Kit - Blade	1	49	T5065	End Ring	2
42	T0315	Bearing 3/4" w/Locking Collar	2	50	T5062	Plate - Blade Carrier	20
43	T5185	Stamping Kit w/Hardware	2	51	T5063	Plate - Blade Spacer	10
				*	T8523	Decal Kit - Seeder Attach.	1
				*	T8528	Decal Kit - Seeder	1
				*†	62069	Flail Reel Kit (Optional)	1

* Not Illustrated

† Option To Convert Seeder With Hopper To Power Rake



★ REQUIRES SPECIAL TOOLS
TO INSTALL. SEE REPAIR
INSTRUCTION MANUAL.

Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 135202-0142-03


Ref. No.	Part No.	Description	No. Used
1	497144	Cylinder Assembly	1
2	399268	Bushing – Cylinder	1
★3	299819	Seal – Oil	1
5	214040	Head – Cylinder	1
■★7	272157	Gasket – Cylinder Head	1
8	495774	Breather – Valve Chamber	1
■★9	27549	Gasket – Breather	1
10	94621	Screw – Breather Mtg.	1
11	231550	Tube – Breather	1
13	94221	Screw – Cylinder Head (2-3/32" Long)	1
14	94679	Screw – Cylinder Head (2-15/32" Long)	1
15	94916	Plug – Oil Drain	1
306	224820	Shield – Cylinder	1
307	94680	Screw – Hex.	1

Ref. No.	Part No.	Description	No. Used
308	224738	Cover – Cylinder	1
337	802592	Plug – Spark	1
383	89838	Wrench – Spark Plug	1
527	223786	Clamp – Tube	1
529	67838	Grommet	1
529A	66578	Grommet	1
552	231079	Bushing – Gov. Crank	1
635	66538	Elbow – Spark Plug	1
869	211787	Seat – Intake Valve	1
870	211172	Seat – Exhaust Valve	1
871	262001	Guide – Exhaust Valve	1
		Note: 63709 Guide – Intake Valve	1
1019	491100	Label Kit	1
1058	272646	Owner's Manual	1

Obtain Parts From Briggs & Stratton Dealer

★ Included in Gasket Set—Part No. 495605.

■ Included in Valve Overhaul Gasket Set—Part No. 498694.






Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 135202-0142-03

Ref. No.	Part No.	Description	No. Used
25	298904	Piston Assy. (Standard)	1
	298905	Piston Assy. (.010" O.S.)	1
	298906	Piston Assy. (.020" O.S.)	1
	298907	Piston Assy. (.030" O.S.)	1
26	298982	Ring Set (Standard)	1
	299742	Ring Set (Std. Chrome)	1
	298983	Ring Set (.010" O.S.)	1
	298984	Ring Set (.020" O.S.)	1
	298985	Ring Set (.030" O.S.)	1
27	26026	Lock - Piston Pin	1
28	298909	Pin - Piston (Standard)	1
	298908	Pin - Piston (.005" O.S.)	1
29	299430	Rod - Connecting (Standard)	1
	390459	Rod - Connecting (.020" U.S. Crank Pin)	1
30	225183	Dipper - Connecting Rod	1
32	94699	Screw - Connecting Rod	1
33	211119	Valve - Exhaust	1
34	261044	Valve - Intake	1
35	260552	Spring - Valve (Intake)	1
36	26478	Spring - Valve (Exhaust)	1
40	93312	Retainer - Valve Spring	1
45	260642	Tappet - Valve	1
456	225257	Retainer - Valve	1

Obtain Parts From Briggs & Stratton Dealer



★ REQUIRES SPECIAL TOOLS
TO INSTALL. SEE REPAIR
INSTRUCTION MANUAL.


Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 135202-0142-03

Ref. No.	Part No.	Description	No. Used
★12	270080	Gasket – Crankcase (.015” Thick, Std.)	1
★	270125	Gasket – Crankcase (.005” Thick)	1
★	270126	Gasket – Crankcase (.009” Thick)	1
16	492088	Crankshaft	1
18	494044	Cover – Crankcase	1
19	495660	Bushing	1
★20	294606	Seal – Oil	1

Ref. No.	Part No.	Description	No. Used
21	281658	Cap – Oil Fill	1
21A	399195	Cap – Oil Fill	1
22	94682	Screw – Hex.	1
24	222698	Key – Flywheel	1
46	212733	Gear – Cam	1
146	94388	Key – Timing	1
219	494845	Gear – Governor	1
220	221551	Washer – Thrust	1
524	271485	Seal – O-Ring	1
741	262992	Gear – Timing	1

Obtain Parts From Briggs & Stratton Dealer
★ Included in Gasket Set—Part No. 495603.



Assemblies include all parts shown in frames.

T-0323


ENGINE BRIGGS & STRATTON MODEL 135202-0142-03

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
●★51	273113	Gasket – Intake	1	205	231520	Screw – Shoulder	1
90	495426	Carburetor	1	212	262270	Link – Throttle	1
●94	231533	Valve – Idle Adjustment	1	392	262328	Spring – Pump Diaphragm	1
95	93499	Screw – Throttle Valve Mtg.	1	●394	272538	Diaphragm – Carburetor	1
96	223793	Valve – Throttle	1	432	221377	Cap – Spring	1
97	490048	Shaft – Throttle	1	433	93265	Pin – Roll	1
109	497230	Shaft – Choke	1	434	213963	Cover – Diaphragm	1
124	94616	Screw – Carburetor Mtg.	1	435	93141	Screw – Slotted	1
127	220352	Plug – Welch	1	611	231068	Pipe – Fuel	1
127A	223789	Plug – Welch	1	612	391813	Tube – Pick-Up	1
149	26336	Spring – Needle Valve	1	634	271853	Seal	1
152	260575	Spring – Adjustment	1	679	270382	Washer – Felt	1
154	93527	Screw – Slotted	1	680	221839	Washer	1
●★191	272489	Gasket – Fuel Tank	1	987	398970	Seal – Throttle Shaft	1
203	280720	Crank – Bell	1				

Obtain Parts From Briggs & Stratton Dealer

★ Included in Gasket Set—Part No. 495603.

● Included in Carburetor Kit—Part No. 495606.





Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 135202-0142-03

Ref. No.	Part No.	Description	No. Used
190	94924	Screw – Torx	1
202	262280	Link – Mech. Governor	1
206	231266	Nut	1
207	26855	Spring – Control Rod	1
208	262323	Rod – Control	1
209	262283	Spring – Governor	1
216	262359	Link – Choke	1
222	490649	Bracket – Control	1
227	490374	Lever – Governor	1
230	94742	Washer – Flat	1
267	94906	Screw – Slotted Hex.	1

Ref. No.	Part No.	Description	No. Used
280	223798	Bracket – Rod	1
333	397358	Armature – Magneto	1
334	93414	Screw – Hex.	1
356	398808	Wire – Stop	1
467	280715	Knob	1
562	94907	Screw – Gov. Lever	1
592	231978	Nut – Hex.	1
614	93306	Pin – Cotter	1
616	495243	Crank – Governor	1
621	396847	Switch – Stop	1
851	493880	Terminal – Cable	1

Obtain Parts From Briggs & Stratton Dealer



Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 135202-0142-03

Ref. No.	Part No.	Description	No. Used
161	492797	Base – Air Cleaner	1
■★163	271935	Gasket – Air Cleaner	1
180	495405	Tank – Fuel	1
190	94924	Screw – Torx	1
190A	94919	Screw – Torx	1
●★191	272489	Gasket – Fuel Tank	1
526	94914	Screw – Hex.	1
535	491435	Filter – Air	1





Ref. No.	Part No.	Description	No. Used
536	494279	Cleaner – Air	1
621	396847	Switch – Stop	1
916	280321	Rack – Gov. Gear	1
957	494559	Cap – Fuel Tank	1
967	491588	Filter – Air	1
968	495872	Cover – Air Cleaner	1
969	490073	Screw – Cover Mtg.	1
971	94902	Screw – Air Cleaner	1

Obtain Parts From Briggs & Stratton Dealer

● Included in Carburetor Kit—Part No. 495606.

★ Included in Gasket Set—Part No. 495603.

■ Included in Valve Overhaul Gasket Set—Part No. 498529.



Assemblies include all parts shown in frames.


ENGINE BRIGGS & STRATTON MODEL 135202-0142-03

Ref. No.	Part No.	Description	No. Used
23	399673	Flywheel	1
37	222443	Guard – Flywheel	1
81	222263	Locknut – Muffler Screw	1
200	223886	Guide – Air	1
300	391313	Muffler – Exhaust	1
304	495759	Housing – Blower	1
305	94786	Screw – Hex.	1
307	94680	Screw – Hex.	1
332	94877	Nut – Flywheel	1

Ref. No.	Part No.	Description	No. Used
346	94896	Screw – Hex.	1
346A	94887	Screw – Hex.	1
363	19069	Flywheel Puller	1
613	94042	Screw – Shoulder	1
646	222361	Brace – Muffler	1
676	393757	Deflector – Muffler	1
832	391232	Guard – Muffler	1
★883	272309	Gasket – Exhaust	1

Obtain Parts From Briggs & Stratton Dealer

★ Included in Gasket Set—Part No. 495603.






Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 135202-0142-03

Ref. No.	Part No.	Description	No. Used
55	497442	Housing - Rewind Starter	1
56	498144	Pulley - Starter	1
57	263074	Spring - Rewind Starter	1
58	280399	Rope - Starter (Cut to Required Length)	1
59	396892	Insert - Grip	1
60	393152	Grip - Starter Rope	1
65	94904	Screw - Hex.	1

Ref. No.	Part No.	Description	No. Used
73	225176	Screen - Rotating	1
373	94908	Nut - Hex.	1
455	225121	Cup - Flywheel	1
456	281503	Retainer - Spring	1
459	281505	Pawl - Ratchet	1
608	497830	Starter - Rewind	1
623	94943	Screw - Shoulder	1
689	263073	Spring - Friction	1

Obtain Parts From Briggs & Stratton Dealer



Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 135202-0142-03

Ref. No.	Part No.	Description	No. Used
★3	299819	Seal – Oil	1
■★7	272157	Gasket – Cylinder Head	1
■★9	27549	Gasket – Breather	1
★12	270080	Gasket – Crankcase (.015" Thick, Std.)	1
★	270125	Gasket – Crankcase (.005" Thick)	1
★	270126	Gasket – Crankcase (.009" Thick)	1
★20	294606	Seal – Oil	1

Ref. No.	Part No.	Description	No. Used
■●★51	273113	Gasket – Intake	1
●94	231533	Valve – Idle Adjustment	1
121	495606	Carburetor Kit	1
■★163	271935	Gasket – Air Cleaner	1
●★191	272489	Gasket – Fuel Tank	1
358	495603	Gasket Set	1
●394	272538	Diaphragm – Carburetor	1
★883	272309	Gasket – Exhaust	1
1095	498529	Gasket Set – Valve Overhaul	1

Obtain Parts From Briggs & Stratton Dealer

■ Included in Valve Overhaul Gasket Set—Part No. 498529.

★ Included in Gasket Set—Part No. 495603.

● Included in Carburetor Kit—Part No. 495606.