


TORO[®]

MODEL NO. 53080-790001 & UP


**PARTS
CATALOG****LAWN VACUUM**

C-2693

HANDLE AND BAG ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	98-2502	Handle	1
2	98-2527	Cross Bar	1
3	321-9	Screw - HH	4
4	3296-8	Nut	4
5	98-2504	Handle Sleeve	1
6	98-2503	Cloth Bag	1
7	98-2523	Support	2
8	32121-103	Rollpin	2
9	98-2522	Axle	1
10	98-2519	Height Adjustment	1
11	98-2524	Pivot	2
12	323-10	Screw - HH	4
13	3272-22	Cotter Pin	2
14	98-2526	Lower Handle	2
15	98-2529	Spacer	4
16	98-2518	Wheel	4

Ref. No.	Part No.	Description	No. Used
17	3213-14	Screw - HH	2
18	3220-5	Nut - Jam	2
19	98-2515	Deflector	1
20	3255-8	Washer - Lock	1
21	3256-15	Washer - Flat	2
22	98-2511	Screw - Thread Forming	2
23	98-2516	Throttle Cable Assembly	1
24	3250-23	Screw - THMS	2
25	3296-2	Nut	2
26	3256-14	Washer - Flat	2
27	98-2528	Spacer	2
28	98-2513	Snap - Mount	1
29	98-2512	Knob	1
30	3296-47	Nut - Lock	1
31	3253-4	Washer	1
32	3256-66	Washer - Flat	1



C-2694

HOUSING ASSEMBLY


Ref. No.	Part No.	Description	No. Used
1		Engine (V12F7021741A1)	1
2	98-2514	Upper Blower Housing	1
3	98-2532	Lower Blower Housing	1
4	98-2535	Impeller Asm. Complete	1
5	98-2533	Spacer	1
6	98-2509	Key	1
7	98-2534	Engine Plate	1
8	98-2521	Foam	1
9	322-3	Screw - HH	3
10	98-2510	Rubber Shim	1
11	98-2520	Adjustment Bracket	1
12	322-2	Screw - HH	4
13	322-5	Screw - HH	4
14	322-7	Screw - HH	2
15	322-12	Screw - HH	1

Ref. No.	Part No.	Description	No. Used
16	3211-11	Screw - HH	1
17	3253-5	Washer	1
18	98-2507	Safety Switch	1
19	98-2500	Switch Nut	1
20	98-2501	Switch Bracket	1
21	3256-66	Washer - Flat	7
22	3296-29	Nut	11
23	98-2508	Retaining Ring	4
24	98-2525	Hinge	2
25	98-2530	Pivot Pin	2
26	98-2536	Decal - Toro	1
28	98-2541	Decal - Toro	1
*	53086	Bag Platform	1
*	53085	Vacuum Hose Kit	1

* Optional Equipment
Not Illustrated

Obtain Parts From a Briggs & Stratton Dealer

3319-631



★ REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL.

1019 LABEL KIT

1058 OWNER'S MANUAL

Assemblies include all parts shown in frames.

T-0323


ENGINE BRIGGS & STRATTON MODEL 12F702-1741-A1

Ref. No.	Part No.	Description	No. Used
1	493260	Cylinder Assembly	1
2	293708	Bushing - Cylinder	1
★3	299819	Seal - Oil	1
5	214626	Head - Cylinder	1
‡★7	272916	Gasket - Cylinder Head	1
8	495786	Breather - Valve Chamber	1
‡★9	272481	Gasket - Breather	1
10	94650	Screw - Hex. Head	1
11	231933	Tube - Breather	1
13	94547	Screw - Cylinder Head	1
★52	272199	Gasket - Intake Elbow	1
54	94526	Screw - Hex. Head	1
★116	280393	Seal - O-Ring	1
★116A	280966	Seal - O-Ring	1
227	492349	Lever Assembly - Gov.	1
230	67072	Washer - Gov. Crank	1
284	94511	Screw - Hex. Head	1
306	224324	Shield - Cylinder	1
307	94515	Screw - Hex. Head	1
337	802592	Plug - Spark	1

Ref. No.	Part No.	Description	No. Used
383	89838	Wrench - Spark Plug	1
523	495264	Dipstick	1
525	495265	Tube - Oil Filler	1
562	94852	Bolt - Carriage	1
584	224328	Baffle - Cylinder	1
★585	272238	Gasket - Baffle Plate	1
592	231082	Nut - Hex.	1
615	94474	Fastener	1
616	263175	Crank - Governor	1
625	497465	Manifold - Intake	1
635	66538	Elbow - Spark Plug	1
847	495263	Dipstick/Tube Assy.	1
869	213512	Seat - Intake Valve	1
870	213513	Seat - Exhaust Valve	1
871	262001	Guide - Exhaust Valve	1
		Note: 63709 Guide - Intake Valve	1
1019	494256	Label Kit	1
1058	273125	Owner's Manual	1

★ Included in Gasket Set - Part No. 497316.

‡ Included in Valve Overhaul Gasket Set - Part No. 498528.



Assemblies include all parts shown in frames.


T-0323

ENGINE BRIGGS & STRATTON MODEL 12F702-1741-A1

Ref. No.	Part No.	Description	No. Used
4	493279	Sump - Engine	1
★12	272198	Gasket - Crankcase	1
15	94720	Plug - Oil Drain	1
16	498565	Crankshaft	1
★20	399781	Seal - Oil	1
22	94220	Screw - Hex. Head	1
		Note: 94612 Screw - Hex. Head (One Used in Hole Nearest Breather)	1
24	222698	Key - Flywheel	1
25	499429	Piston Assy. (Standard)	1
26	499425	Ring Set (Standard)	1

Ref. No.	Part No.	Description	No. Used
27	263190	Lock - Piston Pin	1
28	499423	Pin - Piston (Standard)	1
29	499424	Rod Assembly - Connecting	1
32	94699	Screw - Connecting Rod	1
33	262651	Valve - Exhaust	1
34	262652	Valve - Intake	1
35	262224	Spring - Valve	1
40	93312	Retainer - Valve Spring	1
43	493737	Slinger - Oil	1
45	262204	Tappet - Valve	1
46	498275	Gear - Cam	1
146	94388	Key - Timing	1
741	262598	Gear - Timing	1

★ Included in Gasket Set - Part No. 497316.



Assemblies include all parts shown in frames.

T-0323

ENGINE BRIGGS & STRATTON MODEL 12F702-1741-A1


Ref. No.	Part No.	Description	No. Used
●94	493765	Valve – Idle Adjustment	1
95	94098	Screw – Throttle Valve Mtg.	1
98	398185	Screw – Idle Speed	1
●104	231371	Pin – Float Hinge	1
108	223471	Valve – Choke	1
●◆110		Gasket – Sealing (Sold in Kit Only)	1
117	498977	Jet – Main (Standard) Note: 498981 Jet – Main (High Altitude)	1
124	94525	Screw – Carburetor Mtg.	1
125	498965	Carburetor	1
●127		Plug – Welch	

Ref. No.	Part No.	Description	No. Used
		(Sold in Kit Only)	1
130	223470	Valve – Throttle	1
131	493267	Shaft – Throttle	1
133	398187	Float – Carburetor	1
●134	398188	Valve – Inlet (Includes Seat)	1
●◆137		Gasket – Bowl (Sold in Kit Only)	1
141	494218	Shaft – Choke	1
◆◆★163	272653	Gasket – Air Cleaner	1
●◆617	270344	Seal – Intake Manifold	1
618	262749	Spring – Choke	1
●◆634		Washer – Shaft (Sold in Kit Only)	1
975	493640	Bowl – Float	1

● Included in Carburetor Kit – Part No. 498260.

◆ Included in Carburetor Gasket Set – Part No. 498261.

★ Included in Gasket Set – Part No. 497316.



Assemblies include all parts shown in frames.


T-0323

ENGINE BRIGGS & STRATTON MODEL 12F702-1741-A1

Ref. No.	Part No.	Description	No. Used
98A	493280	Screw - Idle Speed	1
188	94644	Screw - Hex. Head	1
201	262579	Link - Governor	1
209	262655	Spring - Governor	1
265	213626	Clamp - Cable	1

Ref. No.	Part No.	Description	No. Used
267	94694	Screw - Slotted Hex.	1
620	495975	Bracket - Control	1
621	396847	Switch - Stop	1
★670	493823	Spacer - Bracket (Includes 2)	1

★ Included in Gasket Set - Part No. 497316.



Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F702-1741-A1

Ref. No.	Part No.	Description	No. Used
161	496116	Base – Air Cleaner	1
◆★163	272653	Gasket – Air Cleaner	1
529	281556	Grommet – Breather	1
967	491788	Filter – Air	1
968	281340	Cover – Air Cleaner	1







Ref. No.	Part No.	Description	No. Used
969	94120	Screw – Cover Mtg.	1
971	94121	Screw – Air Cleaner	1
971A	94249	Screw – Air Cleaner	1
974	224815	Bracket – Support	1

★ Included in Gasket Set—Part No. 497316.

● Included in Carburetor Kit—Part No. 498260.

◆ Included in Carburetor Gasket Set—Part No. 498261.

Obtain Parts From a Briggs & Stratton Dealer




Assemblies include all parts shown in frames.

T-0323

ENGINE BRIGGS & STRATTON MODEL 12F702-1741-A1

Ref. No.	Part No.	Description	No. Used
81	223664	Lock – Muffler Screw	1
187	492790	Hose – Fuel	1
188A	398540	Screw – Tank Mounting	1
284	94511	Screw – Shoulder	1
300	496106	Muffler – Exhaust	1
346	93705	Screw – Hex. Head	1
346A	94602	Screw – Hex. Head	1
601	93053	Clamp – Hose	1

Ref. No.	Part No.	Description	No. Used
613	94231	Screw – Shoulder	1
670A	280512	Spacer – Fuel Tank	1
676	396548	Deflector – Muffler	1
832	494224	Guard – Muffler	1
949	281136	Guard – Rewind	1
957	397974	Cap – Fuel Tank	1
972	497227	Tank Assembly – Fuel	1




Assemblies include all parts shown in frames.

T-0323

ENGINE BRIGGS & STRATTON MODEL 12F702-1741-A1

Ref. No.	Part No.	Description	No. Used
23	492893	Flywheel	1
304	493294	Housing - Blower	1
305	94744	Screw - Hex.	1
332	92284	Nut - Flywheel	1
333	802574	Armature - Magneto	1
334	94731	Screw - Hex.	1

Ref. No.	Part No.	Description	No. Used
356	398808	Wire - Ground	1
363	19069	Flywheel Puller	1
455	225121	Cup - Starter	1
851	493880	Terminal - Ignition Cable	1
1036	499340	Label Kit - Emission	1







Assemblies include all parts shown in frames.

ENGINE BRIGGS & STRATTON MODEL 12F702-1741-A1

Ref. No.	Part No.	Description	No. Used
55	497440	Housing – Rewind Starter	1
56	498144	Pulley – Rewind Starter	1
58	280399	Rope – Rewind Starter (Cut to Required Length)	1
59	224467	Insert – Starter Grip	1
60	493926	Handle – Rewind Starter	1
456	281503	Retainer – Rewind Starter	

Ref. No.	Part No.	Description	No. Used
459	281505	Pawl – Starter	1
461	94943	Pin – Starter	1
515	263073	Spring – Torsion	1
608	497680	Starter Assy. – Rewind	
Includes:			
		94904 Screw – Hex. Head	1
		94908 Nut – Hex.	1



Assemblies include all parts shown in frames.

T-0323

ENGINE BRIGGS & STRATTON MODEL 12F702-1741-A1

Ref. No.	Part No.	Description	No. Used
★3	299819	Seal – Oil	1
‡★7	272916	Gasket – Cylinder Hd.	1
‡★9	272481	Gasket – Breather	1
★12	272198	Gasket – Crankcase	1
★20	399781	Seal – Oil	1
★52	272199	Gasket – Intake Elbow	1
●94	493765	Valve – Idle Adjustment	1
●104	231371	Pin – Float Hinge	1
●◆110		Gasket – Sealing (Sold in Kit Only)	1
★116	280393	Seal – O-Ring	1
★116A	280966	Seal – O-Ring	1
121	498260	Carburetor Kit	1
●127		Plug – Welch (Sold in Kit Only)	1

Ref. No.	Part No.	Description	No. Used
●134	398188	Valve – Inlet (Includes Seat)	1
●◆137		Gasket – Bowl (Sold in Kit Only)	1
◆●★163	272653	Gasket – Air Cleaner	1
358	497316	Gasket Set	1
★585	272238	Gasket – Baffle Plate	1
●◆617	270344	Seal – Intake Manifold	1
●◆634		Washer – Shaft (Sold in Kit Only)	1
★670	493823	Spacer – Bracket (Includes 2)	2
977	498261	Gasket Set – Carburetor	1
1095	498528	Gasket Set – Valve Overhaul	1

★ Included in Gasket Set—Part No. 497316.

● Included in Carburetor Kit—Part No. 498260.

◆ Included in Carburetor Gasket Set—Part No. 498261.

‡ Included in Valve Overhaul Gasket Set—Part No. 498528.

