





MODEL NO. 51917-7900001 & UP

**PARTS
CATALOG**
16" TRIMMER

BOOM AND TRIMMER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	3296-12	Lock Nut	2
2	57-5481	R. H. Housing	1
3	53-7290	Trough	1
4	53-7120	Grip	1
5	92-3239	Lead Wire Asm.	1
6	92-3278	Throttle Cable	1
7	53-7273	Throttle Lever	1
8	610327	Shoulder Strap Clamp	1
9	218-557	Switch Cap	1
10	42-6000	Switch	1
11	57-5491	L.H. Housing	1
12	32105-12	Hex Head Screw	2

Ref. No.	Part No.	Description	No. Used
14	180869	Handle w/Hardware	1
15	180870	Handle Hardware	1
16	181530	Drive Shaft Housing Asm.	1
17	153597	Clamp Asm.	1
18	682064	Flexible Drive Shaft	1
19	180547	Guard Mount Screw Asm.	3
20	180548	Guard and Blade Asm.	1
21	682061	Blade Asm.	1
22	145569	Anti-Rotation Screw	1
23	180549	Gearbox Asm.	1
24	153619	Outer Spool and Eyelet Asm.	1




BOOM AND TRIMMER ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
25	145566	Eyelet	1
26	610660	Retainer	1
27	610317	Spring	1
28	610318	Inner Reel	1
29	682069	Bump Head Knob Asm.	1


Ref. No.	Part No.	Description	No. Used
31	92-3328	Decal - Safety Symbols	1
*	610375	Monoflail Cutting Line, 50 ft	1
*	92-3450	Spool & Line (25ft) Asm.	1
*	66-2090	Toro 2-Cycle Oil	1

*Not Illustrated



ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	145888	Screw	4	44	180244	Fuel Line Asm.	1
2	92-3273	Rear Cover	1	45	180245	Power Shaft Asm.	1
3	180211	Heat Shield	1	46	180246	Crankcase Cap Gasket	1
4	180212	Mounting Screw	4	47	180236	Cylinder Gasket	1
5	180213	Crankcase Cap	1	48	180534	Piston and Rod Asm.	1
36	180249	Crankcase Asm. (Incl. Ref. # 5, 45-46)	1	49	180240	Fuel Tank Asm.	1
37	145918	Spacer	1	50	180241	Rear Fuel Tank Pad	1
38	180535	Recoil Pulley	1	51	180536	Fuel Tank Bracket	1
39	613102	Recoil Spring	1	52	180000	Fuel Tank Cap	1
40	180929	Flywheel Asm.	1	53	180243	Return Fuel Line	1
41	92-3223	Ground Tab	1	55	92-3332	Decal - Warning	1
42	180238	Module Asm.	1	56	92-3334	Decal - Fuel & Oil Mix	1
43	180239	Front Pad -Fuel Tank	1	57	92-3345	Decal - Carb.	1




C-2538

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
6	180214	Muffler Mounting Screws	2
7	180215	Muffler Asm.	1
8	180216	Muffler Gasket	1
9	181527	Cylinder	1
10	610311	Spark Plug	1
11	180217	Spacer Nut Set	1
12	180218	Spacer Screw Set	1
13	683974	Primer Bulb & Hose	1
14	92-3281	Plug Switch	1
15	180225	Choke Lever	1
16	180226	Wavey Washer	1

Ref. No.	Part No.	Description	No. Used
17	180533	Carburetor Mount Screw Asm.	2
18	180230	Screw	4
19	180229	Air Cleaner Cover	1
20	180228	Air Filter Element	1
21	180223	Air Cleaner Base Asm.	1
22	181526	Carburetor Asm.	1
23	612113	Carburetor Gasket	1
24	180532	Spacer, Carburetor Asm.	1
25	180220	Cylinder/Carburetor Gasket	1
26	180221	Screw	4



C-2539

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
27	610300	Pull Handle	1	*	180090	Carb. Repair Kit (Zama)	1
28	613103	Starter Rope	1	*	181069	Gasket—Diaphragm	
29	153591	Clutch Rotor Asm.	1			Repair Kit (Walbro)	1
30	180232	Clutch Drum Asm.	1	*	180091	Gasket—Diaphragm	
31	153597	Clamp Asm.	1			Repair Kit (Zama)	1
32	180231	Clutch Housing Asm.	1	*	610676	Flywheel Key	1
33	92-3274	Starter Housing Asm.	1	*	180537	Piston Ring	1
34	611061	Rope Guide	1	*	180248	Short Block Asm.	
35	153644	Pulley Retainer	1			(Incl. Ref. #5,9,10,26,36,45-48)	1
54	92-3344	Decal - Toro	1	*	610676	Flywheel Key	1
*	180247	Engine Gasket Kit	1	*	610309	Crankcase Seal	1
*	153308	Carb. Repair Kit (Walbro)	1				

*Not Illustrated

TORO PART NUMBER INDEX

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
145569	Anti–Rotation Screw	1 22 1	180548	Guard and Blade Asm.	1 20 1
145569	Eyelet	2 25 1	180549	Gearbox Asm.	1 23 1
145888	Screw Asm.	3 1 4	180869	Handle w/Hardware	1 14 1
145918	Spacer	3 37 1	180870	Handle Hardware	1 15 1
153308	Carb. Repair Kit (Walbro)	5 * 1	180929	Flywheel Asm.	3 40 1
153591	Clutch Rotor Asm.	5 29 1	181069	Gasket–Diaphragm	5 * 1
153597	Clamp Asm.	5 31 1	181526	Carburetor Asm.	4 22 1
153597	Clamp Asm.	1 17 1	181527	Cylinder	4 9 1
153619	Outer Spool and Eyelet Asm.	1 24 1	181530	Drive Shaft Housing Asm.	1 16 1
153644	Pulley Retainer	5 35 1	610300	Pull Handle	5 27 1
180000	Fuel Tank Cap	3 52 1	610309	Crankcase Seal	5 * 1
180090	Carb. Repair Kit (Zama)	5 * 1	610311	Spark Plug	4 10 1
180091	Gasket–Diaphragm	5 * 1	610317	Spring	2 27 1
180211	Heat Shield	3 3 1	610318	Inner Reel	2 28 1
180212	Mounting Screw	3 4 4	610327	Shoulder Strap Clamp	1 8 1
180213	Crankcase Cap	3 5 1	610375	Monoflail Cutting Line, 50 ft	2 * 1
180214	Muffler Mounting Screws	4 6 2	610660	Retainer	2 26 1
180215	Muffler Asm.	4 7 1	610676	Flywheel Key	5 * 1
180216	Muffler Gasket	4 8 1	610676	Flywheel Key	5 * 1
180217	Spacer Nut Set	4 11 1	611061	Rope Guide	5 34 1
180218	Spacer Screw Set	4 12 1	612113	Carburetor Gasket	4 23 1
180220	Cylinder/Carburetor Gasket	4 25 1	613102	Recoil Spring	3 39 1
180221	Screw	4 26 4	613103	Starter Rope	5 28 1
180223	Air Cleaner Base Asm.	4 21 1	682064	Flexible Drive Shaft	1 18 1
180225	Choke Lever	4 15 1	682069	Bump Head Knob Asm.	2 29 1
180226	Wavey Washer	4 16 1	682061	Blade Asm.	1 21 1
180228	Air Filter Element	4 20 1	683974	Primer Bulb & Hose	4 13 1
180229	Air Cleaner Cover	4 19 1	42–6000	Switch	1 10 1
180230	Screw	4 18 4	53–7120	Grip	1 4 1
180231	Clutch Housing Asm.	5 32 1	53–7273	Throttle Lever	1 7 1
180232	Clutch Drum Asm.	5 30 1	53–7290	Trough	1 3 1
180236	Cylinder Gasket	3 47 1	57–5481	R. H. Housing	1 2 1
180238	Module Asm.	3 42 1	57–5491	L.H. Housing	1 11 1
180239	Front Pad –Fuel Tank	3 43 1	66–2090	Toro 2–Cycle Oil	2 * 1
180240	Fuel Tank Asm.	3 49 1	92–3223	Ground Tab	3 41 1
180241	Rear Fuel Tank Pad	3 50 1	92–3239	Lead Wire Asm.	1 5 1
180243	Return Fuel Line	3 53 1	92–3273	Rear Cover	3 2 1
180244	Fuel Line Asm.	3 44 1	92–3274	Starter Housing Asm.	5 33 1
180245	Power Shaft Asm.	3 45 1	92–3278	Throttle Cable	1 6 1
180246	Crankcase Cap Gasket	3 46 1	92–3281	Plug Switch	4 14 1
180247	Engine Gasket Kit	5 * 1	92–3450	Spool & Line (25ft) Asm.	2 * 1
180248	Short Block Asm.	5 * 1	218–557	Switch Cap	1 9 1
180249	Crankcase Asm.	3 36 1	3296–12	Lock Nut	1 1 2
180532	Spacer, Carburetor Asm.	4 24 1	32105–12	Hex Head Screw	1 12 2
180533	Carburetor Mount	4 17 2	92–3328	Decal – Safety Symbols	2 31 1
180534	Piston and Rod Asm.	3 48 1	92–3332	Decal – Warning	3 55 1
180535	Recoil Pulley	3 38 1	92–3334	Decal – Fuel & Oil Mix	3 56 1
180536	Fuel Tank Bracket	3 51 1	92–3344	Decal – Toro	5 54 1
180537	Piston Ring	5 * 1	92–3345	Decal – Carb.	3 57 1
180547	Guard Mount Screw Asm.	1 19 3			

Compliance with Radio Interference Regulations Certified.
Certifie Conforme au Reglement sur le Brouillage Radioelectrique.