Form No. 3372-625 Rev B

TORO®

Count on it.

Parts Catalog

Hand Spray Gun Kit

Multi-Pro® 5800 Turf Sprayer

Model No. 41605—Serial No. 313000001 and Up

Register at www.Toro.com.
Original Instructions (EN)

3372-625 B

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquefied Petroleum Gas

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head


Contents

Hand Spray Gun Kit 4
Spray Gun Assembly No. 120-8610 6

© 2013—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved

Hand Spray Gun Kit




Hand Spray Gun Kit (continued)

Ref.	Part Number	Qty.	Description
1		1	Manual Valve ASM ●
1:1	119-4935	1	Valve-Manual
1:3	119-4901	1	Fork
2	121-4986-03	1	Bracket-Spraygun
3	40153-03	1	Hook-Hose
4	3256-3	2	Washer-Flat
5	104-8300	4	Nut-Flange, NI
6	2815-16	1	Fitting-HYD, Tee
7	100-8667	1	Coupler-Reducer
8	120-8591-03	1	Mount-Control
9	3234-33	3	Screw-HHF
10	32128-33	3	Nut-HF
11	120-8590	1	Box-Control
13	120-8546	1	Gauge-Pressure
14	100-1535	1	Switch
15	99-7420	1	Plug-Hole
16	100-8665	1	Reducer-Gauge, Pressure
17	119-4954	1	Gauge-Pressure, Tube
18	94-5627	1	Plug
19	120-8610	1	Spray Gun ASM
20	107-8751	1	Hose-Spray Gun
21	2412-36	2	Clamp-Hose
22	120-0686	1	Decal-Spray Gun
23	119-5788	1	Harness-Wire, Spray Gun
23:1	32180-033	1	Grommet
24	100-8674	1	Coupler-Tube
27	3230-2	4	Bolt-CARR
28	120-8592	2	Clamp-R
29	3296-1	4	Nut-Lock
30	363-3160	4	Screw-Ssh
31	121-4982	1	Hosebarb-Spray Gun
32	120-8593-03	1	Bracket-Spray Gun
34		1	Bracket-Mounting Kit ●
34:1	119-4880	4	Screw-HH
34:2	119-4974	1	O-Ring
35	120-0682	1	Hosebarb
35:1	119-4975	1	O-Ring
99	3290-379	2	Tie-Cable

● Not serviced separately

Spray Gun Assembly No. 120-8610



Spray Gun Assembly No. 120-8610 (continued)

Ref.	Part Number	Qty.	Description
1	121-4950	1	Nozzle-2.3Mm
1:1	121-4951	1	O-Ring
2	121-4952	1	Head-Nozzle Holder
4	121-4954	1	Ring-Spacer
5	121-4955	1	Spreader-Micro Jet
6	121-4956	1	Tube-Spray Gun
7	121-4957	1	Conveyor-Inner
8	121-4958	1	Tube-Spray Gun, Inner
9	121-4959	1	Drum-Regulation
10	121-4960	1	Spring-Spray Gun
14	121-4964	1	Pin-Hinge
16	121-4966	2	Washer-Teflon
18	121-4968	1	Lever-Drum, Spray Gun
19	121-4969	1	Screw
20	121-4970	1	Grip-Spray Gun
21	121-4971	1	Fork
22	121-4973	1	Hose-Tail
22:1	121-4972	2	O-Ring
23	121-4974	1	Slide-Lever
24	121-4975	1	Lever-Spraygun
25	121-4977	1	Spring
26	121-4978	1	Pin-Lever
27	121-4979	1	Cover-Drum
28	121-4980	1	Drum-Regulation
99	121-4981	1	Spray Gun Seal Kit ●
99:1	121-4951	1	O-Ring
99:2	121-4953	2	Gasket
99:3	121-4967	2	O-Ring
99:4	121-4972	2	O-Ring
99:5	121-4962	1	Plunger-Cone
99:6	121-4961	1	O-Ring
99:7	121-4963	1	Box And Seat
99:8	121-4965	1	Seal

● Not illustrated



Count on it.