Form No. 3378-395 Rev A

TORO®

Count on it.

Parts Catalog

Electric Hose Reel Kit

Multi Pro WM Turf Sprayer

Model No. 41243—Serial No. 314000001 and Up

Register at www.Toro.com.
Original Instructions (EN)

CE

3378-395 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquefied Petroleum Gas

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping


TTH: torx truss head

Contents

Electric Hose Reel Kit 4
Spray Gun Assembly No. 120-8610 6
Hose Reel and Frame Assembly No. 127-3910 8

© 2013—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420


Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved



Electric Hose Reel Kit

Ref.	Part Number	Qty.	Description
1	125-8084-03	2	Tube
2	125-4142-03	1	Frame-Base
3	93-4510	2	Bushing-Caster
4	125-4080-03	1	Plate-Pivot
5	125-8051	1	Slide-Plastic
6	127-3910	1	Hose Reel ASM
8	116-0104	1	Pin-Spring
9	302-11	1	Fitting-Lube, 45 DEG
10	100-9880	4	Bolt-Shoulder
11	104-8300	8	Nut-Flange, NI
12	3234-39	4	Screw-HHF
13	104-8301	8	Nut-Flange, NI
14	32120-84	1	Ring-Snap, External
15	62-2170	1	Washer-Thrust
16	3230-23	6	Screw-CARR
17	3234-42	4	Screw-HHF
18	3256-4	4	Washer-Flat
19	3296-47	4	Nut-Lock, NI
20	105-4551	1	Washer-Flat
21	127-3963-03	1	Bracket-Hand Gun
22	120-8610	1	Spray Gun ASM

Ref.	Part Number	Qty.	Description
23	121-4983	1	Bracket-Roller
24	125-8086-03	1	Box-Switch, Hose Reel
25	100-1535	1	Switch
26	112-3324	1	Switch-Horn
27	112-3313	1	Nut-Weatherproof
28	99-7435	1	Relay-Power
29	240-7	1	Grommet-Rubber
30	121-4982	1	Hosebarb-Spray Gun
31	125-8039	1	Manual Valve ASM
31:2	121-5102	1	Hosebarb
31:2:1	119-4975	1	O-Ring
31:3	119-4901	1	Fork
32	119-4880	4	Screw-HH
33	110-5065	1	Hosebarb
34	3234-47	6	Screw-HHF
35	108-0069	1	Valve-Ball
36	110-5224	2	Fitting-Barbed, Straight
37	2412-34	2	Clamp-Hose
38	2412-36	2	Clamp-Hose
39	2412-129	2	Clamp-Hose
40	65-5100	1	Handle-Door




Electric Hose Reel Kit (continued)

Ref.	Part Number	Qty.	Description
41	46-8092	2	Screw-Plastite
42	2815-16	1	Fitting-HYD, Tee
43	120-8547	1	Gauge-Pressure
44	107-8756	1	Hose-Hose Reel
45	119-0491	1	Hose-Supply
46	2412-104	1	Clamp-R
47	322-5	2	Screw-HH

Ref.	Part Number	Qty.	Description
48	3218-2	2	Nut-Jam
49	127-3953	1	Decal-Hose Reel
51	122-0161	1	Harness-Wire, Hose Reel
51:4	99-6124	1	Fuse-Blade, 40 Amp
52	3290-321	1	Screw-HWH
53	3296-2	1	Nut-Lock, NI
54	119-4974	1	O-Ring


Spray Gun Assembly No. 120-8610



Spray Gun Assembly No. 120-8610 (continued)

Ref.	Part Number	Qty.	Description
1	121-4950	1	Nozzle-2.3Mm
1:1	121-4951	1	O-Ring
2	121-4952	1	Head-Nozzle Holder
4	121-4954	1	Ring-Spacer
5	121-4955	1	Spreader-Micro Jet
6	121-4956	1	Tube-Spray Gun
7	121-4957	1	Conveyor-Inner
8	121-4958	1	Tube-Spray Gun, Inner
9	121-4959	1	Drum-Regulation
10	121-4960	1	Spring-Spray Gun
14	121-4964	1	Pin-Hinge
16	121-4966	2	Washer-Teflon
18	121-4968	1	Lever-Drum, Spray Gun
19	121-4969	1	Screw
20	121-4970	1	Grip-Spray Gun
21	121-4971	1	Fork
22	121-4973	1	Hose-Tail
22:1	121-4972	2	O-Ring
23	121-4974	1	Slide-Lever
24	121-4975	1	Lever-Spraygun
25	121-4977	1	Spring
26	121-4978	1	Pin-Lever
27	121-4979	1	Cover-Drum
28	121-4980	1	Drum-Regulation
99	121-4981	1	Spray Gun Seal Kit ●
99:1	121-4951	1	O-Ring
99:2	121-4953	2	Gasket
99:3	121-4967	2	O-Ring
99:4	121-4972	2	O-Ring
99:5	121-4962	1	Plunger-Cone
99:6	121-4961	1	O-Ring
99:7	121-4963	1	Box And Seat
99:8	121-4965	1	Seal

● Not illustrated



Hose Reel and Frame Assembly No. 127-3910

Ref.	Part Number	Qty.	Description
1	104-8803	1	Frame-Hose Reel
2	104-8804	1	Disc And Gear
3	104-8805	1	Disc-Crank, Side
4	104-8806	1	Drum-Center
5	104-8807	1	Axle
6	104-8808	1	Swivel ASM
6:1	104-8812	1	Ring-Retainer
6:2	104-8864	1	Swivel Seal Kit
7	104-8809	2	Block-Pillow, Top
8	104-8810	2	Block-Pillow, Bottom
9	104-8811	2	Bearing
10	104-8812	4	Ring-Retainer
11	104-8813	1	Cap-Pipe
12	322-3	8	Screw-HH
13	104-8814	1	Trim-Edge, Drum
14	3296-29	8	Nut-Lock, NI

Ref.	Part Number	Qty.	Description
15	3256-23	16	Washer-Flat
16	3253-21	4	Washer-Lock
17	323-6	4	Screw-HH
18	32128-21	1	Nut-HF
19	104-8815	1	Bracket-Motor, 12V Dc
20	104-8816	1	Motor-12V Dc
21	104-8817	1	Pinion
22	104-8818	4	Key
23	322-5	8	Screw-HH
24	3253-4	1	Washer-Lock
25	104-8819	4	Screw-Set
26	3256-23	4	Washer-Flat
27	104-8715	1	Chainguard-Reel, Hose
27:1	322-5	4	Screw-HH
27:2	3256-23	4	Washer-Flat
27:3	3296-29	4	Nut-Lock, NI

Notes:

Notes:

Notes:



Count on it.