Form No. 3378-408 Rev A

TORO®

Count on it.

Parts Catalog

EU Compliance Kit

Multi Pro WM Turf Sprayer

Model No. 41204

Register at www.Toro.com.
Original Instructions (EN)

CE

3378-408 A

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1,6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustration and in parts lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

List of Abbreviations

AR: as required

ASM: assembly

BBC: blade brake control

BHTF: button head thread forming

CARR: carriage

CCW: counter clockwise

CW: clockwise

DEG: degrees

DPA: Dual Point Adjustment

ECM: electronic control module

EXT: external

FH: flat head

GA: gauge

HD: heavy-duty

HF: hex flange

HH: hex head

HHF: hex head flange

HHFTF: hex head flange thread forming

HJ: hex jam

HLH: hex lag head

HOC: height-of-cut

HSBH: hex socket button head

HSFH: hex socket flat head

HSH: hex socket head

HWH: hex washer head

HWHTF: hex washer head thread forming

HYD: hydraulic

LH: left hand

LP: Liquefied Petroleum Gas

LPG: Liquefied Petroleum Gas

NI: nylon insert

NPTF: national pipe thread fine

PFH: phillips flat head

PPH: phillips pan head

PPHTF: phillips pan head thread forming

PRH: phillips round head

PTH: phillips truss head

PTO: power-take-off

RH: right hand

ROPS: roll-over protection system

RRB: rear roller brush

SFH: slotted fillister head

SHH: slotted hex head

SHWH: slotted hex washer head

SPH: slotted pan head

SQH: square head

SRH: slotted round head

STD: standard

TAP: self tapping

TTH: torx truss head


Contents

EU Compliance Kit 4
Spray Gun and Pressure Filter Assembly 6
Spray Gun Assembly No. 120-8610 8
Pressure Filter Assembly No. 127-9721 10
Pressure Filter Assembly No. 127-9726 11

© 2013—The Toro® Company
8111 Lyndale Avenue South
Bloomington, MN 55420

Contact us at www.Toro.com.
Printed in the USA.
All Rights Reserved


EU Compliance Kit



EU Compliance Kit (continued)

Ref.	Part Number	Qty.	Description
1	99-8664	2	Screw-HH
2	100-6708	1	Fork
3	100-6713	1	Nut-Bulkhead
4	104-8300	2	Nut-Flange, NI
5	104-8301	4	Nut-Flange, NI
6	106-4896	1	Fitting-Bulkhead
6:1	100-6710	1	Gasket-Bulkhead
7	106-4940	1	Hosebarb-90 DEG
7:1	100-6712	1	O-Ring
8	107-8641	1	Cap-Water, Fresh
9	108-3439	1	Tee
10	117-7872	1	Pump-Rinse
11	119-0479	2	Nozzle-Rinse
12	119-0489	2	Bulkhead
13	119-0490	2	Elbow-Hosebarb
14	119-0493	2	Hose-Supply, Rinse
15	119-0496	1	Hosebarb
16	119-0528	2	Bushing
17	119-4881	2	Bolt-Shoulder
18	119-4980	1	Valve, 4-Way
19	120-0657-03	1	Bracket-Face Plate
20	120-0673	1	Decal-Selection
21	120-0688	1	Hosebarb-90 DEG
22	105-4320	1	Switch
23	120-8635	2	Vain-Rinse
24	121-6519	1	Tank-Rinse, 20 Gallon
25	125-0635-03	2	Strap-Tank, Rinse
26	125-4071-03	2	Angle-Mount, Rinse Tank Band
27	125-4145	1	Hose-Filter, Rinse
28	125-4146	1	Hose-Supply, Rinse
29	125-8085	1	Cover-Rinse Pump
30	127-9761-03	1	Valve-Mount
31	127-9762-03	1	Bracket-Mount, Rinse Pump
32	240-12	1	Grommet
33	321-10	4	Screw-HH
34	2412-129	8	Clamp-Hose
35	3231-21	2	Screw-CARR
36	3234-17	2	Screw-HHF
37	3256-22	4	Washer-Flat
38	3256-4	4	Washer-Flat
39	32128-33	4	Nut-HF
40	33023-00	4	Nut-Lock
41	33093-00	4	Washer-Flat
42	33113-016	4	Screw-HH
43	9335044	2	Pin-Hair

Spray Gun and Pressure Filter Assembly




Spray Gun and Pressure Filter Assembly (continued)

Ref.	Part Number	Qty.	Description
1	100-6704	1	Tee
2	100-6708	1	Fork
3	100-8635	3	Fork
4	104-8301	4	Nut-Flange, NI
5	106-4938	1	Reducer ASM
5:1	100-8637	1	O-Ring
6	106-4947	1	Connector
6:1	100-8637	2	O-Ring
7	107-8751	1	Hose-Spray Gun
8	108-0069	1	Valve-Ball
9	119-0493	1	Hose-Supply, Rinse
10	119-0496	1	Hosebarb
11	120-0652	2	Hosebarb
12	120-0668	1	Hosebarb
13	120-0669	1	Reducer
14	120-0670	1	Hosebarb
15	120-0687	1	Decal-Rinse Flow
16	120-0688	1	Hosebarb-90 DEG
17	120-8610	1	Spray Gun ASM
18	121-4982	1	Hosebarb-Spray Gun
19	127-9713-03	1	Hand Gun Bracket ASM
20	127-9721	1	Pressure Filter ASM
21	127-9726	1	Pressure Filter ASM
22	127-9730	1	Nipple
23	127-9764-03	1	Bracket-Hose
24	127-9765-03	1	Bracket-Shutoff Valve
25	127-9768	1	Supply-Hose ASM
25:1		1	Hosebarb-90 DEG ●
25:1:1	100-6712	1	O-Ring
26	127-9770	1	Hose-Shutoff
27	2412-129	5	Clamp-Hose
28	2412-36	2	Clamp-Hose
29	3230-23	2	Screw-CARR
30	3231-21	2	Screw-CARR
31	3234-7	2	Screw-HHF
32	127-9779	1	Hosebarb-Str
33	125-4117	1	O-Ring
34	125-4000	1	Fork
99	112-7929	1	Beaker-Plastic
99	99-6124	1	Fuse-Blade, 40 Amp

● Not serviced separately


Spray Gun Assembly No. 120-8610



Spray Gun Assembly No. 120-8610 (continued)


Ref.	Part Number	Qty.	Description
1	121-4950	1	Nozzle-2.3Mm
1:1	121-4951	1	O-Ring
2	121-4952	1	Head-Nozzle Holder
4	121-4954	1	Ring-Spacer
5	121-4955	1	Spreader-Micro Jet
6	121-4956	1	Tube-Spray Gun
7	121-4957	1	Conveyor-Inner
8	121-4958	1	Tube-Spray Gun, Inner
9	121-4959	1	Drum-Regulation
10	121-4960	1	Spring-Spray Gun
14	121-4964	1	Pin-Hinge
16	121-4966	2	Washer-Teflon
18	121-4968	1	Lever-Drum, Spray Gun
19	121-4969	1	Screw
20	121-4970	1	Grip-Spray Gun
21	121-4971	1	Fork
22	121-4973	1	Hose-Tail
22:1	121-4972	2	O-Ring
23	121-4974	1	Slide-Lever
24	121-4975	1	Lever-Spraygun
25	121-4977	1	Spring
26	121-4978	1	Pin-Lever
27	121-4979	1	Cover-Drum
28	121-4980	1	Drum-Regulation
99	121-4981	1	Spray Gun Seal Kit ●
99:1	121-4951	1	O-Ring
99:2	121-4953	2	Gasket
99:3	121-4967	2	O-Ring
99:4	121-4972	2	O-Ring
99:5	121-4962	1	Plunger-Cone
99:6	121-4961	1	O-Ring
99:7	121-4963	1	Box And Seat
99:8	121-4965	1	Seal

● Not illustrated



Pressure Filter Assembly No. 127-9721

Ref.	*Part Number*	*Qty.*	*Description*
1	125-0693	1	Filter-Pressure
1:1	120-8695	1	O-Ring
1:2	120-8697	1	Element-Filter, 50 Mesh
1:3	120-8696	1	O-Ring
1:4	120-8693	1	Housing-Filter
1:5	120-8694	1	Flynut-Filter
1:99	120-8698	1	Element-Filter, 32 Mesh
1:99	120-8699	1	Element-Filter, 80 Mesh
2	117-7967	1	Flange-Female
3	119-4870	3	O-Ring
4	119-0463	1	Adapter-Male-Male
5	125-0692	1	Connector-Flange
6	119-4871	16	Washer
7	48-7730	8	Screw-Cap, HH
8	33024-00	8	Nut-Lock, NI



Pressure Filter Assembly No. 127-9726

Ref.	*Part Number*	*Qty.*	*Description*
1	127-9722	1	Seal-Filter
2	127-9723	1	Screen-Filter
3	127-9724	1	Head-Filter
4	127-9725	1	Body-Filter



Count on it.